

Series 3700A System Switch/Multimeter

Reference Manual

3700AS-901-01 Rev. A / July 2011

Series 3700A

System Switch/Multimeter

Reference Manual

© 2011, Keithley Instruments, Inc.

Cleveland, Ohio, U.S.A.

All rights reserved.

Any unauthorized reproduction, photocopy, or use the information herein, in whole or in part, without the prior written approval of Keithley Instruments, Inc. is strictly prohibited.

All Keithley Instruments product names are trademarks or registered trademarks of Keithley Instruments, Inc. Other brand names are trademarks or registered trademarks of their respective holders.

The Lua 5.0 software and associated documentation files are copyright © 1994-2008, Tecgraf, PUC-Rio. Terms of license for the Lua software and associated documentation can be accessed at the [Lua licensing site](http://www.lua.org/license.html) (<http://www.lua.org/license.html>).

Document number: 3700AS-901-01 Rev. A / July 2011

Safety Precautions

The following safety precautions should be observed before using this product and any associated instrumentation. Although some instruments and accessories would normally be used with nonhazardous voltages, there are situations where hazardous conditions may be present.

This product is intended for use by qualified personnel who recognize shock hazards and are familiar with the safety precautions required to avoid possible injury. Read and follow all installation, operation, and maintenance information carefully before using the product. Refer to the user documentation for complete product specifications.

If the product is used in a manner not specified, the protection provided by the product warranty may be impaired.

The types of product users are:

Responsible body is the individual or group responsible for the use and maintenance of equipment, for ensuring that the equipment is operated within its specifications and operating limits, and for ensuring that operators are adequately trained.

Operators use the product for its intended function. They must be trained in electrical safety procedures and proper use of the instrument. They must be protected from electric shock and contact with hazardous live circuits.

Maintenance personnel perform routine procedures on the product to keep it operating properly, for example, setting the line voltage or replacing consumable materials. Maintenance procedures are described in the user documentation. The procedures explicitly state if the operator may perform them. Otherwise, they should be performed only by service personnel.

Service personnel are trained to work on live circuits, perform safe installations, and repair products. Only properly trained service personnel may perform installation and service procedures.

Keithley Instruments products are designed for use with electrical signals that are rated Measurement Category I and Measurement Category II, as described in the International Electrotechnical Commission (IEC) Standard IEC 60664. Most measurement, control, and data I/O signals are Measurement Category I and must not be directly connected to mains voltage or to voltage sources with high transient over-voltages. Measurement Category II connections require protection for high transient over-voltages often associated with local AC mains connections. Assume all measurement, control, and data I/O connections are for connection to Category I sources unless otherwise marked or described in the user documentation.

Exercise extreme caution when a shock hazard is present. Lethal voltage may be present on cable connector jacks or test fixtures. The American National Standards Institute (ANSI) states that a shock hazard exists when voltage levels greater than 30 V RMS, 42.4 V peak, or 60 VDC are present. A good safety practice is to expect that hazardous voltage is present in any unknown circuit before measuring.

Operators of this product must be protected from electric shock at all times. The responsible body must ensure that operators are prevented access and/or insulated from every connection point. In some cases, connections must be exposed to potential human contact. Product operators in these circumstances must be trained to protect themselves from the risk of electric shock. If the circuit is capable of operating at or above 1000V, no conductive part of the circuit may be exposed.

Do not connect switching cards directly to unlimited power circuits. They are intended to be used with impedance-limited sources. NEVER connect switching cards directly to AC mains. When connecting sources to switching cards, install protective devices to limit fault current and voltage to the card.

Before operating an instrument, ensure that the line cord is connected to a properly-grounded power receptacle. Inspect the connecting cables, test leads, and jumpers for possible wear, cracks, or breaks before each use.

When installing equipment where access to the main power cord is restricted, such as rack mounting, a separate main input power disconnect device must be provided in close proximity to the equipment and within easy reach of the operator.

For maximum safety, do not touch the product, test cables, or any other instruments while power is applied to the circuit under test. ALWAYS remove power from the entire test system and discharge any capacitors before: connecting or disconnecting cables or jumpers, installing or removing switching cards, or making internal changes, such as installing or removing jumpers.

Do not touch any object that could provide a current path to the common side of the circuit under test or power line (earth) ground. Always make measurements with dry hands while standing on a dry, insulated surface capable of withstanding the voltage being measured.

The instrument and accessories must be used in accordance with its specifications and operating instructions, or the safety of the equipment may be impaired.

Do not exceed the maximum signal levels of the instruments and accessories, as defined in the specifications and operating information, and as shown on the instrument or test fixture panels, or switching card.

When fuses are used in a product, replace with the same type and rating for continued protection against fire hazard.

Chassis connections must only be used as shield connections for measuring circuits, NOT as safety earth ground connections.

If you are using a test fixture, keep the lid closed while power is applied to the device under test. Safe operation requires the use of a lid interlock.

If a  screw is present, connect it to safety earth ground using the wire recommended in the user documentation.

The  symbol on an instrument means caution, risk of danger. The user should refer to the operating instructions located in the user documentation in all cases where the symbol is marked on the instrument.

The  symbol on an instrument means caution, risk of electric shock. Use standard safety precautions to avoid personal contact with these voltages.

The  symbol on an instrument shows that the surface may be hot. Avoid personal contact to prevent burns.

The  symbol indicates a connection terminal to the equipment frame.

If this  symbol is on a product, it indicates that mercury is present in the display lamp. Please note that the lamp must be properly disposed of according to federal, state, and local laws.

The **WARNING** heading in the user documentation explains dangers that might result in personal injury or death. Always read the associated information very carefully before performing the indicated procedure.

The **CAUTION** heading in the user documentation explains hazards that could damage the instrument. Such damage may invalidate the warranty.

Instrumentation and accessories shall not be connected to humans.

Before performing any maintenance, disconnect the line cord and all test cables.

To maintain protection from electric shock and fire, replacement components in mains circuits — including the power transformer, test leads, and input jacks — must be purchased from Keithley Instruments. Standard fuses with applicable national safety approvals may be used if the rating and type are the same. Other components that are not safety-related may be purchased from other suppliers as long as they are equivalent to the original component (note that selected parts should be purchased only through Keithley Instruments to maintain accuracy and functionality of the product). If you are unsure about the applicability of a replacement component, call a Keithley Instruments office for information.

To clean an instrument, use a damp cloth or mild, water-based cleaner. Clean the exterior of the instrument only. Do not apply cleaner directly to the instrument or allow liquids to enter or spill on the instrument. Products that consist of a circuit board with no case or chassis (e.g., a data acquisition board for installation into a computer) should never require cleaning if handled according to instructions. If the board becomes contaminated and operation is affected, the board should be returned to the factory for proper cleaning/servicing.

Table of Contents

Introduction	1-1
Welcome	1-1
Extended warranty	1-1
Contact information	1-1
CD-ROM contents	1-2
Organization of manual sections	1-2
Capabilities and features	1-3
Measuring capabilities	1-4
General information	1-4
Displaying the instrument's serial number	1-4
General operation	2-1
Turning your instrument on and off	2-1
Procedure	2-1
Front panel operation	2-2
(1) The USB port	2-3
(2) The display	2-3
(3) The navigation wheel	2-6
(4) The POWER key	2-6
(5) The status lights	2-6
(6) The setup and control keys	2-6
Menu overview	2-9
Menu trees	2-9
Front-panel key menu options	2-13
Configuration menu options	2-17
Using the front panel with non-switch channels	2-25
Rear panel summary	2-27
Rear panel connections	2-27
User setup	2-34
Saving user setups	2-34
Recalling a saved setup	2-34
Start-up configuration	2-35
Saving user setups from a command interface	2-35
Using the web interface	2-36
Introduction	2-36
Card pages	2-38
Scan Builder page	2-42
DMM web page	2-47
TSB Embedded	2-48
Admin page	2-49
Unit page	2-50
LXI page	2-50
Communication interfaces	2-52
Selecting an interface	2-53
USB	2-53
GPIB operation	2-59

LAN communications	2-64
Supplied software.....	2-66
Keithley I/O layer.....	2-69
Addressing instruments with VISA	2-72
Switch operation.....	2-77
Working with channels	2-89
Pseudocards.....	2-99
Save the present configuration.....	2-100
Functions and features	3-1
Scanning and triggering	3-1
Introduction to scanning and triggering	3-1
Trigger model	3-1
Scan and step counts.....	3-4
Basic scan procedure.....	3-4
Remote interface scanning	3-8
Hardware trigger modes.....	3-9
Understanding synchronous triggering modes	3-14
Events	3-18
LXI Class B Triggering (IEEE-1588).....	3-19
Files.....	3-23
File formats	3-23
Default file extensions	3-23
File system navigation.....	3-24
File I/O	3-24
Script examples.....	3-26
Display operations.....	3-31
Display functions and attributes	3-31
Display messages	3-31
Input prompting	3-35
Indicators.....	3-37
Local lockout	3-38
Load test menu	3-39
Key-press codes	3-41
Digital I/O	3-42
Digital I/O port	3-42
Using output enable	3-48
TSP-Link synchronization lines	3-48
Reading buffers.....	3-50
Buffer overview	3-50
Front-panel buffer operation.....	3-51
Remote buffer operation	3-55
Basic DMM operation	4-1
DMM measurement capabilities.....	4-1
High-energy circuit safety precautions.....	4-2
Performance considerations	4-2
Warmup time.....	4-2
Autozero.....	4-3
Line cycle synchronization	4-4
Autodelay	4-5
Measure count	4-5
Change the display resolution	4-6

System considerations	4-6
Relationship between DMM functions and attributes	4-6
Relationship between front panel settings and remote commands	4-7
Save DMM configurations	4-7
Open and close relay operation	4-9
Voltage measurements (DC volts and AC volts)	4-10
Settings available for voltage measurement	4-10
Autodelay and auto range settings	4-11
Voltage measurement connections	4-11
Voltage measurement procedure front panel	4-12
Voltage measurement procedure remote commands	4-13
Current measurements (DC current and AC current)	4-14
Settings available for current measurements	4-15
Autodelay and auto range settings	4-15
Current measurement connections	4-16
Current measurement procedure from the front panel	4-16
Current measurement procedure through remote commands	4-17
Resistance measurements	4-17
DMM resistance measurement methods	4-17
Settings available for resistance measurements	4-18
Autodelay and auto range settings	4-19
Resistance measurement connections	4-19
Resistance measurements from the front panel	4-22
Resistance measurements through remote interface	4-23
Temperature measurements	4-23
Settings available for temperature measurements	4-23
Autodelay and auto range settings	4-25
Thermocouples	4-25
Thermistors	4-28
RTDs (Resistance Temperature Detector)	4-31
Frequency and period measurements	4-35
Settings available for frequency and period measurements	4-35
Autodelay and auto range settings	4-36
Trigger level	4-36
Gate time	4-36
Frequency connections	4-36
Frequency and period measurement procedure from front panel	4-37
Frequency and period measurement procedure through remote interface	4-38
Continuity testing	4-38
Settings available for continuity testing	4-38
Autodelay and auto range settings	4-39
Continuity testing connections	4-39
Continuity testing procedure	4-39
Refining measurements	4-41
Relative offset	4-41
Math calculations	4-43
dB commands	4-48
Range	4-49
Optimizing measurement speed	4-52
Optimizing measurement accuracy	4-55
Theory of Operation	5-1
DMM	5-1
Rear panel, backplane, and DMM connect relays schematic	5-1

Line cycle synchronization 5-2
 AC voltage measurements and crest factor 5-5
 DMM resistance measurement methods 5-8
 Reference junctions 5-13
 Open lead detection 5-14
 Open thermocouple detection 5-19
 Accuracy calculations 5-21
 Understanding Precision Time Protocol (PTP) 5-23

Remote commands 6-1

Introduction to remote operation 6-1
 Controlling the instrument by sending individual command messages 6-1
 Queries 6-3
 Data retrieval commands 6-3
 Information on scripting and programming 6-4
 About remote commands 6-4
 Alarms 6-5
 Bit manipulation and logic operations 6-5
 Channel 6-6
 Data queue 6-7
 Digital I/O 6-7
 Display 6-8
 DMM 6-9
 Error queue 6-10
 Event log 6-10
 File I/O 6-10
 File system navigation 6-11
 GPIB 6-12
 Instrument identification 6-12
 LAN and LXI 6-13
 Local node 6-14
 PTP 6-14
 Reading buffer 6-15
 Reset 6-15
 Queries and response messages 6-16
 Saved setups 6-16
 Scan 6-17
 Scripting 6-17
 Status model 6-18
 Slot 6-18
 Time 6-18
 Top level instrument controls 6-19
 Triggering 6-20
 TSP-Link 6-21
 TSP-Net 6-21
 Userstrings 6-21

Instrument programming 7-1

Fundamentals of scripting for TSP 7-1
 What is a script? 7-1
 Runtime and nonvolatile memory storage of scripts 7-2
 What can be included in scripts? 7-2
 Commands that cannot be used in scripts 7-2
 Manage scripts 7-3
 Working with scripts in nonvolatile memory 7-10
 Run a user script from the instrument front panel 7-11

Load a script from the instrument front panel.....	7-12
Save a script from the instrument front panel.....	7-13
Interactive script.....	7-13
Fundamentals of programming for TSP.....	7-15
Introduction.....	7-15
What is Lua?.....	7-15
Lua basics.....	7-15
Standard libraries.....	7-30
Programming example.....	7-35
Using Test Script Builder (TSB).....	7-35
Installing the TSB software.....	7-36
Project Navigator.....	7-36
Script Editor.....	7-37
Programming interaction.....	7-37
Advanced scripting for TSP.....	7-37
Global variables and the script.user.scripts table.....	7-37
Create a script using the script.new() command.....	7-38
Restore a script to the runtime environment.....	7-41
Rename a script.....	7-41
Delete user scripts from the instrument.....	7-43
Memory considerations for the runtime environment.....	7-43
TSP-Link system expansion interface.....	7-45
Overview.....	7-45
Connections.....	7-47
Initialization.....	7-47
Resetting the TSP-Link network.....	7-47
Using the expanded system.....	7-48
TSP advanced features.....	7-49
Using groups to manage nodes on TSP-Link network.....	7-50
Running parallel test scripts.....	7-51
Using the data queue for real-time communication.....	7-52
Copying test scripts across the TSP-Link network.....	7-53
Removing stale values from the reading buffer.....	7-53
TSP-Net.....	7-54
Overview.....	7-54
TSP-Net capabilities.....	7-54
Using TSP-Net with any Ethernet-enabled device.....	7-54
Using TSP-Net with any Ethernet-enabled device.....	7-55
TSP-Net versus TSP-Link to communicate with TSP-enabled devices.....	7-57
Instrument commands: General device control.....	7-57
Instrument commands: TSP-enabled device control.....	7-57
Example: Using tspnet commands.....	7-58
Command reference.....	8-1
Command programming notes.....	8-1
Placeholder text.....	8-1
Syntax rules.....	8-2
Logical instruments.....	8-3
Using channel.*() commands.....	8-4
Time and date values.....	8-6
Using the command reference.....	8-6
Command name and standard parameters summary.....	8-7
Command usage.....	8-8
Command details.....	8-9
Example section.....	8-9

Related commands and information.....	8-9
Commands.....	8-10
beeper.beep().....	8-10
beeper.enable.....	8-10
bit.bitand().....	8-11
bit.bitor().....	8-11
bit.bitxor().....	8-12
bit.clear().....	8-12
bit.get().....	8-13
bit.getfield().....	8-14
bit.set().....	8-14
bit.setfield().....	8-15
bit.test().....	8-16
bit.toggle().....	8-17
bufferVar.appendmode.....	8-17
bufferVar.basetimefractional.....	8-18
bufferVar.basetimeseconds.....	8-19
bufferVar.cachemode.....	8-20
bufferVar.capacity.....	8-20
bufferVar.channels.....	8-21
bufferVar.clear().....	8-23
bufferVar.clearcache().....	8-23
bufferVar.collectchannels.....	8-24
bufferVar.collecttimestamps.....	8-25
bufferVar.dates.....	8-26
bufferVar.formattedreadings.....	8-28
bufferVar.fractionalseconds.....	8-29
bufferVar.n.....	8-30
bufferVar.ptpseconds.....	8-30
bufferVar.readings.....	8-31
bufferVar.relativetimestamps.....	8-33
bufferVar.seconds.....	8-34
bufferVar.statuses.....	8-35
bufferVar.times.....	8-36
bufferVar.timestampresolution.....	8-37
bufferVar.timestamps.....	8-38
bufferVar.units.....	8-39
channel.calibration.adjustcount().....	8-41
channel.calibration.adjustdate().....	8-42
channel.calibration.lock().....	8-43
channel.calibration.password().....	8-44
channel.calibration.save().....	8-45
channel.calibration.step().....	8-46
channel.calibration.unlock().....	8-47
channel.calibration.verifydate().....	8-48
channel.clearforbidden().....	8-49
channel.close().....	8-50
channel.connectrule.....	8-52
channel.connectsequential.....	8-53
channel.createspecifier().....	8-54
channel.exclusiveclose().....	8-56
channel.exclusiveslotclose().....	8-57
channel.getbackplane().....	8-59
channel.getclose().....	8-61
channel.getcount().....	8-63
channel.getdelay().....	8-64
channel.getforbidden().....	8-66
channel.getimage().....	8-68
channel.getlabel().....	8-69
channel.getmatch().....	8-70

channel.getmatchtype()	8-71
channel.getmode()	8-72
channel.getoutputenable()	8-73
channel.getpole()	8-74
channel.getpowerstate()	8-75
channel.getstate()	8-76
channel.getstatelatch()	8-78
channel.gettype()	8-79
channel.open()	8-80
channel.pattern.catalog()	8-81
channel.pattern.delete()	8-82
channel.pattern.getimage()	8-82
channel.pattern.setimage()	8-83
channel.pattern.snapshot()	8-85
channel.read()	8-87
channel.reset()	8-88
channel.resetstatelatch()	8-89
channel.setbackplane()	8-90
channel.setdelay()	8-93
channel.setforbidden()	8-94
channel.setlabel()	8-94
channel.setmatch()	8-96
channel.setmatchtype()	8-97
channel.setmode()	8-98
channel.setoutputenable()	8-100
channel.setpole()	8-101
channel.setpowerstate()	8-103
channel.setstatelatch()	8-104
channel.trigger[N].clear()	8-105
channel.trigger[N].EVENT_ID	8-105
channel.trigger[N].get()	8-106
channel.trigger[N].set()	8-107
channel.trigger[N].wait()	8-108
channel.write()	8-109
comm.gpib.enable	8-110
comm.lan.enable	8-110
comm.lan.rawsockets.enable	8-111
comm.lan.telnet.enable	8-112
comm.lan.vxi11.enable	8-113
comm.lan.web.enable	8-114
createconfigscript()	8-115
dataqueue.add()	8-115
dataqueue.CAPACITY	8-116
dataqueue.clear()	8-117
dataqueue.count	8-117
dataqueue.next()	8-118
delay()	8-119
digio.readbit()	8-120
digio.readport()	8-120
digio.trigger[N].assert()	8-121
digio.trigger[N].clear()	8-122
digio.trigger[N].EVENT_ID	8-122
digio.trigger[N].mode	8-123
digio.trigger[N].overrun	8-124
digio.trigger[N].pulsewidth	8-125
digio.trigger[N].release()	8-125
digio.trigger[N].reset()	8-126
digio.trigger[N].stimulus	8-127
digio.trigger[N].wait()	8-129
digio.writebit()	8-130
digio.writeport()	8-130

digio.writeprotect	8-131
display.clear()	8-132
display.getannunciators()	8-132
display.getcursor()	8-134
display.getlastkey()	8-135
display.gettext()	8-136
display.inputvalue()	8-138
display.loadmenu.add()	8-139
display.loadmenu.catalog()	8-141
display.loadmenu.delete()	8-141
display.locallockout	8-142
display.menu()	8-142
display.prompt()	8-143
display.screen	8-144
display.sendkey()	8-145
display.setcursor()	8-147
display.settext()	8-148
display.trigger.EVENT_ID	8-149
display.waitkey()	8-149
dmm.adjustment.count	8-151
dmm.adjustment.date	8-152
dmm.aperture	8-153
dmm.appendbuffer()	8-155
dmm.autodelay	8-157
dmm.aurange	8-158
dmm.autozero	8-160
dmm.buffer.catalog()	8-161
dmm.buffer.info()	8-162
dmm.buffer.maxcapacity	8-163
dmm.buffer.usedcapacity	8-163
dmm.calibration.ac()	8-164
dmm.calibration.dc()	8-165
dmm.calibration.lock()	8-166
dmm.calibration.password	8-167
dmm.calibration.save()	8-168
dmm.calibration.unlock()	8-168
dmm.calibration.verifydate	8-169
dmm.close()	8-170
dmm.configure.catalog()	8-172
dmm.configure.delete()	8-173
dmm.configure.query()	8-174
dmm.configure.recall()	8-176
dmm.configure.set()	8-178
dmm.connect	8-180
dmm.dbreference	8-181
dmm.detectorbandwidth	8-182
dmm.displaydigits	8-183
dmm.drycircuit	8-184
dmm.filter.count	8-185
dmm.filter.enable	8-186
dmm.filter.type	8-187
dmm.filter.window	8-188
dmm.fourrtd	8-189
dmm.func	8-190
dmm.getconfig()	8-192
dmm.inputdivider	8-193
dmm.limit[Y].autoclear	8-194
dmm.limit[Y].clear()	8-195
dmm.limit[Y].enable	8-196
dmm.limit[Y].high.fail	8-198
dmm.limit[Y].high.value	8-200

dmm.limit[Y].low.fail	8-202
dmm.limit[Y].low.value	8-204
dmm.linesync	8-206
dmm.makebuffer()	8-207
dmm.math.enable	8-209
dmm.math.format	8-211
dmm.math.mxb.bfactor	8-212
dmm.math.mxb.mfactor	8-213
dmm.math.mxb.units	8-214
dmm.math.percent	8-215
dmm.measure()	8-216
dmm.measurecount	8-217
dmm.measurewithtime()	8-218
dmm.measurewithptp()	8-219
dmm.nplc	8-220
dmm.offsetcompensation	8-221
dmm.open()	8-222
dmm.opendetector	8-224
dmm.range	8-225
dmm.refjunction	8-226
dmm.rel.acquire()	8-227
dmm.rel.enable	8-228
dmm.rel.level	8-229
dmm.reset()	8-230
dmm.rtdalpha	8-231
dmm.rtdbeta	8-233
dmm.rtddelta	8-235
dmm.rtdzero	8-236
dmm.savebuffer()	8-238
dmm.setconfig()	8-239
dmm.simreftemperature	8-241
dmm.thermistor	8-242
dmm.thermocouple	8-243
dmm.threertd	8-244
dmm.threshold	8-245
dmm.transducer	8-246
dmm.units	8-247
errorqueue.clear()	8-248
errorqueue.count	8-248
errorqueue.next()	8-248
eventlog.all()	8-250
eventlog.clear()	8-250
eventlog.count	8-251
eventlog.enable	8-251
eventlog.next()	8-252
eventlog.overwritemethod	8-253
exit()	8-254
fileVar.close()	8-254
fileVar.flush()	8-255
fileVar.read()	8-255
fileVar.seek()	8-256
fileVar.write()	8-257
format.asciiprecision	8-257
format.byteorder	8-258
format.data	8-259
fs.chdir()	8-260
fs.cwd()	8-260
fs.is_dir()	8-261
fs.is_file()	8-261
fs.mkdir()	8-262
fs.readdir()	8-262

fs.rmdir()	8-262
gettimezone()	8-263
gpib.address	8-263
io.close()	8-264
io.flush()	8-265
io.input()	8-265
io.open()	8-266
io.output()	8-267
io.read()	8-267
io.type()	8-268
io.write()	8-268
lan.applysettings()	8-269
lan.config.dns.address[N]	8-270
lan.config.dns.domain	8-270
lan.config.dns.dynamic	8-271
lan.config.dns.hostname	8-272
lan.config.dns.verify	8-272
lan.config.gateway	8-273
lan.config.ipaddress	8-273
lan.config.method	8-274
lan.config.subnetmask	8-275
lan.lxidomain	8-275
lan.nagle	8-276
lan.reset()	8-276
lan.restoredefaults()	8-276
lan.status.dns.address[N]	8-277
lan.status.dns.name	8-278
lan.status.duplex	8-278
lan.status.gateway	8-279
lan.status.ipaddress	8-279
lan.status.macaddress	8-280
lan.status.port.dst	8-280
lan.status.port.rawsocket	8-281
lan.status.port.telnet	8-281
lan.status.port.vxi11	8-282
lan.status.speed	8-282
lan.status.subnetmask	8-283
lan.trigger[N].assert()	8-283
lan.trigger[N].clear()	8-284
lan.trigger[N].connect()	8-285
lan.trigger[N].connected	8-285
lan.trigger[N].disconnect()	8-286
lan.trigger[N].EVENT_ID	8-286
lan.trigger[N].ipaddress	8-287
lan.trigger[N].mode	8-287
lan.trigger[N].overrun	8-288
lan.trigger[N].protocol	8-289
lan.trigger[N].pseudostate	8-290
lan.trigger[N].stimulus	8-290
lan.trigger[N].wait()	8-292
localnode.define *	8-293
localnode.description	8-293
localnode.emulation	8-294
localnode.linefreq	8-295
localnode.model	8-296
localnode.password	8-296
localnode.passwordmode	8-297
localnode.prompts	8-297
localnode.prompts4882	8-298
localnode.reset()	8-299
localnode.revision	8-300

localnode.serialno	8-300
localnode.showerrors	8-301
makegetter()	8-301
makesetter()	8-302
memory.available()	8-303
memory.used()	8-304
node[N].execute()	8-305
node[N].getglobal()	8-305
node[N].setglobal()	8-306
opc()	8-307
print()	8-307
printbuffer()	8-308
printnumber()	8-309
ptp.domain	8-310
ptp.ds.info()	8-311
ptp.enable	8-313
ptp.portstate	8-314
ptp.slavepreferred	8-315
ptp.time()	8-315
ptp.utcoffset	8-316
reset()	8-316
scan.abort()	8-317
scan.add()	8-317
scan.addimagestep()	8-320
scan.addwrite()	8-321
scan.background()	8-322
scan.bypass	8-323
scan.create()	8-324
scan.execute()	8-326
scan.list()	8-327
scan.measurecount	8-329
scan.mode	8-330
scan.nobufferbackground()	8-331
scan.nobufferexecute()	8-332
scan.reset()	8-333
scan.scancount	8-334
scan.state()	8-335
scan.stepcount	8-336
scan.trigger.arm.clear()	8-336
scan.trigger.arm.set()	8-337
scan.trigger.arm.stimulus	8-337
scan.trigger.channel.clear()	8-339
scan.trigger.channel.set()	8-340
scan.trigger.channel.stimulus	8-340
scan.trigger.clear()	8-342
scan.trigger.measure.clear()	8-343
scan.trigger.measure.set()	8-343
scan.trigger.measure.stimulus	8-344
scan.trigger.sequence.clear()	8-345
scan.trigger.sequence.set()	8-346
scan.trigger.sequence.stimulus	8-347
schedule.alarm[N].enable	8-349
schedule.alarm[N].EVENT_ID	8-350
schedule.alarm[N].fractionalseconds	8-351
schedule.alarm[N].period	8-352
schedule.alarm[N].ptpseconds	8-352
schedule.alarm[N].repetition	8-353
schedule.alarm[N].seconds	8-354
schedule.disable()	8-354
script.anonymous	8-354
script.delete()	8-355

script.load()	8-356
script.new()	8-357
script.newautorun()	8-358
script.restore()	8-358
script.run()	8-359
script.user.catalog()	8-359
scriptVar.autorun	8-360
scriptVar.list()	8-361
scriptVar.name	8-361
scriptVar.run()	8-362
scriptVar.save()	8-363
scriptVar.source	8-363
settime()	8-364
settimezone()	8-365
setup.cards()	8-366
setup.poweron	8-367
setup.recall()	8-368
setup.save()	8-368
slot[X].banks.matrix	8-369
slot[X].columns.matrix	8-370
slot[X].commonsideohms	8-370
slot[X].digio	8-371
slot[X].endchannel.*	8-371
slot[X].idn	8-375
slot[X].interlock.override	8-376
slot[X].interlock.state	8-377
slot[X].isolated	8-378
slot[X].matrix	8-378
slot[X].maxvoltage	8-379
slot[X].multiplexer	8-379
slot[X].poles.four	8-380
slot[X].poles.one	8-381
slot[X].poles.two	8-382
slot[X].pseudocard	8-382
slot[X].rows.matrix	8-384
slot[X].startchannel.*	8-384
slot[X].tempsensor	8-388
slot[X].thermal.state	8-388
status.condition	8-389
status.measurement.*	8-391
status.node_enable	8-393
status.node_event	8-394
status.operation.*	8-396
status.operation.user.*	8-398
status.questionable.*	8-400
status.request_enable	8-402
status.request_event	8-404
status.reset()	8-406
status.standard.*	8-406
status.system.*	8-408
status.system2.*	8-410
status.system3.*	8-412
status.system4.*	8-414
status.system5.*	8-416
timer.measure.t()	8-418
timer.reset()	8-418
trigger.blender[N].clear()	8-419
trigger.blender[N].EVENT_ID	8-419
trigger.blender[N].orenable	8-420
trigger.blender[N].overrun	8-421
trigger.blender[N].reset()	8-421

trigger.blender[N].stimulus[M]	8-422
trigger.blender[N].wait()	8-424
trigger.clear()	8-425
trigger.EVENT_ID	8-425
trigger.timer[N].clear()	8-426
trigger.timer[N].count	8-426
trigger.timer[N].delay	8-427
trigger.timer[N].delaylist	8-427
trigger.timer[N].EVENT_ID	8-428
trigger.timer[N].overrun	8-428
trigger.timer[N].passthrough	8-429
trigger.timer[N].reset()	8-430
trigger.timer[N].stimulus	8-430
trigger.timer[N].wait()	8-432
trigger.wait()	8-432
tsplink.group	8-433
tsplink.master	8-434
tsplink.node	8-434
tsplink.readbit()	8-435
tsplink.readport()	8-435
tsplink.reset()	8-436
tsplink.state	8-436
tsplink.trigger[N].assert()	8-437
tsplink.trigger[N].clear()	8-438
tsplink.trigger[N].EVENT_ID	8-438
tsplink.trigger[N].mode	8-439
tsplink.trigger[N].overrun	8-441
tsplink.trigger[N].pulsewidth	8-441
tsplink.trigger[N].release()	8-442
tsplink.trigger[N].reset()	8-442
tsplink.trigger[N].stimulus	8-443
tsplink.trigger[N].wait()	8-445
tsplink.writebit()	8-445
tsplink.writeport()	8-446
tsplink.writeprotect	8-447
tspnet.clear()	8-447
tspnet.connect()	8-448
tspnet.disconnect()	8-449
tspnet.execute()	8-450
tspnet.idn()	8-451
tspnet.read()	8-451
tspnet.readavailable()	8-452
tspnet.reset()	8-453
tspnet.termination()	8-453
tspnet.timeout	8-454
tspnet.tsp.abort()	8-455
tspnet.tsp.abortonconnect	8-455
tspnet.tsp.rhtablecopy()	8-456
tspnet.tsp.runscript()	8-457
tspnet.write()	8-457
upgrade.previous()	8-458
upgrade.unit()	8-459
userstring.add()	8-459
userstring.catalog()	8-460
userstring.delete()	8-460
userstring.get()	8-461
waitcomplete()	8-461

Troubleshooting guide	9-1
Contacting support	9-1
USB troubleshooting	9-2
Check driver for the USB Test and Measurement Device	9-2
Troubleshooting GPIB interfaces	9-5
Timeout errors	9-5
Troubleshooting LAN interfaces	9-5
Verify connections and settings	9-6
Use Ping to test the connection	9-6
Open ports on firewalls	9-7
Web page problems	9-7
LXI LAN status indicator	9-8
Initialize the LAN configuration	9-8
Install LXI Discovery Tool software on your computer	9-8
Communicate using VISA communicator	9-9
WireShark	9-9
Testing the display, keys, and channel matrix	9-9
Verify front panel key operation	9-9
Verify display operation	9-9
Update drivers	9-10
Error and status messages	9-10
Introduction	9-10
Error summary	9-10
Effects of errors on scripts	9-10
Error queue remote commands	9-11
Error and status message list	9-12
 Frequently asked questions (FAQs)	 10-1
How do I get my LAN or web connection to work?	10-1
Why can't I close a channel?	10-1
How do I know if an error has occurred on my instrument?	10-2
How do I find the serial number and firmware version of the instrument?	10-3
 Next steps	 11-1
Additional Series 3700A information	11-1
 Maintenance	 A-1
Line fuse replacement	A-1
Fuse replacement	A-2
AMPS analog backplane fuse replacement	A-3
Front panel tests	A-3
Test procedure	A-4
Keys test	A-5
Display patterns test	A-5
Displaying the instrument's serial number	A-6

Upgrading the firmware.....	A-6
Upgrade procedure using the remote interface	A-7
Firmware upgrade using the instrument web interface.....	A-9
LAN concepts and settings.....	B-1
Establishing a point-to-point connection	B-1
Step 1: Identify and record the existing IP configuration	B-2
Step 2: Disable DHCP to use the computer's existing IP address	B-4
Step 3: Configure the instrument's LAN settings.....	B-5
Step 4: Install the crossover cable	B-6
Step 5: Access the instrument's internal web page.....	B-6
Connecting to the LAN	B-7
Setting the LAN configuration method.....	B-7
Setting the IP address.....	B-7
Setting the gateway.....	B-8
Setting the subnet mask.....	B-8
Configuring the domain name system (DNS).....	B-8
LAN speeds.....	B-9
Duplex mode	B-10
Viewing LAN status messages	B-10
Viewing the network settings	B-11
Confirming the active speed and duplex negotiation.....	B-11
Confirming port numbers.....	B-12
Selecting a remote command interface	B-12
VXI-11 connection.....	B-12
Raw socket connection	B-12
Dead socket connection	B-13
Telnet connection.....	B-13
Logging LAN trigger events in the event log.....	B-15
Accessing the event log from the command interface.....	B-16
Calibration	C-1
Verification test requirements.....	C-2
Performing the verification test procedures	C-4
Model 3706A verification tests	C-5
Calibration	C-22
Overview	C-22
Environmental conditions	C-22
Calibration considerations.....	C-23
Calibration	C-24
Remote calibration procedure	C-24
Status model	D-1
Status Byte Register	D-1
Status model diagrams	D-3
Status Byte Register overview	D-4
Measurement summary bit (Measurement event register).....	D-5
System summary bit (System register)	D-5
Standard Event Register	D-8

Error available bit (Error or Event queue).....	D-9
Questionable summary bit (Questionable event register)	D-10
Message available bit (Output queue).....	D-11
Event summary bit (ESB register).....	D-12
Master summary status bit (MSS bit register)	D-13
Operation summary bit (Operation event register)	D-14
Status function summary.....	D-15
Clearing registers and queues	D-15
Startup state.....	D-16
Programming and reading registers.....	D-16
Programming enable and transition registers.....	D-16
Reading registers	D-17
Register programming example	D-17
Status byte and service request (SRQ)	D-18
Service Request Enable Register	D-18
Status Byte Register	D-18
Serial polling and SRQ.....	D-20
SPE, SPD (serial polling)	D-21
Service requests and connections	D-21
Status byte and service request commands.....	D-22
Enable and transition registers.....	D-22
Controlling node and SRQ enable registers.....	D-22
TSP-Link system status	D-23
Status model configuration example	D-23
Index.....	I-1

Introduction

In this section:

Welcome	1-1
Extended warranty	1-1
Contact information	1-1
CD-ROM contents	1-2
Organization of manual sections	1-2
Capabilities and features	1-3
General information.....	1-4

Welcome

Thank you for choosing a Keithley Instruments product. The Series 3700A System Switch/Multimeter features scalable, instrument grade switching and multi-channel measurement solutions that are optimized for automated testing of electronic products and components. The Series 3700A includes four versions of the Model 3706A system switch mainframe, along with a growing family of plug-in switch and control cards. When the Model 3706A mainframe is ordered with the high performance multimeter, you receive a tightly-integrated switch and measurement system that can meet the demanding application requirements in a functional test system or provide the flexibility needed in stand-alone data acquisition and measurement applications.

Extended warranty

Additional years of warranty coverage are available on many products. These valuable contracts protect you from unbudgeted service expenses and provide additional years of protection at a fraction of the price of a repair. Extended warranties are available on new and existing products. Contact your local Keithley Instruments representative for details.

Contact information

If you have any questions after reviewing this information, please contact your local Keithley Instruments representative or call Keithley Instruments corporate headquarters (toll-free inside the U.S. and Canada only) at 1-888-KEITHLEY (1-888-534-8453), or from outside the U.S. at +1-440-248-0400. For worldwide contact numbers, visit the [Keithley Instruments website \(http://www.keithley.com\)](http://www.keithley.com).

CD-ROM contents

Two CD-ROMs are shipped with each Series 3700A order. The Series 3700A Quick Start Guide, User's Manual, Reference Manual, and Switch Card Manual are provided in PDF format on the Series 3700A Product Information CD-ROM.

- **Quick Start Guide:** Provides unpacking instructions, describes basic connections, and reviews basic operation information. If you are new to Keithley Instruments equipment, refer to the Quick Start Guide to take the steps needed to unpack, set up, and verify operation.
- **User's Manual:** Provides application examples. If you need a starting point to begin creation of applications, refer to the User's Manual for a variety of specific examples.
- **Reference Manual:** Includes advanced operation topics and maintenance information. Programmers looking for a command reference, and users looking for an in-depth description of the way the instrument works (including troubleshooting and optimization), should refer to the Reference Manual.
- **Switching and Control Cards Reference Manual:** Contains information specific to the switch cards that can be used with the Series 3700A.
- **Additional product information:** The product data sheet, product specifications, and rack-mount kit instructions are also included on the CD-ROM.

A second CD-ROM contains the Test Script Builder script development software (Keithley Instruments part number KTS-850). Use this CD-ROM to install the Test Script Builder Integrated Development Environment. This software provides an environment to develop a test program and the ability to load the test program onto the instrument. Running a program loaded on the instrument eliminates the need to send individual commands from the host computer to the instrument when running a test.

The second CD-ROM also includes:

- The 3700A TSB Add-in, which is a software tool you can use to create, modify, debug, and store Test Script Processor (TSP[®]) test scripts.
- IVI Instrument Driver, driver for National Instruments LabVIEW[™], and related release notes.
- J2SE[™] Runtime Environment.
- Keithley I/O layer and release notes.
- Keithley LXI Discovery Utility.

For the latest drivers and additional support information, see <http://www.keithley.com> (<http://www.keithley.com>).

Organization of manual sections

Bookmarks for each manual section have been provided in the PDF (see Adobe[®] Acrobat[®] or Reader[®] help for information about bookmarks). The manual sections are also listed in the Table of Contents located at the beginning of this manual.

Capabilities and features

The Series 3700A System Switch/Multimeter is comprised of four versions of the Model 3706A system switch mainframe and a series of plug-in switch and control cards.

Series 3700A available models

Model number	Description
3706A	Six-slot system switch with high-performance digital multimeter (DMM)
3706A-NFP	Six-slot system switch with high-performance digital multimeter (DMM) without front-panel display and keypad
3706A-S	Six-slot system switch
3706A-NFP	Six-slot system switch without front-panel display and keypad

Available plug-in cards

Model number	Description
3720	Dual 1x30 multiplexer card (auto CJC when used with optional Model 3720-ST screw-terminal accessory)
3721	Dual 1x20 multiplexer card (auto CJC when used with optional Model 3721-ST screw-terminal accessory)
3722	Dual 1x48 high-density multiplexer card
3723	Dual 1x30 high-speed reed relay multiplexer card
3724	Dual 1x30 FET multiplexer card
3730	6x16 high-density matrix card
3731	6x16 high-speed reed relay matrix card
3732	Quad 4x28 ultra-high density reed relay matrix card
3740	32-channel isolated switch card
3750	Multifunction control card

Series 3700A instruments have the following features:


- Six slot system switch with optional high-performance multimeter
- Three remote interfaces: LXI/ethernet, general purpose bus (GPIB), and Universal Serial Bus (USB)
- Fourteen programmable digital I/O lines
- Up to 576 2-wire or 720 1-wire multiplexer channels in one mainframe
- Up to 2,688 one-pole matrix crosspoints in one mainframe
- Capable of more than 14,000 readings per second to memory with high-performance multimeter option
- Filtering to reduce reading noise

- Internal memory stores multiple user setups
- USB flash drive access for saving data buffers, test scripts, and user setups
- Digital I/O port: Allows the Series 3700A to control other devices
- LXI[®] Class C compliance
- Embedded TSP scripting engine accessible from any host interface; responds to high-speed test scripts comprised of instrument control commands
- TSP-Link[®] expansion bus that allows TSP-enabled instruments to trigger and communicate with each other; advanced Test Script Processor (TSP[®]) scripting engine features enable parallel script execution across the TSP-Link network
- Supports IEEE-488 (GPIB), RS-232, and ethernet local area network (LAN) connections

Measuring capabilities

The basic measurement capabilities of Series 3700A systems are summarized in the following figure.

Figure 1-1: DMM measurement capabilities



General information

Displaying the instrument's serial number

To display the serial number on the front panel:

1. If the Series 3700A is in remote operation, press the **EXIT (LOCAL)** key once to place the instrument in local operation.
2. Press the **MENU** key.
3. Use the navigation wheel  to scroll to the **UNIT-INFO** menu.
4. Press the **ENTER** key.
5. On the SYSTEM INFORMATION menu, scroll to the **SERIAL#** menu item.
6. Press the **ENTER** key. The Series 3700A serial number is displayed.

General operation

In this section:

Turning your instrument on and off	2-1
Front panel operation	2-2
Rear panel summary	2-27
User setup	2-34
Using the web interface	2-36
Communication interfaces	2-52
Switch operation	2-77

Turning your instrument on and off

Procedure

Follow the procedure below to connect the Series 3700A to line power and turn on the instrument. The Series 3700A operates from a line voltage of 100 V to 240 V at a frequency of 50 Hz or 60 Hz. Line voltage is automatically sensed (there are no switches to set). Make sure the operating voltage in your area is compatible.



CAUTION

Operating the instrument on an incorrect line voltage may cause damage to the instrument, possibly voiding the warranty.

To turn a Series 3700A on and off:

1. Before plugging in the power cord, make sure that the front panel POWER switch is in the off (O) position.
2. Connect the female end of the supplied power cord to the AC receptacle on the rear panel.
3. Connect the other end of the power cord to a grounded AC outlet.



WARNING

The power cord supplied with the Series 3700A contains a separate ground wire for use with grounded outlets. When proper connections are made, the instrument chassis is connected to power-line ground through the ground wire in the power cord. In the event of a failure, not using a grounded outlet may result in personal injury or death due to electric shock.

4. To turn your instrument on, press the front panel **POWER** switch to place it in the on (I) position.
5. To turn your instrument off, press the front panel **POWER** switch to place it in the off (O) position.

Line frequency configuration

The factory configures the Series 3700A to automatically detect the line frequency (either 50 Hz or 60 Hz) at each power-up. This detected line frequency is used for aperture (NPLC) calculations.

To view the line frequency setting, send the following command:

```
print(localnode.linefreq)
```

Fuse replacement

A rear panel fuse drawer is located below the AC receptacle (refer to Rear panel). This fuse protects the power line input of the instrument. If the line fuse needs to be replaced, refer to [Line fuse replacement](#) (on page A-1).

Power-up sequence

When the instrument is turned on, the instrument performs self-tests on its read-only memory, nonvolatile memory, and RAM and momentarily lights all segments and indicators. If a failure is detected, the instrument momentarily displays an error message and the ERR indicator turns on. Error messages are listed in [Error and status messages](#) (on page 9-10).

If there are no errors, the following actions occur when the instrument is turned on:

1. "No Comm Link" is briefly displayed.
2. "Initializing" is displayed for several seconds.
3. Near the end of initialization, the 1588 and LAN status LEDs light.
4. All of the display pixels briefly light.
5. Main display is displayed.


Front panel operation

The Series 3700A includes several models that support different features. The following figures show the front panels of each of the models; a brief description of the features follows the figures.

Figure 2-1: Model 3706A with DMM front panel



Figure 2-2: Model 3706A-S front panel (no DMM)



(1) The USB port



(USB port)


Use the front-panel USB port to connect a USB flash drive. The USB flash drive can be used to store reading buffer data, scripts, and user setup options.

(2) The display

During setup, the display shows menu choices that you can use to configure the instrument. See [Menu overview](#) (on page 2-9) for more information about Series 3700A menus.

During operation, the display provides information about the selected channel, channel pattern, channel state, and errors. It also shows the control status (local or remote). If REM is displayed, the instrument is presently controlled through a remote interface (GPIB, LAN, or USB). If REM is not displayed, control is through the front panel. The following figure shows an example of the Series 3700A during operation.

Figure 2-3: Series 3700A display during operation



Series 3700A display during operation	
1	Active channel (slot 1, channel 004).
2	Channel state (open, 2-pole operation).
3	Present state of the DMM attributes for displayed channel: <ul style="list-style-type: none">• The 4-WΩ and autorange are enabled• Dry-circuit ohms is disabled (DRY-)• Offset compensation is off (OC-) For detailed descriptions of the DMM attribute symbols, see the table labeled "DMM attribute symbols" below.
4	Arrow indicating that more menu items exist; turn the navigation wheel  to the left or right to see the additional items.
5	The 4-W Ω and autorange are enabled.
6	Indicates the instrument is being controlled remotely. Press the LOCAL (EXIT) key to control the instrument through the front panel.

The table below lists the display indicators and what they mean.

Indicator	Meaning
AUTO:	Measure autorange is selected
EDIT:	Instrument is in the editing mode
ERR:	Questionable reading or invalid calibration step
FILT:	Digital filter is enabled
LSTN:	Instrument is addressed to listen
MATH:	Enabled for $mX+b$, percent, or reciprocal ($1/X$) calculation
REL:	Relative mode is enabled
REM:	Instrument is in remote mode
SRQ:	Service request is asserted
TALK:	Instrument is addressed to talk
TRIG:	Instrument is processing a front-panel reading request
4W:	Four-wire resistance or RTD temperature reading
* (asterisk):	Readings are being stored in the buffer

The bottom left line of the display contains the DMM attribute symbols. The symbols that appear are dependent on whether the attribute exists for the selected function. The following table indicates the DMM attribute symbols that may appear on the front panel. If the symbol has a value associated with it, the third column in the table indicates the value definition.

DMM attribute symbols

Front-panel DMM attribute	Symbol	Values
range	R=	AUTO or n, where n equals the range
nplc	N=	n, where n equals the NPLC
auto delay	AD	+ for ON, 1 for ONCE, or 0 for OFF
auto zero	AZ	+ for ON or – for OFF
line sync	LS	+ for ON or – for OFF
limit	LIM	+ for a limit enabled or – for limits disabled
detector bandwidth	DBW	3, 30, or 300
threshold	THR=	n, where n indicates the threshold
aperture	A=	n, where n indicates the aperture setting
dry circuit	DRY	+ for ON or – for OFF
offset compensation	OC	+ for ON or – for OFF
thermocouple sensor K	K_T/C	N/A
thermocouple sensor T	T_T/C	N/A
thermocouple sensor E	E_T/C	N/A
thermocouple sensor R	R_T/C	N/A
thermocouple sensor S	S_T/C	N/A
thermocouple sensor B	B_T/C	N/A
thermocouple sensor N	N_T/C	N/A
thermistor	THRM	N/A
three-wire RTD	3RTD	N/A
4-wire RTD	4RTD	N/A
simulated reference junction	RJ_SIM	N/A
internal reference junction	RJ_INT	N/A
external reference junction	RJ_EXT	N/A

(3) The navigation wheel



Turn the navigation wheel to scroll to the desired menu option or to change the value of the selected numeric parameter. Pressing the navigation wheel has the same functionality as pressing the **ENTER** key.

When changing a multiple character value, such as an IP address or channel pattern name, press the navigation wheel to enter edit mode, rotate the navigation wheel to change the characters value as desired, but do not leave edit mode. Use the **CURSOR** keys to scroll to the other characters and use the navigation wheel to change their value as needed. Press the **ENTER** key when finished changing all the characters.

(4) The POWER key

POWER

Power switch. The in position turns the Series 3700A on (I); the out position turns it off (O).



(5) The status lights

The Series 3700A has three status lights on the front panel.



The 1588 status light indicates 1588 operation. If this light is off, the 1588 feature is disabled or improperly configured. If the light blinks at a one second rate, the instrument is the 1588 master. If the instrument is a slave, the light will not blink.



The LAN status light is lit when the instrument is connected through the local area network (LAN) with no errors. If this is not lit, the instrument is not connected through the LAN or there is a connection problem.

If you are using the web interface, the LAN Status light blinks when you click ID.




The POWER light is lit when power is applied to the instrument.

(6) The setup and control keys

The setup and control keys provide front-panel control and configuration. The following figure illustrates each key's location. Descriptions of the keys follow the figure.

Figure 2-4: Model 3706A setup and control keys



Configuration keys

DISPLAY key	The DISPLAY key cycles between three screens: The channel display or pattern display, the closed channel list, and the user screen text, which is set with display.settext() (on page 8-148). When the closed channel listing is displayed, if the list of channels is longer than one screen, you can use the navigation wheel  to scroll through the list of closed channels.
CONFIG key	The CONFIG key configures a function or operation.
RESET switch	The RESET switch restores factory default LAN settings.

Channel keys

OPEN ALL key	Opens all closed channels.
STEP key	Use to walk through a scan list by closing and opening the channels contained in a single step with each press of the key.
CLOSE and OPEN keys	You can use the front-panel CLOSE and OPEN keys to perform either switch only operations or switch with DMM operations on the selected channels. The operations of the keys depend on the DMM configuration attribute setting of the selected channel. Refer to Channel attributes (on page 2-93) for more information on the DMM configuration attribute. When the DMM configuration is set to <code>nofunction</code> , the CLOSE and OPEN keys function as switch only operations in the same manner as the <code>channel.close</code> and <code>channel.open</code> commands. When the DMM configuration is associated with a particular function (for example, DC Volts), the CLOSE and OPEN keys function as switch with DMM operations, that is, in the same manner as <code>dmm.close</code> and <code>dmm.open</code> commands. To access the other switch-only operations (exclusive close and exclusive slot close), use the CHAN key to choose and initiate the desired operation after selecting a channel or range of channels.
CHAN key	If a channel is displayed, opens the CHANNEL ACTION menu options (on page 2-14), which allows you to open and close channels. If a pattern is displayed, pressing CHAN switches to channel view.
PATT key	If a pattern is displayed, opens the PATTERN ACTION menu options (on page 2-15), which allows you to manage patterns, open and close patterns, and reset them. If a channel is displayed, pressing PATT changes to display a pattern.
SLOT key	Displays information about the installed cards and the instrument. Information includes the firmware revision, model name, and model number. Press SLOT multiple times to view all instrument information.
SCAN key	Opens the SCAN ACTION menu options (on page 2-16), which allows you to run, manage, view, and reset scan lists. See Scanning and triggering (on page 3-1).
INSERT key	Appends the selected channel or channel pattern to the scan list.
DELETE key	Deletes the first occurrence of the selected channel or channel pattern (including function) from the scan list. To remove all occurrences of a channel from the list, keep pressing the DELETE key.

Script keys

LOAD key	Loads test for execution.
RUN key	Runs the last selected user-defined test code.

General function keys

STORE key	Selects, clears, and saves reading buffer data and creates and deletes reading buffers.
REC key	Recalls stored readings for the selected reading buffer. Use the CURSOR keys or turn the navigation wheel to scroll through the buffer. For more information, see Recalling readings (on page 3-53).
RATE key	Sets measurement speed (fast, medium, or slow) for the active or selected function.
FUNC key	Displays a menu that allows you to scroll through the available DMM functions.
DMM key	Opens the DMM ACTION menu options (on page 2-16).
LIMIT key	Set the limits. Press multiple times to cycle through the four combinations of limit settings: <ul style="list-style-type: none"> • Limit1 and Limit2 off • Limit1 on and Limit2 off • Limit1 off and Limit2 on • Limit1 and Limit2 on
REL key	Enable or disable relative offset for the selected DMM function. REL is shown on the display when relative offset is enabled. See Relative.
FILTER key	Enables or disables the digital filter; you can use this filter to reduce reading noise.
TRIG key	Generates a trigger that can be used in a script or the trigger model. See Scanning and triggering (on page 3-1). Also see display.trigger.EVENT_ID (on page 8-149).
MENU key	Opens the Main menu options, which allows you to manage scripts, manage communications, select channel connections, test the keys, test the display, manage digital I/O settings, set up the beeper, and display instrument information.
EXIT (LOCAL) key	<ul style="list-style-type: none"> • Cancels the current selection and returns to the previous menu item. • Exits remote operation so you can control the instrument from the front panel. • Stops a scan that is running. • Stops a script that is executing.
ENTER key	Accepts the current selection or brings up the next menu option. In most cases, pressing ENTER is the same as pressing the navigation wheel  .
AUTO key	Enables or disables autorange for the selected function.
RANGE keys (up and down arrows)	<p>Selects the next higher or lower measurement range on the measurement display for the selected function.</p> <p>If the Model 3706A displays the overflow message on a particular range, select a higher range until an on-range reading is displayed. Use the lowest range possible without causing an overflow to ensure best accuracy and resolution. You can also use these keys when entering a range value from the front panel. For details, see Autoranging over the front panel (see "Set up autoranging from the front panel" on page 4-51).</p> <p>In addition to selecting range functions, the up and down range keys change the format for non-range numbers (as an example, when editing the limit value).</p> <p>If you select a range of channels, that range must stop when the channel type changes. Therefore, you can never select a range of channels which includes different channel types.</p> <p>For more information, see Range (on page 4-49).</p>
CURSOR keys	<p>Use the CURSOR keys to move the cursor left or right. When the cursor is on the desired compliance value digit, push the navigation wheel  to enter edit mode, and turn the navigation wheel to edit the value. Push the navigation wheel again when finished editing.</p> <p>Use the CURSOR keys or the navigation wheel to move through menu items. To view a menu value, use the CURSOR keys for cursor control, and then press the navigation wheel to view the value or sub-menu item.</p>

Menu overview

Menu navigation

To navigate through the menus and submenus, the Series 3700A must not be in edit mode (the EDIT indicator is not illuminated).

Selecting menu items

To navigate the Main and Configuration menus, use the editing keys as follows:

- Use the **CURSOR** arrow keys to select a menu or an option.
- Press the **ENTER** key to select an item or menu option.
- Rotate the navigation wheel  (clockwise or counter-clockwise) to select a value.
- Use the **EXIT (LOCAL)** key to cancel changes or to back out of the menu structure.

NOTE

You can use the navigation wheel  to select items from the menu or submenus.

Setting a value

You can adjust values on the front panel using the navigation wheel:

1. Use the **CURSOR** arrow keys to move the cursor to the value that you want to edit.
2. Press the navigation wheel  or the **ENTER** key to enter edit mode. The EDIT indicator is illuminated.
3. Rotate the navigation wheel  to set the appropriate value.
4. Press the **ENTER** key to select the value or press the **EXIT (LOCAL)** key to cancel the change.
5. (Optional) Press the **EXIT (LOCAL)** key to return to the main menu.

Menu trees


You can configure much of the instrument's operation through the menus accessed on the front panel. Refer to [Menu navigation](#) (on page 2-9) for more details about using menus.

Main menu

The main menu's structure is summarized in the following figure and table. For directions on navigating the menu, see [Menu navigation](#) (on page 2-9). For other menu items, see [Configuration menus](#) (on page 2-12).

Figure 2-5: Series 3700A main menu tree

Press the **MENU** key.



The following table contains descriptions of the main menu items, as well as cross-references to related information. To access a menu item, press the **MENU** key, turn the navigation wheel  to move the cursor to select the desired item, and press the navigation wheel .


Main menu options

Menu selection	Description	For more information, see:
SCRIPT - CREATE-CONFIG - LOAD - SAVE	Saves and recalls users scripts Creates a script from present instrument configuration; optionally sets it to run automatically at instrument power-on Loads scripts into nonvolatile memory Saves scripts	Manage scripts (on page 7-3)
SETUP - SAVE - RECALL - POWERON - RESET	Saves and recalls user setup options Saves user setup options Recalls user setup options Sets the configuration used during startup Resets the setup to factory default settings	User setup (on page 2-34), Start-up configuration (on page 2-35)
GPIB - ADDRESS - ENABLE	Configures the GPIB connection Sets the GPIB address Enables and disables the GPIB interface	Communications interfaces (see " Communication interfaces " on page 2-52)
LAN - STATUS - CONFIG - APPLY - RESET - ENABLE	Configures the local area network (LAN) Displays LAN connection status Configures the LAN IP address and gateway Applies changes made using the CONFIG menu Restores the default settings Enables and disables the LAN interface	LAN concepts and settings (on page B-1)
TSPLINK - NODE - RESET	Configures the instrument in a TSP-Link [®] network Selects the instrument node identifier Resets the TSP-Link network	TSP-Link system expansion interface (on page 7-45)
UPGRADE	Upgrades the firmware from a USB flash drive	Upgrading the firmware (on page A-6)
EMULATION - 3706A - 3706	Configures emulation mode for compatibility with Series 3700 Disables emulation mode Enables Series 3700A to emulate Series 3700 operation	localnode emulation (on page 8-294)
CHANNEL - RULE - SEQUENTIAL	Configures the channel connections Selects channel connection rules Enables and disables sequential channel connections	Switch operation (on page 2-77)
DISPLAY - TEST	Accesses display functions Runs the display tests	Front panel tests
DIGIO - DIGIO-OUTPUT - WRITE-PROTECT	Controls digital outputs Selects the digital I/O values Write-protects specific digital I/O lines	Digital I/O (on page 3-42)
BEEPER - KEYCLICK - BEEP	Controls the key beeps Enables and disables the key clicks Enables and disables the key beeps	General operation (on page 2-1)
UNIT-INFO - FIRMWARE - SERIAL# - MEMORY-USAGE - CAL	Displays the system information Displays the version of firmware installed Displays the serial number of the unit Displays percentage of memory used Displays the last calibration dates and count	General operation (on page 2-1)

Configuration menus

The configuration menu structure is summarized in the following figure and table. For directions on navigating the menu, see [Menu navigation](#) (on page 2-9). For other menu items, see Main menu options

Figure 2-6: Series 3700A configuration menus





Quick Tip

Press the **EXIT** key to return to a previous menu.

The following table contains descriptions of the configuration menus, as well as cross-references to related information. To select a menu, press the **CONFIG** key and then the front-panel key associated with the desired menu (see the description column in the following table).

Configuration menu options

Configuration menu	To access, press the CONFIG key and then:	Description	For more information, see:
CHANNEL ATTRIBUTE	CHAN	If a channel is displayed when selecting this, configure channels; if a channel pattern is displayed when you select this, change channels states in the pattern	CHAN key configuration (on page 2-17)
PATTERN ACTION	PATT	Manage, open and close, and reset patterns	PATT key configuration (see " SCAN key configuration " on page 2-20)
SCAN ATTR	SCAN	Run, manage, view, and reset scan lists	SCAN key configuration (on page 2-20)
DMM	DMM	Manage DMM like n (NPL)	Speed DMM key configuration (see " LIMIT key configuration " on page 2-23)
LIMIT	LIMIT	Manage for the	DMM measurement capabilities (on page 4-1) LIMIT key configuration (on page 2-23)
RELATIVE OFFSET	REL	Set r	Rel (see " Relative offset " on page 4-41) REL key configuration (on page 2-24)
FILTER	FILTER	Manage the digital filter settings	Filters FILTER key configuration (on page 2-24)
FUNCTION	FUNC	Set DMM functions	FUNC key configuration (on page 2-24)
RD BUFFER ATTR	STORE	If a buffer has been selected when you press the key, you can view and set the reading buffer attributes	STORE key configuration (on page 2-24)

Menu trees

Front-panel key menu options

The menus that can be accessed from the front panel of the instrument allow you to set up and run the instrument.

LOAD TEST menu options

Allows you to run scripts and code from the front panel that you created through the communication interface, or configuration scripts created by pressing the front-panel MENU key, then selecting SCRIPT > CREATE-CONFIG.

To open this menu, press **LOAD**.

The User option loads code that was added to Load Test with the [display.loadmenu.add\(\)](#) (on page 8-139) command.

The Scripts option loads named scripts that were added to the runtime environment. See [Manage scripts](#) (on page 7-3) for information on creating and loading scripts.

After selecting code or script from the User or Scripts option, you can press **RUN** to execute the selected code or script.

CHANNEL ACTION menu options

Allows you to change the state of channels from the front panel.

To open this menu, display a channel, then press **CHAN**.

Switch channel options include:

- **OPEN**: Opens the selected channel.
- **CLOSE**: Closes the selected channel.
- **EXCLOSE**: Closes the selected channel and opens any closed channels on the instrument.
- **EXSLOTCLOSE**: Closes the specified channel and opens any closed channels on the same slot. Channels on other slots remain closed.
- **RESET**: Restores the factory default settings to the selected channel. Resetting a channel deletes any channel patterns that contain that channel.

DIGIO channel options include:

- **READ**: Displays a value from a channel as 8-bit binary. This menu option does not appear if a range of channels is selected. Related command: [channel.read\(\)](#) (on page 8-87).
- **WRITE**: Writes a value to a channel. Enter the value as 8-bit binary. Related command: [channel.write\(\)](#) (on page 8-109).
- **RESET-STATE**: Resets the channel state. Related command: [channel.resetstatelatch\(\)](#) (on page 8-89).
- **RESET**: Restores the factory default settings of selected channels or all channels. Related command: [channel.reset\(\)](#) (on page 8-88).

TOTALIZER channel options include:

- **READ:** Displays a value from a channel as a number between 0 and 65535. This menu option does not appear if a range of channels is selected. Related command: [channel.read\(\)](#) (on page 8-87).
- **WRITE:** Writes a value to a channel. Enter the value between 0 and 65535. Related command: [channel.write\(\)](#) (on page 8-109).
- **RESET-STATE:** Resets the channel state. Related command: [channel.resetstatelatch\(\)](#) (on page 8-89).
- **RESET:** Restores the factory default settings of selected channels or all channels. Related command: [channel.reset\(\)](#) (on page 8-88).

DAC channel options include:

- **READ:** Displays a value from a channel. This menu option does not appear if a range of channels is selected. A number is displayed that is dependent on the channel's selected mode function, as well as the card model of the selected channel. Related command: [channel.read\(\)](#) (on page 8-87).
- **WRITE:** Writes a value from a channel. This menu option does not appear if a range of channels is selected. A number is displayed that is dependent on the channel's selected mode function, as well as the card model of the selected channel. Related command: [channel.write\(\)](#) (on page 8-109)
- **RESET-STATE:** Resets the channel state. Related command: [channel.resetstatelatch\(\)](#) (on page 8-89).
- **RESET:** Restores the factory default settings of selected channels or all channels. Related command: [channel.reset\(\)](#) (on page 8-88).

For more information, see [Working with channels](#) (on page 2-89).

PATTERN ACTION menu options

Allows you to configure and change patterns from the front panel.

To open this menu, in pattern view, press **PATT**.

Options include:

- **CREATE:** If no patterns have been created, this is the only option that is displayed. Allows you to create a new pattern.
- **OPEN:** Opens the channels in the selected channel pattern.
- **CLOSE:** Closes the channels in the selected channel pattern. These closures are appended to any channels that are already closed.
- **EXCLOSE:** Closes the channels in the selected pattern so that the channels associated with the pattern are exclusively closed. Any previously closed channels are opened.
- **EXSLOTCLOSE:** Exclusively closes the channels in the specified channel pattern for the selected slots.
- **VIEW:** Displays the channels that are in the selected pattern.
- **DELETE:** Deletes the channel pattern.
- **RESET:** Displays options that allow you to reset the channels in the selected channel pattern to factory default settings. Resetting a channel pattern causes that pattern to be deleted because when channels are reset, they delete patterns that contain them.

For information about working with channel patterns, see [Channel patterns](#) (on page 2-96).

SCAN ACTION menu options

Allows you to work with the scan lists from the front panel. You must have a scan list created before using this option. See [Basic scan procedure](#) (on page 3-4) for information.

To open this menu, press **SCAN**.

Options include:

- **BACKGROUND:** Runs the scan while allowing front panel operation.
- **CREATE:** Reminder that you must use the INSERT key to create a scan list.
- **LIST:** Displays the scan list. Use the navigation wheel  to scroll through the channels.
- **CLEAR:** Clears the scan list.
- **RESET:** Resets the scan settings to the factory default settings, which includes clearing the scan list.

DMM ACTION menu options

Press the DMM key to open the DMM ACTION menu.

The DMM ACTION menu contains the following items:

- **MEASURE:** Takes measurements on the digital multimeter (DMM) without using the trigger model. Related command: [dmm.measure\(\)](#) (on page 8-216).
- **COUNT:** Indicates the number of measurements to take when a measurement is requested. Related command: [dmm.measurecount](#) (on page 8-217).
- **LOAD:** Recalls a user or factory DMM configuration. Use the navigation wheel to scroll through available configurations. Related command: [dmm.configure.recall\(\)](#) (on page 8-176).

- **SAVE:** Creates a DMM configuration with the pertinent attributes based on the selected function, and associates it with the specified name. Related command: [dmm.configure.set\(\)](#) (on page 8-178).
- **OPEN:** Opens the specified channel and/or channel pattern. Related command: [dmm.open\(\)](#) (on page 8-222).
- **CLOSE:** Closes the specified channel or channel pattern in preparation for a DMM measurement. Related command: [dmm.close\(\)](#) (on page 8-170).
- **RESETFUNC:** Returns the DMM aspects of the system for only the active function to factory default settings. Related command: [dmm.reset\(\)](#) (on page 8-230).
- **RESETALL:** Returns all DMM functions of the instrument to the factory default settings. Related command: [dmm.reset\(\)](#) (on page 8-230).

Configuration menu options

CHAN key configuration

The CHAN key configuration menus will display different submenus depending on the type of channel you are using (SWITCH, DIGIO, TOTALIZER, or DAC). The following topics describe the CHAN key configuration menus by channel type.

CONFIG CHAN key - SWITCH channel type

Press the **CONFIG** key and then the **CHAN** key to open the CHANNEL ATTR menu. If you press the CHAN key when a pattern is selected, the instrument goes into channel selection mode.

When changing attribute settings for a range of channels, the menu option for the first channel specified in the range is highlighted. For example, selecting channels 3 to 5 on slot 3 on the front panel (3003:3005) as a range shows the current attribute setting for 3003 when an attribute menu is displayed.

When the attribute setting is selected for a range, the entire range of channels is updated to that value. To view or set an individual attribute setting for only one channel, be sure to select a single channel range. For example, 3003:3003 would only affect channel 3 on slot 3, which is displayed as 3003 with the channel state and poles setting below it.

The CHAN ATTR menu contains:

LABEL: Sets the label associated with the specified channel. From the front panel, the label can be up to 12 characters. Remotely, the label may be up to 19 characters. This option will not be displayed if multiple channels are selected. Related command: [channel.setlabel\(\)](#).

BACKPLANE: Opens the BACKPLANE menu. Use this menu to add or remove backplane channels from the specified channels. Related command: [channel.setbackplane\(\)](#).

FORBID: Allows or prevents the closing of the specified channels. Related commands: [channel.setforbidden\(\)](#) and [channel.clearforbidden\(\)](#).

POLE: Sets the number of poles for the specified channels. Related command: [channel.setpole\(\)](#).

DELAY: Sets additional delay time for the specified channels. Related command: [channel.setdelay\(\)](#).

COUNT: Displays closure cycles for the specified channel. This option is not displayed if multiple channels are selected. Related command: [channel.getcount\(\)](#).

DMM-CONFIG: Sets the DMM configuration associated with the specified channels. Related command: [dmm.setconfig\(\)](#).

CONFIG CHAN key - DIGIO channel type

Press the **CONFIG CHAN** key to open the DIGIO ATTR menu. The DIGIO ATTR menu is not available when a range of channels is selected. If a range is selected, pressing CONFIG CHAN displays the following:

- DIGIO ATTR MENU
- <No Edit by Range, Use EXIT>

Therefore, to see the following options, select a single DIGIO channel.

LABEL: Enter up to 12 characters for the label for a channel. Related command: [channel.setlabel\(\)](#) (on page 8-94).

DELAY: Enter the value for the delay in 1ms steps from 0 to 60 seconds for a channel. Related command: [channel.setdelay\(\)](#) (on page 8-93).

MODE: Sets the mode attribute on a channel. Select INPUT, OUTPUT, or OUTPUT_PROTECTED. Related command: [channel.setmode\(\)](#) (on page 8-98).

MATCH: Sets the match value on a channel. Enter the value as 8-bit binary. Related command: [channel.setmatch\(\)](#) (on page 8-96).

MATCH-TYPE: Sets the match type on a channel. Select EXACT, ANY, NOT_EXACT, or NONE. Related command: [channel.setmatchtype\(\)](#) (on page 8-97).

STATE: Queries for the state of a channel and displays the value in the top line, labeled by STATE=. Related command: [channel.getstate\(\)](#) (on page 8-76).

CONFIG CHAN key - TOTALIZER channel type

Press the **CONFIG CHAN** key to open the TOTAL ATTR menu. The TOTAL ATTR menu is not available when a range of channels is selected. If a range is selected, pressing CONFIG CHAN displays the following:

- TOTAL ATTR MENU
- <No Edit by Range, Use EXIT>

Therefore, to see the following options, select a single totalizer channel.

LABEL: Enter up to 12 characters for the label for a channel. Related command: [channel.setlabel\(\)](#) (on page 8-94).

MODE: Sets the mode attribute on a channel. Select one of the following options:

- **EDGE.** Indicates the edge for the Totalizer channel to increment its count. Select from one of the following options:
 - FALLING
 - RISING
- **THRESHOLD.** Indicates the threshold range. Select from one of the following options:
 - TTL
 - NON_TTL
- **RESET.** Indicates if the count value gets reset after being read. Select from one of the following options:
 - ON
 - OFF

Related command: [channel.setmode\(\)](#) (on page 8-98).

MATCH: Sets the match value on a channel. Enter a value between 0 and 65535. Related command: [channel.setmatch\(\)](#) (on page 8-96).

- **MATCH TYPE:** Sets the match type on a channel. Select EXACT, ANY, NOT_EXACT, or NONE. Related command: [channel.setmatchtype\(\)](#) (on page 8-97).
- **STATE:** Queries for the state of a channel and displays the value in the top line, labeled by STATE=. Related command: [channel.getstate\(\)](#) (on page 8-76).
- **POWER:** Sets the power state attribute on a channel. Select ENABLE or DISABLE. Related command: [channel.setpowerstate\(\)](#) (on page 8-103)

CONFIG CHAN key - DAC channel type

Press the **CONFIG CHAN** key to open the DAC ATTR menu. The DAC ATTR menu is not available when a range of channels is selected. If a range is selected, pressing CONFIG CHAN displays the following:

- DAC ATTR MENU
- <No Edit by Range, Use EXIT>

Therefore, to see the following options, select a single DAC channel.

NOTE

If the DAC channel has power set to DISABLE, the menu choices change to only show the option to change the power setting, until the power is set to ENABLE.

LABEL: Enter up to 12 characters for the label for a channel. Related command: [channel.setlabel\(\)](#) (on page 8-94).

DELAY: Enter the value for the delay in 1 ms steps from 0 to 60 seconds for a channel. Related command: [channel.setdelay\(\)](#) (on page 8-93).

MODE: Sets the mode attribute on a channel. Select one of the following options:

- **FUNCTION.** Sets the desired function for a channel. Select one of the following options:
 - VOLTAGE
 - CURRENT_1
 - CURRENT_2
- **PROTECT.** Indicates if the protection mode for a channel is enabled. Select one of the following options:
 - AUTO
 - OFF

Related command: [channel.setmode\(\)](#) (on page 8-98).

- **OUTPUT:** Sets the output enable attribute on a channel. Select ENABLE or DISABLE. Related command: [channel.setoutputenable\(\)](#) (on page 8-100).
- **STATE:** Queries for the state of a channel and displays the value in the top line, labeled by STATE=. Related command: [channel.getstate\(\)](#) (on page 8-76).
- **POWER:** Sets the power state attribute on a channel. Select ENABLE or DISABLE. Related command: [channel.setpowerstate\(\)](#) (on page 8-103).

PATT key configuration

Press the **CONFIG** key and then the **PATT** key to open the PATTERN ATTR menu.

The PATTERN ATTR menu contains the following item:

- **DMM_CONFIG:** Sets the DMM configuration associated with the specified channel pattern. Use the navigation wheel to scroll through the available DMM configurations. Related command: [dmm.setconfig\(\)](#) (on page 8-239).

SCAN key configuration

Press the **CONFIG** key and then the **SCAN** key to open the SCAN ATTR menu.

The SCAN ATTR menu contains the following items:

- **ADD:** Instructs how to add an additional list of channels and/or channel patterns to scan. When you select **ADD** from the SCAN ATTR menu, "Use <INSERT> key" is displayed for a few seconds before going back to the SCAN ATTR menu options. To add items to an existing scan list, press **INSERT**.

NOTE

Press the **INSERT** key when you are not in the SCAN ATTR menu on the MAIN display.

- **BYPASS:** Enables or disables bypassing the first item in the scan. Related command: [scan.bypass](#) (on page 8-323).

- **MODE:** Sets the `scan.mode` value to one of the following:
 - OPEN_ALL, which is equivalent to `scan.MODE_OPEN_ALL` or 0 (default setting)
 - OPEN_SELECT, which is equivalent to `scan.MODE_OPEN_SELECTIVE` or 1
 - FIXED_ABR, which is equivalent to `scan.MODE_FIXED_ABR` or 2Related command: [scan.mode\(\)](#) (see "[scan.mode](#)" on page 8-330)
- **MEAS_CNT:** Sets the measure count value. Related command: [scan.measurecount](#) (on page 8-329)
- **SCAN_CNT:** Sets the scan count value. Related command: [scan.scancount](#) (on page 8-334)

DMM key configuration

Press the **CONFIG** key and then the **DMM** key to open a DMM attribute menu for the active function. For example, if the DCV function is active, pressing the **CONFIG** key and then the **DMM** key opens the DC VOLT ATTR menu.

Each function only has access to the applicable attributes for that function. Brief definitions of the available attributes are contained in the following paragraphs. Refer to the appropriate command for additional attribute information in the [Command reference](#) (see "[Commands](#)" on page 8-10).

The DMM ATTR menu contains:

APERTURE: Configures the aperture setting for the active DMM function in seconds. Related command: [dmm.aperture](#) (on page 8-153).

AUTODELAY: Configures the auto delay setting for the active DMM function. Related command: [dmm.autodelay](#) (on page 8-157).

AUTORANGE: Configures the auto range setting for the DMM. Related command: [dmm.autorange](#) (on page 8-158).

AUTOZERO: Configures the autozero setting for the DMM, which periodically measures internal voltages to help maintain the stability and accuracy of the instrument over time and changes in temperature. Related command: [dmm.autozero](#) (on page 8-160). Also see [Autozero](#) (on page 4-3).

DBREF: Configures the DB reference setting for the DMM in volts. Related command: [dmm.dbreference](#) (on page 8-181).

DETECTBW: Configures the detector bandwidth setting for the selected DMM function. For more information, see [Bandwidth](#) (on page 4-54). Related command: [dmm.detectorbandwidth](#) (on page 8-182).

DIGITS: Configures the display digits setting for the selected DMM function. For more information, see [Digits programming](#) (see "[Change the display resolution](#)" on page 4-6). Related command: [dmm.displaydigits](#) (on page 8-183).

DRY CIRCUIT: Configures the dry circuit setting for the selected DMM function. Related command: [dmm.drycircuit](#) (on page 8-184).

FILTER: Opens the FILTER menu for the selected DMM function. See [FILTER key configuration](#) (on page 2-24).

FUNC: Displays a menu that allows you to scroll through the available DMM functions. Use the navigation wheel or **CURSOR** keys to scroll the menu options and press **ENTER** when the desired function is highlighted. Related command: [dmm.func](#) (on page 8-190).

INPUTDIV: Enables or disables the 10M Ω input divider. Related command: [dmm.inputdivider](#) (on page 8-193).

LIMIT: Opens the LIMIT menu for the selected DMM function. See [LIMIT key configuration](#) (on page 2-23).

LINESYNC: Enables or disables line sync during measurements. Related command: [dmm.linesync](#) (on page 8-206).

MATH: Selecting the **MATH** menu item opens the MATH MENU. Items contained in this menu are:

- **ENABLE:** Enables or disables math operation on measurements. Related command: [dmm.math.enable](#) (on page 8-209).
- **FORMAT:** Specifies the math operation to perform on measurements. Related command: [dmm.math.format](#) (on page 8-211).
- **BFACTOR:** Specifies the offset for the $y = mX + b$ operation. Related command: [dmm.math.mxb.bfactor](#) (on page 8-212).
- **MFACTOR:** Specifies the scale factor for the $y = mX + b$ operation. Related command: [dmm.math.mxb.mfactor](#) (on page 8-213).
- **MXBUNITS:** Specifies the unit character for the $y = mX + b$ operation. Related command: [dmm.math.mxb.units](#) (on page 8-214).
- **PERCENT:** Specifies the constant to use for the percent operation. Related command: [dmm.math.percent](#) (on page 8-215).

For more information, see:

- [mX+b](#) (on page 4-44)
- [Reciprocal \(1/X\)](#) (on page 4-47)
- [Percent](#) (on page 4-46)

NPLC: Configures the integration rate in line cycles for the DMM. Related command: [dmm.nplc](#) (on page 8-220).

OFFSETCOMP: Configures the offset compensation setting for the DMM. Related command: [dmm.offsetcompensation](#) (on page 8-221).

OPENDETECT: Configures the state of the thermocouple or 4-wire ohms open detector that is being used. Related command: [dmm.opendetector](#) (on page 8-224).

RANGE: Configures the range of DMM for the selected function for one channel type. For more information, see [Range](#) (on page 4-49). Related command: [dmm.range](#) (on page 8-225).

REL: Opens the relative offset menu for the selected DMM function. See [REL key configuration](#) (on page 2-24).

THERMO: Selecting the **THERMO** menu item opens the THERMO menu. Items contained in this menu are:

- **REFJUNCT:** Allows selection of the reference junction to use. Available choices are: SIMULATED, EXTERNAL, or INTERNAL. Related command: [dmm.refjunction](#) (on page 8-226).
- **SIMREF:** Specifies the simulated reference temperature for thermocouples. Related command: [dmm.simreftemperature](#) (on page 8-241).
- **TRANSDUCER:** Selects the transducer type (THERMOCOUPLE, THERMISTOR, 3RTD, or 4RTD). Related command: [dmm.transducer](#) (on page 8-246).
- **THERMISTOR:** Specifies the type of thermistor. Related command: [dmm.thermistor](#) (on page 8-242).
- **THERMOCOUPLE:** Specifies the thermocouple type. Related command: [dmm.thermocouple](#) (on page 8-243).
- **THREERTD:** Specifies the type of 3-wire RTD. Related command: [dmm.threertd](#) (on page 8-244).
- **FOURRTD:** Specifies the type of 4-wire RTD. Related command: [dmm.fourrtd](#) (on page 8-189).
- **USER:** Specifies USER type of RTD (ALPHA, BETA, DELTA, or ZERO). Related commands: [dmm.rtdalpha](#) (on page 8-231), [dmm.rtdbeta](#) (on page 8-233), [dmm.rtddelta](#) (on page 8-235), [dmm.rtdzero](#) (on page 8-236).

THRESHOLD: Configures the threshold range. Related command: [dmm.threshold](#) (on page 8-245).

UNITS: Configures the units for voltage and temperature measurements. Related command: [dmm.units](#) (on page 8-247).

LIMIT key configuration

Pressing the **CONFIG** key and then the **LIMIT** key opens the LIMIT menu. Select LIMIT 1 or LIMIT 2 to open the desired LIMIT 1 or LIMIT 2 menu.

These menus contain the following items:

- **ENABLE:** Enables or disables limit testing. Related command: [dmm.limit\[Y\].enable](#) (on page 8-196).
- **CLEAR:** Clears the test results of the limit. Related command: [dmm.limit\[Y\].clear\(\)](#) (on page 8-195).
- **AUTOCLEAR:** Indicates if the limit should be cleared automatically or not. Related command: [dmm.limit\[Y\].autoclear](#) (on page 8-194).
- **LOWVAL:** Sets the low limit value. Related command: [dmm.limit\[Y\].low.value](#) (on page 8-204).
- **LOWFAIL:** Queries for the low test results of the limit. Related command: [dmm.limit\[Y\].low.fail](#) (on page 8-202).
- **HIGHVAL:** Sets the high limit value. Related command: [dmm.limit\[Y\].high.value](#) (on page 8-200).
- **HIGHFAIL:** Queries for the high test results of limit. Related command: [dmm.limit\[Y\].high.fail](#) (on page 8-198).

REL key configuration

Press the **CONFIG** key and then the **REL** key to open the RELATIVE OFFSET menu.

The RELATIVE OFFSET menu contains the following menu items:

- **ACQUIRE:** Acquires an internal measurement to store as the REL level value. Related command: [dmm.rel.acquire\(\)](#) (on page 8-227).
- **ENABLE:** Enables or disables relative measurement control for the DMM. Related command: [dmm.rel.enable](#) (on page 8-228).
- **LEVEL:** Sets a specific offset value to use for relative measurements for the DMM. Related command: [dmm.rel.level](#) (on page 8-229).

FILTER key configuration

Press the **CONFIG** key and then the **FILTER** key to open the FILTER menu.

The FILTER menu contains the following menu items:

- **ENABLE:** Enables or disables filtered measurements for the selected DMM function. Related command: [dmm.filter.enable](#) (on page 8-186).
- **COUNT:** Indicates the filter count setting for the selected DMM function. Related command: [dmm.filter.count](#) (on page 8-185).
- **TYPE:** Indicates the filter averaging type for the DMM measurements on the selected DMM functions (MOVING or REPEAT). Related command: [dmm.filter.type](#) (on page 8-187).
- **WINDOW:** Indicates the filter window for the DMM measurements (0 to 10% in 0.1% increments). Related command: [dmm.filter.window](#) (on page 8-188).

FUNC key configuration

Press the **CONFIG** key and then the **FUNC** key to display a menu that allows you to scroll through the available DMM functions. Turn the navigation wheel or press the **CURSOR** keys to scroll through available functions. Press the navigation wheel or the **ENTER** key to make the displayed function active when it is highlighted and blinking. While in the configuration mode of the **FUNC** key, the function takes effect for the highlighted function only when the **ENTER** key is pressed (the function does not change while scrolling).

STORE key configuration

With a buffer selected, press the **CONFIG** key and then the **STORE** key to open the RD BUFFER ATTR menu.

This menu contains the following menu items:

- **CAPACITY:** Displays the maximum number of readings that can be stored.
- **COUNT:** Displays the actual number of readings that have been stored.
- **APPEND:** Indicates the append mode setting of the reading buffer. For buffers created on the front panel or web, this defaults to ON or enabled. For buffers created over the bus, the default is OFF or disabled.

Using the front panel with non-switch channels

To read a value from the main front panel screen, select the channel and press the **TRIG** key. To see a digital I/O channel in hexadecimal format (instead of normal binary), press the **CONFIG** key, and then press the **TRIG** key.

A star symbol (*) or exclamation point symbol (!) may appear after the reading. The meaning of the symbol depends on channel type.

- A star symbol (*) appears after the reading to indicate that the reading matches the MATCH setting for digital I/O and totalizer channels.
- An exclamation point symbol (!) appears after the reading to indicate an overload state condition on that channel for digital I/O and DAC channels.
- An exclamation point symbol (!) appears after the reading to indicate an overflow state condition on a totalizer channel.
- If the power state is OFF for totalizer or DAC channels, the display shows “DISABLED” instead of any readings.

The following table lists the front panel channel attributes that indicate the various channel mode settings (remote command equivalent [channel.setmode\(\)](#) (on page 8-98)), channel output enable (remote command equivalent [channel.setoutputenable\(\)](#) (on page 8-100)), and channel label (remote command equivalent [channel.setlabel\(\)](#) (on page 8-94)). Some of the attributes have alternate symbols, depending on the operation you are performing on the front panel and whether it is being used with the 6 or 12 character label symbol.

- For digital I/O and totalizer channels, the label symbol is listed first, followed by a comma and then mode symbols. If the label is the factory default setting, then only the mode is listed.
- For DAC channels, the label symbol is listed first, followed by a comma, and then mode symbols, followed by another comma and the output enable symbol. If the label is the factory default setting, then only the mode and output enable symbols are listed.

Front-panel channel attributes for channel settings

Front-panel channel setting	Symbol	Definition	Symbol meaning
Channel label	XXXXXX	First 6 characters of label	Used with single letter symbols
	XXXXXXXXXXXX	First 12 characters of label	Used with the non-single letter symbols
Digital I/O mode settings	DIG IN	Digital input mode	Used with 12-character label or no label
	DIG OUT	Digital output mode	Used with 12-character label or no label
	DIG pOUT	Digital output protected mode	Used with 12 character label or no label
	I (uppercase "i")	Digital input mode	Used with 6-character label
	O	Digital output mode	Used with 6-character label
	P	Digital output protected mode	Used with 6-character label


Front-panel channel attributes for channel settings

Front-panel channel setting	Symbol	Definition	Symbol meaning
Totalizer mode settings	Rise Ed	Totalizer rising edge mode	Used with 12-character label or no label
	Fall Ed	Totalizer falling edge mode	Used with 12-character label or no label
	Rise-TTL	Totalizer rising edge TTL level mode	Used with 12-character label or no label
	Fall-TTL	Totalizer falling edge TTL level mode	Used with 12-character label or no label
	Rise-RST	Totalizer rising edge read reset mode	Used with 12-character label or no label
	Fall-RST	Totalizer falling edge read reset mode	Used with 12-character label or no label
	RiseTRST	Totalizer rising edge TTL read reset mode	Used with 12-character label or no label
	FallTRST	Totalizer falling edge TTL read reset mode	Used with 12-character label or no label
	R	Totalizer rising edge mode	Used with 6-character label
	F	Totalizer falling edge mode	Used with 6-character label
DAC mode settings	V	Voltage function mode	Used with 6-character label
	I (uppercase "i")	Current function either 1 or 2 mode	Used with 6-character label
	V1	Voltage function 1 mode	Used with 12-character label or no label
	I1	Current function 1 mode	Used with 12-character label or no label
	I2	Current function 2 mode	Used with 12-character label or no label
	pV1	Protected voltage function 1 mode	Used with 12-character label or no label
	pI1	Protected current function 1 mode	Used with 12-character label or no label
	pI2	Protected current function 2 mode	Used with 12-character label or no label
DAC output enable settings	Off	Output enable is disabled	Used with 6 or 12 character label
	On	Output enable is enabled	Used with 6 or 12 character label

Rear panel summary

The following is a brief overview of the Series 3700A System Switch/Multimeter rear panel.

Figure 2-7: Rear panel features



Item	Description
1	Analog backplane AMPS fuse (on page 2-27)
2	Slots (on page 2-27) (6 slots)
3	TSP-Link connector (on page 2-28) (2 connectors)
4	Instrument fuse (on page 2-28)
5	Power connector (on page 2-28)
6	Digital I/O port (on page 2-29, on page 3-42)
7	GPIB connector
8	Ethernet connector
9	USB connector
10	Analog backplane connector (on page 2-33)

Rear panel connections

The following topics describe how to connect the cable connections for the communication interfaces.

To properly set up the communications interfaces after connection, see the information in Communications interfaces.

Analog backplane AMPS fuse

WARNING

For continued protection against fire hazard, replace fuse with same type and rating (3 A / 250 V). See [Fuse replacement](#) (on page A-2, on page 2-2) for details.

Slots

Use any of the six slots of the Keithley Instruments Series 3700A for switching cards. If a slot does not contain a card, make sure that you cover the slot with a slot cover.

To get information about an installed card, press the **SLOT** key.

NOTE


For complete information about Series 3700A switching cards, refer to the Series 3700A Switch and Control Cards Reference Manual (Keithley part number 3700AS-909-01) on the Product Information CD-ROM that came with your Series 3700A.

TSP-Link connector

Connect the TSP-Link connector to one of the TSP-Link connectors on the rear panel of the instrument.

The location of the TSP-Link connectors on the instrument are shown below.

Figure 2-8: Series 3700A TSP-Link connections



Instrument fuse

FOR CONTINUED PROTECTION AGAINST FIRE HAZARD, REPLACE FUSE WITH SAME TYPE AND RATING (1.25A / 250V). See [Fuse replacement](#) (on page A-2, on page 2-2) for details.


Power connector

Using the supplied line cord, connect to a grounded AC power outlet. See Line power connection for connection details.

Digital I/O port

The Series 3700A instruments have a digital input/output port that can be used to control external digital circuitry. For example, a handler that is used to perform binning operations can be used with a digital I/O port. The digital I/O port is a standard female DB-25 connector.

Figure 2-9: Digital I/O port




Pin	Description
1	Digital I/O #1
...	...
9	Digital I/O #9
10	Digital I/O #10 (high-current pins; see NOTE)
...	...
14	Digital I/O #14
15 to 21	Ground
22	V EXT
23	V EXT
24	Pin reserved for future use
25	V EXT

NOTE


For a schematic diagram of the digital I/O hardware, refer to the Series 3700A Specifications on the [Keithley Instruments support website](http://www.keithley.com/support) (<http://www.keithley.com/support>). High-current pins (pins 10 to 14) can be used for binning applications or for external relays.

GPIB connector

To connect a Series 3700A to the GPIB bus, use a cable equipped with standard IEEE-488 connectors, as shown below.

Figure 2-10: IEEE-488 connector


To allow many parallel connections to one instrument, stack the connectors. Two screws are located on each connector to ensure that connections remain secure. The figure below shows a typical connection scheme for a multi-unit test system.

Figure 2-11: Series 3700A multiple parallel connections**CAUTION**

To avoid possible mechanical damage, stack no more than three connectors on any one unit. To minimize interference caused by electromagnetic radiation, use only shielded IEEE-488 cables. Contact Keithley Instruments for shielded cables.

To connect the Series 3700A to the IEEE-488 bus, line up the cable connector with the connector located on the rear panel. Install and tighten the screws securely, making sure not to overtighten them (the following figure shows the location of the connections).

Figure 2-12: Series 3700A GPIB connector




Connect any additional connectors from other instruments as required for your application. Make sure the other end of the cable is properly connected to the controller. You can only have 15 devices connected to an IEEE-488 bus, including the controller. The maximum cable length is either 20 meters or two meters multiplied by the number of devices, whichever is less. Not observing these limits may cause erratic bus operation.

Ethernet connection

Connect the ethernet connector between the rear panel of the instrument and the host computer or network router. You can use an LAN crossover cable (RJ-45, male/male) or straight-through cable. The instrument automatically senses which cable you have connected.

NOTE


The TSP-Link[®] connectors will accept a LAN connection, but will not be identified as a LAN and will not connect properly. Be sure to connect the LAN connector correctly.



Use this RJ-45 connector to connect the instrument to the local area network. When connecting directly to a computer, a crossover cable (included) must be used. When connecting to a network switch, router, or hub, a normal CAT-5 cable (not provided) should be used unless your equipment has Auto-MDIX capabilities. If it does have Auto-MDIX, the crossover cables may be used.

The figure below shows the location of the ethernet connector on the Series 3700A rear panel.


Figure 2-13: Series 3700A ethernet connection



LAN status LEDs

The figure below illustrates the two status light emitting diodes (LED) located at the top of the instrument's LAN connection port. The table below the figure provides explanations the LAN status LED states.

Figure 2-14: LAN Status



- (1) LED indicates port is connected to a 100 Mbps network
- (2) LED indicates port is connected to a 10 Mbps network


When the LED is:	The network:
Off	is NOT connected
On	is connected
Blinking	has traffic traversing the port

USB connectors

The downstream USB-2.0 receptacle (Type B) located on the rear panel connects to a host. The front panel has an upstream USB-2.0 connector (Type A) that connects to a user supplied USB flash drive.

Use the rear connector to communicate with the instrument over USB by sending the desired commands. Use the front panel connector to insert a USB flash drive for saving or loading reading buffers, user setups, or scripts. See the Reference Manual for more information on reading buffers, user setups and scripts.

Figure 2-15: USB connectors




Pin number	Function
1	VBUS (5 volts)
2	D-
3	D+
4	Ground

Analog backplane connector

Refer to the following figure for analog backplane connector information. See [Connections](#) (see "[Connection safety](#)" on page 2-33) before making any connections.

Figure 2-16: Analog backplane connector



Analog backplane connector

The tables below contain pin numbers and descriptions for the analog backplane connector.

Description	Pin
Analog backplane 3-HI	5
Analog backplane 3-LO	6
Analog backplane 4-HI	7
Analog backplane 4-LO	8
Analog backplane 5-HI	12
Analog backplane 5-LO	13
Analog backplane 6-HI	14
Analog backplane 6-LO	15

Description	Pin
DMM-SLO	4
DMM-SHI	3
DMM-LO	2, 9
DMM-HI	1
AMP-LO	2, 9
AMP	10, 11

Connection safety

WARNING

Connection information for switching cards is intended for qualified service personnel. Do not attempt to connect DUT or external circuitry to a switching card unless qualified to do so.

To prevent electric shock that could result in serious injury or death, comply with these safety precautions:

Before making or breaking any connections to the switching card, make sure the instrument is turned off and power is removed from all external circuitry.

Do not connect signals that will exceed the maximum specifications of any installed switching card.

If both the rear analog backplane connector of the instrument and the switching card terminals are connected at the same time, the test lead insulation must be rated to the highest voltage that is connected. For example, if 300V is connected to the analog backplane connector, the test lead insulation for the switching card must also be rated for 300V.

Dangerous arcs of an explosive nature in a high energy circuit can cause severe personal injury or death. If the multimeter is connected to a high energy circuit when set to a current range, low resistance range, or any other low impedance range, the circuit is virtually shorted.

Dangerous arcing can result (even when the multimeter is set to a voltage range) if the minimum voltage spacing is reduced in the external connections. For details about how to safely make high energy measurements, see [High-energy circuit safety precautions](#) (on page 4-2).

As described in the International Electrotechnical Commission (IEC) Standard IEC 664, the instrument is Installation Category I and must not be connected to mains.

User setup

The Series 3700A can be restored to one of six nonvolatile memory setup configurations (five user setups and one factory default), or to a setup stored on an external USB flash drive. As shipped from the factory, the Series 3700A powers-up to the original default settings. The default settings are also contained in the five user setup locations but may be overwritten. The original default settings are listed in the Instrument Command Library found in [Remote commands](#) (on page 6-1). The instrument will always start-up loading the power-on setup.

Saving user setups

You can save the present Series 3700A setup to internal nonvolatile memory or a USB flash drive.

To save a user setup to nonvolatile memory:

1. Configure the Series 3700A for the desired operating modes to be saved.
2. Press the **MENU** key, select **SETUP**, and then press the **ENTER** key.
3. Select the **SAVE** menu item, and then press the **ENTER** key.
4. Select **INTERNAL**, then press the **ENTER** key.

To save a user setup to an external USB flash drive:

1. Configure the Series 3700A for the desired operating modes to be saved.
2. Insert the USB flash drive into the USB port on the front panel of the Series 3700A.
3. Press the **MENU** key, then select **SETUP**, then press the **ENTER** key.
4. Select **SAVE** menu item, then press the **ENTER** key.
5. Select **USB**. The file `setup000.set` is displayed.
6. Turn the navigation wheel  to change the last three digits of the file name and then press the **ENTER** key.

Recalling a saved setup

You can recall setups from internal nonvolatile memory or a USB flash drive at any time. To recall a saved setup:

1. Press the **MENU** key to access the main menu.
2. Select **SETUP**, and then press the **ENTER** key.
3. Select the **RECALL** menu item, and then press the **ENTER** key.

4. Select one of the following:
 - INTERNAL
 - USB
5. USB only: Select the appropriate file and then press the **ENTER** key.

Start-up configuration

You can specify the Series 3700A start-up (power-on) configuration from the front panel. Set the start-up configuration to a previously stored setup (recalled from internal nonvolatile memory).

To select the power-on setup:

1. Press the **MENU** key to access the main menu.
2. Select **SETUP**, and then press the **ENTER** key.
3. Select **POWERON**, and then press the **ENTER** key.
4. Select the configuration you want to use on startup.
5. Press the **ENTER** key.
6. Press the **EXIT (LOCAL)** key to return to the main menu.

Saving user setups from a command interface

Saving and recalling user setups

Use the `setup.save()` and `setup.recall()` functions to save and recall user setups. The following programming example illustrates how to save the present setup as setup 1, and then recall setup 1:

```
-- Save present setup to nonvolatile memory.
setup.save(1)
-- Recall saved user setup from nonvolatile memory.
setup.recall(1)
```

Restoring the factory default setups

Use one of the reset functions to return the Series 3700A to the original factory defaults:

Restore all factory defaults of all nodes on the TSP-Link network:

```
reset()
```

Restore all factory defaults (note that you cannot use `*rst` in a script):

```
*rst
```

Restore all factory defaults:

```
setup.recall(0)
```

Restore all channels on all slots to defaults:

```
channel.reset("allslots")
```

Reset just the local node:

```
localnode.reset()
```

Start-up (power-on) configuration

You can specify the Series 3700A start-up (power-on) configuration. Use the `setup.poweron` attribute to select which setup to return to upon power-up. To set the `setup.poweron` configuration attribute:

```
setup.poweron = n      -- Select power-on setup.
```

Where:

```
n = 0 (*RST/reset() factory defaults)
n = 1
```

Using the web interface

Introduction

The Series 3700A web interface can be used with your choice of web browsers, including Microsoft® Internet Explorer®, Mozilla® Firefox®, Google Chrome™, and Apple® Safari®. Using the web interface, you can review instrument status, control the instrument, and upgrade the instrument over a LAN connection.

The instrument web page resides in the firmware of the instrument. Changes you make through the web interface are immediately made in the instrument.

All examples in this manual can be run through the [TSB Embedded](#) (on page 2-48) web application that is available on the instrument web interface.

Connect to the instrument web interface

To connect to the instrument web interface, you must have an LAN connection from the computer to the instrument. See [LAN concepts and settings](#) (on page B-1) for specific connection instructions.

The web interface requires the web browser plug-in Sun Java™ Runtime Environment Version 6 or higher. Installation files are available from <http://www.java.com/en/download/manual.jsp> (<http://www.java.com/en/download/manual.jsp>).

The ActiveX control and Java applets are installed from the instrument but, depending on the browser security settings, they may require the users permission to be downloaded and installed.

After the instrument is connected and Java is installed, to connect to the instrument:

1. Open an internet browser, such as Windows Internet Explorer (v6.0 or higher only).
2. In the Address box, enter the IP address of the instrument (to find the IP address, from the front panel of the instrument, select **MENU > LAN > STATUS > IP-ADDRESS**).

The Home page of the instrument web interface is displayed.

Web interface home page

The home page of the web interface gives you basic information about the instrument, including:

- The instrument model, serial number, firmware revision, and LXI information
- A list of slots and the switch cards that are installed in each slot
- An **ID** button to help you locate the instrument
- Links to the instrument web applications, including TSB Embedded.

Identify the instrument

If you have a bank of instruments, you can click **ID** to determine which one you are communicating with.

Before trying to identify the instrument, make sure you have a remote connection to the instrument.

To identify the instrument:



In the upper right corner of the Home page, click

The button turns green, and the LAN status indicator on the instrument blinks.

Figure 2-17: ID lit



Click again to return the button to its original color and return the LAN status indicator to steady on.

Log in to the instrument

The web interface has both interactive and read-only pages. These pages are always listed in the navigation panel on the left side of the web interface. You can review information on any of the pages without logging in, but to change information, you must log in.

Pages that contain information you can change include a **Login** button. Once you have logged in to one page of the web interface, you do not need to log in again unless you reload the page.

To log into the instrument:


1. Open a page that contains a **Login** button, such as one of the Cards pages, Scan Builder, or TSB Embedded.

Figure 2-18: Web interface login



2. Click **Login**. The login dialog box is displayed.
3. Enter the password (the default is **admin**).

Figure 2-19: 3700A Enter web interface password



4. Click **Login**.

NOTE

The default password is **admin**. If the password has been changed, it is available from the front panel of the instrument. Press **MENU > LAN > STATUS > PASSWORD**.

Card pages

The card pages are interactive pages where you can work with channels in each slot.

To open a card page, on the left navigation, click the slot number.

There is a specific page for each card installed in the mainframe. The page displays a grid that shows the relay configuration of the switch card.

Figure 2-20: Series 3700A web interface Cards page




Open and close slots from the card pages

You can open and close channels from the card pages in several ways.

The simplest method is to click a connection. The channel changes state to open or closed. When the channel is open, the connection will look similar to one of the following graphics (the actual item on the web interface depends on the installed card):



Figure 2-21: Series 3700A web interface relay open




When the channel is closed, the connection will look similar to one of the following:

Figure 2-22: Web interface closed channel



Figure 2-23: Web interface relay closed



To specify the type of close, select a Channel Action Type from the box in the upper right before closing a channel. The options are:

- **Channel Close:** Close the selected channel without affecting the state of any other channels.
- **Exclusive Slot Close:** Close the selected channel and open any closed channels in the same slot.
- **Exclusive Close:** Close the selected channel and open any closed channels in the instrument (the only closed channel is the selected channel).

You can open all channels in a slot by clicking **Open Slot**.


You can open all channels in the instrument by clicking **Open All**.

For more information on opening and closing channels, see "Working with channels" in the Series 3700A Reference Manual.

Configure channels from the web interface

To configure channels from the web interface, right-click the channel. The Channel Configuration dialog box is displayed.

Figure 2-24: Series 3700A channel configuration dialog box



In this dialog box, you can set:

- **Label:** The label for the channel. This is the same as the command `channel.setlabel()`.
- **Forbidden:** Select this box to set the channel to forbidden. This prevents the channel from being closed from any interface. Note that if the channel is used in a channel pattern, the pattern is deleted when you set the channel to forbidden to close. An analog backplane relay can be marked as forbidden to close.
- **Pole:** Pole setting for multiplexer (MUX) channels indicates if the paired MUX channel should be included when performing a close or open operation on channel. In a switching module that has 60 channels, the Series 3700A automatically pairs Channels 1 through 30 with Channels 31 through 60 (respectively) when the pole setting for a channel is set to 4-pole. Once you configure the pole setting of a switching channel for 4-pole, the associated paired channel becomes unavailable for switching operation. For example, if 3003 is set to 4-pole and its paired channel is 3033, you cannot set attributes or perform close or open operations on channel 3033. If you specify channel 3303 for a close or open operations, a "paired channel settings conflict" error is generated. Matrix channels have fixed pole settings. Multiplexer channels pole settings may be changed.

- **Delay Time:** The additional delay to incur after the relay settles when closing the channel. Enter the value for the delay in seconds. The total delay for channel close is this delay plus the relay settling time.
- **Backplane channels:** You can select the backplane relay with this option.
- **DMM Configuration:** Click Edit to set up configuration of the DMM for this channel.

This dialog box also displays the closure count. See [Determining the number of relay closures](#) (on page 2-92) for information.

Set up channel patterns from the web interface


You can use channel patterns as a convenient way to refer to a group of switching channels and backplane relays with a single alphanumeric name. When you perform close or open operations on a channel pattern, only the channels and analog backplane relays that are in the channel pattern are affected.

There is no speed difference when performing close and open operations on channel patterns compared to performing the same operations on individual channels or a list of channels.

To create a channel pattern from the web interface:

1. From the left navigation, click a slot.
2. Click **Pattern** (above the Channel Action Type box). The Channel Pattern Configuration dialog box is displayed.

Figure 2-25: Series 3700A Channel pattern configuration dialog box



3. Enter a name in the box at the top.
4. From the Channels Available list, select the channels you want to add. You can use Ctrl+click and Shift+click to select multiple channels.
5. Click **Add**. You can add as many channels as needed.
6. Click **Create**.

To create a channel pattern from the web interface using the Snapshot feature:

1. Close the channels that you want to include in the pattern.
2. Click **Pattern** (above the Channel Action Type box). The Channel Pattern Configuration dialog box is displayed.
3. Enter a name in the box at the top.
4. Click **Snapshot**. A new pattern is created that contains the closed channels.

To delete a channel pattern from the web interface:

1. Select the name of the pattern that you want to delete.
2. Click **Delete**.

For more information regarding patterns, including opening and closing the channels that are in patterns, see [Channel patterns](#) (on page 2-96).

Reset a slot from the web interface

You can reset all the relays in the displayed slot by clicking **Reset Slot**.

When you reset the relays in a slot:

- Any closed channels and analog backplane relays open
- The poles of all channels reset to 2-pole operation and paired channels are changed to match
- Labels return to default of slot, channel or slot, row, column
- Analog backplane relays specified by the `channel.setbackplane()` function are cleared
- Delays are set to zero
- If the channel is forbidden to close, it is cleared from being forbidden to close
- The DMM configurations of all channels are set to `nofunction`
- If any of the slot's channels are in channel patterns, the patterns are deleted

The rest of the instrument settings are unaffected.

Scan Builder page

The Scan Builder page allows you to set up and run scans and triggers.

A scan is a series of steps that opens and closes switches sequentially for a selected group of channels. During each step, actions occur, such as waiting for a trigger, taking a measurement on an external instrument, and completing a step count. Scans automate actions that you want to perform consistently and repeatedly on a set of channels.

Triggers are events that prompt the instrument to move from one step to another in a scan. Triggers can come from a variety of sources, such as a key press, digital input, or expiration of a timer. The sequence of actions and events that occur during the scan is called the trigger model, described in [Trigger model](#) (on page 3-1).

Scanning and triggering allow you to synchronize actions across channels. You can set up a scan using the trigger model to precisely time and synchronize the Series 3700A between channels and multiple instruments. You can also use triggers without the triggering model to set up a scan to meet the needs of a specific application that does not fit the triggering model.

NOTE

If you use Scan Builder to create a scan, use the options in the Scan Builder page to run the scan. Using the TSB Embedded page may not give you the expected results.

Create a scan list

Before you can run a scan, you must create a scan list. A scan list is a set of steps that runs in order during a scan. Each step contains a channel, channels, or channel patterns that you want to measure in that step. Each step is acted on separately during the scan.

You can mix channel patterns and individual channels in a scan list. Note that the steps are executed in the order in which they are added to the scan.

NOTE

Before setting up a scan list, make sure your channels and channel patterns are configured. See [Working with channels](#) (on page 2-89) for detail.

If you change the channel configurations or channel patterns after the scan list has been set up, you may not see expected results. If the change prevents the scan from functioning properly (such as deleting something referenced by the scan), an error message is logged.

To create a scan list from the web interface:

1. From the left navigation of the web interface Home page, select **Scan Builder**.
2. In the Add Channel By list on the right, select **Number** to add the channels individually or **Pattern** to select patterns. You can include both channels and patterns in the same scan list.
3. If you selected **Number**, select the channel numbers from the list. To remove your selections from the Add Channel By list, click **Clear Channel Selection**. You can use Ctrl+click to select multiple channels and Shift+click to select a range of channels.
4. If you selected **Pattern**, select a pattern from the Channel Pattern list.
5. Click **Add Step**. The channels and patterns are added to the Steps list.
6. In the **Scan Count** box, enter the number of times you want to repeat the steps in the scan.
7. In the **Measure Count** box, enter the number of times you want to repeat the measurement in the scan.
8. Under **Use DMM Configuration**, select "assigned to the channel(s)" to use the DMM configurations that are assigned to the channels, or select "selected from below to override" to choose from a list of DMM configurations. Repeat these steps as needed to build the scan steps. The scan is saved as you build it.

Clear the scan list from the web interface

Clearing the scan list deletes all channels and channel patterns from the scan list.

To clear the scan list from the web interface:

1. From the left navigation area of the web interface home page, select **Scan Builder**.
2. Click **Scan Clear**.

Review the scan list

You can review the existing scan list to see which channels and channel patterns are listed, and in which order.

To review the scan list from the web interface:

1. From the left navigation of the web interface Home page, select Scan Builder.
2. Select the **Build & Run** tab. The scan list is shown in the Steps box.

Reset the scan list

You can clear the scan list and return scan settings to their factory defaults using scan reset. A scan reset does not affect any settings in the instrument except the scan list and trigger model.

The settings that are affected are:

- Channels and patterns are removed from the scan list
- Bypass: Returned to default setting of ON
- Mode: Returned to default setting of Open All
- Scan count: Returned to default setting of 1
- Trigger to start scan: Set to Immediate
- Trigger to continue channel action for each scan step: Setting is cleared
- Arm (Scan Start Stimulus) is set to None
- Channel Action Stimulus is set to Channel Ready Event
- Channel Ready Event is set to None
- Scan Complete Even is set to None

To reset the scan list from the web interface:

1. From the left navigation of the web interface Home page, select Scan Builder.
2. Click **Scan & Trigger Reset**.

Run the scan

You can run a scan in one of several ways:

- **Background:** Runs the scan in the background so that you can perform other tasks while the scan is running. You can use the Query State to check scan status.
- **Step by Step:** Steps through the scan.

To run the scan as a background scan from the web interface:

Click **Execute Background** or **Step by Step**.

Stop the scan

To stop the scan from the web interface:

On the Build & Run tab, click **Abort**.

Monitor the state of the scan

To monitor the state of the scan, you can click **Query State** on the Build & Run tab. **Query State** displays the current state of the scan, which can be:

- Empty: No scan defined
- Building: Scan list is being created
- Running: Scan in process
- Success: Scan completed successfully

Set up simple triggers

You can set up triggers to control your scan using the options on the Simple Trigger tab. You can set:

- The event that starts the scan
- The time interval event that controls the channel action for each step of the scan
- The time interval event that controls how measurements are taken during the scan

To see these options, click the **Simple Trigger** tab from the top of the Scan Builder page.

Selecting triggers

You can choose the triggers that will be used to start the scan. The options to start the scan are:

Immediate: When Immediate is selected, the scan starts as soon as you click **Execute Background** on the Build & Run tab. Select Immediate when you do not have trigger requirements that must be met before the scan starts. This is the default selection.

Digital Input: When selected, you select the digital line (1 to 14) that is used to start a scan. You can select falling or rising for the digital input. Falling selects the falling edge trigger. Rising selects the rising edge of the trigger.

NOTE

If Other is displayed in the mode list, a different mode (other than falling or rising) is already selected. Other is not a mode and cannot be selected. It is only an indicator that the digital triggering is already set up for a different mode. See the Series 3700A Reference Manual, "Using the web interface" section, and the "Advanced triggering" topic for other options.

Time: When selected, you can select options that define when the scan starts and at what rate triggers will occur.

You can select the trigger to use to continue channel action for each scan. The options to continue channel action are:

Immediate: When immediate is selected, the scan immediately steps to the next channel in the scan list. This is the default setting.

Digital Input: When selected, you select a digital line (1 to 14) that is used to trigger the instrument to step to the next channel. You can select falling or rising for the digital input. Falling selects the falling edge trigger. Rising selects the rising edge of the trigger.

Every *N* seconds: This parameter adds a fixed delay between each channel. The delay occurs before the next channel in the scan list is closed.

You can also select the trigger to use to take a measurement for each scan step.

Immediate: When immediate is selected, the measurement is taken as soon as the channel is closed. This is the default setting.

Digital Input: When selected, you select a digital line (1 to 14) that triggers the instrument to take a measurement. You can select falling or rising for the digital input. Falling selects the falling edge trigger. Rising selects the rising edge of the trigger.

Every *N* seconds: This parameter adds a fixed delay after the channel is closed and before the measurement is taken.

Advanced triggering

The Advanced Trigger tab of the Scan Builder allows you to set the options that are available from the Simple Trigger tab, as well as more sophisticated options to control scan triggering.

The Advanced Trigger tab uses the trigger model flowchart to help you visualize and define the input and output triggers to the scan.

For more information on the trigger model, see [Trigger model](#) (on page 3-1).

The options on the Advanced Trigger tab include:

- **Mode:** Select Open All to open all slots before the scan starts. Select Open Selective to open only channels that are involved in scanning; closed channels that are not involved in scanning remain closed. Select Fixed ABR to open all channels involved in the scan, but close all required backplane relays before the scan.
- **Arm (Scan Start) Stimulus:** Select the event that causes the arm event detector trigger to be set to the detected state (the scan can begin).
- **Measure Stimulus:** Select the event that causes the measure event detector to be set to the detected state (the measurement can begin).
- **Measure Complete Event To:** Select the recipient of the Measure Complete Event.
- **Channel Ready Event To:** Select the recipient of the Channel Ready Event.
- **Scan Complete Event To:** Select the recipient of the Scan Complete Event.

There is also a **Config** button available for each of the options except Mode. When you click this button, a dialog box with additional options for the selection is displayed.

Set the scan mode

The scan mode determines how channels are opened before the start of the scan.

You can select:

- **Open all:** All slots are opened.
- **Open select:** All channels selected in the scan list are opened; any closed channels remain closed if they are not in the scan list.
- **Fixed ABR:** All necessary backplane relays are closed before the scan.

To set the scan mode from the web interface:

1. Select the **Advanced Trigger** tab.
2. Select **Mode**.
3. Select **Fixed ABR**, **Open All** or **Open Selective**.

DMM web page

The DMM web page allows you to configure the various DMM functions, create user-defined DMM configurations and reading buffers, and take measurement readings that may or may not be stored in a reading buffer.

At the top of the DMM web page is a visual representation of the actual front-panel reading and indicators (note that the indicators are not in the same location as the front panel, and not all are on the page). When enabled, you will see DMM display indicators such as **REL**, **FILT**, **MATH**, and **AUTO** (see (2) The display for a complete list of these indicators and their meanings). Below this front-panel view is a scrolling list of the active DMM settings, including the active function and its supporting attribute values. Scroll the list to view the values set.

Use the **Change Active Settings** button to change the settings for the active function. When clicked, a dialog box appears that contains settings that can be changed for that function, and you can also change the function. Changing functions adjusts the displayed attributes to be correct for the newly selected function. After making you desired changes, click the **Close** button at the bottom of the page.

Use the **Edit Configurations...** button to select a DMM configuration from a drop-down list. Once the DMM configuration is selected, the dialog box shows the settings that can be changed for that configuration. This dialog box is very similar to the the dialog box for changing active settings. Until a user-defined DMM configuration is saved with the **Save as** button, only the factory default DMM configurations exist in the list.

After making changes to a factory default DMM configuration, click the **Save as** button to open a dialog box that allows you to name the new configuration and save it to use later. Once you have entered and saved your DMM configuration, select it from the pull-down menu to make changes to it. After making changes, click the **Save as** button again; by default it uses the same name to overwrite your user-defined configuration with the updated settings.

In the Reading Buffer area, you can create a reading buffer or select an existing reading buffer to store your readings, or you can select None. With None selected, readings are not stored in a reading buffer. The readings are only displayed in the Data Table area on the web interface. You can clear the data table (click the **Clear Table** button), save data to to a computer (click the **Save Table to PC** button), select the timestamp format for time associated with the readings (select **Relative**, **Seconds**, **Time** or **Full**). If you want to store readings in a buffer, but no buffers exist, click the **Create** button. Once the buffer is created, it becomes the selected buffer to store readings.

When a new buffer is selected (including None) for readings, the storage the Data Table gets cleared.

When data is being stored to a reading buffer, the readings show on the front-panel display, but do not appear in the Data Table on the web interface until you click the **Refresh Data Table** button. If you want to view the data graphically, click the **View/Refresh Chart** button. If you want to save the reading buffer data to the USB flash drive on the instrument, click the **Save to USB** button.

Click the **Measure** button to take a single reading, or click the **Loop Measure** button to take a measurement per seconds configured below the button. Set the seconds between measurements by using the slide bar below to select ranges from 0.5 to 20 seconds. The measurements will automatically appear in the Data Table when the reading buffer is configured to None. If the reading buffer isn't set to None, click the **Refresh Data Table** to see the measurements.

TSB Embedded

TSB Embedded is an application that includes a command line interface that you can use to issue ICL commands. It also offers script-building functionality. TSB Embedded resides in the instrument.

Script management options

Existing scripts are listed in the User Scripts box on the left side of the web interface.

To run a script, click the name of the script and then click **Run**.

To delete a script, click the name of the script and click **Delete**. The script is deleted from the User Scripts list and from the nonvolatile memory of the instrument.

To stop operation of a script, click **Abort Script**.

To export the selected script to a flash drive, click **Export Script to USB**. Place a flash drive in the USB port on the front panel of the instrument. In TSP, enter the name as appropriate and click **OK**. Scripts are saved to a file with the extension `tsp`. TSP files are native to Test Script Builder or TSB Embedded, but they can be opened and edited in any text editor.

To import scripts from the computer, click **Import from PC**. Select the directory that contains the file. You can only import files with the extension `tsp`.

To clear the name box and the box that contains the script, click **Clear**.

To view the contents of a script, type the name of a script in the **TSP Script** box and click **View Script**.

To create a script, see [Create a script using TSB Embedded](#) (on page 2-49).

Command line interface

Console: Enter command line entries here to send commands to the instrument. Click **Enter** to send the command. The commands and output are shown in the Instrument Output box.

To resend a command, click the button at the left of the Console box.

Instrument control

To reset the entire TSP-enabled system, including the controlling node and all subordinate nodes, click **Reset**.

Create a script using TSB Embedded

NOTE

If you are using TSB Embedded to create scripts, you do not need to use the commands `loadscript` or `loadandrunscript` and `endscript`. For information on using TSB Embedded, select the **Help** button on a web page or the Help option from the navigation pane on the left side.

You can create a script from the instrument web page with TSB Embedded. When you save the script in TSB Embedded, it is loaded into the runtime environment and saved in the nonvolatile memory of the instrument.

To create a script using TSB Embedded:

1. In the TSP Script box, enter a name for the script.
2. In the input area, enter the sequence of commands to be included in the script. Line numbers are automatically assigned.
3. Click **Save Script**. The name is added to the User Scripts list on the left.

Admin page

Through the Admin page, you can change the instrument password and the instrument time.

Change the password

To change the password for the web interface:

1. In the web interface, from the left navigation, click **Admin**. A login page is displayed.
2. Enter the current password in the Password box. (The default is "admin".)
3. Click **Login**. The Administration page is displayed.
4. In the Current Password box, enter the current password.
5. In the New Password box, enter the new password.
6. In the Confirm New Password box, enter the new password again.
7. Click **Submit**. The new password takes effect immediately.

Change the instrument date and time

To change the date and time of the instrument:

1. In the web interface, from the left navigation, click **Admin**. A login page is displayed.
2. Enter the current password in the Password box (the default is "admin").
3. Click **Login**. The Administration page is displayed.
4. Enter the Year.
5. Select the Month, Day, Hour, Minutes and Seconds from the lists.
6. Click **Submit**. The new time and date information takes effect immediately.

Unit page

Save: Save the setup of the instrument.

Recall: Recall the setup of the instrument that was saved with the Save button.

Create Config Script: Save the set up of the instrument as a script.

To create the script:

1. Click **Create Config Script**. The Create Config Script dialog box is displayed.
2. To create a script that will run automatically when the instrument is powered on, select "Auto-execute on powerup." Note that this will overwrite the existing autoexec script.
3. To create a script with a new name, select Name and enter the name.
4. Click **OK**.

Reset: Resets all instruments in the TSP-enabled system. This is only available if the instrument is the master.

Open All: Click this to open all relays on all slots.

Upgrade Firmware: Select a firmware upgrade file to download to the instrument and begin the upgrade process.

Channel Connect Rule: Select the channel connect rule. See [Connection methods for close operations](#) (on page 2-89) for detail.

Digital I/O Lines: This is the tool to configure the 14 digital I/O lines of the instrument. Values can be read or written to the ports, or each individual bit can be toggled. "Write Protect" can be set individually for any I/O line.

Generate Report: This generates an instrument report you can use to:

- Review card or instrument information, including a basic description, the firmware revision, and the serial number.
- Review configuration information, including card configuration, DMM configuration, calibration information, and number of poles.
- Review the number of closures for each channel on the selected slots.
- The number of closures are the closures that have occurred over the lifetime of the card.

To print the report, click **Print**.

To clear the report information from the screen, click **Clear**.

LXI page

The Series 3700A is a LXI Class B instrument. The LXI page is a read-only page that displays the LXI information about the instrument.

IP Config

The IP Config allows you to review and change the LAN connection information.

See Change the IP configuration through the web interface for more information.

Log page

The event log records all LAN[0-7] triggers generated and received and can be viewed over any command interface, including the web interface. The following figure shows the view of the LAN[0-7] event log from the embedded web interface.

Up to 32 LAN[0-7] events are logged and shown on this page. The event log is circular and rolls over after 32 events are captured. The LAN[0-7] events correspond to the lan.trigger[1-8] subsystem.

Figure 2-26: Event log

Receive Time	EventID	From	PTP Timestamp		HWDetect	Sequence	Domain	Flags	Data
			Seconds	FractionalSeconds					
Refresh									

The timestamp, event identifier, the IP address and the domain name identify the incoming and outgoing LXI trigger packets. The following table provides detailed descriptions for the columns in the event log.

Event log descriptions

Column title	Description	Example
Receive Time	Displays the date and time when the LAN trigger occurred in UTC, 24-hour time	06:56:28.000 8 May 2008
EventID	Identifies the lan.trigger[N] that generates an event	LAN0 = lan.trigger[1] LAN1 = lan.trigger[2] LAN2 = lan.trigger[3] LAN3 = lan.trigger[4] LAN4 = lan.trigger[5] LAN5 = lan.trigger[6] LAN6 = lan.trigger[7] LAN7 = lan.trigger[8]
From	Displays the IP address for the device that generates the LAN trigger	localhost 192.168.5.20
System Timestamp	A timestamp that identifies the time the event occurred. The timestamp uses the following: PTP timestamp Seconds Fractional seconds The Series 3700A does not support the IEEE-1588 standard; the values in this field are always 0 (zero)	
HWDetect	Identifies a valid LXI trigger packet	LXI
Sequence	Each instrument maintains independent sequence counters: One for each combination of UDP multicast network interface and UDP multicast destination port. One for each TCP connection.	
Domain	Displays the LXI domain number (the default value is 0 (zero))	0 1523
Flags	Contain data about the LXI trigger packet	Values: 1 - Error 2 - Retransmission 4 - Hardware 8 - Acknowledgments 16 - Stateless bit
Data	The Series 3700A does not support the IEEE-1588 standard; the values in this field are always 0 (zero)	

Communication interfaces

This section shows you how to connect instruments to the following remote communication interfaces:

- Universal serial bus (USB)
- Local area network (LAN)
- General purpose interface bus (GPIB or IEEE-488)

It describes how to configure and troubleshoot these interfaces on computers with Windows 2000, Windows XP, Windows Vista, and Windows 7 operating systems.

It also describes the I/O software, drivers, and application software that can be used with Keithley's instruments.

Selecting an interface

The Keithley Instruments Series 3700A System Switch/Multimeter supports the following remote interfaces:

- GPIB (general purpose interface bus)
- USB
- LAN

NOTE

This section contains information on the GPIB connection (IEEE-488), ethernet connection (LAN), and USB communications interfaces. See [LAN concepts and settings](#) (on page B-1) for more information on LAN interfaces.

The Series 3700A can only be controlled from one remote interface at a time. The instrument will remote to the first interface on which it receives a message. It will ignore the other interface until the instrument is taken back to local operation.

USB

To use the USB connection, you must have the Virtual Instrument Software Architecture (VISA) layer on the host computer. See VISA and [How to install the Keithley I/O Layer](#) (on page 2-70) for more information.

VISA contains a USB Class driver for the USB Test & Measurement Class (USBTMC) protocol which, once installed, allows the Windows operating system to recognize the instrument.

When a USB device that implements the USBTMC or USBTMC-USB488 protocol is plugged into the computer, the VISA driver automatically detects the device. It is important to note that only USBTMC and USBTMC-USB488 devices are automatically recognized by the VISA driver. Other USB devices, such as printers, scanners, and storage devices, are not recognized.

In this section, "USB instruments" refers to devices that implement the USBTMC or USBTMC-USB488 protocol.

NOTE

The full version of National Instruments VISA provides a utility to create a USB driver for any other kind of USB device with which you might want to communicate with VISA. For more information, see the [NI VISA website](http://www.ni.com) <http://www.ni.com>.

Communicate with the instrument

To communicate with the USB device you need to use VISA. VISA requires a resource string to connect to the correct USB instrument of the format:

```
USB[board]::manufacturer ID::model code::serial number[::USB interface number][::INSTR]
```


This requires you to determine the parameters. You can gather this information by running a utility that automatically detects all instruments connected to the computer.

If you installed the Keithley I/O Layer, the Keithley Configuration Panel is available from the Windows Start menu in the Keithley Instruments menu.

To use the Keithley Configuration Panel to determine the VISA resource string:


1. Start the Keithley Configuration Panel. The Select Operation dialog box is displayed.
2. Select **Add**.

Figure 2-27: Select Operation dialog box




3. Click **Next**. The Select Communication Bus dialog box is displayed.

Figure 2-28: Select Communication Bus dialog box




4. Select **USB**.
5. Click **Next**. The Select Instrument Driver dialog box is displayed.

Figure 2-29: Select Instrument Driver dialog box




6. Select **Auto-detect Instrument Driver - Model**.
7. Click **Next**. The Configure USB Instrument dialog box is displayed with the detected instrument VISA resource string displayed.
8. Click **Next**. The Name Virtual Instrument dialog box is displayed.

Figure 2-30: Name Virtual Instrument dialog box.png



9. In the Virtual Instrument Name box, enter a name that you want to use to refer to the instrument.
10. Click **Finish**.
11. Click **Cancel** to close the Wizard.
12. Save the configuration. From the Configuration Utility, select **File > Save**.
13. In the Keithley Communicator, select **File > Open Instrument** to open the instrument you just named.

Figure 2-31: Keithley Communicator Open Instrument



14. Click **OK**.
15. Send a command to the instrument and see if it responds.

NOTE

If you have a full version of NI VISA on your system, you can run NI-MAX or the VISA Interactive Utility. See their documentation for information.

If you have the Agilent Io Libraries on your system, you can run Agilent Connection Expert to check out your USB instruments. See their documentation for information.

Additional USB information

This section provides further details and more advanced information about the USB bus and test and measurement instruments.

Connecting multiple USB instruments to the computer

The most convenient way to connect USB instrumentation to the computer is to plug a USB cable directly from the instrument to the computer. If you have more than one USB instrument or have other USB devices, such as printers, keyboards, and mice, you might not have enough USB connectors on the computer.

To gain more ports, you can use a USB hub or add more USB controller cards if you have available PCI or PCI Express slots.

There are two types of USB hubs, either of which can be used with Series 3700A:

- **Bus Powered:** This type of hub draws its power from the USB bus and can only supply 100 mA (USB 2.0) per port.
- **Self Powered:** This type of hub has an external power supply and can supply up to 500 mA per port (USB 2.0).

GPIB operation

This section contains information about GPIB standards, connections, and address selection.

GPIB standards

The GPIB is the IEEE-488 instrumentation data bus with hardware and programming standards originally adopted by the IEEE (Institute of Electrical and Electronic Engineers) in 1975. The instrument is IEEE Std 488.1 compliant and supports IEEE Std 488.2 common commands and status model topology.

Install the GPIB driver software

Check the documentation for your GPIB controller for information on where to acquire drivers. We also recommend that you check the vendor's website for the latest version of drivers or software.

It is important to install the drivers before the hardware so that the incorrect driver does not get associated with the hardware.

Install the GPIB cards in your computer

Refer the manufacturer's documentation for information on installing the GPIB cards.

Set the GPIB address

The GPIB address value is set to 16 at the factory. The address can be set to any address value between 0 and 30. However, the address must be unique in the system. It cannot conflict with the address assigned to another instrument or to the GPIB controller.

To change the GPIB address:

1. Press the **MENU** key.
2. Select **GPIB > ADDRESS**. Press the navigation wheel  to display the current address.
3. Choose the appropriate GPIB address.
4. Press **ENTER** to save the address.

The address value is saved in nonvolatile memory and will not change when a [reset\(\)](#) (on page 8-316) command is sent or when the power is turned off and then turned on again.

When the GPIB bus is operating, you can use the [gpiib.address](#) (on page 8-263) attribute to change the GPIB address remotely.

Enable GPIB

By default, the instrument is set to GPIB enabled. You only need to enable it if GPIB control was disabled.

To enable control through the GPIB:

1. Press the **MENU** key.
2. Select **GPIB**. Press the navigation wheel  to display the GPIB MENU.
3. Select **ENABLE**. Press the navigation wheel .
4. To enable GPIB, select **ON**. To disable it, select **OFF**.
5. Press **ENTER** to save the setting.

You must turn the instrument on and off before the setting takes effect.

Communicate with instruments

The GPIB driver software you installed installs a interactive dumb terminal program that allows you to send commands to the instrument. They directly call the GPIB driver support libraries.

For the KPCI-488LPA and KUSB-488B GPIB controller from Keithley Instruments, the configuration utility is called the KI-488 Diagnostic Tool. It is available from the Windows Start menu at **Keithley Instruments > KI-488 > KI-488 Diagnostic Tool**.

For the KUSB-488A GPIB controller from Keithley Instruments, the configuration utility is called TrTest. It is available from the Windows Start Menu at **Keithley Instruments > GPIB-488-CEC > TrTest**.

For National Instruments GPIB controllers, you can use NI-MAX. Start NI-MAX. If your hardware is installed correctly, you should see the controller in the GPIB section of the tree control on the left side. Select it and right-click to see an option to communicate with the instrument.

NOTE

If you want to use the GPIB controller with instrument driver (such as VXIPnP or IVI) or high-level software, you must also install I/O software, which installs the VISA layer. See [How to install the Keithley I/O Layer](#) (on page 2-70).

Terminator

When receiving data over the GPIB, the instrument terminates on any line feed character or any data byte with EOI asserted (line feed with EOI asserted is also valid). When sending data through the GPIB drivers, it is not necessary to append a line feed character to all outgoing messages. The EOI line is asserted with the last character sent.

However, if you want your program to communicate with all I/O buses on the instrument (GPIB, USB, LAN (VXI-11 and raw socket)), it is good practice to add a line feed to the end of the outgoing command. Use VISA and the same program will work with all the I/O buses by just changing the resource string in the VISA Open method.

Front-panel GPIB operation

This section describes aspects of the front panel that are part of GPIB operation, including messages, status indicators, and the LOCAL key.

Error and status messages

See Error summary list for a list of status and error messages associated with IEEE-488 programming. The instrument can be programmed to generate an SRQ, and command queries can be performed to check for specific error conditions.

LOCAL key

The EXIT (LOCAL) key cancels the remote state and restores local operation of the instrument. Pressing the EXIT (LOCAL) key also turns off the REM indicator and returns the display to normal if a user-defined message was displayed.

If the LLO (Local Lockout) command is in effect, the EXIT (LOCAL) key is also inoperative. Note that pressing the EXIT (LOCAL) key will also abort any commands or scripts that are being processed.

GPIB reference

General bus commands

General commands are commands that have the same general meaning regardless of the instrument (for example, DCL). The following table lists the general bus commands.

General bus commands

Command	Effect on Series 3700A
REN	Goes into remote when next addressed to listen.
IFC	Goes into talker and listener idle states.
LLO	LOCAL key locked out.
GTL	Cancel remote; restore Series 3700A front panel operation.
DCL	Returns all devices to known conditions.
SDC	Returns Series 3700A to known conditions.
GET	Initiates a trigger.
SPE, SPD	Serial polls the Series 3700A.

REN

The remote enable command (REN) is sent to the Series 3700A by the controller to set up the instrument for remote operation. Generally, the instrument should be placed in the remote mode before you attempt to program it over the bus. Setting REN true does not place the instrument in the remote state. You must address the instrument to listen after setting REN true before it goes into remote.

IFC

The interface clear command (IFC) is sent by the controller to place the Series 3700A in the local, talker, or listener idle states. The unit responds to the IFC command by cancelling front panel TALK or LSTN lights, if the instrument was previously placed in one of these states.

Transfer of command messages to the instrument and transfer of response messages from the instrument are not interrupted by IFC. If a response message was suspended by IFC, transfer of the message will resume when the unit is addressed to talk. If a command message transfer was suspended by IFC, the rest of the message can be sent when the unit is addressed to listen.

LLO

When the unit is in remote operation, all front-panel controls are disabled except the EXIT (LOCAL) key (and, of course, the POWER switch). The LLO command (local lockout) disables the EXIT (LOCAL) key.

GTL

Use the go to local command (GTL) to put a remote-mode instrument into local mode. Leaving the remote state also restores operation of all front panel controls.

DCL (device clear)

Use the device clear command (DCL) to clear the GPIB interface and return it to a known state. Note that the DCL command is not an addressed command, so all instruments equipped to implement DCL will do so simultaneously.

When the Series 3700A receives a DCL command, it clears the Input Buffer and Output Queue, cancels deferred commands, and clears any command that prevents the processing of any other device command. A DCL does not affect instrument settings and stored data.

SDC

The selective device clear command (SDC) is an addressed command that performs essentially the same function as the DCL command. However, since each device must be individually addressed, the SDC command provides a method to clear only selected instruments instead of clearing all instruments simultaneously, as is the case with DCL.

GET

The group execute trigger command (GET) is a GPIB trigger that is used to trigger the instrument to take readings from a remote interface.

SPE, SPD

Use the serial polling sequence to obtain the Series 3700A serial poll byte. The serial poll byte contains important information about internal functions (see [Status Model](#) (on page D-1)). Generally, the serial polling sequence is used by the controller to determine which of several instruments has requested service with the SRQ line. The serial polling sequence may be performed at any time to obtain the status byte from the Series 3700A.

Configure the GPIB controllers

Each instrument on a GPIB bus needs a unique address from a range of 0 to 30. Generally, the GPIB host controller is on address 0. However, there are GPIB controllers that adopt the address of 21. To be safe, do not configure any of the instruments for 21 or 0.

If you do need to change the host controller address, consult the controller documentation.

For the KPCI-488LPA and KUSB-488B GPIB controller from Keithley Instruments, the configuration utility is called the KI-488 Diagnostic Tool. It is available from the Windows Start menu at **Keithley Instruments > KI-488 > KI-488 Diagnostic Tool**.

For the KUSB-488A GPIB controller from Keithley Instruments, the configuration utility is called GPIB Configuration. It is available from the Windows Start Menu at **Keithley Instruments > GPIB-488 > GPIB Configuration**.

For National Instruments GPIB controllers, you can use NI-MAX. Start NI-MAX. If your hardware is installed correctly, you should see the controller in the GPIB section of the tree control on the left side. Select it and right-click to see an option to configure the controller. Do not forget to save your settings.

GPIB status indicators

The remote (REM), talk (TALK), listen (LSTN), and service request (SRQ) indicators show the GPIB bus status. Each of these indicators is described below.

REM

This indicator shows when the instrument is in the remote state. When the instrument is in remote, all front-panel keys, except for the EXIT (LOCAL) key are locked out. When REM is turned off, the instrument is in the local state, and front-panel operation is restored.

TALK

This indicator is on when the instrument is in the talker active state. Place the unit in the talk state by addressing it to talk with the correct talk command. TALK is off when the unit is in the talker idle state. Place the unit in the talker idle state by sending a UNT (Untalk) command, addressing it to listen, or sending the IFC (Interface Clear) command.

LSTN

This indicator is on when the Series 3700A is in the listener active state, which is activated by addressing the instrument to listen with the correct listen command. LSTN is off when the unit is in the listener idle state. Place the unit in the listener idle state by sending UNL (Unlisten), addressing it to talk, or sending IFC (Interface Clear) command over the bus.

SRQ

You can program the instrument to generate a service request (SRQ) when one or more errors or conditions occur. When this indicator is on, a service request has been generated. This indicator stays on until the serial poll byte is read or all the conditions that caused SRQ have been cleared.

LAN communications

This section provides an overview of LAN communications for the Series 3700A. For detailed information about setting up your LAN interface, refer to [LAN concepts and settings](#) (on page B-1).

You can communicate with the instrument using a local area network (LAN).

When you connect using a LAN, you can use a web browser to communicate with the instrument through the instrument's internal web page and other web applets.

Series 3700A are class B LXI version 1.3 compliant. They are scalable test instruments with direct connections to host computers. They can also interact with a DHCP or DNS server and other LXI compliant instruments on a LAN.

The Series 3700A are compliant with IEEE standard 802.3 (Ethernet) and support full connectivity on a 10 Mbps or 100 Mbps network.

NOTE

Contact your network administrator to confirm your specific network requirements before setting up a LAN connection.

Overview of LAN instruments

When Ethernet ports became standard on computers, it was logical that instrumentation would follow. The VXI-11 protocol, which was standardized on in the early 1990s, is the standard used to emulate GPIB over Ethernet.

Even though Ethernet became the standard LAN technology on instruments, LAN instruments from different vendors differed in the approach they took. Some vendors only supported static IP, whereas others had DHCP, DLLA (Auto-IP), and static addressing. The LXI consortium was started to standardize what should be in all instruments that conform to LXI.

An instrument that conforms to LXI version 1.3 must have the following:

- All three IP addressing modes: DHCP, Auto-IP, and static IP.
- A web server that has some standard Ethernet configuration parameters:
 - IP configuration: IP address, subnet mask, gateway.
 - Password protection on anything that might change the instrument state.
 - A control on the web page that flashes an LED or some form of indicator on the front panel of the instrument. LXI calls this the Device Identification Functionality. This allows you to identify the web page you are currently looking at with the instrument. This helps you identify a specific instrument in a rack of similar model instruments.

- A reserved URL in the instrument that provides an xml document that has standard configuration information. This can be useful for software tools that need to identify the instruments and their capabilities. The URL is **http://<host>:<port>/lxi/indentification**.
- An IVI driver for the instrument.
- A LAN Status (fault) indicator.
- VXI-11 discovery protocol.
- LAN reset button or menu option. LXI calls this the LAN Configuration Initialize (LCI).

When the LXI-defined LAN reset is selected, the instrument reverts its LAN settings to a known set of defaults. The default LAN settings for LXI instruments are:

- DHCP and Auto-IP enabled. LXI refers to this as the Auto IP address mode (compared to the manual address mode, which is fixed or static IP addressing).
- Web password is reset to the factory default.
- Ping responder enabled.
- Dynamic DNS and mDNS enabled.

LXI Version 1.3 added the requirement of mDNS (multicast DNS) discovery.


LAN cable connection

The Series 3700A includes two CA-180-3A cables (LAN crossover cables). Use one cable for the TSP-Link[®] network and use the other cable for the LAN.

Use the following figure as a guide when making LAN connections.

To configure the LAN settings, see [LAN concepts and settings](#) (on page B-1).

Figure 2-32: Series 3700A LAN connection



- (1) Series 3700A ethernet port (LAN)
- (2) Straight-through LAN cable or crossover CAT5 LAN cable (CA-180-3A)
- (3) Ethernet port (located on the host computer)

Supplied software

The majority of software applications and all instrument drivers from Keithley Instruments depend on some, or all, of the following software components:

- NI-VISA™
- VISA shared components
- IVI shared components
- NI™ CVI™ runtime engine
- NI™ IVI™ compliance package
- Keithley instrument driver
- LabVIEW™ driver
- Test Script Builder (TSB) Add-in
- J2SE™ Runtime Environment

These software components are included on the CD-ROMs that came with your instrument, and are also available for download at the [Keithley Instruments support website](http://www.keithley.com/support) (<http://www.keithley.com/support>).

Instrument driver types

There are several different styles of instrument drivers. Keithley Instruments provides three different instrument drivers for the Series 3700A: A native LabVIEW driver, an IVI-C driver, and an IVI-COM driver. You need to pick the style that best suits the application development environment (ADE) that you are using. For example, if you are using LabVIEW, you would pick a native LabVIEW driver. If a native LabVIEW driver is not available then you can use an IVI-C driver as LabVIEW has the option of creating a wrapper for the IVI-C driver.

LabVIEW supports IVI-COM drivers but they are definitely not the first or second choice. However, if it is the only driver type for the instrument, it can be used.

If LabWindows/CVI or C/C++ is your programming language, an IVI-C driver is the best option. For VB6 and any .NET language (C#, VB.NET, and so on), an IVI-COM driver would be the best option.

Sometimes instrument vendors do not provide all three driver types. Most languages can accommodate other driver types, but this is not optimal.

The following sections describe the different driver types in more detail.

VXIPnP drivers

VXI (Vixie) Plug-n-Play (VXIPnP) style drivers are Win32 DLLs that have some standard functions defined by the VXIPnP Alliance, such as:

- init
- close
- error_message
- reset
- self_test
- Read
- Initiate
- Fetch
- Abort

The API was defined so that users of instruments would have a familiar API from instrument to instrument. There are some basic guidelines when creating APIs for your instrument, such as using VISA data types and how to construct the CVI hierarchy. There are many VXIPnP drivers available for Agilent, Fluke and Tektronix instruments.

LabVIEW drivers

Native LabVIEW drivers

A native LabVIEW driver is a LabVIEW driver that is created using entirely built-in LabVIEW VIs — it does not make any calls to external DLLs or Library files. This makes the driver portable to all the platforms and operating systems that LabVIEW and VISA supports (currently, Linux on x86, MAC OSX, and Microsoft Windows).

National Instruments (NI™) maintains a native [LabVIEW driver style guide](http://zone.ni.com/devzone/cda/tut/p/id/3271) (<http://zone.ni.com/devzone/cda/tut/p/id/3271>).

LabVIEW driver wrappers

All IVI-C drivers have a function panel file (.fp) that shows a hierarchy of the function calls into a DLL. It is a tool that guides a user to select the correct function call in the driver, since a DLL only has a flat API entry point scheme (unlike COM or .NET). Any CVI generated fp file can be imported into LabVIEW and LabVIEW will generate a wrapper for the DLL. The drawback here is that the driver is dependent on the DLL, which is not portable and is therefore Windows-specific.

Obtaining instrument drivers

To see what drivers are available for your instrument:

1. Go to the [Keithley website](http://www.keithley.com) (<http://www.keithley.com>).
2. Select the Support tab.
3. Enter the model number of your instrument.
4. Select Software Driver from the list.

For LabVIEW, you can also go to National Instrument's website and search their instrument driver database.

Instrument driver examples

All Keithley drivers come with examples written in several programming languages that show you how to do the most common things with the instruments.

Install the driver. The examples are in the Windows Start menu, under **Keithley Instruments > Model Number** (where Model Number is the instrument model number).

IVI shared components

The IVI shared components are a similar concept to the VISA shared components. The IVI Foundation provides class drivers for:

- All the supported instruments (DMM, Scope, Fgen, and so on)
- The configuration store

The IVI shared components also create the installation folders and registry keys that all IVI drivers and support files use for installation.

Interchangeable Virtual Instruments (IVI) style drivers

The major problem with VXIPnP drivers was that the API was not specific to the instrument. For something as standard as measuring DC Volts on a DMM, it would be a good idea if there were a set of standard functions to do this.

The [IVI Foundation](http://www.ivifoundation.org) (<http://www.ivifoundation.org>) defined a set of APIs (Class interfaces) for the following instruments: DMM, Function Generator, DC Power Supply, Scope, Switch, Spectrum Analyzer, RF Signal Generator and Power Meter. They are currently working on class APIs for some other instrument types.

There are two types of IVI drivers: IVI-COM drivers use Microsoft COM technology to expose driver functionality, while IVI-C drivers use conventional Windows DLLs to export simple C-based functions.

For more information about IVI drivers and the differences between the COM, C and .NET interfaces, see [Making the Case for IVI](http://pacificmindworks.com/docs/Making%20the%20Case%20for%20IVI.pdf) (<http://pacificmindworks.com/docs/Making%20the%20Case%20for%20IVI.pdf>).

NI CVI runtime engine

IVI-C drivers that are created using NI's LabWindows/CVI environment depend on either the CVI runtime (cvirte.dll) or the instrument support runtime (instrsup.dll) and must be present on the system for them to run.

NI IVI Compliance Package

The NI IVI Compliance Package is a software package that contains IVI class drivers and support libraries that are needed for the development and use of applications that leverage IVI instrument interchangeability. The IVI Compliance Package also is based on and is compliant with the latest version of the instrument programming specifications defined by the IVI Foundation.

The NI ICP installer installs the IVI shared components, CVI runtime engine and the instrument support runtime engine.

Keithley I/O layer

The Keithley I/O Layer (KIOL) is a software package that contains several utilities and drivers. It is mainly used as a supplement to IVI drivers or application software like TSB.

The KIOL contains:

- NI VISA Runtime
- Keithley Configuration Panel
- Keithley Communicator

NI VISA Runtime

NI VISA is National Instruments implementation of the VISA standard. There are two versions. The full version contains diagnostic and configuration tools such as NI-Spy and NI-MAX and the binary runtime-only files. The runtime version contains only the binary files (DLLs) that allow the drivers to operate.

The KIOL contains a licensed version of the NI VISA runtime.

If you already have NI software (such as LabVIEW or LabWindows) installed, you have a valid license that can be used with Keithley drivers and application software.

If you do not have NI software installed, to use Keithley drivers or application software, you must install the KIOL. This installs a valid, licensed copy of the NI Visa runtime to use with Keithley drivers or application software. KIOL installs a valid license for the VISA runtime only (not the full version of NI VISA).

Keithley Configuration Panel

The Keithley Configuration Panel is a configuration utility for IVI drivers, similar to NI-MAX. It also has the ability to auto-detect USBTMC instruments and LAN instruments that support the VXI-11 protocol.

Keithley Communicator

The Keithley Communicator is a dumb terminal program that uses VISA to communicate with the instrument.

Computer requirements for the Keithley I/O Layer

The Keithley I/O Layer version C02 supports the following operating systems:

- Windows 7 (32-bit only)
- Windows Vista (SP1)
- Windows XP (SP2)
- Windows 2000 (SP4)

Note that Windows 95, Windows ME, Windows 98, and Windows NT are not supported.

How to uninstall previous versions of the Keithley I/O Layer

If you have an earlier version of the Keithley I/O Layer software installed on your computer, you must uninstall it.

To uninstall the Keithley I/O layer:

1. From the Control Panel, select Add/Remove Programs.

2. Uninstall the following components:
 - Keithley I/O Layer
 - Keithley I/O Layer Suite
 - Keithley SCPI-based Instrument IVI-C Driver
 - NI-VISA Runtime x.x.x (If present) (x.x.x is the VISA version)
3. Reboot your computer.

How to install the Keithley I/O Layer

NOTE

Before installing, it is a good idea to check to see if a later version of the Keithley I/O Layer is available. Check the [Keithley Instruments website](http://www.keithley.com) (<http://www.keithley.com>). Select the Support tab, type in KIOL, and select software driver.

You can install the Keithley I/O Layer from the CD that came with your instrument or from the Keithley website.

The software installs the following components:

- Microsoft .NET Framework 2.0
- NI IVI Compliance Package 3.3
- NI-VISA Runtime 4.5.0
- Keithley SCPI-based Instrument IVI-C driver SCPI-856C02
- Keithley I/O Layer KIOL-850C02

To install the Keithley I/O Layer from the CD:

1. Close all programs.
2. Place the CD into your CD-ROM drive.
3. Your web browser should start automatically and display a screen with software installation links. To manually open the web page, use a file explorer to navigate to the CD drive and open the file named `index.html`.
4. From the web page, select the Software category and then click on the Keithley I/O Layer.
5. Accept all defaults. Click **Next**.
6. Click **Install**.
7. Reboot your computer

To install the Keithley I/O Layer from the Keithley website:

1. Download the Keithley I/O Layer Software from the [Keithley Instruments website](http://www.keithley.com) (<http://www.keithley.com>). The software is a single compressed file and should be downloaded to a temporary directory.
2. Run the downloaded file from the temporary directory.
3. Follow the instructions on the screen to install the software.
4. Reboot your computer.

Special installation considerations

Situations may occur during installation that cannot be handled automatically by the installation utility. The installation utility will warn you if one of these situations is detected. The sections below describe the action you must take before the installation can be completed.

Mismatch between IVI Shared Components and IVI Engine Detected

The IVI Shared Components and IVI Engine are software components that may be installed by various test and measurement software applications, instrument drivers, and so on. Keithley I/O Layer software requires that these components, if present, be compatible versions. The installation utility will detect a mismatch, which must be corrected before the software installation can proceed. If this situation is detected, the Keithley I/O Layer software installation will automatically stop.

The recommended way to resolve this situation is to install the IVI Compliance Package (ICP) software from National Instruments. You may download the ICP software and release notes from National Instrument's website. When the ICP installation is complete, restart the Keithley I/O Layer software installation.

Non-National Instruments VISA detected

VISA software is used to communicate with the instrument and may be installed by various test and measurement software applications, instrument drivers, and so on. Keithley I/O Layer software requires and will install National Instrument VISA software. The installer will detect if another vendor's version of VISA is already installed on the computer. If this occurs, the installer will pause and display a warning message. The warning message displays the vendor of the detected VISA in its title bar, if this can be determined. Make a note of the vendor name. At this point, you may elect to continue the installation, which will overwrite the existing VISA installation with NI VISA. This will allow the Keithley I/O Layer software to operate properly, but may cause other applications or instrument drivers that were dependent on the existing VISA to malfunction.

The recommended way to resolve this situation is to perform the following steps:

1. Exit the Keithley I/O Layer software when the warning message is displayed. Make note of the vendor of the VISA vendor in the warning message (if any).
2. Uninstall the non-NI VISA software.
3. Uninstall Tektronix VISA by selecting OpenChoice TekVISA from the Control Panel Add/Remove programs list.
4. Uninstall Agilent VISA by selecting Agilent I/O Libraries Suite from the Control Panel Add/Remove programs wizard list.
5. Uninstall other versions of VISA by selecting the appropriate entry from the Control Panel Add/Remove Programs Wizard list.
6. Restart the Keithley I/O Layer software installation.
7. If the pre-existing version of VISA was supplied by Tektronix or Agilent (as displayed in the warning message), you may safely reinstall that version of VISA once Keithley I/O Layer software installation is complete. When you reinstall Tektronix or Agilent VISA, it may prompt you to preserve the current VISA version, which you should do. This will usually restore the operation of any dependent applications or drivers.
8. If the pre-existing version of VISA was supplied by a vendor other than Tektronix or Agilent, it is recommended that you do not reinstall it as this will likely cause the Keithley I/O Layer software to malfunction.

Installation troubleshooting

If problems occur during installation, it might be helpful to install the components individually. Errors might appear that will help you resolve the installation issue.

If problems occur during installation:

1. Follow the instructions to uninstall all the KIO L components in [Special installation considerations](#) (on page 2-70).
2. Rerun the KIO L installer. Note where the installer unpacks the files (usually in a temporary folder).
3. Cancel the installer.
4. Go to folder where the files were unzipped.
5. Run the setup.exe for each of the following components in the following order:
 - IVI Compliance Package (ICP)
 - Visa Runtime
 - KIO L
 - Keithley SCPI Driver
6. Ignore all the other folders.
7. Reboot the computer.

Modifying, repairing, or removing Keithley I/O Layer software

The Keithley I/O Layer chains many other installers together.

To remove all the KIO L components, you need to uninstall the following applications using Control Panel Add/Remove programs:

- National Instruments NI IVI Compliance Package
- National Instruments NI-Visa Runtime
- IVI Shared Components
- Visa Shared Components
- Keithley SCPI Driver

After uninstalling components, reboot the computer.

Addressing instruments with VISA

VISA allows you to communicate with the instrument on different communication buses by changing a resource string that gets passed in with the viOpen function, in VISA-C, or with the Open method on the VISA-COM resource manager object.

For detailed information on the format of the resource string, refer to the VISA specification VPP4.3 at the IVI Foundation web site or refer to the help file by the vendor of the VISA implementation you are using.

The following sections describe the resource strings for some of the communication types that Keithley supports. Any field that has [] (square brackets) around it is optional and will revert to a default value.

Addressing instruments through the LAN

VISA supports two different LAN protocols, each of which has a different resource string.

VXI-11 is a protocol that emulates GPIB over the LAN. Series 3700A supports this protocol. The resource string is:

```
TCPIP[board]::host address[::LAN device name][::INSTR]
```

board is the network interface card in the computer. This value is usually skipped and VISA determines the correct network interface card (if you have more than one) by looking at the IP address.

host address can be either a valid DNS hostname, mDNS hostname, or the IPv4 IP (only) address of the instrument.

LAN device name is a method of addressing secondary instruments at the main IP address, similar to secondary addressing on the GPIB bus. The default is `inst0`.

A **raw socket** connection requires more work by the driver or application program to make sure the correct amount of data has been sent or received correctly. All Keithley instruments support the raw socket connection.

```
TCPIP[board]::host address::port::SOCKET
```

The *board* and the *host address* are the same as for the VXI-11 protocol.

port is the port to which to connect on the instrument. For the Series 3700A, the port is 5025. See Instrument LAN protocols for a complete list of port numbers.

Addressing instruments using USB

```
USB[board]::manufacturer ID::model code::serial number[::USB interface number][::INSTR]
```

board is not used (0).

manufacturer ID is the USB.org reserved four-digit hex code for the instrument vendor company. Keithley Instruments is `0X5E6`.

model code is the model number of the instrument. For example, when addressing a Model 3706A, use `0X3706`.

serial number is the serial number of the instrument.

USB interface number identifies which USBTMC interface on the instrument to address (usually 0).

NOTE

Also see USB VISA identifiers.

Addressing instruments through GPIB

There are two different resource classes in VISA for the GPIB bus.

INSTR is the basic class that everyone uses. It allows application software to send and receive data and commands without dealing with some low level GPIB nuances. This class is recommended for typical GPIB communication.

The **INTFC** class allows finer control over the GPIB controller card in the computer. You must comply with the IEEE-488.1 protocol and tell the instrument to listen and the controller to talk before sending a message to the instrument. This class allows you to communicate to the instrument using low-level GPIB commands. Refer to your VISA documentation for more details on how to use this class.

The GPIB INSTR resource class format is:

```
GPIB[board][:primary address][:secondary address][:INSTR]
```

board is the number of the GPIB card if there is more than one in the computer. If there is only one GPIB card, skip *board* but do not leave a space.

primary address is the main GPIB address of the instrument, which can be changed if necessary through the front panel of the instrument.

secondary address is for secondary addressing in GPIB. Some instruments have subinstruments or cards inside the main instrument or backplane. The primary address identifies the main instrument. The secondary address identifies subinstruments. Refer to the instrument user manual for the secondary address if need be.

Sending raw commands to an instrument

The next sections show you how to use VISA-C and VISA-COM to send raw instrument commands without using the instrument drivers.

VISA-C sample code

The following is a simple C/C++ console application that reads back the instrument identification string using VISA-C. You need to include visa.h and link with the visa32.lib file.

```
#include "stdafx.h"
#include <visa.h>

#define checkErr(fCall)      if (error = (fCall), (error = (error <
    0) ? error : VI_SUCCESS)) \
                            {goto Error;} else error = error

int _tmain(int argc, _TCHAR* argv[])
{
    ViSession defaultRM, vi;
    char buf [256] = {0};
    ViStatus  error = VI_SUCCESS;

    /* Open session to GPIB device at address 22 */
    checkErr(viOpenDefaultRM(&defaultRM));
    checkErr(viOpen(defaultRM, "GPIB0::14::INSTR", VI_NULL,VI_NULL, &vi));

    /* Initialize device */
    checkErr(viPrintf(vi, "*RST\n"));

    /* Send an *IDN? string to the device */
    checkErr(viPrintf(vi, "*IDN?\n"));
    ViUInt16 status = 0;
    do
    {
        checkErr(viReadSTB(vi, &status));
        printf("ReadSTB = %X\n", status);
    } while(status == 0);

    /* Read results */
    checkErr(viScanf(vi, "%t", &buf));
    /* Print results */
    printf ("Instrument identification string: %s\n", buf);

    /* Close session */
    checkErr(viClose(vi));
    checkErr(viClose(defaultRM));

Error:

    if(error < VI_SUCCESS)
        printf("Visa Error Code: %X\n", error);
    printf("\nDone - Press Enter to Exit");
    getchar();

    return 0;
}
```

VISA-COM sample code

This example gets the instrument identification string using VISA-COM in C#.

The first thing to do is add a reference to the VISA-COM interop DLL, which is usually located at C:\Program Files\IVI Foundation\VISA\VisaCom\Primary Interop Assemblies\Ivi.Visa.Interop.dll.

```
using Ivi.Visa.Interop;

namespace WindowsApplication1
{
    public class IdnSample: System.Windows.Forms.Form
    {
private Ivi.Visa.Interop.FormattedIO488 ioDmm;
        //
    }
}

private void IdnSample_Load(object sender, System.EventArgs e)
{
    ioDmm = new FormattedIO488Class();

    SetAccessForClosed();
}

private void btnInitIO_Click(object sender, System.EventArgs e)
{
    try
    {
        ResourceManager grm = new ResourceManager();
        ioDmm.IO = (IMessage)grm.Open("GPIB::16::INSTR",
            AccessMode.NO_LOCK, 2000, "");
        ioDmm.IO.TerminationCharacterEnabled = true;
    }
    catch (SystemException ex)
    {
        MessageBox.Show("Open failed on " + this.txtAddress.Text + " " +
            ex.Source + " " + ex.Message, "IdnSample", MessageBoxButtons.OK,
            MessageBoxIcon.Error);
        ioDmm.IO = null;
    }
}
}
```

Switch operation

This section gives an overview of working with channels, including a discussion of channel types, selecting channels, opening and closing channels, setting common channel attributes, and setting up channel patterns.

NOTE

To install the switching card, refer to instructions in Series 3700A Quick Start Guide. For detailed information about the Series 3700A switch cards, refer to the Series 3700A Switch and Control Cards Reference Manual (Keithley part number 3700AS-909-01) on the Product Information CD-ROM that came with your instrument.

The switching channels of a Series 3700A have specific settings for switch-only operations and specific settings for switch with DMM operations. The Series 3700A accesses different settings based upon the close or open operation you specify. You can perform such operations on switching module channels, analog backplane relays, and channel patterns.



CAUTION

Hot switching can dry weld reed relays such that they will always be on. Hot switching is recommended only when external protection is provided.

Identify installed switching cards

To identify installed switching cards from the front panel:

Press the **SLOT** key to scroll through the model numbers, descriptions, and firmware revisions of the installed switching cards.

To identify installed switching cards from the web interface:

1. Select the **Unit** page.
2. In the Report area, select the slots that you want information about.
3. Select **Firmware Revision**.
4. Click **Generate Report**. Information about the cards in the slots is displayed below the button.

To identify installed switching cards from the remote command interface:

Use `print (slot[X].idn)` to query and identify installed switching cards:

```
print (slot[X].idn)
```

Where: x = slot number (from 1 to 6)

Example

To get a list of all switching cards installed in the slots of a Series 3700, send the following command over the remote command interface:

```
for x=1,6 do print (slot[x].idn) end
```

The response will be similar to the following:

```
3722, Dual 1x48 Multiplexer, 01.00a, <Module Serial Number>
3721, Dual 1x20 Multiplexer, 01.02a, <Module Serial Number>
Empty Slot
Empty Slot
Empty Slot
Empty Slot
```

Specifying a channel

The channels on the cards that you can use with the Series 3700A are referred to by a channel specifier. You will use the specifier to identify channels for use with close and open operations, scans, and channel patterns. The specifier is used for all interfaces (front panel, web, and remote command).

A channel specifier is a four or five-digit alphanumeric sequence. The first digit is always the slot number of the slot in which the card is installed in the instrument. The remaining digits vary depending on the type of card.

The following sections describe the channel specifier in more detail and provide generic examples (which may or may not be suitable for your installed cards).

Channel types

The channel types that are used to control relays include:

- Matrix
- Multiplexer (MUX)
- Backplane
- Digital I/O
- Totalizer
- Digital to analog converter (DAC)

The channel types that are available on a card are defined by the type of card. The documentation for your card model lists the available channel types.

Specify multiple channel numbers using lists and ranges (a sequence of channel numbers). Lists and ranges build on the individual channel specifier.

Matrix card channel specifiers

The channels on the matrix cards are referred to by their slot, bank, row, and column numbers:

- **Slot number:** The number of the slot in which the card is installed.
- **Bank number:** The bank number, if used by your card. See your card documentation.
- **Row number:** The row number is either 1 to 8 or A to Z. See your card documentation.

Column number: Always two digits. For columns greater than 99, use A, B, C and so on to represent 10, 11, 12, ...; the resulting sequence is: 98, 99, A0, A1, ..., A8, A9, B0, B1, ...

Matrix channel examples

Specifier	Slot number	Bank number	Row number	Column number
1104	1	N/A	1	04
11104	1	1	1	04
1203	1	N/A	2	03
213A4	2	1	3	104
3112	3	N/A	1	12
62101	6	2	1	01

Analog backplane relay channel specifiers

The channels for slots with analog backplane relays are referred to by their slot, backplane, bank, and relay numbers:

- **Slot number:** The number of the slot.
- **Backplane number:** Always 9.
- **Bank number:** The bank number, if used by your card. See your card documentation for detail.
- **Analog backplane relay number:** The number of the backplane relay. Typically 1 to 6. See your card documentation for detail.

Backplane relay examples

Specifier	Slot number	Backplane number	Bank number	Backplane relay number
1914	1	9	1	4
1922	1	9	2	2
2924	2	9	2	4
3916	3	9	1	6

Multiplexer, digital I/O, totalizer, and DAC channel specifiers

The channels for multiplexer (MUX), digital I/O, totalizer, and digital to analog converter channels are referred to by their slot and channel numbers:

- **Slot number:** The number of the slot in which the card is installed.
- **Channel number:** The number of the channel (always three digits).

Specifier	Slot number	Channel number
1004	1	004
2050	2	050
3012	3	012
3003	3	003
2007	2	007
1020	1	020

Close and open channel operations and commands

Switching channels have specific settings for switch-only operations and specific settings for switch with DMM operations. For switch-only operation, there are three close methods and one open method. For switch with DMM operation, there is one close and one open method.

NOTE

You can use scans to perform a user-specified sequence of close and open operations on multiple channels for switch only applications or the switch with DMM applications. Refer to [Scanning and triggering](#) (on page 3-1) for information on scan operations.

The command or operation used to request the close or open specifies the completion of either a switch-only operation or a switch with DMM operation.

You can use the front panel **CLOSE** and **OPEN** keys to perform either switch only operations or switch with DMM operations on the selected channels. The operations of the keys depend on the DMM configuration attribute setting of the selected channel. Refer to [Channel Attributes](#) (on page 2-93) for more information on the DMM Configuration attribute.

- When the DMM configuration is set to “nofunction”, the **CLOSE** and **OPEN** keys function as switch only operations in the same manner as `channel.close` and `channel.open` commands. When the DMM configuration is associated with a particular function (for example, DC Volts), the **CLOSE** and **OPEN** keys function as switch with DMM operations, that is, in the same manner as `dmm.close` and `dmm.open` commands.

NOTE

An error occurs if you attempt to perform a switch with DMM operation on an item that does not have an associated DMM function.


Corresponding remote commands for switch with DMM operations:

ICL command	Action performed
<code>dmm.close()</code>	Equivalent of <code>channel.exclusiveslotclose</code> except it also prepares the DMM for taking a measurement on the function associated with the item. It closes any needed backplane relays and paired channels. It opens channels and backplane relays that will interfere with measuring on the specified item.
<code>dmm.open()</code>	It opens the items that would get closed with a <code>dmm.close()</code> .

When you perform a switch with DMM operation, the Series 3700A also closes the appropriate analog backplane relays to connect to the DMM Input and/or DMM Sense terminals. For 2-wire or two-pole DMM operations, the Series 3700A closes only the analog backplane relay to connect to the DMM Input terminal. For 4-wire or four-pole DMM operations, the Series 3700A closes the analog backplane relays to connect to the DMM Input and DMM Sense terminals.


The following figure shows an example of how the channel is connected to the DMM Input of the Series 3700A for a 2-wire DMM operation. Assume a switching module with 20 channels is installed in Slot 1 of the mainframe and a 2-wire DMM operation, such as DC Volts, is selected. When you perform a DMM close operation on Channel 1001, the Series 3700A closes Channel 1001 and Channel 1911 (the backplane isolation relay) to connect the channel to the DMM Input terminal.

Figure 2-33: Two-wire function



The following figure shows an example of how the channel and its paired channel are connected to the DMM Input and Sense terminals of the Series 3700A for a 4-wire DMM operation. Assume a switching module with 20 channels is installed in Slot 1 of the mainframe, and a 4-wire function, such as 4Ω , is selected. When you perform a DMM close operation on Channel 1001, the Series 3700A closes Channel 1001 and Channel 1911 (backplane isolation relay) to connect the channel to DMM Input. The Series 3700A also closes Channel 1011 (the paired channel) and Channel 1922 (the sense backplane isolation relay) to connect the paired channel to DMM Sense.

Figure 2-34: Four-wire function



Selecting, closing, and opening channels

You can use the channel specifiers to select channels from the front panel, web interface, or over a remote command interface.

The methods for closing and opening channels include:

- Channel close: Close the selected channel
- Channel exclusive close: Close the selected channel and open any closed channels on the instrument (the only closed channel on the instrument is the one you selected)
- Channel exclusive slot close: Close the selected channel and open any closed channels in the same slot (the only closed channel on the slot is the one you selected)
- Channel open

The Series 3700A verifies that the operation being requested for a channel is supported by the specified channel and that the channel exists in the instrument.

NOTE

When you turn on the Series 3700A, relays for all switch cards in the instrument are opened. This includes all backplane relays.

Operating a channel from the front panel

CAUTION

Hot switching can dry-weld reed relays, causing them to always be on. Hot switching is recommended only when external protection is provided.

You can perform operations on a single channel from the front panel.

To select a channel:


1. If the instrument is being controlled remotely, press **EXIT** to allow control from the front panel.
2. Press the navigation wheel  to select the first digit of the channel specifier, which is the slot number ①. The digit flashes, which indicates that it can be edited.

Figure 2-35: Select a channel from the Series 3700A front panel



3. To change to a different slot number, turn the navigation wheel  until the slot number you want is displayed.
4. Press navigation wheel .
5. If your card supports banks, the next number you can select is the bank number. Set this as needed using the navigation wheel .
6. Set the channel number (or rows and columns for installed matrix cards) as needed using the navigation wheel  .
7. The display shows the current state of the selected channel in the bottom row ③. In this example, the channel is open and 2-pole (if you see : followed by a channel specifier, you selected a range; press **EXIT** to return to the main display and reselect your channel).

Figure 2-36: Series 3700A selected channel state



8. To:
 - Close a channel without affecting any other channels: Select **CLOSE**.
 - Open the channel: Press **OPEN**.
 - Close a channel and open any other closed channels on the instrument: Select **CHAN** and select **EXCLOSE**. Press **ENTER** to close the selected channels.
 - Close a channel and open any other closed channels on the slot that contains the selected channel: Select **CHAN**, and then select **EXSLOTCLOSE**. Press **ENTER** to close the selected channels.

NOTE

Once a channel is selected, it is the selected channel for any subsequent front-panel operations.

Open and close channels from the Channel Action Menu

You can also use the options in the Channel Action Menu to open and close channels.

To use the Channel Action Menu to open and close channels:

1. Go to channel view.
2. Select the channel you want to open or close.
3. Press **CHAN**.
4. Use the navigation wheel  to select the option. You can select:
 - **OPEN**: Opens the selected channel.
 - **CLOSE**: Closes the selected channel.
 - **EXCLOSE**: Closes the selected channel; opens any other channels that are closed.
 - **EXSLOTCLOSE**: Closes the selected channel; opens any other channels that are closed on the same slot.
5. Press the navigation wheel  to open or close the channel.


Selecting, closing, and opening a channel from the web interface

You can perform operations on a single channel from the web interface.

To select a channel:

1. You must log into the instrument to work with the channels. See [Log in to the instrument](#) (on page 2-37). After logging in, you can access the channel controls.
2. From the instrument home page, from the navigation on the left, select the slot that contains the channels you want to work with.

Figure 2-37: Web interface Cards list



- To close a channel, click the channel. The display of the channel depends on the card that you have installed. Some examples are shown here.

Figure 2-38: Selecting, closing, and opening a channel from the web interface




Figure 2-39: Selecting, closing, and opening a channel from the web interface





Figure 2-40: Close a channel

4. To open a closed channel, click it again.
5. To perform an exclusive close on a channel:
Select **Exclusive Slot Close** in the Channel Action Type box. (Note that the DMM close option shown here is only available for instruments with the DMM feature installed.)

Figure 2-41: Selecting, closing, and opening a channel from the web interface

Channel Action Type:

<input type="radio"/> Channel Close	<input type="radio"/> Exclusive Close
<input checked="" type="radio"/> Exclusive Slot Close	<input type="radio"/> DMM Close

- a. Click a channel to close that channel and open all other channels.

Selecting, closing, and opening a channel using remote commands

To close or open a channel from the remote interface:

You can open and close channels using the following commands:

- `channel.close()` (on page 8-50)
- `channel.exclusiveclose()` (on page 8-56)
- `channel.exclusiveslotclose()` (on page 8-57)
- `channel.open()` (on page 8-80)

For example, to close channel 1001 over the remote interface, send the command:

```
channel.close("1001")
```

NOTE

Refer to the [Command reference](#) (see "[Commands](#)" on page 8-10) for details on commands.

Channel list parameter for remote commands

The channel list parameter is a string-type parameter that is used when controlling the relays of the Series 3700A using a remote command interface. You can specify a list of individual channels or a range of channels in the channel list parameter.

In the command descriptions, the channel list parameter is shown as *channelList*.

When sending this parameter:

- Enclose the contents of the channel list in either single (') or double (") quotes. The beginning and end quotes must be the same style.
- Use a comma or semicolon to separate the channel list or [channel patterns](#) (on page 2-96).
- The string may contain a single channel, channel pattern, or analog backplane relay, as well as multiple ones that are indicated by a range or comma-delimited.
- Use a colon between the start and end channel to specify a range of channels. The lowest channel must be first and the highest last.

Examples:

- To perform an open or close operation on channels 1 and 3 of slot 1, use ("1001, 1003") for the *channelList* parameter.
- To perform an open or close operation on all channels within the range of channels 1 through 5 of slot 1, use ("1001:1005") for the *channelList* parameter

Queries that return a list of channels

For queries that return a channel list parameter, a channel configured for 4-pole operations will indicate the paired channel in parentheses. For example, if channel 3003 on a 60-channel card is configured for 4-pole, its paired channel is 3033. Notice the response to the query in the code example below:

```
channel.close('3003')
print(channel.getclose('slot3') → 3003(3033)
```

Return value

Several of the channel functions return a value for specified channels and channel patterns.

The return value for these functions is a string containing a list of comma-delimited return items. The *channelList* argument of the remote command determines the number and order of these returned items.

When the *channelList* parameter for these functions is "slotX", the response first lists the channels starting from lowest to highest. More specifically, the channels are returned in numeric order.

When the *channelList* parameter for these functions is "allslots", the response starts with slot 1 and increases to slot 6 for the Series 3700A. Each slot is processed completely before going to the next. Therefore, all slot 1 channels are listed before slot 2 channels.

When the response is numeric, but in string format, use the `tonumber()` function to convert the string to a number. For example, sending these commands:

```
x = tonumber("1403")
print(x)
```

Results in:

```
1.403000000e+03
```

When the response is a comma-delimited string, the individual return items can be identified by iterating through the list using the comma delimiters. For example, the Lua code below will start at the beginning of a string and break the string into individual items at each comma. The `tonumber()` function is used on each item to determine if it is a number or not. In either case, the value is printed.

```
index1 = 1
index2 = 1
text = "123,abc,hello,4.56"
endIndex = string.len(text)
while index2 ~= endIndex do
    index2 = string.find(text, ",", index1)
    if not index2 then
        index2 = endIndex
    end

    subString = string.sub(text, index1, index2 - 1)
    if not number(subString) then
        print(subString)
    else
        print(tonumber(subString))
    end
    index1 = index2 + 1
end
```

Selecting a range of channels on the front panel

You can perform operations on a single channel or range of channels. Specify a channel range by selecting a starting channel number and ending channel number. When you request an operation be performed on a range of channels, the Series 3700A performs the same operation on all channels within the channel range.

To select a channel range on the front panel (for example, channels 1003 through 1005):

NOTE

A single channel is selected when the starting and ending channel for a range match.

You cannot explicitly select an analog backplane relay on the front panel interface. You can only associate a backplane relay with a switching module channel. Refer to [Channel attributes](#) (on page 2-93) for further details.

1. To change the present slot, press the navigation wheel . The first digit of the four-digit channel number flashes, indicating edit mode.
2. Turn the navigation wheel  to change the number to select any slot that has a switching module or pseudocard installed. For example, change the digit to a 1.
3. Press the navigation wheel  a second time. This accepts the slot selection and selects edit mode for the channel. Digits two through four of the four-digit channel number flash, indicating edit mode.
4. Turn the navigation wheel  to change the starting channel number. You can select any channel available for the selected slot's module. For example, change the digits to 003.
5. Press the navigation wheel  a third time. This accepts the channel selection and selects edit mode for the channel range. Digits two through four of the smaller four-digit channel number flash, indicating edit mode.
6. Turn the navigation wheel  to change the ending channel number. You can select any channel available for the selected slot's module. For example, change the digits to 005.
7. Press the navigation wheel  a fourth time to accept the channel selection.
8. Press the navigation wheel  a fifth time to return to the main display after selecting the desired user configuration for the channel range.
9. Press the **CONFIG** key, followed by the **CHAN** key to change other channel attributes for the range. Similarly, press the **CHAN** key without the **CONFIG** key to bring up the CHANNEL ACTION MENU for use with the selected channel range.

Working with channels

Connection methods for close operations

You can dictate the order in which relays are opened and closed using the channel connection rule.

WARNING

When the connection rule is set to break before make, the instrument ensures that all switch channels open before any switch channels close. This behavior covers the most common applications and is considered the safest connection rule because the tested device is completely decoupled from the instrument. This is the default behavior. When switch channels are both opened and closed, this command executes not less than the addition of both the open and close settle times of the indicated switch channels.

When the connection rule is set to make-before-break, the instrument ensures that all switch channels close before any switch channels open. This behavior should be applied with caution because it will connect two test devices together for the duration of the switch close settle time. When switch channels are both opened and closed, the command executes not less than the addition of both the open and close settle times of the indicated switch channels.

With no connection rule (set to `channel.OFF`), the instrument attempts to simultaneously open and close switch channels in order to minimize the command execution time. This results in faster performance at the expense of guaranteed switch position. During the operation, multiple switch channels may simultaneously be in the close position. Make sure your device under test can withstand this possible condition. When switch channels are both opened and closed, the command executes not less than the greater of either the open or close settle times of the indicated switch channels.

Cold switching is highly recommended.



CAUTION

Hot switching can dry weld reed relays such that they will always be on. Hot switching is recommended only when external protection is provided.

The channel connect rule determines the order in which multiple channels are opened and closed on the instrument. This attribute applies to electromechanical, reed, and solid state relay switching cards.

You can set the channel connect rule to be:

- **BBM** (break before make): The instrument ensures that all switch channels open before any switch channels close. It is used to avoid momentary shorting of two voltage sources. This is the default.
- **MBB** (make before break): The instrument ensures that all switch channels close before any switch channels open. It is used to eliminate transients caused by switching between current sources. MBB should be applied with caution because it connects two test devices together for the duration of the switch close settle time.
- **OFF**: Permits the instrument to initiate close and open operations simultaneously. This minimizes settling time for the close operation.

NOTE

You cannot guarantee the sequence of open and closure operations when the channel connect rule set to OFF. It is highly recommended that you implement cold switching when the channel connect rule is set to OFF.

To set the channel connect rule through the front panel interface:

1. Press the **MENU** key.
2. Use the navigation wheel to scroll to the CHANNEL menu item.
3. Press the **ENTER** key (or the navigation wheel) to display the CONNECT MENU.
4. From this menu, select the RULE menu item.
5. Set the rule to BBM, MBB, or OFF.
6. Use the **ENTER** key to apply the selection.
7. Use the **EXIT** key to leave the menu.

To set the channel connect rule through the web interface:

1. On the Unit page, in the upper left corner, select the channel connect rule menu.
2. Select Break Before Make, Make Before Break, or OFF.

To set the channel connect rule through the remote command interface:

Use the `channel.connectrule` command. Refer to the [Command reference](#) (see "[Commands](#)" on page 8-10) for details.

Using sequential connect

During normal operation, the instrument attempts to minimize the duration of any channel action for a given card type and connect rule. This can result in multiple channels closing or opening simultaneously.

To prevent simultaneous closing and opening, you can use a sequential connection. A sequential connection ensures an orderly closing or opening of single individual channels in a channel list. An orderly action provides for:

- Repeatable and deterministic channel operation times
- Minimized power usage

You incur settling times at each close or open operation. If sequential connection is not selected, action settling times may vary depending on the card type. The total settling time is the sum of the settling times for each specified channel, plus any user delays that have been set for any closed channels. To better calculate timing, you can enable sequential channel connections. Deterministic implies that you can determine the time for a close operation to happen. For example, if you close three channels and each takes 4 ms to close, with sequential on, it will take 12 ms. With sequential off, it may be 4, 8 or 12 ms, depending on whether or not the card can close multiple channels at once.

Opening and closing relays in a sequential manner also uses minimum power. Since only one relay is closed or opened at any given time, the power used for that action is for a single relay and not additive.

By default, sequential connections are turned off. The order in which channels are opened or closed is not guaranteed. This feature also applies to scanning.

The sequential setting affects all channels in the instrument.

When specifying multiple channels for a single close or open operation, the total settling time depends on the relay drive scheme for the switching module — how each switching module budgets power to change the state of its relays. The Series 3700A supports the following relay drive schemes:

- **Direct Drive:** You can simultaneously update the state of all relays on a switching module with a single close or open operation. The total settling time for a close or open operation is the settling time for a single relay.
- **Matrix Drive:** You can execute a close or open operation on a list of channels, which can result in multiple actions to update the state of all specified relays. Settling time varies depending on the capabilities of the card and the number of relay closures.
- **Hybrid Matrix Drive:** For a single close or open operation, the state of all relays can be updated in no more than two steps. The total settling time for a close or open operation does is less than twice the settling time for a single relay.

To enable sequential connections through the front panel interface:

1. Press the **MENU** key.
2. Use the navigation wheel to scroll to the CHANNEL menu item.
3. Press the **ENTER** key.
4. Select the SEQUENTIAL menu item.
5. Select ON or OFF.
6. Use the **ENTER** key to apply the selection.
7. Use the **EXIT (LOCAL)** key to leave the menu.

To enable sequential connections through the web interface:

1. Open the **UNIT** page.
2. In the upper left corner, select the Sequential check box (next to the Channel Connect Rule list).

To enable sequential connections through the remote command interface:

Send the command:

`channel.connectsequential` (on page 8-53)

Determining the number of relay closures

The Series 3700A keeps an internal count of the number of times each switching card relay has been closed. The total number of relay closures is stored in nonvolatile memory on the switching card. Use this count to determine when relays require replacement (see the card documentation for information regarding the contact life specifications).

Relay closures are counted only when a relay transitions from open to closed state. If you send multiple close commands to the same channel without sending an open command, only the first closure is counted.

This option is not displayed if multiple channels are selected. A backplane relay has a close count associated with it as well; the number of closures are the closures that have occurred over the lifetime of the card. To view the close count for a channel from the front panel:

NOTE

You cannot query backplane relay closure counts through the front panel. You must use the remote command interface.

1. Use the navigation wheel  to select the channel.
2. Press the **CONFIG** key.
3. Press the **CHAN** key.
4. Use the navigation wheel to scroll to the "COUNT" menu item.
5. Press the **ENTER** key (or the navigation wheel) to display the close counts.
6. Use the **EXIT** key to leave the menu.

To view the close count for a channel from the web interface:

1. From the list on the left, select a slot with an installed card.
2. Right-click a channel. The Channel Configuration dialog box is displayed.
3. Check the value in the Closure Count box.

NOTE

You can also work with channel patterns using the command `channel.getcount()`.

Viewing the close or open status of a channel

To determine whether a channel or backplane relay is closed or open, you can view its status using the front panel interface, remote command query, or instrument web page.

Viewing status from the front panel

Closed channels are shown on the display of the instrument, separated by commas. If more than one line of closed channels are displayed, you can press **DISPLAY** to display the full list. Use the navigation wheel  to scroll through the list.



NOTE

For a four-pole operation the paired channel is not displayed on the front panel of the Series 3700A.

Viewing status from the remote command interface

To view a list of closed channels, use the `channel.getclose()` command. For example:

```
print(channel.getclose("allslots"))
```

To view the close and open status of channels, use the `channel.getstate()` command.

Viewing status from the instrument web page

To view status from the instrument web page, from the list on the left, select the slot that contains the channel. The status is displayed on the web page for the slot.

Channel attributes

You can use the front panel and command options to set attributes for specific channels. Some of the attributes you can set are adding a delay, forbidding closure of a channel, and setting channel labels, which are described in the following sections.

Setting and querying channel attributes

You can view and edit channel attributes on the front panel using the channel attributes menu. To access the channel attributes menu, press the **CONFIG** key and then press the **CHAN** key. Use the navigation wheel and **CURSOR** keys to change attribute values. Use the **ENTER** and **EXIT** keys to apply or cancel settings.

With the exception of the DMM configuration attribute, you can view and edit channel attributes using the remote command interface using the commands residing in the channel logical instrument. For example, to set the label attribute of a channel, use the `channel.setlabel` command; to retrieve the label attribute of a channel, use the `channel.getlabel` query.

To set the DMM configuration attribute for a channel or group of channels, use the `dmm.setconfig` command and specify the desired channels in the `<ch_list>` parameter. To retrieve the DMM configuration attribute for a channel or group of channels, use the `dmm.getconfig` query.

For specific instructions on retrieving the relay closure count attribute, refer to [Relay closure count](#) (see "[Determining the number of relay closures](#)" on page 2-92).

Set additional delay

You can set an additional delay to incur after the relay settles when closing.

To set additional delay time from the front panel:

1. Display a channel (you might need to press **DISPLAY**).
2. Select the channel for which you want to set attributes.
3. Press **CONFIG**, then press **CHAN**.
 - **DELAY:** Additional delay to incur after the relay settles. Enter the value for the delay in seconds. The total delay for channel operation is user delay plus the relay settling time.

To set additional delay time from the web interface:

1. From the list on the left, select the slot that contains the channel you want to set an additional delay on.
2. Right-click on the channel you want to bring up the channel configuration dialog box for that channel.
3. Enter the desired delay time (in seconds) in the delay time field on the right side of the dialog box. Once the desired time is entered, click **OK**.

To set additional delay time through the remote interface:

Use the command:

```
channel.setdelay() (on page 8-93)
```

Forbid closing a channel

You can prevent a channel from being closed from any interface by setting it to forbidden.

NOTE

If the channel that is to be forbidden is used in a channel pattern, the pattern is deleted when you set the channel to be forbidden to close. An analog backplane relay can be marked as forbidden to close. Analog backplane relays only support the forbidden setting attribute.

To forbid closing of a channel from the front panel:

1. Display a channel (you might need to press **DISPLAY** first).
2. Select the channel for which you want to set attributes.
3. Press **CONFIG**, then press **CHAN**.
4. Use the navigation wheel  to select **FORBID**.
5. Select Yes to prevent a channel from being closed or No to allow closures.
6. Press the navigation wheel  to save the change.

To forbid closing of a channel from the web interface:

1. From the list on the left, select the slot that contains the channel you want to forbid close on.
2. Right-click the channel.
3. Select the forbidden checkbox.
4. Click **OK**.

To forbid closing of a channel from the remote interface:

You can also set this attribute using the following commands:

- `channel.setforbidden()` (on page 8-94)
- `channel.clearforbidden()` (on page 8-49)

Set up labels

You can define labels for channels.

Labels must be unique; they cannot have the same as the name of another channel or channel pattern. Labels cannot contain spaces, and they do not persist through a power cycle.

You cannot apply a label to a range of channels.

Channel labels can be up to 19 characters.

You can only set labels for channels that are installed in the instrument.

To set up labels from the front panel:

1. Display a channel (you might need to press **DISPLAY** first).
2. Select the channel for which you want to set labels.
3. Press **CONFIG**, then press **CHAN**.
4. Use the navigation wheel  to select **LABEL**, which allows you to set the label that will show on the front-panel for the specified channel.
5. Change the name using the navigation wheel .
6. Press the navigation wheel  to save the change.

To set up labels from the web interface:

1. From the list on the left, select the slot that contains the channel you want to set up a label on.
2. Right-click the channel.
3. In the Label box, enter the label.
4. Click **OK**.

To set up labels from the remote interface use the [channel.setlabel\(\)](#) (on page 8-94) command.

You can use labels to refer to the channels in commands. For example, if you set the label for channel 3005 to "start", you could use "start" to close and open the channel.

This is shown in the following example:

```
channel.setlabel("3005","start")
channel.close("start")
print(channel.getclose("allslots"))
```

Pole settings

- **BACKPLANE RELAYS:** List of backplane relays to control when performing a switch-only operation on a single channel or range of channels. This attribute is not applicable to channel patterns. Refer to Channel patterns.
- **POLE SETTING:** Pole setting for multiplexer (MUX) channels indicates if the paired MUX channel should be included when performing a close or open operation on channel. In a switching module that has 60 channels, the Series 3700A automatically pairs Channels 1 through 30 with Channels 31 through 60 (respectively) when the pole setting for a channel is set to 4-pole. Once you configure the pole setting of a switching channel for 4-pole, the associated paired channel becomes unavailable for switching operation. For example, assume 3003 is set to 4-pole and its paired channel is 3033. Now, you cannot set attributes or perform close/open operations on 3033. A paired channel settings conflict error generates if you specify Channel 3033 for a close/open operation.

NOTE

Matrix channels have fixed pole settings. Multiplexer channels pole settings may be changed.

Channel patterns

You can use channel patterns as a convenient way to refer to a group of switching channels and backplane relays with a single alphanumeric name. When you perform close or open operations on a channel pattern, only the channels and analog backplane relays that are in the channel pattern are affected.

There is no speed difference when performing close and open operations on channel patterns compared to performing the same operations on individual channels or a list of channels.

Assigning channel pattern attributes

A channel pattern has only two attributes: the channel pattern name and a DMM configuration. An error occurs if you attempt to assign or query any channel attributes other than DMM configuration for a channel pattern.

You associate a name with a channel pattern when you create the pattern.

To assign a DMM configuration to a channel pattern using the front panel interface use the PATTERN ATTRIBUTES menu. You must create the channel pattern before you can access the PATTERN ATTRIBUTES menu. To access this menu after creating a channel pattern, press the **CONFIG** key followed by the **PATT** key.

To assign a DMM configuration to a channel pattern using the remote command interface, use the `dmm.setconfig` command and specify the channel pattern name for the `channelList` parameter. To retrieve the DMM configuration attribute for a channel pattern, use the `dmm.getconfig` query and specify the channel pattern name for the `channelList` parameter.

Pole settings and channel patterns

NOTE

Changing a channel's pole setting deletes all patterns containing that channel.

Set the pole setting of switching module channels prior to creating a channel pattern image. If you change the pole setting for a channel, the Series 3700A will delete any patterns that contain that channel. For example, assume a channel pattern called 'myimage' has channels 2004, 2008 and 2012 associated with it while 'myimage2' has channels 2005, 2009 and 2011. Now, if pole setting of Channel 2004 changes then the channel pattern 'myimage' is deleted and no longer exists in system. However, the pattern called 'myimage2' still exists.

While creating channel pattern images, the paired channel is automatically accounted for based on pole setting. Therefore, you do not need to manually specify the paired channel in the channel pattern image. For example, assume Slot 1 has a 3720 card installed and all channels are set to 4-pole operation. With all channels configured for 4-pole, the available channels are 1001 to 1030. To create a channel pattern called 'one4wire' with Channel 1001 and backplane relays 1911 and 1922, the corresponding bus command is:

```
channel.pattern.setimage('1001, 1911, 1922', 'one4wire')
```

To see the image associated with a channel pattern, use the `channel.pattern.getimage` command. For example, to see the image of the pattern, just created called 'one4wire':

```
print(channel.pattern.getimage('one4wire')) → 1001(1031),1911,1922
```

NOTE

Paired channel are indicated in parentheses in `<ch_list>` queries.

Create a channel pattern

When you create a channel pattern, make sure to:

- Include all the channels and backplane relays that are needed for that channel pattern.
- Check that channels contained in the pattern are correct.
- Check that channels contained in the pattern create the desired path connection.
- Make sure that channels that you want to include in the pattern are not set to forbidden to close.

When naming the channel pattern, be aware:

- The first character of the name must be alphabetic (upper or lower case)
- Names are case sensitive
- Pattern names must be different than channel labels

Performing close and open operations on channel patterns



WARNING

Careless channel pattern operation could create an electric shock hazard that could result in severe injury or death. Improper operation can also cause damage to the switching cards and external circuitry. The control of multiple channels using channel patterns should be restricted to experienced test engineers who recognize the dangers associated with multiple channel closures.

You can close and open channel patterns the same way you do for individual channels.

When you request a close or open operation, the Series 3700A verifies that the channels exist for a pattern, but does not verify that the switch path connection is correct. You must ensure the requested operation is safe for a channel pattern and that a good connection will result for your application with the channel pattern.

Channel pattern storage

Channel patterns are:

- Part of saved setup data and restored when a setup is recalled.
- Deleted when the instrument is reset or has a pole setting change.
- Deleted when a channel associated with the pattern is reset.
- Allocated 32KB of memory in the Series 3700A instrument for all channel patterns.

The number of channel patterns you can store varies with the number of characters of the channel pattern name, the number of characters used in listing the switching channels, and the number of characters in the name of the DMM configuration. 32KB of memory is equivalent to 32,000 characters. If each channel pattern name is five characters long, and each pattern is comprised of five channels, and the channel list is comma delimited (for example, "2003,4003,2005,4005,2915"), then you can store 642 channel patterns. You can store additional channel patterns by decreasing the number of characters in each channel pattern name or the number of channels in the channel pattern image. Conversely, you store fewer than 642 channel patterns by increasing the number of characters in the channel pattern name or number of channels in the channel pattern image.

To see how much of the channel pattern memory is available or used, send the command:

```
print(memory.available())
```

or

```
print(memory.used())
```

Refer to `memory.available()` (on page 8-303) or `memory.used()` (on page 8-304).

Reset a channel

You can reset a channel to its factory default settings. When you reset a channel:

- Any closed channels and analog backplane relays open
- The poles of all channels reset to 2-pole operation and paired channels are changed to match
- Additional user delay is set to zero
- Labels return to default of SCCC or slot, row, column
- Analog backplane relays specified by the `channel.setbackplane()` function are cleared
- If the channel is forbidden to close, it is cleared from being forbidden to close
- If the channels are used in channel patterns, the channel patterns that contain the channels are deleted.
- The DMM configurations of all channels are set to `nofunction`

Using this function to reset a channel or backplane relay involved in scanning invalidates the existing scan list. The list has to be recreated before scanning again.



CAUTION

Resetting a channel deletes any channel patterns that contain that channel.

To reset a channel from the front panel:

1. Display a channel.
2. Select the channel you want to reset.
3. Press **CHAN**.
4. Select **RESET**.
5. Select **SELECTED**, **ALL**, or **CANCEL**.
6. Press the navigation wheel  to reset the channel.

To reset all channels on a slot from the web interface:

1. Select the slot that contains channels you want to reset.
2. Click **RESET SLOT**.
3. All channels on the slot are reset.

To reset a channel from the remote interface:

Send the command `channel.reset()` (on page 8-88).

Pseudocards

You can perform open, close, and scan operations and configure your system without having an actual switching card installed in your instrument. Using the remote interface, you can assign a pseudocard to an empty switching card slot, allowing the instrument to operate as if a switching card were installed.

A pseudocard cannot be configured from the front panel. However, once the remote configuration is complete, you can take the instrument out of remote mode and use the front panel. Press the **EXIT** key to take the instrument out of remote mode.

When the instrument is turned off, the pseudocard is no longer assigned to the slot.

NOTE

A saved setup or created configuration script retains the model number of the card installed in each slot. The model number of a pseudocard is the same as the model number of an actual card (except for Model 3732 cards; see the "Pseudocard support for the Model 3732" topic in the Series 3700 Switch and Control Cards Reference Manual for details). This allows a saved setup or created configuration script to be recalled if the installed card (or pseudocard) matches the model number for the slot in the saved setup or created configuration script.

Pseudocards programming example

Use the following command to set the pseudocard of slot 6 for 3720 Dual 1 x 30 Multiplexer card simulation:

```
slot[6].pseudocard = 3720
```

Alternatively, you could send the following command:

```
slot[6].pseudocard = 3720
```

Save the present configuration

You can capture the present settings of the instrument using the create configuration script feature. When you run this feature, the configuration script is created and saved. You can run it later to return to that configuration, or set it up to be the autoexec script. The configuration script is a normal TSP script; once created, you can use it and modify it as you would any other script.

The configuration script includes:

- Comment lines that identify the script as auto created and the date and time of creation.
- The cards that are installed and the slots in which they are installed.
- A reset command, which will reset the instrument to the factory default settings.
- The commands to reconfigure the instrument. The configuration script only captures settings that have been changed from the factory defaults.

Later, when you run the configuration script, the script will verify that the installed cards and slots match. If they do not, a message is displayed, the script stops, and the configuration is not restored.

Note that the configuration script does not include the status of channels. As initially created, the configuration script performs a reset, which opens all channels.

NOTE

You can modify the script to change the card models or slots. However, you must make sure that all subsequent commands are valid for the card model or slot change.

NOTE

For more information on scripts, see [Fundamentals of scripting for TSP](#) (on page 7-1). For more information on the autoexec script, see [Autoexec script](#) (on page 7-7).

A sample configuration script is shown in the following example.

<code>--Auto created configuration script</code>	Indicates that this was created with the Create Configuration Script feature
<code>--Tue Jul 13 13:02:12 2010</code>	Date and time stamp
<code>if string.find(slot[1].idn, "7174") == nil then print("Card installed in slot 1 needs to be a 7174.") display.clear() display.settext("Card installed in\$N" .. "\$Bslot 1\$R needs to be a \$B7174\$R")</code>	Code that verifies that card and slot are in agreement
<code>else</code>	
<code> reset()</code>	Reset command
<code> channel.setlabel("1A01", "FirstRowCol") channel.setlabel("1A12", "LastRowCol") channel.setlabel("1B01", "FirstNextRow") channel.setlabel("1B12", "LastNextRow") channel.pattern.setimage("1A01,1B01", "Row1_2_col_1") channel.pattern.setimage("1A02,1B02", "Row1_2_col_2") channel.pattern.setimage("1A03,1B03", "Row1_2_col_3") channel.pattern.setimage("1A04,1B04", "Row1_2_col_4") channel.pattern.setimage("1A05,1B05", "Row1_2_col_5") channel.pattern.setimage("1A06,1B06", "Row1_2_col_6") channel.pattern.setimage("1A07,1B07", "Row1_2_col_7") channel.pattern.setimage("1A08,1B08", "Row1_2_col_8") channel.pattern.setimage("1A09,1B09", "Row1_2_col_9") channel.pattern.setimage("1A10,1B10", "Row1_2_col_10") channel.pattern.setimage("1A11,1B11", "Row1_2_col_11") channel.pattern.setimage("1A12,1B12", "Row1_2_col_12") collectgarbage() scan.trigger.channel.stimulus = scan.trigger.EVENT_CHANNEL_READY scan.create() scan.mode = 0 scan.bypass = 1 scan.add("Row1_2_col_1") scan.add("Row1_2_col_2") scan.add("Row1_2_col_3") scan.add("Row1_2_col_4") scan.add("Row1_2_col_5") scan.add("Row1_2_col_6") scan.add("Row1_2_col_7") scan.add("Row1_2_col_8") scan.add("Row1_2_col_9") scan.add("Row1_2_col_10") scan.add("Row1_2_col_11") scan.add("Row1_2_col_12")</code>	Code that captures the non-factory default settings
<code>end</code>	

Create a configuration script

When you run the create configuration script feature, it automatically generates a user script that is saved to a script with a name that you define. Create configuration script is available from the front panel of the instrument, the web interface, and the remote interface.

NOTE

When you specify the name of the script, be aware that if you specify a name that already exists (including `autoexec`), the existing script is overwritten with the new configuration script.


To create a configuration script from the front panel:

1. Press **MENU**.
2. Select **SCRIPT**.
3. Select **CREATE-CONFIG**. The AUTOEXEC ON PWR UP prompt is displayed.
4. Select **Yes** or **No**.
5. If AUTOEXEC is set to no, at the name prompt, enter the name of the configuration. The default name is config01.
6. Press **ENTER**.
7. The AUTOEXEC message is displayed again. Press **EXIT** several times to return to the normal display.

To create a configuration script from the web interface:

1. Open the **Unit** page.
2. Log in if necessary.
3. Click **Create Config Script**.

Figure 2-42: Create Config Script dialog box



4. To make the configuration script the autoexec script, select Auto-execute on powerup.
5. To assign a name (the script will not be the autoexec script), select Name and enter a name in the box.
6. Click **OK**. The configuration script is created.

To create a configuration script from the remote interface:

Send the command:

```
createconfigscript (name)
```

Where *name* is the name you want to assign to the configuration script.

Running the configuration script

You can run the configuration using the same methods as any other script. See [Run scripts](#) (on page 7-5) for information.

Functions and features

In this section:

Scanning and triggering	3-1
Files	3-23
Display operations.....	3-31
Digital I/O	3-42
Reading buffers.....	3-50

Scanning and triggering

Introduction to scanning and triggering

A scan is a series of steps that opens and closes switches sequentially for a selected group of channels. During each step, actions occur, such as waiting for a trigger, taking a measurement, and completing a step count. Scans automate actions that you want to perform consistently and repeatedly on a set of channels.

Triggers are events that prompt the instrument to move from one step to another in a scan. Triggers can come from a variety of sources, such as a key press, digital input, or expiration of a timer. The sequence of actions and events that occur during the scan is called the trigger model.

Scanning and triggering allow you to synchronize actions across channels. You can set up a scan using the trigger model to precisely time and synchronize the Series 3700A between channels and multiple instruments. You can also use triggers without the triggering model to set up a scan to meet the needs of a specific application that does not fit the triggering model.

You can configure and run scans from the front panel, over a remote communication interface, or through the web interface. If you are using the communication interface or the web interface, the scan is a set of actions determined by the trigger model. If you use the front panel, key presses determine the order of the scan.

The Keithley Instruments Series 3700A can scan channels with up to six Keithley Instruments switching cards installed. Each scan channel can have its own unique setup. Aspects of operation that may be uniquely set for each channel include function, range, rate, AC bandwidth, REL, filter, digits, math, offset compensation, temperature transducers, limits, volts dB, and so on.

NOTE

If desired, readings for scanned channels may be automatically stored in a specified reading buffer (Buffer: Data Storage and Retrieval).

Trigger model

When you run a scan, the scan sequence follows a trigger model. The trigger model is shown in the following flowchart.

NOTE


In Series 3700A, only scanning operations use the trigger model. Individual open, close, and measure commands do not affect the trigger model.

The trigger model is used during a scan only. For front panel operation, you use the **SCAN** and **STEP** keys to perform scan actions. For remote operation, you use the scan functions and attributes commands, for example, `scan.execute()` and `scan.mode`.

NOTE

You cannot use an external trigger event (for example, digital I/O) for the channel stimulus setting of the trigger model when using the front-panel STEP key.

Figure 3-1: Trigger model



Trigger model components

The individual components of the trigger model are explained in the following paragraphs.

Trigger model events and associated commands

The Model 3706A trigger model has the following events and associated command attributes. These events, along with other events in the system, may be used to configure various stimulus settings.

For example, the channel ready event (`scan.trigger.EVENT_CHANNEL_READY`) may be set to pulse digital I/O line 3 when it gets generated. The command message for this would be:

```
digio.trigger[3].stimulus = scan.trigger.EVENT_CHANNEL_READY
```

Likewise, you can use the digital I/O line 5 trigger event to satisfy the scan trigger channel stimulus, which causes the channel action to occur when a trigger is detected on line 5. The command message for this is:

```
scan.trigger.channel.stimulus = digio.trigger[5].EVENT_ID
```

Event	Associated attribute
Scan Ready Event	<code>scan.trigger.EVENT_SCAN_READY</code>
Scan Start Event	<code>scan.trigger.EVENT_SCAN_START</code>
Channel Ready Event	<code>scan.trigger.EVENT_CHANNEL_READY</code>
Measure Complete Event	<code>scan.trigger.EVENT_MEASURE_COMP</code>
Sequence Complete Event	<code>scan.trigger.EVENT_SEQUENCE_COMP</code>
Scan Complete Event	<code>scan.trigger.EVENT_SCAN_COMP</code>
Idle Event	<code>scan.trigger.EVENT_IDLE</code>

NOTE

Scanning operations run through the trigger model, but individual open, close, and DMM measure commands have no interaction with the trigger model.

Scan and step counts

When running a scan, it may be necessary to determine the scan progress. You can use `scan.state()` to read the scan and step count to determine the point in the scan table being executed.

"Scan count" represents the number of the current iteration through the scan portion of the trigger model. This number does not increment until after the scan begins. Therefore, if an instrument is waiting for an input to trigger a scan start, the scan count represents the previous number of scan iterations. If no scan has yet to begin, the scan count is zero.

"Step count" represents the number of times the scan has completed a pass through the channel action portion of the trigger model. This number does not increment until after the action completes. Therefore, if the instrument is waiting for an input to trigger a channel action, the step count represents the previous step. If no step has yet to complete, the step count is zero. If the step count has yet to complete the first step in a subsequent pass through a scan, the scan count represents the last step in the previous scan pass.

For example:

- `1003:1005` will add Channels 1003, 1004, and 1005 to the list as three distinct steps, with Channel 3 added first, Channel 4 added second, and Channel 5 added third.
- Adding individual channels in the order of 1003, 1005, and 1004 will add the channels to the list as three distinct steps with Channel 3 added first, Channel 5 added second, and Channel 4 added last.

Basic scan procedure

NOTE

It is always better to configure all channel and DMM attributes before creating a scan. You cannot use an external trigger event, like digital I/O, for the channel stimulus setting of the trigger model when using the front panel **STEP** key. For more information, see Scanning and [Trigger model](#) (on page 3-1).

To perform a scan:

1. Configure the channels for scanning as needed.
2. Select (or create, if necessary) the reading buffer to store measurements (if desired).
3. Build the scan list:
 - **Front panel:** Press the **INSERT** key. The steps are executed in the order in which they are added. When adding a range of channels, they are added to the end of the existing scan list.
 - **Remote interface:** Send the `scan.create()`, `scan.add()`, or `scan.addimagestep()` command.
4. Configure the scan settings (for example, scan count, bypass, mode, and so on).
5. To start the scan:
 - **Front panel:** Press the **STEP** key or the **SCAN** key and select the **BACKGROUND** menu item.
 - **Remote interface:** Send the command `scan.execute` or `scan.background`.

6. The trigger model leaves the idle state and performs actions on the channels involved in scanning, along with channels that would interfere with scanning, such as AMP channels, analog backplane relays 1 and 2 on all slots, commonside ohm backplane channels, and other channels in banks involved in scanning.

- **Front panel:** When you press the **STEP** key, the Model 3706A leave the idle state and perform the channel action associated with the first step in the scan list.

Measurements are then taken (if part of the scan). If a reading buffer was selected, the result from the measurements are stored there. The measurement action, if started, is completed. The channel and DMM remain as previously configured until the next step in the scan is initiated. The DMM configuration changes to the attribute settings tied to the channel in the next step.

NOTE

While scanning is enabled, pressing most front panel keys will display the message "ERROR CODE : 5522 Scan Running, Must Abort Scan."

7. The channels are scanned or stepped in the order they were added to the list.
 - **Front panel:** If you are stepping through the scan, press the **STEP** key to proceed to the next step in the list.
 - **Remote interface:** You cannot step a scan remotely over the bus.
8. To abort the scan:
 - **Front panel:** Press the **EXIT** key.
 - **Remote interface:** Use the `scan.abort()` ICL command.

NOTE

Even if the scan is aborted, the DMM remains as configured in the last completed step of a scan that involved measuring and channel states match the aborted state of channels in terms of which are closed and opened.

The DMM remains as previously configured in the last completed measurement step of a scan that involved measuring. The function associated with that configuration will have the associated DMM attributes updated to match. All other functions will remain as configured prior to scanning.

If configured to scan the channels in the scan list again, the Series 3700A waits at the control source for another trigger event. After the scan is complete, the Series 3700A outputs another trigger pulse, if configured to do so. After all requested scans are complete, the instrument returns to the idle state with the channels associated with last scan step closed.

Buffer

To recall scanned readings stored in the buffer, press the **REC** key and turn the navigation wheel to navigate through the buffer. See [Recalling readings](#) (on page 3-53) for details on recalling buffer readings. When finished, make sure to exit from buffer recall (press the **EXIT** key). Also see [Reading buffers](#) (on page 3-56, on page 3-50).

Changing attributes of an existing scan

When a scan already exists, changing channel and DMM attributes also causes the scan to change. Once a scan list has been defined, the Series 3700A tries to incorporate your changes into the scan. For example, changing a DMM configuration assigned to a channel used in scanning affects the scan list. But changing a DMM configuration on a channel not involved in scanning does not affect the scan list. If the change impacts the ability of the scan to function properly (such as deleting something referenced by the scan), an error message is logged and the scan list may be cleared.

To see how the scan list may have changed, view the current scan list:

1. Press the **SCAN** key when on the main display.
2. Select the **LIST** option and press the **ENTER** key.
3. Use the navigation wheel or **CURSOR** keys to scroll through the list.

For remote operation, use the `scan.list()` function.

For performance reasons, it is always better to configure all channel and DMM attributes before creating a scan. Afterward, changes may cause the scan to take more time to modify the scan list.

You can clear an existing scan list before making any changes after making a scan list. From the front panel, press the **SCAN** key and select the **CLEAR** option. For bus operation, use the `scan.create()` function.

Some changes may cause channels to be dropped from the list when they become paired with another channel for a 4-wire operation. These channels will not be added back into the list during subsequent changes that free the paired channel from a 4-wire operation. To get a recently unpaired channel back in the list, create a new scan list or add it back into the list.

For example, a scan list is comprised of Channels 1 to 60 on a Model 3720 card with the channels configured to measure DC volts. Changing Channels 1 to 30 to be configured for 4-wire ohms measurements causes the scan list to change. The scan list changes to contain Channels 1 to 30 measuring 4-wire ohms, and Channels 31 to 60 are removed because they are paired with Channels 1 to 30. If you then change Channels 1 to 60 to be configured for measuring DC volts, the scan list will still only contain Channels 1 to 30, but it will be measuring DC volts. Channels 31 to 60 are not automatically added back into the list.

The ICL commands to simulate this example follow. Assume the Model 3720 is in Slot 3:

```
-- Configure Channels 1 to 60 to measure DC volts.
dmm.setconfig('slot3', 'dcvolts')
-- Create a scan list, channels measuring DC volts.
scan.create('slot3')
-- View the scan list, 60 channels measuring DC volts.
print(scan.list())
-- Change Channels 1 to 30 to 4-wire ohms.
dmm.setconfig('slot3', 'fourwireohms')
-- List now has Channels 1 to 30 measuring 4-wire ohms.
print(scan.list())
-- Change back to DC volts on Channels 1 to 60.
dmm.setconfig('slot3', 'dcvolts')
-- List still has Channels 1 to 30, but measures DC volts.
print(scan.list())
```

To configure a scan from the SCAN ATTR MENU, while in an active scan list:

1. Press the **CONFIG** key.
2. Press the **SCAN** key. Modify any of the following menu items as desired:
 - **ADD**: Displays **Use INSERT** key. The related ICL is `scan.add`, without the optional DMM configuration.
 - **BYPASS**: Enables (ON) or disables (OFF) bypassing the first step of the first scan pass. Related ICL command: `scan.bypass` (on page 8-323).
 - **MODE**: Sets the scan mode value to one of the following:
 - OPEN_SELECT
 - FIXED_ABR
 -Related ICL command: `scan.mode()` (see "`scan.mode`" on page 8-330).
 - **MEAS_CNT**: Sets the measure count value. Related ICL command: `scan.measurecount` (on page 8-329).
 - **SCAN_CNT**: Sets the scan count value. Related ICL command: `scan.scancount` (on page 8-334).
3. Press the **EXIT** key to leave the menu.

Front-panel scanning

After channels have been added to the scan list, press the **SCAN** key to display the SCAN ACTION MENU. If no scan list exists, pressing the **SCAN** key will briefly display "No Scan List. Use INSERT to add selection."

The menu contains the following items:

- **BACKGROUND**: Runs scan list in the background
- **CREATE**: Displays **Use INSERT** key
- **LIST**: Displays the current scan list steps. Turn the navigation wheel to scroll through the list.
- **CLEAR**: Clears the existing scan list.
- **RESET**: Resets the unit's scan settings, which include scan count, clearing the scan list, and scan stimulus settings like scan trigger arm.

Press the **INSERT** key to add the selected channels or pattern to the existing scan list.

Press the **DELETE** key to remove the selected channels or pattern from the existing scan list. Only the first occurrence of the selected item is removed. For example, if Channel 3003 appears in the list three times and Channel 3003 is selected when the **DELETE** key is pushed, the first step using Channel 3003 will be removed (the remaining two will stay in the list).

When removing channels, channel patterns are not checked to determine if the channel being removed is associated with its image. To remove a channel pattern in a scan list, select the channel pattern to be removed, and then press the **DELETE** key. Continuing the previous example of Channel 3003, if 'mypat1' is comprised of Channels '3003, 3033, 3911, and 3922' when the remove request for Channel 3003 is made, it will not remove 'mypat1' from the list. To remove 'mypat1' from list, select the channel pattern 'mypat1' and press the **DELETE** key, which removes the step and all associated channels.

Press the **STEP** key to single step through a scan list.

Foreground and background scan execution

You can execute a scan in the foreground or background. Background execution allows you to query settings or access reading buffer data. If a scan is running in the foreground, it will need to finish or be aborted before you can query any settings or access reading buffers.

When a scan is running in the background, you can send commands to be processed. The commands that you can use include most of the command messages that you use to query for settings, for example:

```
print(dmm.func)
printbuffer(1, 5, rb)
print(scan.state())
```

Most of the commands to change how the instrument is configured will log the following error message to the error queue:

```
5522, Scan Running, Must Abort Scan
```

Include multiple channels in a single scan step

Through the remote control interface, you can use `scan.addimagestep` to combine a list of channels into a scan step.

The following example creates five scan steps with the indicated channels.

```
scan.create()
scan.addimagestep("1A01, 1B01, 1C03")
scan.sddimagestep("1A03, 1B03, 1C03")
scan.addimagestep("1A05, 1B05, 1C03")
scan.sddimagestep("1A07, 1B07, 1C03")
scan.addimagestep("1A09, 1B09, 1C03")
```

Remote interface scanning

Scan and trigger commands

The following list contains commands associated with triggers and bus operation scanning:

- [lan.trigger\[N\].clear\(\)](#) (on page 8-284)
- [trigger.blender\[N\].stimulus\[M\]](#) (on page 8-422)
- [trigger.blender\[N\].wait\(\)](#) (on page 8-424)
- [trigger.timer\[N\].clear\(\)](#) (on page 8-426)
- [trigger.timer\[N\].stimulus](#) (on page 8-430)
- [digio.trigger\[N\].clear\(\)](#) (on page 8-122)
- [digio.trigger\[N\].pulsewidth](#) (on page 8-125)
- [digio.trigger\[N\].stimulus](#) (on page 8-127)
- [digio.trigger\[N\].wait\(\)](#) (on page 8-129)

- [lan.trigger\[N\].assert\(\)](#) (on page 8-283)
- [lan.trigger\[N\].clear\(\)](#) (on page 8-284)
- [lan.trigger\[N\].overrun](#) (on page 8-288)
- [lan.trigger\[N\].stimulus](#) (on page 8-290)
- [lan.trigger\[N\].wait\(\)](#) (on page 8-292)
- [scan.add\(\)](#) (on page 8-317)
- [scan.background\(\)](#) (on page 8-322)
- [scan.bypass](#) (on page 8-323)
- [scan.create\(\)](#) (on page 8-324)
- [scan.execute\(\)](#) (on page 8-326)
- [scan.list\(\)](#) (on page 8-327)
- [scan.measurecount](#) (on page 8-329)
- [scan.mode](#) (on page 8-330)
- [scan.reset\(\)](#) (on page 8-333)
- [scan.scancount](#) (on page 8-334)
- [scan.state\(\)](#) (on page 8-335)
- [scan.stepcount](#) (on page 8-336)
- [scan.trigger.arm.clear\(\)](#) (on page 8-336)
- [scan.trigger.arm.set\(\)](#) (on page 8-337)
- [scan.trigger.arm.stimulus](#) (on page 8-337)
- [scan.trigger.channel.clear\(\)](#) (on page 8-339)
- [scan.trigger.channel.set\(\)](#) (on page 8-340)
- [scan.trigger.channel.stimulus](#) (on page 8-340)
- [scan.trigger.clear\(\)](#) (on page 8-342)
- [scan.trigger.measure.clear\(\)](#) (on page 8-343)
- [scan.trigger.measure.set\(\)](#) (on page 8-343)
- [scan.trigger.measure.stimulus](#) (on page 8-344)
- [scan.trigger.sequence.clear\(\)](#) (on page 8-345)
- [scan.trigger.sequence.set\(\)](#) (on page 8-346)
- [scan.trigger.sequence.stimulus](#) (on page 8-347)

Hardware trigger modes

Use the hardware trigger modes to integrate Keithley Instruments and non-Keithley instruments into an efficient test system. The hardware synchronization lines are classic trigger lines. The Series 3700A contains 14 digital I/O lines and three TSP-Link synchronization lines that you can use for input or output triggering. The following table provides a summary for each hardware trigger mode.

Trigger mode	Output		Input	Notes
	Unasserted	Asserted	Detects	

Trigger mode	Output		Input	Notes
	Unasserted	Asserted	Detects	
Bypass	N/A	N/A	N/A	Use the <code>writetbit</code> and <code>writeport</code> commands for direct line control
Either edge	High	Low	Either	Short input pulses can cause a trigger overrun
Falling edge	High	Low	Falling	
Rising edge	N/A	N/A	N/A	<ul style="list-style-type: none"> The programmed state of the line determines if the behavior is similar to RisingA or RisingM High similar to RisingA Low similar to RisingM
Rising A	High	Low	Rising	
RisingM	Low	High	None	
Synchronous	High latching	Low	Falling	<ul style="list-style-type: none"> Behaves similar to SynchronousA Trigger overrun detection is disabled To mirror the SynchronousA trigger mode, set the pulse duration to 1 μs or any small nonzero value
SynchronousA	High latching	High	Falling	Ignores the pulse duration
SynchronousM	High	Low	Rising	

Each trigger mode controls the input trigger detection and output trigger generation. The input detector monitors for and detects all edges, even if the node that generates the output trigger causes the edge.

A trigger overrun generates if an input trigger is received before the previous input trigger processes. To determine if a trigger overrun has occurred, reference the trigger overrun attributes.

For additional information on the hardware trigger modes, see the [Command reference](#) (see "[Commands](#)" on page 8-10).

NOTE


To have direct control of the line state, use the bypass trigger mode.

Falling edge trigger mode


The falling edge trigger mode generates low pulses and detects all falling edges. The figure titled "Falling edge input trigger" shows the characteristics of the falling edge input trigger; the figure titled "Falling edge output trigger" shows the falling edge output trigger.

Input characteristics:

- Detects all falling edges as input triggers.

Figure 3-2: Falling edge input trigger**Output characteristics:**

- In addition to trigger events from other trigger objects, the `digio.trigger[N].assert()` and `tsplink.trigger[N].assert()` commands generate a low pulse for the programmed pulse duration.
- An action overrun occurs if the physical line state is low and a source event occurs.
- When the trigger is asserted, it generates a low pulse for the programmed pulse duration.

Figure 3-3: Falling edge output trigger**Rising edge master trigger mode**

Use the rising edge master (RisingM) trigger mode (see the figure titled "RisingM output trigger") to synchronize with non-Keithley instruments that require a high pulse. Input trigger detection is not available in this trigger mode. You can use the RisingM trigger mode to generate rising edge pulses.


NOTE

The RisingM trigger mode does not function properly if the line is driven low by an external drive.

Output characteristics:

- Configured trigger events, as well as the `digio.trigger[N].assert()` and `tsplink.trigger[N].assert()` commands, cause the physical line state to float high during the trigger pulse duration.
- An action overrun occurs if the physical line state is high while a stimulus event occurs.
- When the trigger is asserted, it causes the physical line state to float high during the trigger pulse duration.

Figure 3-4: RisingM output trigger




Rising edge acceptor trigger mode

The rising edge acceptor trigger mode (RisingA) generates a low pulse and detects rising edge pulses (see the following figures).

Input characteristics:


- All rising edges generate an input event.

Figure 3-5: RisingA input trigger



Output characteristics:


- In addition to trigger events from other trigger objects, the `digio.trigger[N].assert()` and `tsplink.trigger[N].assert()` commands generate a low pulse that is similar to the falling edge trigger mode.

Figure 3-6: RisingA output trigger**Either edge trigger mode**

The either edge trigger mode generates a low pulse and detects both rising and falling edges.


Input characteristics:

- All rising or falling edges generate an input trigger event.

Figure 3-7: Either edge input trigger

Output characteristics:

- In addition to trigger events from other trigger objects, the `digio.trigger[N].assert()` and `tsplink.trigger[N].assert()` commands generate a low pulse that is similar to the falling edge trigger mode.
- An action overrun occur if the physical line state is low while a stimulus event occurs.

Figure 3-8: Either edge output trigger**Understanding synchronous triggering modes**

Use the synchronous triggering modes to implement bidirectional triggering, to wait for one node, or to wait for a collection of nodes to complete all triggered actions.

All non-Keithley instrumentation must have a trigger mode that functions similar to the SynchronousA or SynchronousM trigger modes.

To use synchronous triggering, configure the triggering master to the SynchronousM trigger mode or the non-Keithley equivalent. Configure all other nodes in the test system to SynchronousA trigger mode or a non-Keithley equivalent.

Synchronous master trigger mode (SynchronousM)

Use the synchronous master trigger mode (SynchronousM) to generate falling edge output triggers, to detect the rising edge input triggers, and to initiate an action on one or more external nodes with the same trigger line.

In this mode, the output trigger consists of a low pulse. All non-Keithley instruments attached to the synchronization line in a trigger mode equivalent to SynchronousA must latch the line low during the pulse duration.


To use the SynchronousM trigger mode, configure the triggering master as SynchronousM and then configure all other nodes in the test system as Synchronous, SynchronousA, or to the non-Keithley Instruments equivalent.

NOTE


Use the SynchronousM trigger mode to receive notification when the triggered action on all nodes is complete.

Input characteristics:

- All rising edges are input triggers.
- When all external drives release the physical line, the rising edge is detected as an input trigger.
- A rising edge is not detected until all external drives release the line and the line floats high.

Figure 3-9: SynchronousM input trigger**Output characteristics:**

- In addition to trigger events from other trigger objects, the `digio.trigger[N].assert()` and `tsplink.trigger[N].assert()` functions generate a low pulse that is similar to the falling edge trigger mode.
- An action overrun occurs if the physical line state is low while a stimulus event occurs.
- When the trigger is asserted, it generates a low pulse that is similar to the Falling Edge trigger mode

Figure 3-10: SynchronousM output trigger


Synchronous acceptor trigger mode (SynchronousA)

Use the synchronous acceptor trigger mode (SynchronousA) in conjunction with the SynchronousM trigger mode. The role of the internal and external drives are reversed in the SynchronousA trigger mode.

Input characteristics:

- The falling edge is detected as the external drive pulses the line low, and the internal drive latches the line low.


Figure 3-11: SynchronousA input trigger



Output characteristics:

- In addition to trigger events from other trigger objects, the `digio.trigger[N].assert()` and `tsplink.trigger[N].assert()` functions release the line if the line is latched low. The pulse width is not used.
- When the trigger is asserted, it releases the line if the line is latched low.
- The physical line state does not change until all drives (internal and external) release the line.
- Action overruns occur if the internal drive is not latched low and a source event is received.

Figure 3-12: SynchronousA output trigger



Synchronous trigger mode

The synchronous trigger mode is a combination of SynchronousA and SynchronousM trigger modes.


NOTE

Keithley Instruments recommends using SynchronousA and SynchronousM modes only.

Input characteristics:


- The falling edge generates an input event and latches the internal drive low.

Figure 3-13: Synchronous input trigger




Output characteristics:

- In addition to trigger events from other trigger objects, the `digio.trigger[N].assert()` and `tsplink.trigger[N].assert()` functions generate a low pulse for the programmed pulse duration if the line is latched low, a falling edge does not occur.
- When the trigger is asserted and the line is latched low, the pulse duration is enforced, and then the internal line drive is released.
- A normal falling edge pulse generates when the internal drive is not latched low and the `digio.trigger[N].assert()` and `tsplink.trigger[N].assert()` functions are issued.
- To mirror the SynchronousA trigger mode, set the pulse width to 1 μs or any small nonzero value.
- Action overruns are disabled.

Figure 3-14: Synchronous output trigger**Events**

Event detectors monitor an event. They have one input signal (the stimulus), which is the event that they monitor (in some cases, the stimulus is an action in the system, like a timer expiring or a key press). They have two optional output signals (see figure below). "Detected" reflects the detection state of the event detector. If an event was detected, the detected signal is asserted. Event detectors are usually coupled to something that consumes the events. When an event is consumed, the detected state of the event detector is reset. Should an event be detected while the event detector is in the detected state, the overrun signal will be asserted. You can only clear the overrun signal by sending an ICL command.

Figure 3-15: Event detector



Event blenders

Advanced event handling requires a way to wait for one of several events (or all of several events). An event blender provides for this combining or blending of events. An event blender can combine up to four events in either an "or" mode or an "and" mode. When in "or" mode, any one of the input events will cause an output event to be generated. When in "and" mode, all the input events must occur before an output event is generated.

When operating in "and" mode, if an event is detected more than once before all events necessary for the generation of an output event, an action overrun will be generated. When operating in "or" mode, an action overrun will be generated when two or more source events are detected simultaneously.

Event blenders each have an associated event detector that can be accessed through script control. Event blenders can only be accessed over a remote interface (no front panel control is available). The following ICL commands provide additional information on available blenders:

```

trigger.blender[N].clear() (on page 8-419)
trigger.blender[N].orenable (on page 8-420)
trigger.blender[N].overrun (on page 8-421)
trigger.blender[N].stimulus[M] (on page 8-422)
trigger.blender[N].wait() (on page 8-424)
  
```

LXI Class B Triggering (IEEE-1588)

Introduction to IEEE-1588 based triggering

The Series 3700A uses IEEE-1588 precision time protocol (PTP) to implement synchronized measurements and initiate time-triggered events over the LAN (Ethernet) interface. IEEE-1588 is a requirement of the LXI B Functional Class. Using IEEE-1588, you can schedule instrument-driven actions, such as measurements, to occur at a specific date and time and synchronize timebases between instruments on the same network. You can only access these capabilities through the remote command interfaces.

NOTE

You can find detailed information on the syntax and usage of each remote command presented in this section in Command reference.

IEEE-1588 implementation in the Series 3700A

When you enable IEEE-1588 on a Series 3700A on a local network, the Series 3700A communicates with other IEEE-1588 enabled devices on the network through a dedicated network port called the PTP port. A predetermined algorithm then automatically selects the network device with the most accurate clock. This network device becomes the IEEE-1588 master. If multiple devices have the same clock accuracy, the protocol arbitrarily chooses one device to be the IEEE-1588 master.

When the protocol selects the Series 3700A as the master clock, the Series 3700A uses the time value stored in its battery-backed real-time clock and updates the time in all subordinate devices. When the protocol selects another networked device as the master clock, the Series 3700A is subordinate to the more accurate device and adjusts its time to that of the master clock. Additionally, the Series 3700A updates its battery-backed clock so that the time is "remembered" if the master clock is removed from the network.

At periodic intervals, the master clock synchronizes to all subordinate clocks through timestamped messages over the PTP port. This allows IEEE-1588 to maintain time synchronization between multiple devices on a network.

Program the synchronization interval in the Series 3700A using the `ptp.syncinterval` attribute. The default synchronization interval is two seconds. Increasing the synchronization interval to values of more than two seconds increases the amount of time that it takes devices on the LAN to synchronize. If you change the synchronization interval, you must restart the clock of the Series 3700A by cycling its power.

Read the current time delay and offset between any subordinate device and its master on the LAN using the `ptp.ds.current` attribute. Synchronization of timestamps between IEEE-1588 enabled devices to within 150 ns can take as long as two minutes.

Correlating PTP to Coordinated Universal Time (UTC)

To ensure synchronization across networked devices, you must be aware of the time protocol utilized by those other devices on the network.

The most widely accepted time scale is Coordinated Universal Time (UTC); in many places, it is considered standard time. UTC is nearly the same time as Greenwich Mean Time (GMT), another very familiar time scale, and for the purposes of the Series 3700A, UTC and GMT are the same. Local time is offset from UTC according to time zones; additional offsets can occur due to Daylight Savings Time adjustments.

UTC suffers from discontinuities because of nonperiodic adjustments known as "leap seconds." These adjustments present problems because they can make events that occurred at different periods of time appear to occur at the same time. PTP is a time standard that does not have any discontinuities and has no adjustments for local time (that is, it is not time-zone aware). PTP is presented as the number of seconds since January 1, 1970.

The Series 3700A offers two versions of time for most IEEE-1588-related commands, `.seconds` and `.ptpseconds`, representing UTC and PTP respectively. IEEE-1588 requires that devices are synchronized using UTC or PTP time, not local time. The Series 3700A does not distinguish UTC, PTP, and local time; it is not time-zone aware. You must be aware of this when synchronizing with devices that are time-zone aware.

When IEEE-1588 selects a time-zone aware device to be the master clock, the Series 3700A accepts the time of that clock. This time may not agree with the local time of the Series 3700A, especially when a network spans multiple time zones. If you schedule events on the Series 3700A to occur according to your local time, events will not occur at the time you expect.

You can avoid confusion by setting the time on the Series 3700A to UTC time instead of local time. Manage the conversion from UTC to local time in your software application. For example, assume local time is Eastern Standard Time in the United States (EST), which is equivalent to GMT-5 (hours). Therefore, if the current local time is 3:00 PM, the UTC time is 8:00 PM. Set the time of the Series 3700A clock to 8:00 PM. If it is then synchronized with a time-zone aware master clock, its time will not change significantly.

NOTE

The Series 3700A does not differentiate UTC and PTP time. The `ptp.utcoffset` (on page 8-316) attribute is zero unless a master clock that is aware of the difference between UTC and PTP time populates this value. This value is volatile and does not persist through a power cycle.

Configuring and enabling IEEE-1588

To configure IEEE-1588, connect the Series 3700A to the LAN, along with any other IEEE-1588 enabled devices that you want to synchronize to the Series 3700A. Refer to the Series 3700A User Manual for information on connecting the Series 3700A to the LAN. If you want to synchronize multiple Series 3700A instruments on a LAN, each instrument must have the same PTP subdomain name.

The default PTP subdomain name is `_DFLT` for all Series 3700A devices. Use the `ptp.subdomain` attribute to change the subdomain name for any Series 3700A on the LAN. After changing the subdomain name, you must power cycle the Series 3700A to restart its clocks. If you have changed the subdomain name of any third-party IEEE-1588 enabled device in that subdomain, you must also restart its clock.

NOTE

Cycling the power to the Series 3700A does not return the IEEE-1588-related parameters to factory default state. To return these to factory defaults, perform a LAN configuration reset. This can be done using the `lan.status.reset()` function on the remote command interface. You can also perform a reset through the front-panel interface by entering the Main menu, selecting LAN, and selecting Reset.

Use the [ptp.enable](#) (on page 8-313) attribute to enable IEEE-1588 on the Series 3700A. The IEEE-1588 protocol then determines the master clock. The IEEE-1588 indicator on the front panel of the Series 3700A updates to display the IEEE-1588 status.

- If the indicator is off, IEEE-1588 is disabled or the device is not connected to a working network.
- If the network is not working, the LAN indicator blinks. If the indicator is solidly on, the IEEE-1588 is successfully enabled and synchronized, and the Series 3700A is a subordinate (slave) clock.
- If the indicator blinks once every second, IEEE-1588 is successfully enabled and synchronized, and the Series 3700A is the master clock.
- If the indicator blinks once every two seconds, IEEE-1588 is successfully enabled and synchronized, and the Series 3700A is the grandmaster clock.

You can also use the `ptp.synchronized` attribute to determine if the Series 3700A is a master or subordinate on the LAN.

NOTE

The [ptp.enable](#) (on page 8-313) attribute is saved in nonvolatile memory. Therefore, if you turn off a Series 3700A with IEEE-1588 enabled and then turn on the Series 3700A power on a different network, it attempts to synchronize with any other IEEE-1588 enabled devices on that new network. You do not need to re-enable IEEE-1588.

Monitoring alarms with LAN triggers and LXI event log

Use the LXI event log to monitor the firing of scheduled alarms. The LXI event log in the Series 3700A only captures LAN triggers that occur in its defined LXI domain. To monitor alarms, configure the alarm to generate a LAN trigger by using [schedule.alarm\[N\].EVENT_ID](#) (on page 8-350) as the control source for [lan.trigger\[N\].stimulus](#) (on page 8-290) in the trigger model. You can define up to eight LAN triggers.

Use `lan.lxidomain` to specify the LXI domain. Additionally, you can broadcast LAN triggers to all devices on an LXI domain, or you can transmit LAN triggers between two individual devices. To configure the LAN trigger broadcast, use `lan.trigger[N].protocol`.

The following example demonstrates how to generate a LAN trigger when a scheduled alarm fires:

```
-- configure the LXI domain
lan.lxidomain=0
-- configure the LXI trigger to broadcast to all devices in this LXI domain
lan.trigger[2].protocol=2
lan.trigger[2].connect()
-- associate the firing of the alarm to the generation of a LAN trigger
lan.trigger[2].stimulus = schedule.alarm[1].EVENT_ID
```

LXI event log

The LXI event log of a Series 3700A monitors all LAN triggers that the instrument receives or generates. The LXI event log has nine comma-delimited fields. Below is an example entry to an LXI event log and a description of the log fields in order of appearance.

```
"17:26:35.690 10 Oct 2007, LAN0, 192.168.1.102, LXI, 0, 1192037132,
1192037155.733269000, 0, 0x0"
```

Value	Description
"17:26:35.690 10 Oct 2007"	Formatted UTC time in 24-hour format including fractional seconds.
"LAN0"	Event identifier. This event identifier is zero-based (LAN0-LAN7). When specifying the LAN trigger using <code>lan.trigger[N]</code> , the minimum value for <i>N</i> is 1. Therefore LAN0 to LAN 7 corresponds to <code>lan.trigger[1]</code> through <code>lan.trigger[8]</code> , respectively.
"192.168.1.102"	IP address of the device that issued the LAN trigger.
"LXI"	LXI version identifier. Currently only LXI is defined.
"0"	LXI Domain number.
"1192037132"	Sequence number from the device that issued the LAN trigger. This number is incremented after generation of each LAN trigger.
"1192037155.733269000"	PTP time formatted as a floating point number.
"0"	The overflow from PTP seconds. Currently, this is "0". Also referred to as IEEE-1588 Epoch.
"0x0"	Hex value of the flag field, which is the logical OR of several conditions (error=1, retransmission=2, hardware=4, acknowledgement=8).

Files

File formats

Each script, reading buffer, and saved setup is represented on a flash drive as a separate file.

Directories on a flash drive used with the Series 3700A can only contain a limited number of files. The top-level directory is limited to approximately 150 files, while subdirectories are limited to approximately 500 files. Once the limit has been reached, a "file system full" error message is generated.

Default file extensions

You must specify the full filename, including the extension, when sending commands. Note, however, that the front panel automatically generates a generic filename that you can use as a base for naming your files. Also, some commands (for example, [io.open\(\)](#) (on page 8-266)) will work with either a relative or absolute path to the current working directory.

The Model 3706A has the following set of default extensions:

- **.tsp** (Test Script Processor) for scripts
- **.csv** (comma-separated values) for reading buffers
- **.set** for saved setups

File system navigation

The Lua FS library provides the command set necessary to navigate the file system and list the available files on a flash drive. The instrument encapsulates this command set as an `fs` logical instrument, so that the file system of any given node is available to the entire TSP-Link[®] system. For example, the command `node[5].fs.readdir(". ")` can be used to read the contents of the current working directory on Node 5.

To allow for future enhancements, the root folder of the USB flash drive has the absolute path `/usb1/`.

NOTE

Both slash (/) and backslash (\) are supported as directory separators, but because backslash is an escape character in Lua, it appears as a double backslash in this context.

The following Lua FS commands, which support basic navigation and directory listing, are included for your reference.

- [fs.chdir\(\)](#) (on page 8-260)
- [fs.cwd\(\)](#) (on page 8-260)
- [fs.is_dir\(\)](#) (on page 8-261)
- [fs.is_file\(\)](#) (on page 8-261)
- [fs.mkdir\(\)](#) (on page 8-262)
- [fs.readdir\(\)](#) (on page 8-262)
- [fs.rmdir\(\)](#) (on page 8-262)

The following Lua FS commands are not supported at this time:

- `fs.chmod`
- `fs.chown`
- `fs.stat`

File I/O

You can use the file I/O commands to open and close directories and files, write data, or to read a file on an installed USB flash drive. File I/O commands are organized into two groups:

- Commands that reside in the `fs` and `io` table, for example: `io.open()`, `io.close()`, `io.input()`, and `io.output()`. These commands manage file system directories; open and close file descriptors; and perform basic I/O operations on a pair of default files (one input and one output).
- Commands that reside in the file descriptors (for example: `fileVar:seek()`, `fileVar:write()`, and `fileVar:read()`) operate exclusively on the file with which they are associated.

The root folder of the USB flash drive has the absolute path:

`/usb1/`

NOTE

Both slash (/) and backslash (\) are supported as directory separators.

For basic information about navigation and directory listing of files on a flash drive, see [File system navigation](#) (on page 6-11).

NOTE

File descriptor commands (represented by `fileVar`) for file I/O use a colon (:) to separate the command parts rather than a period (.), like the `io` commands.

File descriptors cannot be passed between nodes in a TSP-Link[®] system, so the `io.open()`, `fileVar::read()`, and `fileVar::write` commands are not accessible to the TSP-Link system. However, the default input and output files mentioned above allow for the execution of many file I/O operations without any reference to a file descriptor.

[fileVar.close\(\)](#) (on page 8-254)

[fileVar.flush\(\)](#) (on page 8-255)

[fileVar.read\(\)](#) (on page 8-255)

[fileVar.seek\(\)](#) (on page 8-256)

[fileVar.write\(\)](#) (on page 8-257)

[fs.chdir\(\)](#) (on page 8-260)

[fs.cwd\(\)](#) (on page 8-260)

[fs.is_dir\(\)](#) (on page 8-261)

[fs.is_file\(\)](#) (on page 8-261)

[fs.mkdir\(\)](#) (on page 8-262)

[fs.readdir\(\)](#) (on page 8-262)

[fs.rmdir\(\)](#) (on page 8-262)

[io.close\(\)](#) (on page 8-264)

[io.flush\(\)](#) (on page 8-265)

[io.input\(\)](#) (on page 8-265)

[io.open\(\)](#) (on page 8-266)

[io.output\(\)](#) (on page 8-267)

[io.read\(\)](#) (on page 8-267)

[io.type\(\)](#) (on page 8-268)

[io.write\(\)](#) (on page 8-268)

The following standard I/O commands are not supported at this time:

File	I/O
<ul style="list-style-type: none"> <code>fileVar:lines()</code> <code>fileVar:setvbuf()</code> 	<ul style="list-style-type: none"> <code>io.lines()</code> <code>io.popen()</code>

Script examples

The following script will open three different files to help illustrate the differences between the `io` commands and file descriptor commands. After opening the files, the script designates each one as the default output file (using the `io.output` command). While each file is the default for file writes (using the `io.write` command), the script also uses the file descriptor from the `io.open` to write to the file (`file:write` command).

After all files are closed (using the `io.close` command), the script will open the files again for reading. Two files are read by:

- Designating the file the default input file (using the `io.input` command)
- Being the default read contents of file (using the `io.read` command)

The third file is read by using the file descriptor from the `open` (`file:read` command). After reading all files, they are closed using the file descriptor and `close` option (`file:close` command).

```
loadscript file_io_test
-- get the current date and time
date_time = os.date('%c', os.time())
-- open the three files for writing
myfile1, myfile1_err, myfile1_errnum = io.open('/usb1/myfile_io1', 'w')
myfile2, myfile2_err, myfile2_errnum = io.open('/usb1/myfile_io2', 'w')
myfile3, myfile3_err, myfile3_errnum = io.open('/usb1/myfile_io3', 'w')
if (io.type(myfile1) == 'file') then
if (io.type(myfile2) == 'file') then
if (io.type(myfile3) == 'file') then
-- make myfile1 the default output file
io.output(myfile1)
-- write some data to the default file
io.write('Using io write to myfile1 to io output\n')
io.write(date_time)
io.write('\n')
-- now write to myfile2 using descriptor rather than io write command
myfile2:write('    file handle to write to myfile2\n')
myfile2:write('    while myfile1 is output file for io\n')
-- make myfile2 the default output file
io.output(myfile2)
-- write some data to the default file
io.write('Using io write to myfile2 to io output\n')
io.write(date_time)
io.write('\n')
-- now write to myfile3 using descriptor rather than io write command
myfile3:write('    file handle to write to myfile3\n')
myfile3:write('    while myfile2 is output file for io\n')
-- make myfile3 the default output file
io.output(myfile3)
-- write some data to the default file
io.write('Using io write to myfile3 to io output\n')
io.write(date_time)
io.write('\n')
-- now write to myfile1 using descriptor rather than io write command
myfile1:write('    file handle to write to myfile1\n')
myfile1:write('    while myfile3 is output file for io\n')
-- use the io close rather than file descriptor close command
io.close(myfile1)
io.close(myfile2)
io.close(myfile3)
else
print('myfile3 did not open for write')
print('error string is ' .. myfile3_err)
print('error number is ' .. myfile3_errnum)
end
else
print('myfile2 did not open for write')
print('error string is ' .. myfile2_err)
print('error number is ' .. myfile2_errnum)
end
else
print('myfile1 did not open for write')
print('error string is ' .. myfile1_err)
print('error number is ' .. myfile1_errnum)
end
-- open the 3 files again for reading
```

```
myfile1, myfile1_err, myfile1_errnum = io.open('/usb1/myfile_io1', 'r')
myfile2, myfile2_err, myfile2_errnum = io.open('/usb1/myfile_io2', 'r')
myfile3, myfile3_err, myfile3_errnum = io.open('/usb1/myfile_io3', 'r')
if (io.type(myfile1) == 'file') then
if (io.type(myfile2) == 'file') then
if (io.type(myfile3) == 'file') then
-- make myfile1 the default input file
io.input(myfile1)
-- read the default file
filecontents = io.read('*a')
print('contents of myfile1 are:')
print(filecontents)
print()
-- make myfile2 the default input file
io.input(myfile2)
-- read the default file
filecontents = io.read('*a')
print('contents of myfile2 are:')
print(filecontents)
print()
-- read myfile3 using file descriptor instead of io read
filecontents = myfile3:read('*a')
print('contents of myfile3 are:')
print(filecontents)
print()
-- use file descriptor close command rather than io close
myfile1:close()
myfile2:close()
myfile3:close()
else
print('myfile3 did not open for read')
print('error string is ' .. myfile3_err)
print('error number is ' .. myfile3_errnum)
end
else
print('myfile2 did not open for read')
print('error string is ' .. myfile2_err)
print('error number is ' .. myfile2_errnum)
end
else
print('myfile1 did not open for read')
print('error string is ' .. myfile1_err)
print('error number is ' .. myfile1_errnum)
end
endscript
```

After downloading the above script, type `file_io_test()` to execute the script:

```
file_io_test()
```

The following output is returned after executing the `file_io_test()` script:

```
contents of myfile1 are:
Using io write to myfile1 to io output
11/27/07 07:57:23
file handle to write to myfile1
while myfile3 is output file for io

contents of myfile2 are:
file handle to write to myfile2
while myfile1 is output file for io
Using io write to myfile2 to io output
11/27/07 07:57:23

contents of myfile3 are:
file handle to write to myfile3
while myfile2 is output file for io
Using io write to myfile3 to io output
11/27/07 07:57:23
```

The following script will open a file called `myfiletest` three times. The first time it is opened is for writing. Note that opening an existing file for writing deletes any existing information in the file. The second time it is opened is for appending more data to the existing data in the file. Opening a file for append will not delete any existing data; it only adds data to the end of the existing file contents. The third time the file is opened is for reading the entire contents of the file (existing data and appended data).

```
loadscript filetest
-- script to write 2 lines to a file
-- append 2 lines to the same file
-- read the entire file contents and print them

-- open the file for writing
myfile = io.open('/usb1/myfiletest', 'w')
if io.type(myfile) == 'file' then
myfile:write('This is my first line WRITING\n')
myfile:write('This is my next line WRITING\n')
myfile:close()

-- open the file for appending
myfile = io.open('/usb1/myfiletest', 'a')
if io.type(myfile) == 'file' then
myfile:write('This is my first APPEND line\n')
myfile:write('This is my next APPEND line\n')
myfile:close()

-- open the file for reading
myfile = io.open('/usb1/myfiletest', 'r')
if io.type(myfile) == 'file' then
filecontents = myfile:read('*a')
print('the file contains:')
print()
print(filecontents)
myfile:close()
else
print('The file did not open correctly for reading')
end
else
print('The file did not open correctly for appending')
end
else
print('The file did not open correctly for writing')
end
end
endscript
```

After downloading the above script, type `filetest()` to execute the script. Here are the output results:

```
the file contains:
This is my first line WRITING
This is my next line WRITING
This is my first APPEND line
This is my next APPEND line
```

Display operations

Display functions and attributes

You will use the display functions and attributes to perform the display operations covered in this section. The following table lists each display function or attribute (in alphabetic order) and cross references it to the section topic where the function or attribute is explained.

[Remote commands](#) (on page 6-1) provides additional information about the display functions and attributes.

Cross-referencing functions and attributes to section topics

Function or attribute	Section topic
<code>display.clear()</code>	Clearing the display (on page 3-32)
<code>display.getannunciators()</code>	Indicators (on page 3-37)
<code>display.getcursor()</code>	Cursor position (on page 3-32)
<code>display.getlastkey()</code>	Capturing key-press codes (on page 3-41)
<code>display.gettext()</code>	Displaying text messages (on page 3-33)
<code>display.inputvalue()</code>	Parameter value prompting (on page 3-36)
<code>display.loadmenu.add()</code> <code>display.loadmenu.delete()</code>	Load test menu (on page 3-39)
<code>display.locallockout</code>	LOCAL lockout (on page 3-38)
<code>display.menu()</code>	Menu (on page 3-35)
<code>display.prompt()</code>	Parameter value prompting (on page 3-36)
<code>display.screen</code>	Display screen
<code>display.sendkey()</code>	Sending key codes (on page 3-41)
<code>display.setcursor()</code>	Cursor position (on page 3-32)
<code>display.settext()</code>	Displaying text messages (on page 3-33)

Display messages

NOTE

Most of the display functions and attributes that are associated with display messaging will automatically select the user screen. The attribute for the display screen is explained in Display screen.

The `reset()` function has no effect on the defined display message or its configuration, but will set the display mode back to the previous display mode.

The display of the Series 3700A can be used to display user-defined messages. For example, while a test is running, the following message can be displayed on the Series 3700A.

```
Test in Process
Do Not Disturb
```

The top line of the display can accommodate up to 20 characters (including spaces). The bottom line can display up to 32 characters (including spaces) at a time.

NOTE

The `display.clear()`, `display.setcursor()`, and `display.setText()` functions (which are explained in the following paragraphs) are overlapped, nonblocking commands. The script will NOT wait for one of these commands to complete.

These nonblocking functions do not immediately update the display. For performance considerations, they write to a shadow and will update the display as soon as processing time becomes available.

Clearing the display

When sending a command to display a message, a previously defined user message is not cleared. The new message starts at the end of the old message on that line. It is good practice to routinely clear the display before defining a new message.

After displaying an input prompt, the message will remain displayed even after the operator performs the prescribed action. The `clear()` function must be sent to clear the display. To clear both lines of the display, but not affect any of the indicators, send the following function:


```
display.clear()
```

Cursor position

When displaying a message, the cursor position determines where the message will start. On power-up, the cursor is positioned at row 1, column 1 (see the following figure). At this cursor position, a user-defined message will be displayed on the top row (row 1).

Top line text will not wrap to the bottom line of the display automatically. Any text that does not fit on the current line will be truncated. If the text is truncated, the cursor will be left at the end of the line.

Figure 3-16: Row/column format for display messaging



The function to set cursor position can be used two ways:

```
display.setcursor(row, column)
display.setcursor(row, column, style)
```

Where:

<i>row</i>	1 or 2
<i>column</i>	1 to 20 (row 1) 1 to 32 (row 2)
<i>style</i>	0 (invisible) 1 (blink)

When set to 0, the cursor will not be seen. When set to 1, a display character will blink to indicate its position.

The `display.getcursor()` function returns the present cursor position, and can be used three ways:

```
row, column, style = display.getcursor()
row, column = display.getcursor()
row = display.getcursor()
```

The following programming example illustrates how to position the cursor on row 2, column 1, and then read the cursor position:

```
display.setCursor(2, 1)
row, column = display.getcursor()
print(row, column)
```

Output: 2.00000e+00 1.00000e+00

Displaying text messages

To define and display a message, use the `display.setText(text)` function (*text* is the text string to be displayed). The message will start at the present cursor position. The following programming example illustrates how to display “Test in Process” on the top line, and “Do Not Disturb” on the bottom line:

```
display.clear()
display.setCursor(1, 1, 0)
display.setText("Test in Process")
display.setCursor(2, 6, 0)
display.setText("Do Not Disturb")
```

Character codes

The following special codes can be embedded in the `text` string to configure and customize the message:

- \$N Starts text on the next line (newline). If the cursor is already on line 2, text will be ignored after the '\$N' is received.
- \$R Sets text to Normal.
- \$B Sets text to Blink.
- \$D Sets text to Dim intensity.
- \$F Set text to background blink.
- \$\$ Escape sequence to display a single "\$".

In addition to displaying alpha-numeric characters, other special characters can be displayed. Refer to Display character codes for a complete listing of special characters and their corresponding codes. The following programming example illustrates how to display the Greek symbol omega (Ω):

```
display.clear()
c = string.char(18)
display.setText(c)
```

The following programming example illustrates how to use the `$N` and `$B` character codes to display the message “Test in Process” on the top line and the blinking message “Do Not Disturb” on the bottom line:

```
display.clear()
display.setText("Test in Process $N$BDo Not Disturb")
```

The following programming example illustrates how to use the `$$` character code to display the message “You owe me \$8” on the top line:

```
display.clear()
display.setCursor(1, 1)
display.setText("You owe me $$8")
```

If the extra `$` character is not included, the `$8` would be interpreted as an undefined character code and will be ignored. The message “You owe me” will instead be displayed.

NOTE

Be careful when embedding character codes in the text string; it is easy to forget that the character following the `$` is part of the code. For example, assume you want to display “Hello” on the top line and “Nate” on the bottom line, and so you send the following command:

```
display.setText("Hello$Nate")
```

The above command displays “Hello” on the top line and “ate” on the bottom line. The correct syntax for the command is as follows:

```
display.setText("Hello$NNate")
```

Returning a text message

The `display.getText()` function returns the displayed message (*text*) and can be used in five ways:

```
text = display.getText()
text = display.getText(embellished)
text = display.getText(embellished, row)
text = display.getText(embellished, row, columnStart)
text = display.getText(embellished, row, columnStart, columnEnd)
```

Where:

<i>embellished</i>	Returns text as a simple character string (<code>false</code>) or includes character codes (<code>true</code>)
<i>row</i>	The row to read text from (1 or 2); if not included, text from both rows is read
<i>columnStart</i>	Starting column for reading text
<i>columnEnd</i>	Ending column for reading text

Sending the command without the *row* parameter returns both lines of the display. The $\$N$ character code will be included to show where the top line ends and the bottom line begins. The $\$N$ character code will be returned even if *embellished* is set to *false*.

With *embellished* set to *true*, all other character codes that were used in the creation of each message line will be returned along with the message. With *embellished* set to *false*, only the message will be returned.

Sending the command without the *columnStart* parameter defaults to column 1. Sending the command without the *columnEnd* argument defaults to the last column (column 20 for row 1, column 32 for row 2).

Input prompting

Display messaging can be used along with front panel controls to make a user script interactive. In an interactive script, input prompts are displayed so that the operator can perform a prescribed action using the front panel controls. While displaying an input prompt, the test will pause and wait for the operator to perform the prescribed action from the front panel.

Menu

A user-defined menu can be presented on the display. The menu consists of the menu name on the top line, and a selectable list of menu items on the bottom line. To define a menu, use the `display.menu(menu, items)` function.

Where:

menu The name of the menu; use a string of up to 20 characters (including spaces)
items A string is made up of one or more menu items; each item must be separated by white space

When the `display.menu()` function is sent, script execution will wait for the operator to select one of the menu items. Rotate the navigation wheel  to place the blinking cursor on the desired menu item. Items that don't fit in the display area will be displayed by rotating the navigation wheel  to the right. With the cursor on the desired menu item, press the navigation wheel  (or the **ENTER** key) to select it.

Pressing the EXIT (LOCAL) key will not abort the script while the menu is displayed, but it will return `nil`. The script can be aborted by calling the `exit()` function when `nil` is returned.

The following programming example illustrates how to present the operator with the choice of two menu items: Test1 or Test2. If Test1 is selected, the message `Running Test1` will be displayed. If Test2 is selected, the message `Running Test2` will be displayed.

```
display.clear()
menu = display.menu("Sample Menu", "Test1 Test2")
if menu == "Test1" then
    display.settext("Running Test1")
else
    display.settext("Running Test2")
end
```

Parameter value prompting

There are two functions to create an editable input field on the user screen at the present cursor position: `display.inputvalue()` and `display.prompt()`.

The `display.inputvalue()` function uses the user screen at the present cursor position. Once the command is finished, it returns the user screen back to its previous state. The `display.prompt()` function creates a new edit screen and does not use the user screen.

Each of these two functions can be used in four ways:

```
display.inputvalue(format)
display.inputvalue(format, default)
display.inputvalue(format, default, min)
display.inputvalue(format, default, min, max)
display.prompt(format, units, help)
display.prompt(format, units, help, default)
display.prompt(format, units, help, default, min)
display.prompt(format, units, help, default, min, max)
```

Where:

<i>format</i>	String that creates an editable input field on the user screen at the present cursor position (examples: +0.00 00, +00, 0.00000E+0) Value field: + = Include for positive/negative value entry; omitting the + prevents negative value entry 0 = Defines the digit positions for the value (up to six zeros (0)) Exponent field (optional): E = include for exponent entry + = Include for positive/negative exponent entry; omitting the + prevents negative value entry 0 = Defines the digit positions for the exponent
<i>default</i>	Option to set a default value for the parameter, which will be displayed when the command is sent
<i>min</i>	Option to specify minimum limits for the input field <ul style="list-style-type: none"> When NOT using the "+" sign for the value field, the minimum limit cannot be set to less than zero When using the "+" sign, the minimum limit can be set to less than zero (for example, -2)
<i>max</i>	Option to specify maximum limits for the input field
<i>units</i>	Text string to identify the units for the value (8 characters maximum), for example: Units text is "V" for volts and "A" for amperes
<i>help</i>	Informational text string to display on the bottom line (32 characters maximum).

Both the `display.inputvalue()` and `display.prompt()` functions display the editable input field, but the `display.inputvalue()` function does not include the text strings for *units* and *help*.

After one of the above functions is executed, command execution will pause and wait for the operator in input the source level. The program will continue after the operator enters the value by pressing the navigation wheel  or the ENTER key.

In this example, the command `display.prompt` prompts the operator to input a measurement speed. If the operator does not enter a value, the default level of 1 is set when the operator presses **ENTER**. The operator must input values that are within the limits (minimum of 0.01 and maximum of 3.0); any other values are not accepted.

Example: Interactive script	
Code	Output
<pre>myFunc = display.menu ("Select function", "dcvolts twowireohms") if (myFunc == 'dcvolts') then myRange = display.menu('Select range', '10 100') if (myRange == '10') then rangeValue = 10 else rangeValue = 100 end else myRange = display.menu('Select range', '1000 10000') if (myRange == '1000') then rangeValue = 1000 else rangeValue = 10000 end end speed = display.prompt('0.00', 'NPLC', 'Enter measure speed', 1, 0.01, 3) dmm.reset('all') dmm.func = myFunc dmm.range = rangeValue dmm.nplc = speed print(dmm.measure())</pre>	<p>Prompt operator to select function.</p> <p>Prompt for range based on function selected.</p> <p>Prompt operator to set the measurement speed.</p> <p>Wait for operator to set the measurement speed.</p>

Display trigger wait and clear

The `display.trigger.wait()` function causes the instrument to wait for the front panel TRIG key to be pressed, while the `display.trigger.clear()` function clears the trigger event detector.

Indicators

To determine which display indicators are turned on, use the `display.getannunciators()` function. The following programming example illustrates how to determine which display indicators are turned on:

```
annun = display.getannunciators()
print(annun)
```

The 16-bit binary equivalent of the returned value is a bitmap. Each bit corresponds to an indicator. If the bit is set to "1", the indicator is turned on. If the bit is set to "0", the indicator is turned off.

The following table identifies the bit position for each indicator. The table also includes the weighted value of each bit. The returned value is the sum of all the weighted values for the bits that are set.

For example, assume the returned bitmap value is 34061. The binary equivalent of this value is as follows:

1000010100001101

For the above binary number, the following bits are set to "1": 16, 11, 9, 4, 3 and 1. Using the table, the following indicators are on: REL, REM, EDIT, AUTO, 4W and EDIT.

Bit identification for indicators

Bit	B16	B15	B14	B13	B12	B11	B10	B9
Annunciator	REL	REAR	SRQ	LSTN	TALK	REM	ERR	EDIT
Weighted value*	32768	16384	8192	4096	2048	1024	512	256
Binary value	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1

Bit	B8	B7	B6	B5	B4	B3	B2	B1
Annunciator	SMPL	STAR	TRIG	ARM	AUTO	4W	MATH	FILT
Weighted value*	128	64	32	16	8	4	2	1
Binary value	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1

* The weighted values are for bits that are set to "1." Bits set to "0" have no value.

Not all of the above indicators shown in above table may used by the Series 3700A.

Local lockout

You can use the front-panel EXIT (LOCAL) key to cancel remote operation and return control to the front panel. However, this key can be locked-out to prevent a test from being interrupted. When locked, this key becomes a NO-OP (no operation). Configure the following attribute to lock or unlock the EXIT (LOCAL) key:

```
display.locallockout = lockout
```

Where *lockout* is set to one of the following values:

0 or `display.UNLOCK`

1 or `display.LOCK`

Example:

The following programming example illustrates how to lock out the EXIT (LOCAL) key:

```
display.locallockout = display.LOCK
```

Load test menu

Allows you to run scripts and code from the front panel that you created through the communication interface, or configuration scripts created by pressing the front-panel MENU key, then selecting SCRIPT > CREATE-CONFIG.

To open this menu, press **LOAD**.

The User option loads code that was added to Load Test with the [display.loadmenu.add\(\)](#) (on page 8-139) command.

The Scripts option loads named scripts that were added to the runtime environment. See [Manage scripts](#) (on page 7-3) for information on creating and loading scripts.

After selecting code or script from the User or Scripts option, you can press **RUN** to execute the selected code or script.

User tests

User tests can be added or deleted from the to the USER TESTS submenu.

Adding USER TESTS menu entries

The following function can be used in two ways to add an entry into the USER TESTS submenu:

```
display.loadmenu.add(displayname, chunk)  
display.loadmenu.add(displayname, chunk, memory)
```

Where:

<i>displayname</i>	Name string to add to the menu.
<i>chunk</i>	The code to be executed.
<i>memory</i>	Specifies whether the <i>chunk</i> and <i>displayname</i> parameters are saved in nonvolatile memory; set to one of the following values: 0 or <code>display.DONT_SAVE</code> 1 or <code>display.SAVE</code> (default is <code>display.SAVE</code>)

The *chunk* parameter can be made up of any valid Lua code. With the *memory* parameter set to `display.SAVE`, the entry is saved in nonvolatile memory. Scripts, functions, and variables used in the chunk are not saved when `display.SAVE` is used. Functions and variables need to be saved with the script (see [Manage scripts](#) (on page 7-3)). If the script is not saved in nonvolatile memory, it will be lost when the Series 3700A is turned off. See Example 1 below.

Example 1:

Assume a script with a function named “DUT1” has already been loaded into the Series 3700A, and the script has NOT been saved in nonvolatile memory.

Now assume you want to add a test named “Test” to the USER TESTS menu. You want the test to run the function named “DUT1” and sound the beeper. The following programming example illustrates how to add “Test” to the menu, define the chunk, and then save *displayname* and *chunk* in nonvolatile memory:

```
display.loadmenu.add("Test", "DUT1() beeper.beep(2, 500)", display.SAVE)
```

When “Test” is run from the front-panel USER TESTS menu, the function named “DUT1” will execute and the beeper will beep for two seconds.

Now assume you turn the Series 3700A power off and then on again. Because the script was not saved in nonvolatile memory, the function named “DUT1” is lost. When “Test” is again run from the front panel, the beeper will beep, but “DUT1” will not execute because it no longer exists in the run-time environment.

Example 2:

The following command adds an entry called “Part1” to the front-panel USER TESTS submenu for the chunk “testpart([[Part1]], 5.0)”, and saves it in nonvolatile memory:

```
display.loadmenu.add("Part1", "testpart([[Part1]], 5.0)", display.SAVE)
```

Deleting USER TESTS menu entries

The following function can be used to delete an entry from the front-panel USER TESTS submenu:

```
display.loadmenu.delete(displayname)
```

Where:

displayname Name to delete from the menu.

The following programming example removes the entry named “Part1” from the front-panel USER TESTS submenu:

```
display.loadmenu.delete("Part1")
```

LOAD TEST menu options

Allows you to run scripts and code from the front panel that you created through the communication interface, or configuration scripts created by pressing the front-panel MENU key, then selecting SCRIPT > CREATE-CONFIG.

To open this menu, press **LOAD**.

The User option loads code that was added to Load Test with the [display.loadmenu.add\(\)](#) (on page 8-139) command.

The Scripts option loads named scripts that were added to the runtime environment. See [Manage scripts](#) (on page 7-3) for information on creating and loading scripts.

After selecting code or script from the User or Scripts option, you can press **RUN** to execute the selected code or script.

Key-press codes

Sending key codes

Key codes are provided to remotely simulate pressing a front-panel key or the navigation wheel . There are also key codes to simulate rotating the navigation wheel  to the left or right (one click at a time). Use the `display.sendkey()` function to perform these actions. The following programming examples illustrate how to simulate pressing the MENU key in two different ways:

```
display.sendkey(display.KEY_MENU)
display.sendkey(68)
```

Capturing key-press codes

A history of the key code for the last pressed front panel key is maintained by the Series 3700A. When the instrument is turned on (or when transitioning from local to remote operation), the key code is set to 0 (`display.KEY_NONE`).

When a front-panel key is pressed, the key code value for that key can be captured and returned. There are two functions associated with the capture of key-press codes: `display.getlastkey()` and `display.waitkey()`.

`display.getlastkey()`

The `display.getlastkey()` function is used to immediately return the key code for the last pressed key. The following programming example illustrates how to display the last key pressed:

```
key = display.getlastkey()
print(key)
```

The above code will return the key code value (see the following table). Remember that a value of 0 (`display.KEY_NONE`) indicates that the key code history had been cleared.

Key code values returned for `display.getlastkey`

Value	Key list	Value	key list
0	(<code>display.KEY_NONE</code>)	82	(<code>display.KEY_ENTER</code>)
65	(<code>display.KEY_RANGEUP</code>)	83	(<code>display.KEY_MEASB</code>)
67	(<code>display.KEY_RELB</code>)	84	(<code>display.DIGITSB</code>)
68	(<code>display.KEY_MENU</code>)	85	(<code>display.KEY_RECALL</code>)
69	(<code>display.KEY_MODEA</code>)	86	(<code>display.KEY_MEASA</code>)
70	(<code>display.KEY_RELA</code>)	87	(<code>display.KEY_DIGITSA</code>)
71	(<code>display.KEY_RUN</code>)	90	(<code>display.KEY_LIMITB</code>)
72	(<code>display.KEY_DISPLAY</code>)	91	(<code>display.KEY_SPEEDB</code>)
73	(<code>display.KEY_AUTO</code>)	92	(<code>display.KEY_TRIG</code>)
74	(<code>display.KEY_FILTERB</code>)	93	(<code>display.KEY_LIMITA</code>)
75	(<code>display.KEY_EXIT</code>)	94	(<code>display.KEY_SPEEDA</code>)
76	(<code>display.KEY_SRCB</code>)	95	(<code>display.KEY_LOAD</code>)
77	(<code>display.KEY_FILTERA</code>)	97	(<code>display.WHEEL_ENTER</code>)
78	(<code>display.KEY_STORE</code>)	103	(<code>display.KEY_RIGHT</code>)
79	(<code>display.KEY_SRCA</code>)	104	(<code>display.KEY_LEFT</code>)
80	(<code>display.KEY_CONFIG</code>)	114	(<code>display.WHEEL_RIGHT</code>)
81	(<code>display.KEY_RANGEDOWN</code>)		

display.waitKey()

The `display.waitKey()` function captures the key code value for the next key press:

```
key = display.waitKey()
```

After sending the `display.waitKey()` function, the script will pause and wait for the operator to press a front-panel key. For example, if the MENU key is pressed, the function will return the value 68, which is the key code for that key. The key code values are the same as listed in [display.getLastkey\(\)](#) (on page 3-41).

The following programming example illustrates how to prompt the user to press the **EXIT (LOCAL)** key to abort the script, or any other key to continue it:

```
display.clear()
display.setCursor(1, 1)
display.setText("Press EXIT to Abort")
display.setCursor(2, 1)
display.setText("or any key to continue")
key = display.waitKey()
display.clear()
display.setCursor(1, 1)
if key == 75 then
    display.setText("Test Aborted")
    exit()
else
    display.setText("Test Continuing")
end
```

The above code captures the key that is pressed by the operator. The key code value for the EXIT (LOCAL) key is 75. If the EXIT (LOCAL) key is pressed, the script aborts. If any other key is pressed, the script continues.

Digital I/O


Digital I/O port

The Keithley Instruments Series 3700A System Switch/Multimeter has a digital input/output port that can be used to control external digital circuitry. For example, a handler that is used to perform binning operations can be used with a digital I/O port.

Port configuration

The digital I/O port, a standard female DB-25 connector (shown below), is located on the rear panel.

Figure 3-17: Digital I/O port



Connecting cables

Use a cable equipped with a standard male DB-25 connector (Keithley Instruments part number CA-126-1).


+5 V output

The digital I/O port provides a +5 V output that is used to drive external logic circuitry. Maximum current output for this line is 250 mA. This line is protected by a self-resetting fuse (one hour recovery time).

Vext

The Series 3700A digital I/O provides flyback diode pins named Vext. When connected, Vext can clamp external inductive circuitry (for example, relay drive coils) from +5 V to +33 V. Refer to the figure below for a simplified digital I/O schematic.

Figure 3-18: Vext flyback diode digital I/O schematic



Output enable line

The Series 3700A output enable (OE) line of the digital I/O can be used with a switch in the test fixture or component handler. With proper use, power is removed from the DUT when the lid of the fixture is opened. See [Using output enable](#) (on page 3-48) for more details.

! WARNING


The digital I/O port Series 3700A is not suitable for control of safety circuits and should not be used to control a safety interlock. When an interlock is required for safety, a separate circuit should be provided that meets the requirements of the application to reliably protect the operator from exposed voltages.

Hardware interlocks

Some switching cards are capable of switching high-voltage signals. For safety reasons, hardware interlocks are provided. The hardware interlocks are present on the switching card itself and are designed to keep the switching card disconnected from the system backplane. This means that when the interlock circuit is disengaged, no measurements can be performed through a switching card. However, channel relays can continue to operate.

Below is a simplified schematic of the interlock circuit present on the applicable switching cards.

Figure 3-19: Simplified interlock circuit




Digital I/O configuration

The following figure shows the basic configuration of the digital I/O port. Writing a 1 to a line sets that line high ($\sim +5$ V). Writing a 0 to a line sets that line low (~ 0 V). Note that an external device pulls an I/O line low by shorting it to ground, so that a device must be able to sink at least $480 \mu\text{A}$ per I/O line.

Figure 3-20: Digital I/O port configuration**DIGITAL I/O INTERFACE:**

Connector: 25-pin female D
 Input/Output pins: 14 open-drain I/O bits
 Absolute maximum input voltage: 5.25 V
 Absolute minimum input voltage: -0.25 V
 Maximum logic low input voltage: 0.7 V @ +850 μ A
 Minimum logic high input voltage: 2.1 V @ +570 μ A
 Maximum source current (flowing out of digital I/O bit): +960 μ A
 Absolute Maximum sink current (flowing into digital I/O bit): -11.0 A
 Maximum Sink Current @ Maximum Logic Low Voltage (0.7 V): -5.0 mA.

**Controlling digital I/O lines**

Although the digital I/O lines are primarily intended for use with a device handler for limit testing, they can also be used for other purposes such as controlling external logic circuits. You can control lines either from the front panel or over a remote interface.

NOTE

You must write a 1 to all digital I/O lines that are to be used as inputs.

The trigger mode for the line must be set to `digio.TRIG_BYPASS` in order to use the line for digital I/O. See [Trigger model](#) (on page 3-1) for more information.

The digital I/O lines are not affected by any reset. However, they are affected by a power cycle.

To set digital I/O values from the front panel:

1. Press the **MENU** key, select **DIGIO**, and then press the **ENTER** key or press the navigation wheel .
2. Select **DIGIO-OUTPUT**, and then press the **ENTER** key or the navigation wheel .
3. Set the decimal value as required to set digital I/O lines within the range of 0 to 16,383 (see the table in [Digital I/O bit weighting](#) (on page 3-47)), and then press the **ENTER** key or the navigation wheel .
4. Press the **EXIT (LOCAL)** key as needed to return to the main menu.

To write-protect specific digital I/O lines to prevent their values from being changed:

1. Press the **MENU** key, then select **DIGIO**, and then press the **ENTER** key or the navigation wheel .
2. Select **WRITE-PROTECT**, and then press the **ENTER** key or the navigation wheel .
3. Set the decimal value as required to write-protect digital I/O lines within the range of 0 to 16,383 (see [Digital I/O bit weighting](#) (on page 3-47)), and then press the **ENTER** key or the navigation wheel .
4. Press the **EXIT (LOCAL)** key as needed to return to the main menu.
5. To remove write protection, repeat the above steps, but enter the original value in step 3.

Digital I/O bit weighting

Bit weighting for the digital I/O lines is shown in the following table.

Digital bit weight

Line #	Bit	Decimal weighting	Hexadecimal weighting
1	B1	1	0x0001
2	B2	2	0x0002
3	B3	4	0x0004
4	B4	8	0x0008
5	B5	16	0x0010
6	B6	32	0x0020
7	B7	64	0x0040
8	B8	128	0x0080
9	B9	256	0x0100
10	B10	512	0x0200
11	B11	1024	0x0400
12	B12	2048	0x0800
13	B13	4096	0x1000
14	B14	8192	0x2000

Remote digital I/O commands

Commands that control and access the digital I/O port are summarized in the following table. See [Remote Commands](#) (on page 6-1) for complete details on these commands. See the following table for decimal and hexadecimal values used to control and access the digital I/O port and individual lines. Use these commands to trigger the Series 3700A using external trigger pulses applied to the digital I/O port, or to provide trigger pulses to external devices.

Use these commands to perform basic steady-state digital I/O operations such as reading and writing to individual I/O lines or reading and writing to the entire port.

NOTE

The digital I/O lines can be used for both input and output. You must write a 1 to all digital I/O lines that are to be used as inputs.

Remote digital I/O commands

Command	Description
<code>digio.readbit(<i>bit</i>)</code>	Read one digital I/O input line
<code>digio.readport()</code>	Read digital I/O port
<code>digio.writebit(<i>bit</i>, <i>data</i>)</code>	Write data to one digital I/O output line
<code>digio.writeport(<i>data</i>)</code>	Write data to digital I/O port
<code>digio.writeprotect = <i>mask</i></code>	Write protect mask to digital I/O port

Digital I/O programming example

The programming commands below illustrate how to set bit B1 of the digital I/O port high, and then read the entire port value.

```
digio.trigger[1].mode = digio.TRIG_BYPASS
-- Set Bit B1 high.
digio.writebit(1,1)
-- Read digital I/O port.
data = digio.readport()
```

Using output enable

Overview

The Series 3700A digital I/O port provides an output enable line for use with a test fixture switch. When properly used, the output of the Series 3700A will turn OFF when the lid of the test fixture is opened. See DUT Test Connections for important safety information when using a test fixture.

WARNING

When an interlock is required for safety, a separate circuit should be provided that meets the requirements of the application to reliably protect the operator from exposed voltages. The digital I/O port of the Series 3700A is not suitable for control of safety circuits and should not be used to control a safety interlock.

Operation

When enabled, the output of the Series 3700A can only be turned on when the output enable line is pulled high through a switch to +5 V (as shown). If the lid of the test fixture opens, the switch opens, and the output enable line goes low, turning the output of the Series 3700A System SourceMeter[®] instrument off. The output will not automatically turn on when output enable is set high. The output cannot be turned back on until +5 V is applied to the output enable line.

TSP-Link synchronization lines

The Series 3700A has three synchronization lines that you can use for triggering, digital I/O, and to synchronize multiple instruments on a TSP-Link[®] network.

Connecting to the TSP-Link system

The TSP-Link[®] synchronization lines are built into the TSP-Link connection. Use the TSP-Link connectors located on the back of the Series 3700A. If you are using a TSP-Link network, you do not have to modify any connections. See [TSP-Link system expansion interface](#) (on page 7-45) for detailed information about connecting to the TSP-Link system.

Using TSP-Link synchronization lines for digital I/O

Each synchronization line is an open-drain signal. When using the TSP-Link[®] synchronization lines for digital I/O, any node that sets the programmed line state to zero (0) causes all nodes to read 0 from the line state. This occurs regardless of the programmed line state of any other node. See the table in the [Digital I/O bit weighting](#) (on page 3-47) topic for digital bit weight values.

Remote TSP-Link synchronization line commands

Commands that control and access the TSP-Link[®] synchronization port are summarized in the following table. See [Remote commands](#) (on page 6-1) for complete details on these commands. See the table in [Digital I/O bit weighting](#) (on page 3-47) for the decimal and hexadecimal values used to control and access the digital I/O port and individual lines.

Use the commands in following table to perform basic steady-state digital I/O operations; for example, you can program the Series 3700A to read and write to a specific TSP-Link synchronization line or to the entire port.

NOTE

The TSP-Link synchronization lines can be used for both input and output. You must write a 1 to all TSP-Link synchronization lines that are used as inputs.

Remote synchronization line commands

Command	Description
<code>tsplink.readbit(<i>bit</i>)</code>	Reads one digital I/O input line.
<code>tsplink.readport()</code>	Reads the digital I/O port.
<code>tsplink.writebit(<i>bit</i>, <i>data</i>)</code>	Writes data to one digital I/O line.
<code>tsplink.writeport(<i>data</i>)</code>	Writes data to the digital I/O port.
<code>tsplink.writeprotect = <i>mask</i></code>	Sets write-protect mask of the digital I/O port.

Programming example

The programming example below illustrates how to set Bit B1 of the digital I/O port high, and then read the entire port value:

```
tsplink.trigger[1].mode = tsplink.TRIG_BYPASS
-- Set Bit B1 high.
tsplink.writebit(1, 1)
-- Read I/O port.
data = tsplink.readport()
```

Reading buffers

Buffer overview

Reading buffers capture measurements, channels or channel patterns, instrument status, and measure functions of the Keithley Instruments Series 3700A.

The Series 3700A uses synchronous reading acquisitions to take readings for a dynamically-created reading buffer. The instrument stores the numbered readings that are acquired during the storage process. Each reading includes reading units with options that include timestamp and channel information. All routines that return measurements can return the measurements in a reading buffer. Synchronous measurements return a single value or both a single value and a reading buffer. More advanced users can access the additional information stored in the reading buffer.

You can configure single-point measurement routines to make multiple measurements when only one would ordinarily be made. Also, the measured value is not the only component of a reading. The measurement status (for example, limit or overflow) is also data associated with a particular reading.

Create and configure buffers using the front panel or through a remote interface using remote commands.



CAUTION

Once you create a reading buffer, if you use that buffer name for another buffer or variable, you can no longer access the original buffer.

Reading buffer names are just like any other global variables in the system. For example, if `buf1` is a reading buffer name, `buf1 = 5` will cause the reading buffer data currently associated with `buf1` to be lost and `buf1` to equal 5.

NOTE

The various instrument operations, including buffer operation, are performed on the input signal in a specific, predetermined order. For example, if both REL and MXB (a math operation) are enabled, the REL operation will always be performed before MXB.

Front-panel buffer operation

In the following procedures, pressing in the navigation wheel  will perform the same function as pressing the **ENTER** key. Also, you can turn the navigation wheel  instead of using the **CURSOR** keys.

Read [Creating and selecting a reading buffer](#) (on page 3-51) or [Selecting a reading buffer](#) (on page 3-51) before performing the following procedures:

- [Storing readings](#) (on page 3-52)
- [Saving readings](#) (on page 3-52)
- [Clearing readings](#) (on page 3-52)
- [Deleting a reading buffer](#) (on page 3-53)
- [Recalling readings](#) (on page 3-53)
- [Buffer configuration \(front panel\)](#) (on page 3-54)
- [Appending readings](#) (on page 3-54)

Creating and selecting a reading buffer

To create a new reading buffer that will be automatically selected after it is created:

1. Press the **STORE** key.
2. Select **CREATE** from the buffer choices and press the **ENTER** key.
3. Using the navigation wheel  and the **CURSOR** keys, scroll through the characters, changing them until the desired name is shown.

NAME = _ _ _ _ _

4. Press the **ENTER** key. The starting name is:

f p b u f n _ _ _ _ _

Where:

fp = front panel

buf = buffer

n = number, sequentially incremented

5. Specify the number of readings to store in the buffer.
6. Press the **ENTER** key. The append attribute of this buffer is enabled (set to 1).

NOTE

The newly-created buffer is automatically selected as the buffer for storing front-panel readings.

Selecting a reading buffer

You can only select an existing reading buffer. If necessary, create it first. See [Creating and selecting a reading buffer](#) (on page 3-51) for more information.

NOTE

When you create a new reading buffer from the front panel, it is automatically selected.

To select a reading buffer:

1. Set up the Model 3706A to take measurements.
2. Press the **STORE** key.
3. Select **SELECT** from the buffer choices and press the **ENTER** key.
4. Use the **CURSOR** keys to select the desired buffer.

Storing readings

Before storing readings, make sure you have selected the desired reading buffer. See [Selecting a reading buffer](#) (on page 3-51) for more information.

To store a reading, press the **TRIG** key or execute a scan. The asterisk (*) annunciator turns on, which indicates that the buffer is enabled, and turns off when storage is finished. The annunciator stays on as long as the created buffer's capacity is less than the number of readings stored.

To stop the buffer, press the **EXIT** key, or if you are taking continuous readings, press the **TRIG** key.

NOTE

Stored readings are lost when the instrument is turned off. To save your stored readings, see [Saving readings](#) (on page 3-52).

Saving readings

When saving readings to a USB flash drive, you must select a non-empty reading buffer. See [Selecting a reading buffer](#) (on page 3-51) for more information.

To save readings to a USB flash drive:

1. Select a reading buffer that is not empty.
2. Press the **STORE** key. The bufferVar MENU is displayed.
3. Select the **SAVE** menu item, and press the **ENTER** key. The SAVE RD BUFFER menu is displayed.
4. Press the **ENTER** key when **USB** is highlighted.
5. Using the navigation wheel  and **CURSOR** keys, enter the filename where the data will be saved on the installed USB flash drive. The starting name is:
`<reading buffer name>_nn_ _ _`
Where: *nn* starts at 01 and automatically increments. For example, if the selected reading buffer is *fpbuf1*, then the starting name is *fpbuf1_01_ _ _*.
6. Press the **ENTER** key to save the data to the installed USB flash drive or the **EXIT** key to cancel.

Clearing readings

When clearing readings, you must select a reading buffer. See [Selecting a reading buffer](#) (on page 3-51) for more information.

To clear readings:

1. Select a reading buffer.
2. Press the **STORE** key. The bufferVar MENU is displayed.
3. Select the **CLEAR** menu item, and press the **ENTER** key.
4. At the prompt, select **YES** or **NO** and press the **ENTER** key.

Deleting a reading buffer

To delete a reading buffer:

1. Select the reading buffer you want to delete.
2. Press the **STORE** key. The bufferVar MENU is displayed.
3. Select the **DELETE** menu item, and press the **ENTER** key.
4. At the prompt, select **YES** or **NO** and press the **ENTER** key.
 - If you select **YES**, the RD BUFF ACTION MENU is displayed.
 - If you select **NO**, the bufferVar MENU is displayed.

NOTE

To delete a buffer (including front-panel buffers) remotely (over the bus), set the buffer's name to `nil`. For example, to delete a buffer named FPBUF1, send the command: `FPBUF1 = nil`.

Recalling readings

When recalling readings, you must select a reading buffer that is not empty. See [Selecting a reading buffer](#) (on page 3-51) for more information.

Readings stored in the buffer are displayed by pressing the **REC** key. Turn the navigation wheel  or use the **CURSOR** keys to cycle through the buffer's contents. A message is displayed if a buffer is empty.

When recalling a buffer, the display contains the following information:

- Measurement reading for each entry is at the top right.
- Buffer location number is at the bottom left.
- [Timestamp](#) (on page 3-53) (if used) is positioned at the bottom right.
- [Channel display](#) (on page 3-54) or channel pattern (if used) associated with the reading for each entry is at the top left.

Timestamp

When timestamps are enabled, they are shown in absolute time and stored as the number of seconds in Universal Coordinated Time (UTC) format. Therefore, the displayed timestamp will show month, day, and year, as well as hour, minutes, seconds, and fractional seconds.

Channel display

The returned value provides different information, based on what is opened or closed when the reading is acquired:

- If no channel or channel pattern is closed when the reading is acquired, "None" is displayed.
- If only a single channel or backplane relay is closed, the channel number is displayed (for example, 5003 or 5915).
- If a channel or backplane relay plus another backplane relay or other channel is closed, then the channel number is displayed, followed by a + sign (for example, 3005+ or 3915+). The channel is in the image unless the last close operation involved only backplane relays.
- If multiple channels and/or backplane relays are closed in a channel list, the last channel specified is stored. Channels take precedence over backplane relays when stored. However, if only multiple backplane relays are specified, then the first one is stored.
- If a channel pattern is closed, then the first eight characters of the channel pattern name are returned (for example, `mypattern1` is shown as `mypatter`).

Displaying other buffer readings and statistics

To display other readings in the reading buffer:

1. While still in the buffer recall mode, if viewing the data stored in the buffer, turn the navigation wheel  to increment and decrement the selected digit of the location number by one. Press the navigation wheel  and then turn it or use the **CURSOR** keys to move to the next digit that the navigation wheel  will change.
2. To exit from the reading buffer recall mode, press the **EXIT (LOCAL)** key.

Buffer configuration (front panel)

When configuring the buffer through the front panel, you must select a reading buffer. See [Selecting a reading buffer](#) (on page 3-51) for more information.

To configure a buffer from the front panel:

1. Press the **CONFIG** key.
2. Press the **STORE** key. The RD BUFFER ATTR menu opens.
3. To view the count and capacity of a selected buffer, select the **COUNT** or **CAPACITY** menu choice. To configure the buffer's append mode, select **APPEND**, then **ON** or **OFF**.

Appending readings

When the buffer append mode is disabled, the buffer is cleared (readings are lost) before a new storage operation starts.

When buffer append mode is enabled, the buffer is not cleared and each subsequent storage operation appends the readings to the buffer. When the buffer is filled to capacity, the storage process stops. The readings must be cleared before the next storage operation starts.

See [bufferVar.appendmode](#) (on page 8-17) for more information.

NOTE

Buffers created on the front panel have the append mode enabled by default.

Remote buffer operation

You can control the Model 3706A buffer using remote commands.

Data store (buffer) commands

The following commands are associated with data store operation:

- [dmm.appendbuffer\(\)](#) (on page 8-155)
- [dmm.buffer.catalog\(\)](#) (on page 8-161)
- [dmm.buffer.info\(\)](#) (on page 8-162)
- [dmm.buffer.maxcapacity](#) (on page 8-163)
- [dmm.buffer.usedcapacity](#) (on page 8-163)
- [dmm.makebuffer\(\)](#) (on page 8-207)
- [dmm.savebuffer\(\)](#) (on page 8-238)

To delete a dynamically allocated buffer, use the command `bufferVar = nil`.

Command	Description
<code>dmm.appendbuffer()</code>	Creates a file on a USB flash drive if it doesn't already exist. If the file already exists on the flash drive, it will be overwritten.
<code>dmm.buffer.catalog()</code>	An iterator that can act on all reading buffer names in the system.
<code>dmm.buffer.info("buffer name")</code>	Returns the number of stored readings in the specified buffer, along with the overall buffer capacity. The first returned value is the stored readings number, while the second is the capacity.
<code>dmm.buffer.maxcapacity</code>	Returns the overall maximum storage capacity of all reading buffers in the system.
<code>dmm.buffer.usedcapacity</code>	Returns the sum storage capacity allocated for all currently created reading buffers in the system.
<code>dmm.makebuffer()</code>	Creates buffer to store measurement data.
<code>dmm.savebuffer()</code>	Saves buffer data to a file on a USB flash drive. If the file already exists on the flash drive, it will be overwritten.

To see the current storage number and capacity of all reading buffers in the system, use the following at a Test Script Processor (TSP™) prompt or in a script:

```
for n in dmm.buffer.catalog() do stored, cap = dmm.buffer.info(n) print(n, 'stored
= ' .. stored, 'capacity = ' .. cap) end
```

Sample output:

```
buf1    stored = 0      capacity = 1000
buf2    stored = 0      capacity = 2000
buf4    stored = 0      capacity = 4000
buf5    stored = 0      capacity = 5000
buf3    stored = 0      capacity = 3000
```

As the sample output shows, the system has five reading buffers, but currently none of them have data stored in them (`stored = 0`). The storage capacity of the buffers ranges from 1000 to 5000. If you send:

```
print(dmm.buffer.usedcapacity)
```

The output is 1.500000000e+004.

This means the system is allocating 15000 of its maximum storage capacity for reading buffers.

Reading buffers

A reading buffer is based on a Lua table. The measurements themselves are accessed by ordinary array notation. If `rb` is a reading buffer, the first measurement is accessed as `rb[1]`, the ninth measurement as `rb[9]`, and so on. The additional information in the table is accessed as additional members of the table.

Reading buffer designations

To access the buffer, include the buffer attribute in the respective command. For example, the following commands store five readings from the DMM into a buffer named `readingbuffer`:

```
-- Sets how many readings to take with the dmm.measure command.
dmm.measurecount = 5
-- Takes the measurements and stores them in readingbuffer.
dmm.measure(readingbuffer)
```

NOTE

Do not use quotation marks around the reading buffer name when you send the `dmm.measure(readingbuffer)` command from the instrument front panel, because a data type error message will be logged to the error queue.

Buffer storage control attributes ****3700A***

Buffer storage attributes are summarized in the following table. To control which elements are stored in the buffer, enable the desired attribute for the buffer (which sets it to 1). The following attributes are all available per reading buffer. For example, to access the `appendmode` attribute for a buffer named `rb`, send `rb.appendmode`.

Attribute	Description
<code>appendmode</code>	When off, a new measurement to this buffer will clear the previous contents before storing the new measurement. When on, the first new measurement will be stored at what was formerly <code>rb[n+1]</code> . This attribute is initialized to off when the buffer is created over the bus. However, the default is on for the front panel or web interface to allow triggered readings to fill a buffer without clearing the previous ones.
<code>cachemode</code>	When this attribute is on, the reading buffer cache improves access speed to reading buffer data. When running successive operations that overwrite reading buffer data without running any commands that automatically invalidate the cache, the reading buffer may return stale cache data. This attribute is initialized to on when the buffer is created.
<code>collectchannels</code>	When on, channel or channel pattern information is stored with readings in the buffer. This requires eight extra bytes of storage per reading. This value, <code>off</code> or <code>on</code> , can only be changed when the buffer is empty (cleared). When the buffer is created, this attribute is initialized to on.
<code>collecttimestamps</code>	When on, timestamps will be stored with readings in the buffer. This requires eight extra bytes of storage per reading. This value, <code>off</code> or <code>on</code> , can only be changed when the buffer is empty (cleared). When the buffer is created, this attribute is initialized to on.

Buffer read-only attributes

Use buffer read-only attributes to access the information contained in an existing buffer. The following attributes are available per reading buffer (for example, `rb.basetimeseconds` would access `basetimeseconds` for reading buffer `rb`, and the number of readings the reading buffer can store is accessed as `rb.capacity`).

Attribute	Description
<code>basetimefractional</code>	The fractional portion of the timestamp of when the reading at <code>rb[1]</code> was stored in the reading buffer (in seconds).
<code>basetimeseconds</code>	The seconds portion of the timestamp, in whole seconds, when the reading at <code>rb[1]</code> was stored in the buffer.
<code>capacity</code>	The total number of readings that can be stored in the reading buffer.
<code>timestampresolution</code>	The timestamp resolution, in seconds. The resolution is fixed at 1e-9 seconds.

Buffer programming examples

Refer to the following for buffer control programming examples. In the example, the buffer is named `readingbuffer`.

NOTE

You must clear the buffer using the `readingbuffer.clear()` command before changing buffer control attributes.

Command	Description
<code>readingbuffer.collectchannels = 1</code>	Enable channel storage.
<code>readingbuffer.appendmode = 1</code>	Enable the buffer append mode.
<code>readingbuffer.collecttimestamps = 0</code>	Disable timestamp storage.

Refer to the following for buffer read-only attribute programming examples. In the example, the buffer is named `readingbuffer`.

Command	Description
<code>number = readingbuffer.n</code>	Request number of readings stored in the buffer.
<code>buffer_size = readingbuffer.capacity</code>	Request the buffer storage capacity.

Buffer reading attributes

The table in [Buffer recall attributes](#) (on page 3-58) lists the attributes that control which elements are recalled from the buffer. To access specific elements, append the desired attribute to the buffer designation.

For example, the following command line returns 100 readings from `readingbuffer1`:

```
printbuffer(1, 100, readingbuffer1.readings)
```

Similarly, the following command line returns 100 channel values from `readingbuffer1`:

```
printbuffer(1, 100, readingbuffer1.channels)
```

The default reading buffer recall attribute is `readings`, which can be omitted. Thus, the following command line also returns 100 readings from `readingbuffer1`:

```
printbuffer(1, 100, readingbuffer1)
```

Buffer recall attributes

The following table lists the attributes that control which elements are recalled from the buffer. Each is actually a nested table. Related entries are stored at the same index as the relevant measurement.

NOTE

The default attribute is `readings` and can be omitted. For example, `readingbuffer1` and `readingbuffer1.readings` will both return readings from the buffer named `readingbuffer1`.

Recall attribute	Description
<code>channels</code>	<p>An array (a Lua table) of strings indicating the channel or channel pattern associated with the measurement.</p> <p>The returned value provides different information, based on what was opened or closed when the reading was acquired:</p> <ul style="list-style-type: none"> • If no channel or channel pattern is closed when the reading was acquired, "None" is displayed. • If only a single channel or backplane relay was closed, the channel number is displayed (for example, 5003 or 5915). • If a channel or backplane relay plus another backplane relay or other channel is closed, then the channel number will be displayed followed by a + sign (for example, 3005+ or 3915+). The channel will be in the image unless the last close operation involved only backplane relays. • If multiple channels and backplane relays were closed in a channel list, the last channel specified will be stored. Channels take precedence over backplane relays when stored. However, if only multiple backplane relays are specified, then the first one will be stored. • If a channel pattern was closed, then the first eight characters of the channel pattern name are returned (for example, <code>mypattern1</code> is shown as <code>mypatte</code>).
<code>dates</code>	An array (a Lua table) of strings, indicating the date of the reading formatted in month, day, and year.
<code>formattedreadings</code>	An array (a Lua table) of strings indicating the formatted reading as viewed on the display.
<code>ptpseconds</code>	An array (a Lua table) of the seconds portion of the time stamp of when the reading was stored. These seconds are absolute and in PTP format.
<code>readings</code>	An array (a Lua table) of the readings stored in the reading buffer. This array holds the same data that is returned when the reading buffer is accessed directly, that is, <code>rb[2]</code> and <code>rb.readings[2]</code> are the same value.
<code>relativetimestamps</code>	An array (a Lua table) of timestamps, in seconds, of when each reading occurred relative to the timestamp of reading buffer entry number 1. These are equal to the time that has lapsed for each reading since the first reading was stored in the buffer. Therefore, the relative timestamp for entry number 1 in the buffer will equal 0.

Recall attribute	Description
statuses	An array (a Lua table) of status values for all readings in the buffer. The status values are floating-point numbers that encode the status value into a floating-point value (see the table in Buffer status (on page 3-60)).
times	An array (a Lua table) of strings, indicating the time of the reading formatted in hours, minutes, and seconds.
timestamps	An array (a Lua table) of strings, indicating the timestamp of the reading formatted in month, day, year, hours, minutes, seconds, and fractional seconds.
fractionalseconds	An array (a Lua table) of the fractional portion of the timestamps, in seconds, of when each reading occurred. These are absolute fractional times.
seconds	An array (a Lua table) of the seconds portion of the timestamp when the reading was stored, in seconds. These seconds are absolute and in UTC format.
units	An array (Lua table) of the strings, indicating the unit of measure stored with readings in the buffer. Units may be designated as one of the following: Volts AC, Volts DC, Amps AC, Amps DC, dB VAC, dB VDC, Ohms 2wire, Ohms 4wire, Ohms ComSide, Fahrenheit, Kelvin, Celsius, Hertz, Seconds, and Continuity.

Example to access recall attributes

To see seconds, fractional seconds, and relative timestamps for entry numbers 2 and 3 in buffer `mybuffer2`, assuming `mybuffer2.collecttimestamps` was set to 1 when the readings were stored (`mybuffer2.collecttimestamps = 1`):

```
printbuffer(2,3, mybuffer2.seconds)
printbuffer(2,3, mybuffer2.fractionalseconds)
printbuffer(2,3, mybuffer2.relativetimestamps)
```

Time and date values

Time and date values are represented as a number of UTC seconds since 12:00 a.m. Jan. 1, 1970. The `os.time()` command returns values in this format. Use `os.date()` to return values in month, day, year, hours, and minutes format, or to access the timestamp table. The only exception to this is the use of the `ptpseconds` recall attribute, which has the seconds in PTP format.

Time and date values are represented as the number of seconds since some base. Representing time as a number of seconds is referred to as “standard time format.” The three time bases used for the Series 3700A are:

- **UTC 12:00 am Jan 1, 1970.** Some examples of UTC time are reading buffer seconds, adjustment dates, and the value returned by `os.time()`.
- **Instrument on.** References time to when the instrument was turned on. The value returned by `os.clock()` is referenced to the turn-on time.
- **Event.** Time referenced to an event, such as the first reading stored in a reading buffer.

Buffer status

The buffer reading status attribute can include the status information as a numeric value shown in the following table. To access status information, send the following command:

```
stat_info = readingbuffer.statuses[2]
```

Buffer status bits

Bit	Name	Hex value	Remote command
B0	Low limit 1	0x01	dmm.buffer.LIMIT1_LOW_BIT
B1	High limit 1	0x02	dmm.buffer.LIMIT1_HIGH_BIT
B2	Low limit 2	0x04	dmm.buffer.LIMIT2_LOW_BIT
B3	High limit 2	0x08	dmm.buffer.LIMIT2_HIGH_BIT
B6	Measure overflow	0x40	dmm.buffer.MEAS_OVERFLOW_BIT
B7	Measure connect question	0x80	dmm.buffer.MEAS_CONNECT_QUESTION_BIT

Dynamically-allocated buffers

RAM reading buffers are created and dynamically allocated with the `dmm.makebuffer(N)` command, where *N* is the maximum number of readings the buffer can store.

Example 1

To allocate a buffer named *mybuffer* that can store 100 readings:

```
mybuffer = dmm.makebuffer(100)
```

Example 2

To delete an allocated buffer named *mybuffer*:

```
mybuffer = nil
```

Example 3

To see if the high limit 1 was exceeded during the reading:

```
stat_info = readingbuffer.statuses[3]
if (bit.band(stat_info, dmm.buffer.LIMIT1_HIGH_BIT) ==
    dmm.buffer.LIMIT1_HIGH_BIT) then
print("Limit 1 high exceeded")
else
print("Limit 1 high okay")
end
```

Dynamic buffer programming example

The programming example below shows how to store data using a dynamically-allocated buffer named `mybuff`.

```
-- Reset the DMM.
dmm.reset("all")
-- Create a buffer named mybuffer and allocate space for 100,000 readings.
mybuffer = dmm.makebuffer(100000)
-- Enable append buffer mode.
mybuffer.appendmode = 1
-- Set count to 1.
dmm.measurecount = 1
-- Select the DMM function as DC volts.
dmm.func = dmm.DC_VOLTS
-- Start for . . . do loop. Measure and store readings in buffer. End loop.
for x = 1, 100 do
    dmm.measure(mybuffer)
end
-- Return readings 1 through 100.
printbuffer(1, 100, mybuffer.readings)
-- Return units 1 through 100.
printbuffer(1, 100, mybuffer.units)
```

Buffer for . . . do loops

The following examples illustrate the use of `for . . . do` loops when recalling buffer data from a reading buffer called `mybuffer`. The following code may be sent as one command line or as part of a script. Sample outputs follow the line of code. Also see the `printbuffer()` command.

NOTE

Buffer `mybuffer` has time stamp collection enabled in the example below.

This example loop uses the `printbuffer()` command to show the reading, units, and relative timestamps for all readings stored in the buffer. The information for each reading (reading, units, and relative timestamps) is shown on a single line with the elements comma-delimited.

```
for x = 1,mybuffer.n do
    printbuffer(x,x,mybuffer, mybuffer.units, mybuffer.relativetimestamps)
end
```

Sample comma-delimited output of above code:

```
3.535493836e-002, Volts DC, 0.000000000e+000
-4.749810696e-002, Volts DC, 5.730966000e-002
-8.893087506e-002, Volts DC, 7.722769500e-002
4.164193198e-002, Volts DC, 1.246876800e-001
-6.900507957e-002, Volts DC, 1.815213600e-001
-8.851423860e-002, Volts DC, 2.009161500e-001
3.891038895e-002, Volts DC, 2.647790700e-001
-7.581630349e-002, Volts DC, 3.032140350e-001
-8.236359060e-002, Volts DC, 3.226125750e-001
-8.551311493e-002, Volts DC, 3.425625900e-001
```

The following loop uses the `print` command instead of the `printbuffer` command. This loop shows the same information described in the previous example (reading, units, and relative timestamps for all readings stored in the buffer). However, because the `print` command is used over `printbuffer`, each line is tab-delimited (rather than comma-delimited) to produce a columnar output, as shown below:

```
for x = 1,mybuffer.n do
  print(mybuffer.readings[x], mybuffer.units[x], mybuffer.relativetimestamps[x])
end
```

Sample columnar output of above code:

```
3.535493836e-002      Volts DC      0.000000000e+000
-4.749810696e-002    Volts DC      5.730966000e-002
-8.893087506e-002    Volts DC      7.722769500e-002
4.164193198e-002     Volts DC      1.246876800e-001
-6.900507957e-002    Volts DC      1.815213600e-001
-8.851423860e-002    Volts DC      2.009161500e-001
3.891038895e-002     Volts DC      2.647790700e-001
-7.581630349e-002    Volts DC      3.032140350e-001
-8.236359060e-002    Volts DC      3.226125750e-001
-8.551311493e-002    Volts DC      3.425625900e-001
```

If data was collected by executing a three-channel scan list with a scan count of 10, the buffer has 30 readings in it. To see the comma-delimited data on the three-channel boundary, send:

```
x = 1
y = 3
for z = 1, 10 do
  printbuffer(x, y, mybuffer, mybuffer.channels)
  x = x + 3
  y = y + 3
end
```

The sample output from the above code has six comma-delimited entries per line (reading, channel, reading, channel, reading, channel):

```
3.181298825e-002, 2001+, -5.602844334e-002, 2002+, -7.811298360e-002, 2003+
3.228547367e-002, 2001+, -5.299202901e-002, 2002+, -8.676257870e-002, 2003+
3.736769697e-002, 2001+, -3.247188344e-002, 2002+, -5.106155438e-002, 2003+
-6.473406636e-002, 2001+, -9.218081926e-002, 2002+, 3.419026595e-002, 2003+
-3.856921662e-002, 2001+, -6.672781529e-002, 2002+, -7.762540017e-002,
2003+
2.876431571e-002, 2001+, -4.056434134e-002, 2002+, -6.119288115e-002, 2003+
-7.301064720e-002, 2001+, 2.893913659e-002, 2002+, -3.164065858e-002, 2003+
-6.794576932e-002, 2001+, -8.067066262e-002, 2002+, 2.339088329e-002, 2003+
-5.288247880e-002, 2001+, -6.769966949e-002, 2002+, -7.572277347e-002,
2003+
2.618149827e-002, 2001+, -3.164126270e-002, 2002+, -6.306067024e-002, 2003+
```

If you want to see more information about the readings, add the appropriate buffer recall attribute to the `printbuffer` line in the sample code. For example, to see the relative timestamp with each reading, add `mybuffer.relativetimestamps` to the `printbuffer` command as follows:

```
printbuffer(x, y, mybuffer, mybuffer.channels, mybuffer.relativetimestamps)
```

In the output from this `printbuffer` command, nine comma-delimited entries appear on each line. Each line will include the following entries: Reading, channel, relative timestamp, reading, channel, relative timestamp, reading, channel, relative timestamp.

Exceeding reading buffer capacity

If the reading buffer count is not exceeded, readings are stored as expected. But if new readings would exceed reading buffer capacity when they are added to the current buffer index, the count is lowered to a new count so it does not exceed the buffer capacity. Once the buffer is full (to the new count), no more readings are taken and error message 4915 is displayed, stating that you attempted to exceed the capacity of the reading buffer. If you attempt to store additional readings in a full buffer, the same message appears, and no readings are taken.

Example

Create a buffer with:

- A capacity for 50 readings
- Append mode enabled
- Measure count to 30

Tell the instrument to print the current number of buffer elements stored and take readings to store in the buffer. The following occurs:

1. The first time the measurement is called, the buffer is empty (no readings), so it stores 30 readings.
2. The second time the measurement is called it stores only 20 readings. This is because $30 + 30$ is 60 readings, which exceeds buffer capacity (50). Because 30 readings are already stored, only 20 readings are taken and stored. Error message 4915 is displayed.
3. The third time the measurement is called, the buffer is full (already has 50 readings). Because there is no more room, no readings are taken (nil response for reading) and error message 4915 is again displayed.

The code for the previous example follows:

```
-- Create a buffer named buf and allocate space for 50 readings.
buf = dmm.makebuffer(50)
-- Enable append buffer mode.
buf.appendmode = 1
-- Set count to 30.
dmm.measurecount = 30
-- Show the current number of readings in the buffer,
-- and then measure and store readings in the
-- buffer (first pass).
-- Output from the print command:
-- 0.000000000e+000
-- 5.245720223e-002
print(buf.n, dmm.measure(buf))
-- Show the current number of readings in the buffer,
-- and then measure and store readings in the
-- buffer (second pass).
-- Output from the print command:
-- 3.000000000e+001
-- -1.388141960e-001
-- 4915, Attempting to store past capacity of reading buffer
print(buf.n, dmm.measure(buf))
-- Show the current number of readings in the buffer,
-- and then measure and store readings in the
-- buffer (third pass).
-- Output from the print command:
-- 5.000000000e+001
-- nil
-- 4915, Attempting to store past capacity of reading buffer
print(buf.n, dmm.measure(buf))
```


Basic DMM operation

In this section:

DMM measurement capabilities	4-1
High-energy circuit safety precautions	4-2
Performance considerations.....	4-2
System considerations	4-6
Voltage measurements (DC volts and AC volts)	4-10
Current measurements (DC current and AC current).....	4-14
Resistance measurements.....	4-17
Temperature measurements	4-23
Frequency and period measurements.....	4-35
Continuity testing.....	4-38
Refining measurements	4-41

DMM measurement capabilities

NOTE

The DMM is not available on the Models 3706-S or 3706-SNFP.

The DMM of the Model 3706A can make the following measurements:

- DC voltage measurements from –10 nV to 300 V
- AC voltage measurements from 100 nV to 300 V
- DC current measurements from 1pA to 3.0 A
- AC current measurements from 1 nA to 3.0 A
- Two-wire resistance measurements from 1 $\mu\Omega$ to 120 M Ω
- Four-wire resistance measurements from 100 $\mu\Omega$ to 120 M Ω
- Commonsense ohms resistance measurements from 1 $\mu\Omega$ to 2 k Ω
- Frequency measurements from 3 Hz to 500 kHz
- Period measurements from 2 μ s to 330 ms
- Temperature measurements from –200 °C to 1820 °C
- Continuity testing using the 1 k Ω range



CAUTION

When using a switching module, do not exceed the maximum signal levels of the module.

NOTE

For information on verification and calibration of the DMM, see [Verification](#) (on page C-1).

High-energy circuit safety precautions

To optimize safety when measuring voltage in high-energy distribution circuits, read and use the directions in the following warning.



WARNING

Dangerous arcs of an explosive nature in a high-energy circuit can cause severe personal injury or death. If the multimeter is connected to a high-energy circuit when set to a current range or low resistance range, the circuit is virtually shorted. Dangerous arcing can result even when the multimeter is set to a voltage range if the minimum voltage spacing is reduced in the external connections.

As described in International Electrotechnical Commission (IEC) Standard IEC 664, the Model 3706A is Installation Category I and signal lines must not be directly connected to AC mains.

When making measurements in high-energy circuits, use test leads that meet the following requirements:

- Test leads should be fully insulated.
- Only use test leads that can be connected to the circuit (for example, alligator clips and spade lugs) for hands-off measurements.
- Do not use test leads that decrease voltage spacing. These diminish arc protection and create a hazardous condition.

Use the following procedure when testing power circuits:

1. Turn off power to the circuit using the regular installed connect-disconnect device. For example, remove the device's power cord or turn off the power switch.
2. Attach the test leads to the circuit under test. Use appropriate safety rated test leads for this application. If over 42 V, use double-insulated test leads or add an additional insulation barrier for the operator.
3. Set the multimeter to the proper function and range.
4. Power the circuit using the installed connect-disconnect device and make measurements without disconnecting the multimeter.
5. Remove power from the circuit using the installed connect-disconnect device.
6. Disconnect the test leads from the circuit under test.

Performance considerations

There are several settings and conditions that apply to all DMM measurements, as described in the following sections.

Warmup time

After the Model 3706A is turned on, it must be allowed to warm up for at least two hours to allow the internal temperature to stabilize. If the instrument has been exposed to extreme temperatures, allow extra warmup time.

Autozero

When the autozero feature is enabled, the Model 3706A periodically measures internal voltages that correspond to offset (zero) and amplifier gain reference points. The Model 3706A includes these measurements when it calculates the reading of the input signal. This helps maintain stability and accuracy over time and changes in temperature.

You can disable autozero to improve measurement speed. However, if autozero is disabled for long periods, the zero and gain reference points will drift, resulting in inaccurate readings.

NOTE

To maintain accuracy of your DMM readings, you should disable autozero for only short periods.

When autozero is enabled after being disabled for a long period, the internal reference points are not updated immediately. This initially results in inaccurate measurements, especially if the ambient temperature has changed by several degrees.

To force a rapid update of the internal reference points, you can set the AUTOZERO attribute for the function to ONCE. This updates the internal reference points once and stops. See [dmm.autozero](#) (on page 8-160) for more information. For example, you could send the following commands to update the internal reference points and then enable autozero if autozero had been set to off for a long period:

```
dmm.autozero = dmm.AUTOZERO_ONCE
dmm.autozero = dmm.ON
first_reading = dmm.measure()
```

NOTE

Internal temperature references used for thermocouple measurements are performed regardless of the autozero state because they do not have a significant effect on measurement speed.

To set autozero from the front panel for the selected function:

1. Press the **CONFIG** key.
2. Press the **DMM** key.
3. Use the navigation wheel  to select AUTOZERO.
4. Select:
 - OFF to disable autozero
 - ON to enable autozero
 - ONCE to update the reference points once and then disable autozero
5. Press the navigation wheel  or **ENTER** to save the setting for the selected function.

To set autozero remotely, see [dmm.autozero](#) (on page 8-160).

Line cycle synchronization

Using line synchronization helps increase common mode and normal mode noise rejection. When line cycle synchronization is enabled, measurements are initiated at the first positive-going zero crossing of the power line cycle after the trigger.

Line cycle synchronization only applies to the following DMM functions:

- Commonside ohms
- Continuity
- DC current
- DC volts
- Four wire ohms
- Temperature
- Two wire ohms

Line synchronization can be enabled for NPLC measurements, increasing NMRR and CMRR.

To set line synchronization from the front panel for the selected function:

1. Press the **CONFIG** key.
2. Press the **DMM** key.
3. Use the navigation wheel  to select **LINESYNC**.
4. Select:
 - OFF to disable line synchronization
 - ON to enable line synchronization
5. Press the navigation wheel  or **ENTER** to save the setting for the selected function.

To set line synchronization remotely, see [dmm.linesync](#) (on page 8-206).

Autodelay

Autodelay applies a wait period at the start of measurement. The delay allows cables, Series 3700A cards, or internal DMM circuitry to settle for best measurement accuracy. For the AC current and AC volts functions, the autodelay includes both the RMS filter and AC coupling capacitor settling times.

When autodelay is disabled, no wait time is applied. When autodelay is enabled, every start of measurement for a function is delayed by the same amount of time.

You can also use autodelay once to include a delay for only the first measurement in a set of measurements. Each measurement after the first one has no additional delay.

To set autodelay from the front panel for the selected function:

1. Press the **CONFIG** key.
2. Press the **DMM** key.
3. Use the navigation wheel  to select **AUTODELAY**.
4. Select:
 - **OFF** to disable auto delay
 - **ON** to enable auto delay
 - **ONCE** to enable auto delay for only the first measurement
5. Press the navigation wheel  or **ENTER** to save the setting for the selected function.

To set autodelay remotely, [dmm.autodelay](#) (on page 8-157).

Measure count

The DMM can be set up to take multiple measurements when **MEASURE** is selected from the DMM Action Menu on the front panel or when a single trigger is sent. This is useful in channel closures or in a scan list where multiple measurements are required per channel.

To set up multiple measurements from the front panel:

1. Press the **DMM** key.
2. Use the navigation wheel  to select **COUNT**.
3. Set the number of measurements to take (maximum of 450,000).
4. Press the navigation wheel  or **ENTER** to save the setting. Note that this settings affects all measurements for all functions (it is not tied to a specific function).

To set the measurement counts remotely, see [dmm.measurecount](#) (on page 8-217).

When continuous measurements are taken with the front panel TRIG key, they are taken at 250 ms intervals. You take continuous measurements by pressing and holding the TRIG key in for a few seconds. After doing this, the TRIG annunciator will flash to indicate that readings are being triggered.

The front panel TRIG key will perform the number of measurements equal to the measurecount number. Press EXIT or send `dmm.measurecount=1` to halt triggering.

Change the display resolution

You can set the display resolution for measurements that are shown on the front panel of the instrument. You can set the resolution to 3½, 4½, 5½, 6½, or 7½ digits. Display resolution can be set for all functions except "nofunction" and "continuity".

The display resolution does not affect the number of digits returned in a remote command reading, and does not affect the accuracy or speed of measurements.

To set the display resolution delay from the front panel for the selected function:

1. Press the **CONFIG** key.
2. Press the **DMM** key.
3. Use the navigation wheel  to select DIGITS.
4. Select 3, 4, 5, 6, or 7 to select a 3½, 4½, 5½, 6½, or 7½ digit display, respectively.
5. Press the navigation wheel  or **ENTER** to save the setting for the selected function.

To set display resolution remotely, see [dmm.displaydigits](#) (on page 8-183).

System considerations

Relationship between DMM functions and attributes

Each DMM function can be modified by a set of attributes. For example, you can use the relative offset attribute to set a value that zeroes out noise in a measurement.

Attribute settings apply only to the function that is active when the attribute is set. They remains in effect for that function until the instrument is powered off, reset, or a saved configuration is recalled.

If you set the same attribute for a different function, the setting changes for the new function, but does not change for the previous function. An example is shown here using the remote commands, but the same concept applies to front panel settings.

<pre>reset() dmm.func = "acvolts" print(dmm.func, dmm.autorange)</pre>	<p>Reset the instrument. Set the function to AC volts. Print the function and autorange values. Output: acvolts 1.000000000e+000 This indicates that the active function is AC volts, with autorange set on.</p>
<pre>dmm.func = "accurrent" dmm.autorange = "dmm.OFF" print(dmm.func, dmm.autorange)</pre>	<p>Change to the AC current function and turn autorange off. Print the function and autorange values. Output: accurrent 0.000000000e+000 This indicates that the active function is AC current, with autorange set off.</p>
<pre>dmm.func = "acvolts" print(dmm.func, dmm.autorange)</pre>	<p>Return to AC volts as the active function. Print the function and autorange values. Output: acvolts 1.000000000e+000 Note that when AC volts is the active function, the autorange value is on.</p>

Relationship between front panel settings and remote commands

When you change the active DMM function from the front panel, the active function for all other interfaces is changed as well. This is also true for attributes.

When you change the active DMM function through a remote interface, the front panel settings are also changed.

Save DMM configurations

After you set up the attributes for a DMM function, you can save the settings for future use using the DMM configuration options. You can use this configuration to:

- Switch quickly between set ups
- Assign the configuration to channels or channel patterns
- Assign the configuration to scanning

DMM configurations include all the attribute settings for the selected DMM function. You can save multiple configurations with different names so that you can save different sets of attributes for the DMM functions.

When the DMM configuration is assigned to channels, channel patterns or scans, the Model 3706A verifies that the attributes that are set in the DMM configuration are valid for all the channels included in the channel list, pattern, or scan. If there are attributes that are not valid, an error occurs and you cannot take measurements.

However, the DMM configuration and the pole setting of the channel can be incompatible without causing an error. For example, the DMM configuration may have a channel configured for two-pole measurement (for example, DC volts), while the pole setting may be configured for four-pole. Or, a channel may have a DMM configuration of four-wire ohms while the pole setting is at two-pole. If the pole settings conflict, the pole settings that take precedence depend on the operation:

- If you send `dmm.close` or `dmm.open`, the pole setting in the DMM configuration is used.
- If you send `channel.close`, `channel.open`, `channel.exclusiveclose`, or `channel.exclusiveslotclose`, the pole setting of the channel is used.

The DMM configurations are saved in configuration scripts. See [Create a configuration script](#) (on page 2-102) for more information on configuration scripts.

DMM configurations are deleted if the system is reset. They are not affected by a DMM reset (`dmm.reset`).

Memory available for DMM configurations

All DMM configurations are allocated 32 KB of memory. The number of DMM configurations you can store varies with the number of characters of the name of the DMM configuration and the number of attributes associated with a particular function. For example, if each DMM configuration name is six characters, you can store 78 temperature configurations (temperature has 41 unique DMM attribute settings). However, if the the function is set to DC volts, and each name is six characters, you can store 99 DMM configurations (DC volts only has 31 unique DMM attribute settings). You can use the DMM configuration query command to determine how many attributes are associated with a function (see [dmm.configure.query](#) (see "[dmm.configure.query\(\)](#)" on page 8-174)).

To see how much of the DMM configuration memory is available or used, see the [memory.available](#) (see "[memory.available\(\)](#)" on page 8-303) or [memory.used](#) (see "[memory.used\(\)](#)" on page 8-304) commands.

How to save a DMM configuration

To create and save a DMM configuration from the front panel:

1. Press **DMM**.
2. Use the navigation wheel  to select **SAVE**.
3. Press the navigation wheel  or press **ENTER**.
4. Assign a name to the configuration.
5. Press **ENTER**.

To create a configuration script from the web interface:

1. From the Cards listing, select the slot that you want to set up configuration for.
2. Click **DMM Config**. The DMM Configuration dialog box is displayed.
3. Complete the values in the Configuration dialog box as needed.
4. Click **Save as** to save the settings.

To create a configuration script from the remote interface:

Send the command:

```
dmm.configure.set (name)
```

Where *name* is the name you want to assign to the DMM configuration.

Open and close relay operation

The **OPEN** and **CLOSE** keys operate differently if they are configured for switch operation or DMM operation.

If they are configured for DMM operation, backplane relays are automatically closed to connect the channel to the DMM to make a measurement. If you assign a DMM configuration to a channel, the **OPEN** or **CLOSE** keys behave as a DMM operation — the input signals are automatically routed to the DMM through the backplane relays.

In switch operation, backplane relays are not closed unless they are assigned to a channel. When that channel is closed, the associated backplane channel also closes. A backplane relay cannot be closed as a stand-alone channel from the front panel. By default, the channels are not assigned a measurement function ("nofunction") and the **OPEN** or **CLOSE** keys behave as a switch.


If Error #1114, settings conflict error, is displayed, the channel that is being closed has "nofunction" assigned to it. For remote operation, to use `dmm.close`, you must assign a valid function to a channel.

Front panel close and open operation is shown in the following example.

Example 1: Close channel and take measurement using the DMM operation method

When you assign a measurement function to a channel and press the **Close** key, the **Close** key routes the input signal automatically to the DMM through the appropriate backplane relays. This behavior is referred to as DMM operation.

Figure 4-1: Close channel and trigger measurement on instrument using the DMM method



1. Assign a measurement function of two-wire ohms to channel 1031:
 - a. Use navigation wheel  to modify the channel designation from **001** to **031**.
 - b. Use navigation wheel  to select **twowireohms** as the measurement function.
2. Press the **CLOSE** key to close channel 1031.
3. Press the **TRIG** key to acquire and display a single measurement.

Voltage measurements (DC volts and AC volts)

The Model 3706A can make DC volt measurements from –10 nV to 300 V and AC volt measurements from 100 nV to 300 V_{RMS} (425 V peak for AC waveforms).

- DC volt input resistance: 100 mV through 10 V ranges: more than 10 GΩ
- 100 V and 300 V ranges: more than or equal to 10 MΩ

Refer to the specifications for complete and up-to-date information and tolerances.

Settings available for voltage measurement

The following DMM attributes are available for voltage measurements:

- aperture (range of 10e-6 s to 0.250 s for 50 Hz; 8.33e-6 s to 0.250 s for 60 Hz)
- autodelay (dmm.AUTODELAY_ONCE, dmm.ON or dmm.OFF)
- autorange (dmm.ON or dmm.OFF)
- autozero (dmm.AUTOZERO_ONCE, dmm.ON or dmm.OFF)
- DB reference (1e-7 V to 1000 V)
- detector bandwidth (3, 30, or 300)
- display digits (3, 4, 5, 6, or 7)
- filter count (1 to 100)
- filter enable (dmm.ON or dmm.OFF)
- filter type (dmm.FILTER_MOVING_AVG or dmm.FILTER_REPEAT_AVG)
- filter window (0 to 10%)
- input divider (dmm.ON or dmm.OFF)
- DMM limit auto clear (dmm.ON or dmm.OFF)
- DMM limit enable (dmm.ON or dmm.OFF)
- DMM limit high fail (0 or 1)
- DMM limit high value (–4294967295 to +4294967295)
- DMM limit low fail (0 or 1)
- DMM limit low value (–4294967295 to +4294967295)
- line synchronization (dmm.ON or dmm.OFF)
- math enable (dmm.ON or dmm.OFF)
- math format (dmm.MATH_NONE, dmm.MATH_MXB, dmm.MATH_PERCENT, or dmm.MATH_RECIPROCAL)

- math mxb b factor (–4294967295 to +4294967295)
- math mxb m factor (–4294967295 to +4294967295)
- math mxb units
- math percent (–4294967295 to +4294967295)
- nplc (0.0005 to 15 for 60 Hz; 0.0005 to 12 for 50 Hz)
- range (0 to 303)
- relative offset enable (dmm.ON or dmm.OFF)
- relative offset level
- units (dmm.UNITS_VOLTS or dmm.UNITS_DECIBELS)

Autodelay and auto range settings

The following table provides times for autodelay and autorange time for the Model 3706A DMM functions.

Function	Detector bandwidth	Range and delays					
		Range	100 mV	1 V	10 V	100 V	300 V
DC volts	Not applicable	Range	100 mV	1 V	10 V	100 V	300 V
		Autodelay	1 ms	1 ms	1 ms	5 ms	5 ms
		Autorange	1 ms	1 ms	1 ms	5 ms	5 ms
AC volts	Not applicable	Range	100 mV	1 V	10 V	100 V	300 V
		Autodelay	200 ms	200 ms	200 ms	200 ms	1 s
	3 or 30 Hz	Autodelay	200 ms	200 ms	200 ms	200 ms	1 s
		Autorange	200 ms	200 ms	200 ms	200 ms	1 s
	300 Hz	Autodelay	50 ms	50 ms	50 ms	50 ms	250 ms
		Autorange	50 ms	50 ms	50 ms	50 ms	250 ms

Voltage measurement connections



WARNING

Even though the Model 3706A can measure up to 300V, the maximum input to a switching module may be less. Exceeding the voltage rating of a switching module may cause damage and create a safety hazard.

Make sure the insulation and wire sizes used are appropriate for the voltages and current being applied to the Model 3706A analog backplane connector. Use supplementary insulation as needed. Exceeding the voltage rating of a wiring may cause damage and create a safety hazard.

Figure 4-2: DCV connection





Figure 4-3: ACV connection



Voltage measurement procedure front panel

⚠ WARNING

If both the analog backplane connector and a switching module's terminals are connected at the same time, all wiring and connections must be rated to the highest voltage that is connected. For example, if 300 V is connected to the analog backplane connector, the test lead insulation for the switching module must also be rated for 300 V.

⚠ CAUTION

Do not apply more than maximum input levels indicated or instrument damage may occur. The voltage limit is subject to the 8×10^7 VHz product.

Perform the following steps to change a DMM function and its attributes.

1. Press the **OPENALL** key to open all switching channels.
2. Select the voltage measurement function by pressing the **CONFIG** key, and then pressing the **DMM** key. **FUNC** flashes on, then off. Press the **ENTER** key or wheel. **Function?** is displayed on the first line of the display and the second line displays available functions. Use the left or right arrow keys or the knob to select DCV.
3. Use the **RANGE** \blacktriangle and \blacktriangledown keys to:
 - Select a measurement range
 - Adjust the attributes after selecting the desired function under the Config DMM menu
 - Press the **AUTO** key to select autoranging (AUTO annunciator turns on)
4. Apply the voltages to be measured.
5. If using a Series 3700A switch card, perform the following steps to assign a range of channels and assign the channel a DMM configuration:
 - a. Using the navigation wheel:
 - Press once to select 3700 card slot number and adjust 1-6.
 - Press a second time to select the start channel number.
 - Press a third time to select the end channel.
 - Press a fourth time to allow DMM configuration assignment to the channel or range of channels.
 - b. Press the **CLOSE** key.
6. Press the **TRIG** key and observe the display. If the "Overflow" message is displayed, select a higher range until a normal reading is displayed (or press the **AUTO** key for autoranging). For manual ranging, use the lowest possible range for the best resolution.
7. To measure other switching channels, repeat steps 5 and 6.
8. When finished, press the **OPENALL** key to open all channels.

Voltage measurement procedure remote commands

WARNING

If both the analog backplane connector and a switching module's terminals are connected at the same time, all wiring and connections must be rated to the highest voltage that is connected. For example, if 300 V is connected to the analog backplane connector, the test lead insulation for the switching module must also be rated for 300 V.

CAUTION

Do not apply more than maximum input levels indicated or instrument damage may occur. The voltage limit is subject to the 8×10^7 V Hz product.

Use `dmm.func` to set the active function to AC volts, then set attributes as needed for your application. An example is shown in the following table.

Example program code for voltage measurement

Code	Notes and comments
<code>reset()</code>	Reset the Series 3700A to the factory defaults.
<code>dmm.func="acvolts"</code> <code>dmm.range=1</code> <code>dmm.detectorbandwidth=300</code>	Sets the DMM function to AC volts, with a range of 10 and detector bandwidth of 300.
<code>dmm.nplc=0.06</code> <code>dmm.autozero=0</code>	When bandwidth set to 300, NPLC can be programmed from 0.0005 plc to 12 plc at 60 Hz or 15 plc at 50 Hz.
<code>dmm.autodelay=dmm.AUTODELAY_ONCE</code>	Include a single 50 ms delay before each measurement after channel closure.
<code>scan.measurecount=25</code>	DMM takes a 25 readings on the same channel.
<code>dmm.configure.set("my-1Vac")</code>	Define this group of DMM settings as "my-1Vac".
<code>dmm.setconfig("4004, 4024", "my-1Vac")</code>	Assign the configuration for channels 4 and 24 to "my-1Vac".
<code>buf=dmm.makebuffer(200)</code> <code>buf.clear()</code> <code>buf.appendmode=1</code>	Set the buffer size set to 200 readings, clear the buffer, and set the readings to be appended to the existing buffer content.
<code>scan.create("4004, 4024")</code>	Create a scan list that includes channels 4 and 24. Backplane channels 4911 and 4921 are automatically paired.
<code>scan.scancount=4</code>	Set the scan to loop 4 times.
<code>scan.execute(buf)</code> <code>for x=1,buf.n do printbuffer(x,x,buf,</code> <code> buf.relativetimestamps)</code> <code>end</code>	Start the scan. Note that <code>x, x</code> prints reading and time vertically so you can copy and paste the information into Microsoft® Excel®.

Current measurements (DC current and AC current)

The Model 3706A can make DC current measurements from 1 pA to 3 A and AC current measurements from 1 mA to 3 A_{RMS}.

WARNING

To prevent electric shock, never make or break connections while power is present in the test circuit.

NOTE

Also see crest factor information contained in [AC voltage measurements and crest factor](#) (on page 5-5).

Settings available for current measurements

The following DMM attributes are available for AC current and DC current measurements:

- aperture (range of 10e-6 s to 0.250 s for 50 Hz; 8.33e-6 s to 0.250 s for 60 Hz)
- autodelay (dmm.AUTODELAY_ONCE, dmm.ON or dmm.OFF)
- autorange (dmm.ON or dmm.OFF)
- autozero (dmm.AUTOZERO_ONCE, dmm.ON or dmm.OFF)
- display digits (3, 4, 5, 6, or 7)
- filter count (1 to 100)
- filter enable (dmm.ON or dmm.OFF)
- filter type (dmm.FILTER_MOVING_AVG or dmm.FILTER_REPEAT_AVG)
- filter window (0 to 10%)
- DMM limit auto clear (dmm.ON or dmm.OFF)
- DMM limit enable (dmm.ON or dmm.OFF)
- DMM limit high fail (0 or 1)
- DMM limit high value (–4294967295 to +4294967295)
- DMM limit low fail (0 or 1)
- DMM limit low value (–4294967295 to +4294967295)
- line synchronization (dmm.ON or dmm.OFF) (dc only)
- math enable (dmm.ON or dmm.OFF)
- math format (dmm.MATH_NONE, dmm.MATH_MXB, dmm.MATH_PERCENT, or dmm.MATH_RECIPROCAL)
- math mxb b factor (–4294967295 to +4294967295)
- math mxb m factor (–4294967295 to +4294967295)
- math mxb units
- math percent (–4294967295 to +4294967295)
- npic (0.0005 to 15 for 60 Hz; 0.0005 to 12 for 50 Hz)
- range (0 to 3.1)
- relative offset enable (dmm.ON or dmm.OFF)
- relative offset level

Autodelay and auto range settings

The following table provides times for autodelay and autorange time for the Model 3706A DMM current function.

Function	Detector bandwidth	Range and delays							
		Range	10 μ A	100 μ A	1 mA	10 mA	100 mA	1 A	3 A
DC current	Not applicable	Range	10 μ A	100 μ A	1 mA	10 mA	100 mA	1 A	3 A
		Autodelay	13 ms	2 ms	2 ms	2 ms	2 ms	2 ms	2 ms
		Autorange	13 ms	2 ms	2 ms	2 ms	2 ms	2 ms	2 ms
AC current	Not applicable	Range			1 mA	10 mA	100 mA	1 A	3 A
		Autodelay			200 ms	200 ms	200 ms	200 ms	300 ms
	3 or 30 Hz	Autorange			200 ms	200 ms	200 ms	200 ms	300 ms
		Autodelay			50 ms	50 ms	50 ms	50 ms	75 ms
	300 Hz	Autorange			50 ms	50 ms	50 ms	50 ms	75 ms
		Autodelay			50 ms	50 ms	50 ms	50 ms	75 ms

Current measurement connections

See the Model 3721 information in the Series 3700 Switch and Control Cards Reference Manual for connection information.

NOTE

The Model 3721 switch card is the only card that supports DC current and AC current functions. You can only assign DC current or AC current to channels 41 and 42. If DC current or AC current is assigned to Channel 1-40, error 1116 "function mismatch in configuration" is displayed. Also, if a function other than DC or AC current is assigned to channel 41 or 42, error 1114 "function mismatch in configuration" is displayed.

Current measurement procedure from the front panel

1. Press the **OPENALL** key to open all switching channels.
2. Select the current measurement function by pressing the **CONFIG** key, and then pressing the **DMM** key. **FUNC** flashes on, then off. Press the **ENTER** key or wheel. **Function?** is displayed on the first line of the display and the second line displays available functions. Use the left or right arrow keys or the knob to select ACI or DCI.
3. Use the **RANGE** \blacktriangle and \blacktriangledown keys to:
 - Select a measurement range
 - Adjust the attributes after selecting the desired function under the Config DMM menu
4. Press the **AUTO** key to select autoranging (AUTO annunciator turns on).
5. Apply the currents to be measured.
6. If using a Series 3700A switch card, perform the following steps to assign a range of channels and assign the channel a DMM configuration:
 - a. Using the navigation wheel:
 - Press once to select 3721 card slot number and adjust 1-6.
 - Press a second time to select the start channel number.
 - Press a third time to select the end channel.
 - Press a fourth time to allow DMM configuration assignment to the channel or range of channels.
 - b. Press the **CLOSE** key.

7. Press the **TRIG** key and observe the display. If the "Overflow" message is displayed, select a higher range until a normal reading is displayed (or press the **AUTO** key for autoranging). For manual ranging, use the lowest possible range for the best resolution.
8. To measure other switching channels, repeat steps.
9. When finished, press the **OPENALL** key to open all channels.

NOTE

When an amps-only channel is closed, you cannot select a non-amps function.

When making measurements less than 1 μA , to minimize 50/60 Hz noise, use a twisted pair for current and DMM connections.

Current measurement procedure through remote commands

To set the DMM function for AC current measurements, send the command:

```
dmm.func = "accurrent"
```

To set the DMM function for DC current measurements, send the command:

```
dmm.func = "dccurrent"
```

Resistance measurements

The Model 3706A can make resistance measurements from 0.1 $\mu\Omega$ to 120 $\text{M}\Omega$. For resistances more than 1 $\text{k}\Omega$, the two-wire method is typically used for measurements. For resistances more than or equal to 1 $\text{k}\Omega$, the four-wire measurement method should be used to cancel the effect of test lead and channel path resistances.

DMM resistance measurement methods

The method that the Model 3706A uses to measure resistance depends on the resistance range. For resistance ranges from 1 Ω to 1 $\text{M}\Omega$, the Model 3706A uses the constant-current method to measure resistance. For resistance ranges from 10 $\text{M}\Omega$ to 100 $\text{M}\Omega$ ranges, the ratiometric method is used.

When the constant-current method is used, the Model 3706A sources a constant current (I) to the device under test and measures the voltage (V). Resistance (R) is then calculated and displayed using the known current and measured voltage ($R = V/I$).

When the ratiometric method is used, test current is generated by a 6.4 V reference through a 10 $\text{M}\Omega$ reference resistance (R_{REF}).

For more detail on these methods, see [Constant-current source method](#) (on page 5-9) and [Ratiometric method](#) (on page 5-9).

The Model 3706A uses four methods to detect open leads. For detail, see [Open lead detection](#) (on page 5-14).

Settings available for resistance measurements

The following DMM attributes are available for resistance measurements:

- aperture (range of 10e-6 s to 0.250 s for 50 Hz; 8.33e-6 s to 0.250 s for 60 Hz)
- autodelay (dmm.AUTODELAY_ONCE, dmm.ON or dmm.OFF)
- autorange (dmm.ON or dmm.OFF)
- autozero (dmm.AUTOZERO_ONCE, dmm.ON or dmm.OFF)
- display digits (3, 4, 5, 6, or 7)
- dry circuit (dmm.ON or dmm.OFF) (only for four-wire ohms and commonside ohms)
- filter count (1 to 100)
- filter enable (dmm.ON or dmm.OFF)
- filter type (dmm.FILTER_MOVING_AVG or dmm.FILTER_REPEAT_AVG)
- filter window (0 to 10%)
- DMM limit auto clear (dmm.ON or dmm.OFF)
- DMM limit enable (dmm.ON or dmm.OFF)
- DMM limit high fail (0 or 1)
- DMM limit high value (–4294967295 to +4294967295)
- DMM limit low fail (0 or 1)
- DMM limit low value (–4294967295 to +4294967295)
- line synchronization (dmm.ON or dmm.OFF)
- math enable (dmm.ON or dmm.OFF)
- math format (dmm.MATH_NONE, dmm.MATH_MXB, dmm.MATH_PERCENT, or dmm.MATH_RECIPROCAL)
- math mx b factor (–4294967295 to +4294967295)
- math mx m factor (–4294967295 to +4294967295)
- math mx units
- math percent (–4294967295 to +4294967295)
- npic (0.0005 to 15 for 60 Hz; 0.0005 to 12 for 50 Hz)
- offset compensation (dmm.ON or dmm.OFF) (only for four-wire ohms and commonside ohms)
- open detector (dmm.ON or dmm.OFF) (only for four-wire ohms and commonside ohms)
- range (0 to 120e6)
- relative offset enable (dmm.ON or dmm.OFF)
- relative offset level

Autodelay and auto range settings

The following table provides times for autodelay and autorange time for the Model 3706A DMM functions.

When measuring resistances that are more than 10 K Ω , cable and Series 3700A card capacitance, along with dielectric absorption, can cause uncertainties, such as low readings. The low readings are caused by insufficient settling time after the closure of a Series 3700A switch card channel. Automatic delays have been optimized to allow proper settling after the close of a channel. See below settling times. If the application requires an additional settling delay, use the following commands to add delays to the channel or slot:

```
channel.setdelay("4004", 0.050)
```

Adds 50 ms of delay after closing channel 4 in slot 4.

```
channel.setdelay("slot4", 0.050)
```

Adds 50 ms of delay to all channels in slot 4.

For continuity, the range is 1 k Ω with an autodelay of 3 ms and auto range of 2.5 ms.

Function	Range and delays							
2-wire ohm and 4-wire ohm	Range	1 - 100 Ω	1 k Ω	10 k Ω	100 k Ω	1 M Ω	10 M Ω	100 M Ω
	Autodelay	3 ms	3 ms	13 ms	25 ms	100 ms	250 ms	375 ms
	Autorange	2.5 ms	2.5 ms	12.5 ms	25 ms	100 ms	250 ms	375 ms
Dry circuit ohms	Range	1 - 10 Ω	100 - 2k Ω					
	Autodelay	3 ms	13 ms					
	Autorange	2.5 ms	12.5 ms					


Resistance measurement connections

Analog backplane connector (rear panel)

Connections for resistance measurements are shown below.


For 2-wire resistance measurements, connect the leads to INPUT HI and LO.

Figure 4-4: Two-wire resistance measurements




For 4-wire resistance, connect the leads to INPUT HI and LO, and sense Ω4 HI and LO.

Figure 4-5: Four-wire resistance measurement




Switching module connections

Connections for the switching module are shown below. As shown, each of the 40 channels can be used to perform 2-wire resistance measurements.

Figure 4-6: Two-wire switching module resistance connection

For 4-wire resistance measurements, a channel pair is used for each 4-wire measurement, as shown below. For 4-wire resistance connections on a 40-channel switching module, channels 1 through 20 (which are used as the INPUT terminals) are paired to channels 21 through 40 (which are used as the SENSE terminals). Channel 1 is paired to channel 21, channel 2 is paired to channel 22, and so on.

Figure 4-7: Four-wire switching module resistance connection

NOTE Source current flows from input high (H) to input low (L).

Cable leakage

For high resistance measurements in a high humidity environment, use Teflon™ insulated cables to minimize errors due to cable leakage.

Shielding

To achieve a stable reading, it helps to shield resistances greater than 100 kΩ. As shown in [Analog backplane connector \(rear panel\)](#) (on page 4-19), place the resistance in a shielded enclosure and connect the shield to the INPUT LO terminal of the instrument electrically.

Commonside ohms

The following figure provides a switching schematic for the Model 3721 when measuring 4-wire commonside ohms.

Resistance measurements from the front panel



CAUTION

Inputs: Do not apply more than 425 V peak between INPUT HI and LO. Failure to observe this caution may result in instrument damage.

Switching cards: Do not apply more than 300 V DC or 300 V_{RMS} (425 V_{peak}) for AC waveforms between any two pins. Failure to observe this caution may result in switching module damage.

For example, if INPUT channel 1 HI is 300 VDC from channel 1 LO, channel 1 LO must be ≈ 0 VDC from chassis ground.

Perform the following steps to measure resistance:

1. Press the **OPENALL** key to open all switching channels. Refer to DCV for DMM function, range, and other settings.
2. Connect the resistances to be measured.
3. Select the resistance measurement function by pressing the **CONFIG** key, and then pressing the **DMM** key. FUNC flashes on, then off. Press the **ENTER** key or wheel. **Function?** is displayed on the first line of the display and the second line displays available functions. Use the left or right arrow keys or the knob to select **TWOWIREOHMS**, **FOURWIREOHMS**, or **COMMONSIDE**.
4. Use the **RANGE** \blacktriangle and \blacktriangledown keys to:
 - Select a measurement range
 - Adjust the attributes after selecting the desired function under the Config DMM menu
 - Press the **AUTO** key to select autoranging (AUTO annunciator turns on)
5. Apply the resistances to be measured.
6. If using a Series 3700A switch card, perform the following steps to assign a range of channels and assign the channel a DMM configuration:
 - a. Using the navigation wheel:
 - Press once to select 3700 card slot number and adjust 1-6.
 - Press a second time to select the start channel number.
 - Press a third time to select the end channel.
 - Press a fourth time to allow DMM configuration assignment to the channel or range of channels.
 - b. Press the **CLOSE** key.
7. Press the **TRIG** key and observe the display. If the "Overflow" message is displayed, select a higher range until a normal reading is displayed (or press the **AUTO** key for autoranging). For manual ranging, use the lowest possible range for the best resolution.
8. To measure other switching channels, repeat steps 5 and 6.
9. When finished, press the **OPENALL** key to open all channels.

Resistance measurements through remote interface

Examples of remote interface measurements setups through the remote interface are shown here.

```
dmm.func = "twowireohms"
dmm.autodelay = dmm.ON
dmm.measurecount = 10
ReadingBufferOne = dmm.makebuffer(1000)
dmm.measure(ReadingBufferOne)
```

An automatic delay is applied to each measurement when the DMM is measuring two-wire ohms. Take 10 measurements and store them in a reading buffer named ReadingBufferOne that can store up to 1000 readings.

```
dmm.func = "fourwireohms"
dmm.autodelay = dmm.AUTODELAY_ONCE
dmm.measurecount = 10
ReadingBufferTwo = dmm.makebuffer(1000)
dmm.measure(ReadingBufferTwo)
```

Sets an auto delay for the first of the ten four-wire ohm readings. Readings two through ten will occur as quickly as possible, with readings stored in a reading buffer called ReadingBufferTwo that can store up to 1000 readings.

Temperature measurements

The Model 3706A can measure temperature using various thermoelectric transducers, including: thermocouples, thermistors, and 3 or 4-wire resistance temperature detectors (RTDs).

When deciding which type to use, note that the thermocouple is the most versatile and useful for significant distances between the sensor and the instrument, the thermistor is the most sensitive, the 4-wire RTD is the most stable, and the 3-wire RTD minimizes the number of conductors per sensor (3).

Settings available for temperature measurements

- aperture (range of 10e-6 s to 0.250 s for 50 Hz; 8.33e-6 s to 0.250 s for 60 Hz)
- autodelay (dmm.AUTODELAY_ONCE, dmm.ON or dmm.OFF)
- autozero (dmm.AUTOZERO_ONCE, dmm.ON or dmm.OFF)
- display digits (3, 4, 5, 6, or 7)
- filter count (1 to 100)
- filter enable (dmm.ON or dmm.OFF)
- filter type (dmm.FILTER_MOVING_AVG or dmm.FILTER_REPEAT_AVG)
- filter window (0 to 10%)
- Four-wire RTD (dmm.RTD_PT100, dmm.RTD_D100, dmm.RTD_F100, dmm.RTD_PT385, dmm.RTD_PT3916, dmm.RTD_USER) (only with dmm.transducer set to dmm.TEMP_FOURRTD)
- DMM limit auto clear (dmm.ON or dmm.OFF)
- DMM limit enable (dmm.ON or dmm.OFF)
- DMM limit high fail (0 or 1)
- DMM limit high value (–4294967295 to +4294967295)
- DMM limit low fail (0 or 1)

- DMM limit low value (–4294967295 to +4294967295)
- line synchronization (dmm.ON or dmm.OFF)
- math enable (dmm.ON or dmm.OFF)
- math format (dmm.MATH_NONE, dmm.MATH_MXB, dmm.MATH_PERCENT, or dmm.MATH_RECIPROCAL)
- math mxb b factor (–4294967295 to +4294967295)
- math mxb m factor (–4294967295 to +4294967295)
- math mxb units
- math percent (–4294967295 to +4294967295)
- npic (0.0005 to 15 for 60 Hz; 0.0005 to 12 for 50 Hz)
- offset compensation (dmm.ON or dmm.OFF)
- open detector (dmm.ON or dmm.OFF)
- reference junction (dmm.REF_JUNCTION_SIMULATED, dmm.REF_JUNCTION_INTERNAL, or dmm.REF_JUNCTION_EXTERNAL) (only available when transducer type is set to thermocouple).
- relative offset enable (dmm.ON or dmm.OFF)
- relative offset level
- RTD alpha (0 to 0.01) (only with dmm.transducer set to dmm.TEMP_FOURRTD or dmm.TEMP_THREERTD)
- RTD beta (0 to 1.0) (only with dmm.transducer set to dmm.TEMP_FOURRTD or dmm.TEMP_THREERTD)
- RTD delta (0 to 5) (only with dmm.transducer set to dmm.TEMP_FOURRTD or dmm.TEMP_THREERTD)
- RTD zero (0 to 10000) (only with dmm.transducer set to dmm.TEMP_FOURRTD or dmm.TEMP_THREERTD)
- simulated reference temperature (Celsius (0 °C to 65 °C), Fahrenheit (32 °F to 149 °F), or Kelvin (273 °K to 338 °K)) (only with dmm.transducer set to dmm.TEMP_THERMOCOUPLE)
- thermistor type (2252, 5000, or 10000) (only with dmm.transducer set to dmm.TEMP_THERMISTOR)
- thermocouple type (dmm.THERMOCOUPLE_J, dmm.THERMOCOUPLE_K, dmm.THERMOCOUPLE_T, dmm.THERMOCOUPLE_E, dmm.THERMOCOUPLE_R, dmm.THERMOCOUPLE_S, dmm.THERMOCOUPLE_B, dmm.THERMOCOUPLE_N) (only with dmm.transducer set to dmm.TEMP_THERMOCOUPLE)
- three-wire RTD type (dmm.RTD_PT100, dmm.RTD_D100, dmm.RTD_F100, dmm.RTD_PT385, dmm.RTD_PT3916, dmm.RTD_USER) (only with dmm.transducer set to dmm.TEMP_THREERTD)
- transducer type (dmm.TEMP_THERMOCOUPLE, dmm.TEMP_THERMISTOR, dmm.TEMP_THREERTD, or dmm.TEMP_FOURRTD)
- units (dmm.UNITS_CELSIUS, dmm.UNITS_KELVIN, or dmm.UNITS_FAHRENHEIT)

Autodelay and auto range settings

The following table provides times for autodelay and auto range time for the Model 3706A DMM functions.

For the standard RTD values (PT100, D100, F100, PT385, and PT3916), use 1 k Ω . For user-set RTDs, use 1 k Ω or 10 k Ω , depending on the alpha, beta, delta, and Ro values.

For thermocouples, the autodelay and auto range functions are 1 ms.

For thermistors, for:

- 2252 Ω and 5k Ω : 100 M Ω to 10 M Ω , dependent on temperature
- 10k Ω : 1 k Ω to 10 M Ω , dependent on temperature

Thermocouples

For thermocouples, temperature measurement range depends on which type of thermocouple is being used. Thermocouples that are supported include types J, K, N, T, E, R, S, and B.

Type	Range	Resolution
J	-200 °C to +760 °C	0.001 °C
K	-200 °C to +1372 °C	0.001 °C
N	-200 °C to +1300 °C	0.001 °C
T	-200 °C to +400 °C	0.001 °C
E	-150 °C to +1000 °C	0.001 °C
R	0 °C to +1768 °C	0.1 °C
S	0 °C to +1786 °C	0.1 °C
B	+350 °C to +1820 °C	0.1 °C

When two wires made up of dissimilar metals are joined together, a voltage is generated. The generated voltage is a function of temperature. As temperature changes, the voltage changes. The thermocouple voltage equates to a temperature reading. This is the basic operation principle of the thermocouple.

When you connect a thermocouple directly to the input of the Model 3706A, at least one of those connections will be a junction made up of two dissimilar metals. Hence, another voltage is introduced and is algebraically added to the thermocouple voltage. The result will be an erroneous temperature measurement.

To cancel the affects of the unwanted thermal voltage, the thermocouple circuit requires a reference junction that is at a known temperature.

The Model 3706A has an open thermocouple detection circuit. Long lengths of thermocouple wire can have a large amount of capacitance, which is seen at the input of the DMM. If an intermittent open occurs in the thermocouple circuit, the capacitance can cause an erroneous on-scale reading. The open thermocouple detection circuit, when enabled, applies a 100 μ A pulse of current to the thermocouple before the start of each temperature measurement. For more detail, see [Open thermocouple detection](#) (on page 5-19).

NOTE

The default setting is for open thermocouple detection to be on (`dmm.opendetector = dmm.ON`).

Thermocouple connections


Connections for thermocouples are shown below. Thermocouples are color coded to identify the positive (+) and negative (-) leads (see the table). Note that the negative (-) lead for U.S. type T/Cs is red.

T/C type	Positive (+)	Negative (-)
J	White	Red
	Yellow	Blue
	Red	Blue
	Red	White
	Yellow	Black
K	Yellow	Red
	Brown	Blue
	Red	Green
	Red	White
	Yellow	Purple
N	Orange	Red
	—	—
	—	—
	—	—
	—	—
T	Blue	Red
	White	Blue
	Red	Brown
	Red	White
	Yellow	Blue

T/C type	Positive (+)	Negative (-)	
E	U.S.	Purple	Red
	British	Brown	Blue
	DIN	Red	Black
	Japanese	Red	White
	French	Yellow	Blue
	R	U.S.	Black
British		White	Blue
DIN		Red	White
Japanese		Red	White
French		Yellow	Green
S		U.S.	Black
	British	White	Blue
	DIN	Red	White
	Japanese	Red	White
	French	Yellow	Green
	B	U.S.	Gray
British		—	—
DIN		Red	Gray
Japanese		Red	Gray
French		—	—

When using the Model 3706A analog backplane connector, use a simulated reference junction for thermocouple temperature measurements. An ice bath, as shown below, serves as an excellent cold junction because it is relatively easy to hold the temperature to 0 °C. Notice that copper wires are used to connect the thermocouple to the Model 3706A input.

Figure 4-8: Simulated reference junction



NOTE

The positive lead of the type T thermocouple is made of copper. Therefore, that lead can be connected directly to the input of the switching module (it does not have to be maintained at the simulated reference temperature, in other words, immersed in an ice bath).

For the thermocouple-capable switching modules, you can also use a simulated reference junction as shown, or you can connect the thermocouple wires directly to the screw terminals (internal reference junction). Using a simulated reference junction may be inconvenient, but it will provide more accurate temperature measurements (assuming the user enters a precise reference temperature).

Figure 4-9: Simulated reference junction switching module





Figure 4-10: Internal reference junction (40 channel switching module)



Thermocouple measurement from the front panel

NOTE

If the Model 3706A is being controlled remotely, place the instrument in local control by pressing the **EXIT** key.

To make a thermocouple measurement from the front panel:

1. Press the **OPENALL** key to open all switching channels.
2. Select the temperature measurement function by pressing the **CONFIG** key, and then pressing the **DMM** key. FUNC flashes on, then off. Press the **ENTER** key or wheel. **FUNCTION?** is displayed on the first line of the display and the second line displays available functions. Use the left or right arrow keys of the knob to select TEMP.
3. Press the **CONFIG** key and then the **DMM** key. The "TEMP ATTR MENU" opens.
4. Set units of measurement degrees:
 - Turn the navigation wheel to scroll to the "UNITS" menu item (right most menu item) and press the **ENTER** key.
 - Turn the navigation wheel to select desired units (Celsius, Kelvin, or Fahrenheit) and press the **ENTER** key.
5. Set THERMO device attributes:
 - Turn the navigation wheel to scroll to the "THERMO" menu item and press the **ENTER** key.
 - Turn the navigation wheel to scroll to the "THERMOCOUPLE" type and press the **ENTER** key.
 - Turn the navigation wheel to select desired type and press the **ENTER** key.
6. Press the **EXIT** key twice to leave the "TEMP ATTR MENU."
7. Connect the temperature transducers to be measured.
8. If using a switching module, perform the following steps to close the desired channel.
 - a. Use the navigation wheel to dial in the channel number.
 - b. Press the **CLOSE** key.
9. Press the **TRIG** key and observe the displayed reading.
10. To measure other channels, repeat steps 7 and 8.
11. When finished, press the **OPENALL** key to open all channels.

Thermocouple measurement through the remote interface

To take thermocouple measurements through the remote interface:

<pre>dmm.func = "temperature" dmm.transducer = dmm.TEMP_THERMOCOUPLE dmm.thermocouple = dmm.THERMOCOUPLE_J</pre>	Sets the thermocouple type to J.
--	----------------------------------

Thermistors

The temperature measurement range for thermistors is $-80\text{ }^{\circ}\text{C}$ to $150\text{ }^{\circ}\text{C}$ (0.01 ° resolution). Thermistor types that are supported include the $2.2\text{ k}\Omega$, $5\text{ k}\Omega$, and $10\text{ k}\Omega$ types.

The thermistor is a temperature sensitive resistor. Its resistance changes non-linearly with changes in temperature. Most thermistors have a negative temperature coefficient — as temperature increases, the resistance decreases. The Model 3706A measures the resistance of the thermistor and calculates the temperature reading.



Of all the temperature transducers, the thermistor is the most sensitive. It can detect minute changes in temperature. It is a good choice when measuring slight changes in temperature. The downside for this increased sensitivity is the loss of linearity. Because they are especially non-linear at high temperatures, it is best to use them for measurements below $100\text{ }^{\circ}\text{C}$.

NOTE

Curve fitting constants are used in the equation to calculate thermistor temperature. The thermistor manufacturer's specified curve fitting may not be exactly the same as the ones used by the Model 3706A.

Thermistor connections

A thermistor can be connected directly to the analog backplane connector or to any of the applicable input channels of a thermistor capable switching module.

Figure 4-11: Thermistor analog backplane connection**Figure 4-12: Thermistor switching module connection****Thermistor measurement from the front panel****To configure thermistor measurements from the front panel:**

1. If needed, change to the temperature function ("TMP" is displayed) by pressing the **FUNC** key.
2. Select the temperature measurement function by pressing the **CONFIG** key, and then pressing the **DMM** key. FUNC flashes on, then off. Press the **ENTER** key or wheel. **FUNCTION?** is displayed on the first line of the display and the second line displays available functions. Use the left or right arrow keys of the knob to select TEMP.
3. Set units of measurement degrees:
 - Turn the navigation wheel to scroll to the "UNITS" menu item (right most menu item) and press the **ENTER** key.
 - Turn the navigation wheel to select desired units (Celsius, Kelvin, or Fahrenheit) and press the **ENTER** key.

4. Set THERMO device attributes:
 - Turn the navigation wheel to scroll to the "THERMO" menu item and press the **ENTER** key.
 - Turn the navigation wheel to scroll to the "THERMISTOR" temperature connection and press the **ENTER** key.
 - Turn the navigation wheel to select desired resistance (2252 Ω , 5000 Ω , or 10000 Ω) and press the **ENTER** key.
5. Press the **EXIT** key twice to leave the "TEMP ATTR MENU."

Thermistor measurement through the remote interface

This sample remote code configures a thermistor type 2252 and assigns it to a 4-channel scan list.

```
reset ()
dmm.func=dmm.TEMPERATURE
dmm.transducer= dmm.TEMP_THERMISTOR          -- or 2
dmm.thermistor=2.252e3
dmm.units=dmm.UNITS_FAHRENHEIT              -- or 4
dmm.configure.set ("my_thermist")
dmm.setconfig("4011:4014", "my_thermist")
scan.measurecount=1
buf=dmm.makebuffer (20)
buf.clear ()
buf.appendmode=1
scan.create ("4011:4014")
scan.scancount=5
scan.execute (buf)
for x=1, buf.n do printbuffer (x,x,buf) end
channel.open ("allslots")
```

Also see remote command `dmm.thermistor` (on page 8-242) for more information on setting thermistor measurement attributes.

RTDs (Resistance Temperature Detector)

Of all the temperature transducers, the resistance temperature detector (RTD) exhibits the most stability and linearity. The Model 3706A supports 3-wire and 4-wire RTD types of:

- PT100
- D100
- F100
- PT385
- PT3916

A USER type is also available to modify RTD parameters, such as the resistance at 0°C. The USER type can be enabled from the front panel, but the settings can only be changed using remote programming.

For 4-wire RTDs, the temperature measurement range is –200 °C to 630 °C (0.01 °C resolution).

The RTD has a metal construction (typically platinum). The resistance of the RTD changes with change with temperature. The Model 3706A measures the resistance and calculates the temperature reading. When using default RTD parameters, the resistance of the RTD will be 100 Ω at 0°C.

By default, the Model 3706A performs the 4-wire measurement using offset-compensated ohms, which provides the most accurate way to measure the low resistance of the RTD. For faster RTD measurements when the most accurate measurements are not required, offset-compensation may be disabled for 4-wire RTD measurements.

Use of a 3-wire RTD requires a special math capability to compensate for lead resistance on the 3rd wire.

3-wire RTD connections

Shown below are 3-wire RTD connections to the Model 3706A. For a 3-wire RTD capable 40-channel switching module, paired channels perform the 3-wire measurement. For example, the two input leads of the RTD are connected to a primary channel (1 through 20), while only the LO sense lead is connected to its paired channel (21 through 40). Channel 1 is paired to channel 21, channel 2 is paired to channel 22, and so on.

NOTE

The HI sense of the paired channels are not used for 3-wire RTD.

Figure 4-13: Three-wire RTD connections





Figure 4-14: Three-wire RTD switching module connections



4-wire RTD connections

Shown below are 4-wire RTD connections to the Model 3706A. For a 4-wire RTD capable 40-channel switching module, paired channels are used to perform the 4-wire measurement. For example, the two input leads of the RTD are connected to a primary channel (1 through 20), while the two sense leads are connected to its paired channel (21 through 40). Channel 1 is paired to channel 21, channel 2 is paired to channel 22, and so on.

Figure 4-15: Four-wire RTD connections





Figure 4-16: Four-wire RTD switching module connections

RTD temperature measurement configuration

The alpha, beta, delta, and Ω at 0 °C parameters for the five basic RTD types are provided in the table below.

NOTE

These parameters can be modified using remote commands for USER type RTDs.

Type	Standard	Alpha	Beta	Delta	Ω at 0 °C
PT100	ITS-90	0.00385055	0.10863	1.49990	100
D100	ITS-90	0.003920	0.10630	1.49710	100
F100	ITS-90	0.003900	0.11000	1.49589	100
PT385	IPTS-68	0.003850	0.11100	1.50700	100
PT3916	IPTS-68	0.003916	0.11600	1.50594	100

RTD measurement from the front panel

To configure 3 or 4-wire RTD measurements from the front panel:

1. If needed, change to the temperature function ("TMP" is displayed) by pressing the **FUNC** key.
2. Select the temperature measurement function by pressing the **CONFIG** key, and then pressing the **DMM** key. FUNC flashes on, then off. Press the **ENTER** key or wheel. **FUNCTION?** is displayed on the first line of the display and the second line displays available functions. Use the left or right arrow keys of the knob to select TEMP.
3. Set units of measurement degrees:
 - Turn the navigation wheel to scroll to the "UNITS" menu item (right most menu item).
 - Press the **ENTER** key.
 - Using the navigation wheel, select desired units (Celsius, Kelvin, or Fahrenheit).
 - Press the **ENTER** key.

4. Set three-wire or four-wire RTD device attributes:
 - Turn the navigation wheel to scroll to the "THERMO" menu item and press the **ENTER** key.
 - Turn the navigation wheel to scroll to the "THREERTD" or "FOURRTD" temperature connection and press the **ENTER** key.
 - Turn the navigation wheel to select desired RTD type (PT100, D100, F100, PT3916, PT385, or USER) and press the **ENTER** key.
5. Press the **EXIT** key twice to leave the "TEMP ATTR MENU."
6. Connect the temperature transducers to be measured.
7. If using a switching module, perform the following steps to close the desired channel. Note that for 3 or 4-wire RTD measurements, you will close the primary (INPUT) channel (1 through 10). The channel that it is paired to will close automatically.
 - a. Use the navigation wheel to dial in the channel number.
 - b. Press the **CLOSE** key.
8. Press the **TRIG** key and observe the displayed reading.
9. To measure other switching channels, repeat steps 6 and 7.
10. When finished, press the **OPENALL** key to open all channels.

RTD measurement from the remote interface

You can use the remote command [dmm.fourrtd](#) (on page 8-189) or [dmm.threertd](#) (on page 8-244) to set attributes.

For example, the following remote commands configure temperature function to a custom RTD and assign it to a 10-channel scan list.

```

reset ()
dmm.func=dmm.TEMPERATURE
-- or 3, or dmm.TEMP_FOURRTD, or 4
dmm.transducer= dmm.TEMP_THREERTD
-- dmm.fourrtd also supported
dmm.threertd=dmm.RTD_USER
-- allowed values are 0 to 0.01
dmm.rtdalpha= 0.003
-- allowed values are 0 to 1.00
dmm.rtdbeta= 0.105
-- allowed values are 0 to 5.00
dmm.rtddelta = 1.51
-- allowed values are 0 to 10,000
dmm.rtdzero= 125
-- default dmm.ON
dmm.offsetcompensation=dmm.OFF
dmm.configure.set("my_rtd_user")
dmm.setconfig("4001:4010", "my_rtd_user")
scan.measurecount=1
buf=dmm.makebuffer(20)
buf.clear()
buf.appendmode=1
scan.create("4001:4010")
scan.scancount=2
scan.execute(buf)
for x=1, buf.n do printbuffer (x,x,buf) end
channel.open("allslots")

```

Frequency and period measurements

The Model 3706A is specified for frequency measurements from 3 Hz to 500 kHz on voltage ranges of 100 mV, 1 V, 10 V, 100 V, and 300 V. Period (1/ frequency) measurements can be taken from 2 μ s to 333 ms on the same voltage ranges as the frequency.

the input impedance is 1 M Ω || less than 100 pF, AC coupled.

The instrument uses the volts input to measure frequency. The AC voltage range can be changed with the **RANGE** \blacktriangledown and \blacktriangle keys. The signal voltage must be greater than 10% of the full-scale range.

NOTE

Frequency or period measurements as low as 0.5 Hz (2 seconds) and less than or equal to 1 MHz (1 μ s) are possible but depend on the selected range.



CAUTION

Do not apply more than maximum input levels indicated or instrument damage may occur. The voltage limit is subject to the 8×10^7 VHZ product.

Settings available for frequency and period measurements

- aperture (range of 0.01 s to 0.273 s)
- autodelay (dmm.AUTODELAY_ONCE, dmm.ON or dmm.OFF)
- autozero (dmm.AUTOZERO_ONCE, dmm.ON or dmm.OFF)
- display digits (3, 4, 5, 6, or 7)
- DMM limit auto clear (dmm.ON or dmm.OFF)
- DMM limit enable (dmm.ON or dmm.OFF)
- DMM limit high fail (0 or 1)
- DMM limit high value (–4294967295 to +4294967295)
- DMM limit low fail (0 or 1)
- DMM limit low value (–4294967295 to +4294967295)
- math enable (dmm.ON or dmm.OFF)
- math format (dmm.MATH_NONE, dmm.MATH_MXB, dmm.MATH_PERCENT, or dmm.MATH_RECIPROCAL)
- math mxb b factor (–4294967295 to +4294967295)
- math mxb m factor (–4294967295 to +4294967295)
- math mxb units
- math percent (–4294967295 to +4294967295)
- relative offset enable (dmm.ON or dmm.OFF)
- relative offset level
- threshold (0 to 303 V)

Autodelay and auto range settings

The following table provides times for autodelay and autorange time for the Model 3706A DMM functions.

Function	Ranges and delays					
Frequency and periods	Range	100 mV	1 V	10 V	100 V	300 V
	Autodelay	100 ms				
	Autorange	100 ms				

Trigger level

Frequency and period use a zero-crossing trigger, meaning that a count is taken when the frequency crosses the zero level. The Model 3706A uses a reciprocal counting technique to measure frequency and period. This method generates constant measurement resolution for any input frequency. The multimeter's AC voltage measurement section performs input signal conditioning. If the input signal voltage exceeds the selected voltage range, 000.0000 mHz (0.000000 μ s) will be returned.

Gate time

The gate time is the amount of time the Model 3706A uses to sample frequency or period readings. The gate time can be set from 0.01 to 0.273 s by setting the DMM aperture attribute.

The Model 3706A completes a reading when it receives its first positive zero-crossing after the gate time expires. For example, for any arbitrary frequency, you may wait up to the gate time plus two times the period of the input waveform before the Model 3706A returns a reading.

Frequency connections

Frequency connections for the Model 3706A and a switching module are shown below.





Figure 4-18: FREQ and PERIOD connections (switching module)



Frequency and period measurement procedure from front panel

CAUTION

Do not apply more than the maximum input levels for the Model 3706A or installed switching module (whichever is lower) or instrument damage may occur.

NOTE

If the Model 3706A is being controlled remotely, place the instrument in local control by pressing the **LOCAL** or **EXIT** key.

1. Press the **OPENALL** key to open all switching channels.
2. Select the **CONFIG** key, and then select the **DMM** key. Select the FUNC menu by pressing **ENTER**. Scroll through the menu until FREQ or PERIOD is displayed, using the navigation wheel or left right arrows.
3. Set threshold voltage:
 - Turn the navigation wheel to scroll to the "THRESHOLD" menu item (right most menu item) and press the **ENTER** key.
 - Using the navigation wheel, dial in the desired voltage to be used as a threshold (0 V to 303 V; default is the 10 V range).
 - Press the **ENTER** key to set.
 - Press the **EXIT** key to leave the "FREQ ATTR MENU."
4. Apply the AC voltages to be measured (see CAUTION).

NOTE

When observing the displayed readings, if 000.0000 mHz or 000.0000 ms is displayed, select a lower range until a normal reading is displayed. Use the lowest possible range for the best resolution.

5. Press the **TRIG** key and observe the displayed reading.
6. To measure other switching channels, repeat steps 5 and 6.
7. When finished, press the **OPENALL** key to open all channels.

Frequency and period measurement procedure through remote interface



CAUTION

Do not apply more than the maximum input levels for the Model 3706A or installed switching module (whichever is lower) or instrument damage may occur.

To set the frequency through the remote command interface:

```
dmm.func = "frequency"
dmm.threshold = 30
```

Sets the threshold range for frequency to 30.

Continuity testing

The Model 3706A can test continuity using the 2-wire 1 k Ω range with a user selectable threshold resistance level (1 Ω to 1000 Ω). When the measured circuit is below the set threshold level, the instrument displays the resistance readings. When the measured circuit is above the threshold level, the instrument displays the message "OPEN."

The continuity function does not support relative offset. Use the [math calculations](#) (see "[Settings available for continuity testing](#)" on page 4-38), with b as an offset, to compensate for cable and 3700A card path resistance.

NOTE

The reading rate for continuity is fixed at 0.006 power line cycles. Limits and digital outputs cannot be used when testing continuity with the continuity (CONT) function. If you need to use these operations, use the two-wire ohm function to test continuity.

Settings available for continuity testing

- autodelay (dmm.AUTODELAY_ONCE, dmm.ON or dmm.OFF)
- display digits (3, 4, 5, 6, or 7)
- line synchronization (dmm.ON or dmm.OFF)
- math enable (dmm.ON or dmm.OFF)
- math format (dmm.MATH_NONE, dmm.MATH_MXB, dmm.MATH_PERCENT, or dmm.MATH_RECIPROCAL)
- math mxb b factor (–4294967295 to +4294967295)
- math mxb m factor (–4294967295 to +4294967295)
- math mxb units
- math percent (–4294967295 to +4294967295)
- nplc (0.0005 to 15 for 60 Hz; 0.0005 to 12 for 50 Hz)
- threshold (1 to 1000 Ω)

Autodelay and auto range settings


The following table provides times for autodelay and auto range time for the Model 3706A DMM functions.

Function	Detector bandwidth	Range and delays
	Range	1k Ω
Continuity	Autodelay	3ms
	Autorange	2.5ms

Continuity testing connections


When using the rear analog backplane connector, connect the test leads to the INPUT HI and LO terminals as shown below.

Figure 4-19: Continuity connections



Connections to test continuity using a switching module are shown below. Because this is a 2-wire ohm measurement, channels 1 through 40 of a 40-channel switching module can be used.

Figure 4-20: Continuity connections using a switching module



Continuity testing procedure

NOTE

If the Model 3706A is in remote, place the unit in local by pressing the **LOCAL** key (or the **EXIT** key). Refer to DCV measurements for function configuration and menus.

1. Select the continuity measurement function:
 - a. Press the **CONFIG** key, and then press the **DMM** key. **FUNC** flashes on, then off.
 - b. Press the **ENTER** key or navigation wheel \odot . The "Function?" menu is displayed.
 - c. Turn the navigation wheel \odot to highlight **CONT**, then push the navigation wheel \odot to select it.
 - d. Press the **EXIT** key to leave the "Function?" menu.
2. Set threshold resistance:
 - a. Press the **CONFIG** key, and then press the **DMM** key. **FUNC** flashes on, then off.
 - b. Turn the navigation wheel to scroll to the **THRESHOLD** menu item, and then press the **ENTER** key.
 - c. Using the <mw>, dial in the desired resistance to be used as a threshold (1 Ω to 1000 Ω).
 - d. Press the **ENTER** key to set.
 - e. Press the **EXIT** key to leave the "CONT ATTR MENU."
3. Apply the resistance to be tested. If using a switching module, perform the following steps to close the appropriate channel.
 - a. Use the navigation wheel \odot to dial in the channel number.
 - b. Press the **CLOSE** key.
4. Press the **TRIG** key and observe the displayed reading.
5. To measure other switching channels, repeat steps 5 and 6.

NOTE

If the measured circuit is below the set threshold level, the instrument will display the resistance readings. If the measured circuit is above the threshold level, the instrument will display the message "OPEN."

6. To disable continuity testing, select a different function (for example, DCV).
7. When finished, press the **OPENALL** key to open all channels.

NOTE

Limits and digital outputs cannot be used when testing continuity with the continuity (CNT) function. If you need to use these operations, use the 2W Ω function to test continuity.

Also see the bus command `dmm.threshold` (on page 8-245) for more information on threshold attributes.

`dmm.threshold` is a common command. To enable a unique continuity threshold, first select the function `dmm.func = "continuity"`, then select the threshold value. The threshold value will be remembered after exiting when returning to the function (unless reset).

Refining measurements

Relative offset

The relative offset (REL) feature can be used to set offsets to zero (0) or subtract a baseline reading from present and future readings. With relative offset enabled, subsequent readings are the difference between the actual input value and the relative offset value, as follows:

$$\text{Displayed reading} = \text{Actual input} - \text{Relative offset value}$$

Once a relative offset value is established for a measurement function, the value is the same for all ranges. For example, if 0.5 A is set as a relative offset value on the 1 A range, the relative offset value is also 0.5 A on the lower current ranges.

Selecting a range that cannot accommodate the relative offset value does not cause an overflow condition, but it also does not increase the maximum allowable input for that range. For example, on the 1 A range, the Series 3700A still overflows for a more than 1.02 A input.

When relative offset is enabled, the REL indicator turns on. Changing measurement functions changes the relative offset value to the established relative offset value and state for that measurement function.

The various instrument operations, including relative offset, are performed on the input signal in a specific, predetermined order. For example, if both relative offset and a math operation are enabled, the relative offset operation is always performed before the math operation.

Set relative offset from the front panel

You can set a relative offset through front panel by acquiring the offset or by setting an offset manually.

To set and enable a relative offset through the front panel by acquiring the offset:

1. Select the desired measurement function and an appropriate range setting.
2. Apply the signal to which you want to apply a relative offset to a switching channel input or to the Model 3706A inputs.
3. If you are using a switching module, close the input channel. (see Operation keys for basic information about the front panel user interface).
4. Press the **REL** key to acquire the relative offset value. The REL annunciator turns on. The displayed value will not become zero until a new reading is triggered.
5. Apply the signal to be measured. The relative offset value is subtracted from the next reading that is triggered.

To set and enable a relative offset through the front panel manually:

1. Select the desired measurement function and an appropriate range setting.
2. If you are using a switching module, close the input channel. (see Operation keys for basic information about the front panel user interface).
3. Press **CONFIG**, then press the **REL** key. The Relative Offset Menu is displayed.
4. Select **ENABLE**.
5. Select **Yes**. The REL annunciator turns on.
6. Press **EXIT** to return to the Relative Offset Menu.
7. Select **LEVEL**.
8. Set the relative offset value as needed.
9. Apply the signal to be measured. The relative offset value is subtracted from the next reading that is triggered.

NOTE

If you press the **REL** key, the manually entered value will be overwritten with an acquired value.

To disable the relative offset function:

Press **REL** a second time to disable the relative offset function.

NOTE

You can perform the equivalent of relative offset manually by using the [mX+b](#) (on page 4-44) math function. Set m to 1 and b to the value of the offset.

Set relative offset through the remote interface

The `dmm.rel.level()` command is used to specify the relative offset value for the active function.

The `dmm.rel.acquire()` command uses the input signal as the relative offset value for the active function. The `dmm.rel.acquire()` command is typically used to zero the display. For example, if the instrument is displaying a 1 μV offset, sending `dmm.rel.acquire()` and enabling relative offset (`dmm.rel.enable = dmm.ON`) zeros the display.

The following command sequence is equivalent to pressing the front panel **REL** key:

```
dmm.rel.acquire()  
dmm.rel.enable=dmm.ON
```

To manually set a relative offset value of 1.5 μV , use this command sequence:

```
dmm.rel.level=1.5e-6  
dmm.rel.enable=dmm.ON
```

For example, if the instrument is on the DCV function, the `dmm.rel.acquire()` command is applicable to DCV measurements.

Scanning

When a scan is configured, each channel can have its own unique relative offset value. For remote programming, the channel list parameter is used to configure channels for a scan.

For example:

To attach a 1 μ V relative offset level to a configuration, send the following commands:

```
-- Select DC volts function.
dmm.func = "dcvolts"
-- Reset DC volts only.
dmm.reset("active")
-- Set the relative offset level.
dmm.rel.level=1e-6
-- Enable relative offset.
dmm.rel.enable = dmm.ON
-- Call the configuration myconfig.
dmm.configure.set("myconfig")
-- Set channels 1001 to 1030 to use myconfig configuration.
dmm.setconfig("1001:1030", "myconfig")
-- Create scan list of channels 1001 to 1030 using myconfig.
scan.create("1001:1030")
```

Math calculations

The Model 3706A has three built-in math calculations:

- $mX+b$
- percent
- reciprocal ($1/X$)

NOTE

The various instrument operations, including Math, are performed on the input signal in a specific, predetermined order. For example, if both relative offset and a math operation are enabled, the relative offset operation is always performed before the math operation.

Basic math operation

1. Select the desired measurement function.
2. Configure and enable the $mX+b$, percent, or reciprocal ($1/X$) math function.
3. Apply the signal to be measured to a switching channel input.
4. Close the input channel. The result of the math calculation is displayed when a reading is triggered.

mX+b

This math operation lets you manipulate normal display readings (X) mathematically according to the following calculation:

$$mX + b = Y$$

Where:

- **X** is the normal display reading.
- **m** is a user-defined constant for the scale factor.
- **b** is the user-defined constant for the offset.
- **Y** is the displayed result.

NOTE

If you are using a relative offset, **X** is the input signal with the relative offset applied.

Set the relative offset using mX+b

You can use the mX+b function to manually establish a relative offset value. To do this, set the scale factor (M) to 1 and set the offset (b) to the offset value. Each subsequent reading will be the difference between the actual input and the offset value.

Set mX+b units from the front panel

The attribute for mX+b must be one character. It can be any letter of the alphabet, the degrees symbol (°), the micro symbol (μ), or the ohms symbol (Ω).

To set mX+B units from the front panel:

NOTE

The following procedure sets MXBUNITS. You can change the other MATH menu options (BFACTOR and MFACTOR) by changing the b and m values.

1. Press the **CONFIG** key.
2. Press the **DMM** key.
3. Turn the navigation wheel to highlight the **MATH** menu item.
4. With **MATH** highlighted, press the **ENTER** key. The MATH MENU opens.
5. Select the **MXBUNITS** menu item.
6. With **MXBUNITS** highlighted, press the **ENTER** key.
7. Press the navigation wheel to enter EDIT mode.
8. Scroll until the desired character is displayed, and then press the **ENTER** key. The MATH MENU will open.
9. From the MATH MENU, turn the navigation wheel to highlight and select the **ENABLE** menu item.
10. Select **ON** and press the **ENTER** key.
11. Press the **EXIT** key twice to return to the main display.

Set mX+b units through the remote interface

You can set mX+b units through the remote interface with the command `dmm.math.mxb.units`. The attribute for `dmm.math.mxb.units` must be one character enclosed in single or double quotes. It can be any letter of the alphabet, the degrees symbol ($^{\circ}$), the micro symbol (μ), or the ohms symbol (Ω).

The ohm symbol (Ω), the micro symbol (μ), and the degree symbol ($^{\circ}$) are not ASCII characters and must be substituted with the `]`, `[` and `\` characters. Valid characters are therefore:

- **A to Z**
- `]` for ohms
- `[` for microvolts
- `\` for degrees

To use the ohms symbol (Ω) as units designator:

```
value = ']'
dmm.math.mxb.units = value
```

To use the micro symbol (μ) as units designator:

```
value = '['
dmm.math.mxb.units = value
```

To use the degrees symbol ($^{\circ}$) as units designator:

```
value = '\\\
dmm.math.mxb.units = value
```

NOTE

When sending mxb units remotely, to embed a `\` into a string, precede the `\` with an additional `\` (see the previous example code).

Use [dmm.math.mxb.bfactor](#) (on page 8-212) and [dmm.math.mxb.mfactor](#) (on page 8-213) to set the b and m factor for mX+b.

Once all settings are configured, set [dmm.math.enable](#) (on page 8-209) to `dmm.ON` to enable math operation.

NOTE

For more detail, see [dmm.math.mxb.units](#) (on page 8-214).

Percent

The percent math function determines percent deviation from a specified reference value. The percent calculation is:

$$\text{Percent} = \left(\frac{\text{input} - \text{reference}}{\text{reference}} \right) \times 100\%$$

Where:

Input: The normal measurement (if using relative offset, this is the relative offset value)

Reference: The user-entered constant (**PERCENT** or `dmm.math.percent`)

Percent: The result

The result of the percent calculation is positive when the input exceeds the reference and negative when the input is less than the reference. The result of the percent calculation may be displayed in exponential notation. For example, a displayed reading of +2.500E+03% is equivalent to 2500% (2.5K%).

Set percent from the front panel

To set a percent value on the front panel:

1. Open the function attribute menu:
 - Press the **CONFIG** key.
 - Press the **DMM** key.
2. Turn the navigation wheel to highlight the **MATH** menu item.
3. With **MATH** highlighted, press the **ENTER** key. The MATH MENU opens.
4. Select the **PERCENT** menu item.
5. Press the **ENTER** key to enter edit mode.
6. Turn the navigation wheel to edit the value.
7. Once the desired value is displayed, press the **ENTER** key. The MATH MENU opens.
8. From the MATH MENU, turn the navigation wheel to highlight and select the **ENABLE** menu item.
9. Select **ON** and press the **ENTER** key.
10. Press the **EXIT** key twice to return to the main display.

Set percent through the remote interface

The `dmm.math.percent` attribute (see [dmm.math.percent](#) (on page 8-215)) specifies the reference value for the percent calculation, while the `dmm.rel.acquire` function (see [dmm.rel.acquire](#) (see "[dmm.rel.acquire\(\)](#)" on page 8-227)) uses the input signal as the reference value.

The acquire function triggers a single reading and uses the result as the new relative offset value. When a value is set using [dmm.math.percent](#) (on page 8-215), the [dmm.math.percent](#) (on page 8-215) query command returns the programmed value. When reference is set using [dmm.rel.acquire\(\)](#) (on page 8-227), the [dmm.math.percent](#) (on page 8-215) query command returns the acquired reference value.

To set a percent value from a remote interface, send the following commands:

```
-- Set percent to 5
dmm.math.percent = 5
-- Sends 5 to the computer for display
print(dmm.math.percent)
```

You can use the relative offset used to set the percent as follows:

```
-- Sets percent with relative offset acquire value.
dmm.math.percent = dmm.rel.acquire()
-- Send the result of relative offset acquire to a computer.
print(dmm.math.percent)
```

Reciprocal (1/X)

The reciprocal of a reading is displayed when the reciprocal (1/X, where X is the normal input reading) math function is enabled:

$$dB = 20 \log \frac{V_{in}}{V_{ref}}$$

The displayed units designator for reciprocal readings is "R." You cannot change this units designator.

Example:

Assume the normal displayed reading is 002.5000 Ω . The reciprocal of resistance is conductance. When the reciprocal math function is enabled, the following conductance reading is displayed:

```
0.400000 R
```

NOTE

The result of the 1/X calculation may be displayed in exponential notation. For example, a displayed reading of +2.500E+03 R is equivalent to 2500 R (2.5K R). When using relative offset, the 1/X calculation uses the input signal with relative offset applied.

Scanning

When a scan is configured, each channel can have its own unique math setup. For remote programming, the channel list parameter is used to configure channels for a scan.

Example:

To perform the reciprocal math operation on DC volt measurements, send the following commands:

```
-- Select DC volts function.
dmm.func = "dcvolts"
-- Reset DC volts only.
dmm.reset("active")
-- Set the math operation to be reciprocal for measurements.
dmm.math.format = dmm.MATH_RECIPROCAL
-- Enable the math operation for measurements.
dmm.math.enable = dmm.ON
-- Call the configuration mymath.
dmm.configure.set("mymath")
-- Set Channels 1001 to 1030 to use the mymath configuration.
dmm.setconfig("1001:1030", "mymath")
-- Create scan list of channels 1001 to 1030 using mymath.
scan.create("1001:1030")
```

dB commands

Expressing DC or AC voltage in decibels (dB) makes it possible to compress a large range of measurements into a much smaller scope. The relationship between dB and voltage is defined by the following equation:

$$dB = 20 \log \frac{V_{in}}{V_{ref}}$$

Where:

V_{IN} : DC or AC input signal.

V_{REF} : Specified voltage reference level.

The instrument will read 0 dB when the reference voltage level is applied to the input. If a relative value is in effect when dB is selected, the value is converted to dB, and then relative offset is applied to the dB value. If relative offset is applied after dB has been selected, dB has relative offset applied to it.

NOTE

The dB calculation takes the absolute value of the ratio V_{IN}/V_{REF} . The largest negative value of dB is -160 dB. This will accommodate a ratio of $V_{IN} = 1 \mu\text{V}$ and $V_{REF} = 1000 \text{ V}$.

dB configuration

You can select UNITS (V or dB) from the front panel or from the remote interface.

To select UNITS from the front panel, while the active DMM function is DCV or ACV:

1. Press the **CONFIG** key.
2. Press the **DMM** key.
3. Turn the navigation wheel to scroll to the **UNITS** menu item.
4. Press the navigation wheel (or the **ENTER** key) to select.
5. Select units: V for voltage or dB for decibels.
6. Press the navigation wheel (or the **ENTER** key) to set.
7. Press the **EXIT** key to close the attribute menu.

To select dB configuration over the remote interface:

Set the active DMM function to DCV or ACV and set `dmm.dbreferenc`. For example:

```
dmm.func = "dcvolts"  
dmm.dbreferenc = 5
```

dB scanning

Each channel in a scan may be configured to use dB.

Create a configuration that has dB enabled for units for the desired function by using the [dmm.configure.set](#) (see "[dmm.configure.set\(\)](#)" on page 8-178) command. Once the configuration exists, use the [dmm.setconfig\(\)](#) (on page 8-239) command to connect the configuration to the desired channels. Now the channels can be added to scanning (see [scan.create\(\)](#) (on page 8-324) and [scan.add\(\)](#) (on page 8-317) commands). To remotely control the units for AC and DC volts, use the [dmm.units](#) (on page 8-247) command.

Range

You can use the range to set an expected measurement value. The instrument will select the range appropriate to measure that value.

If you set a range, the autorange feature is automatically disabled. The instrument selects the range to best match the expected measure value for the functions, as shown below.

The range setting is saved with the DMM function setting, so if you select another function, then return to the previous function, the range settings you set previously are retained.

You cannot select a range that includes different channel types.

NOTE

A power cycle or an instrument reset will clear the saved ranges.

Measurement ranges and maximum readings

The range that is selected affects both measurement accuracy and the maximum measurable level. Input values that exceed the maximum readings cause an "Overflow" message to be displayed.

Function	Ranges	Maximum reading
DCV (DC voltage)	100 mV, 1 V, 10 V, 100 V, 300 V	± 303 V
ACV (AC voltage)	100 mV, 1 V, 10 V, 100 V, 300 V	± 303 V
DCI (DC current)	10 µA, 100 µA, 1 mA, 10 mA, 100 mA, 1 A, 3 A	± 3.1 A
ACI (AC current)	1 mA, 10 mA, 100 mA, 1 A, 3 A	± 3.1 A
Ω2 (2-wire ohm)	10 Ω, 100 Ω, 1 kΩ, 10 kΩ, 100 kΩ, 1 MΩ, 10 MΩ, 100 MΩ	120 MΩ
Ω4 (4-wire ohm)	1 Ω, 10 Ω, 100 Ω, 1 kΩ, 10 kΩ, 100 kΩ, 1 MΩ, 10 MΩ, 100 MΩ	120 MΩ
Ω4 OC (4-wire ohm offset compensated)	1 Ω, 10 Ω, 100 Ω, 1 kΩ, 10 kΩ	12 kΩ
Ω4 DRY+ (4-wire ohm dry circuit)	1 Ω, 10 Ω, 100 Ω, 1 kΩ, 10 kΩ	2.4 kΩ
TMP (temperature)	–200 °C to 1820 °C	Sensor dependent
FREQ (frequency)	100 mV, 1 V, 10 V, 100 V, 300 V	3 Hz to 500 kHz
PER (period)	100 mV, 1 V, 10 V, 100 V, 300 V	2 µs to 333 ms
CNT (continuity)	1 kΩ Threshold adjustable 1 Ω to 1000 Ω	
CSΩ (commonsense ohm)	1 Ω, 10 Ω, 100 Ω, 1 kΩ, 10 kΩ, 100 kΩ, 1 MΩ, 10 MΩ, 100 MΩ	120 MΩ

Temperature

There is no range selection for temperature measurements, which are performed on a single fixed range. Depending on the sensor, the maximum temperature readings range from –200 °C to 1820 °C.

Select a range from the front panel

To change the range for the active DMM function, press the **RANGE ▲** or **▼** key. The instrument changes one range value of the active function for each key press. The selected range is displayed in the attribute list on the second line of the front panel display.

If the instrument displays the "Overflow" message on a particular range, select a higher range until an on-range reading is displayed. For best accuracy and resolution, use the lowest range available that does not cause an overflow.

Select range through the remote interface

To select a range through the remote interface, specify the expected reading as an absolute value for the `dmm.range` (on page 8-225) command. The Model 3706A will then go to the most sensitive range for that expected reading.

For example, if you expect a reading of approximately 3 V, send:

```
dmm.range = 3
```

The instrument will select the 10 V range.

Set up autoranging from the front panel

To enable autorange, press the **AUTO** key. The AUTO indicator turns on when autoranging is selected. While autoranging is enabled, the instrument automatically selects the best range at which to measure the applied signal.

Autoranging should not be used when optimum speed is required.

NOTE

The **AUTO** key has no effect on temperature measurements.

Up-ranging occurs at 120% of range. The Model 3706A will down-range when the reading is less than 10% of nominal range.

To disable auto ranging, press the **AUTO** key. This will leave the instrument set to the present range.

Autoranging is automatically disabled when you select a specific range by pressing the **▲** or **▼** key or by sending the remote command `dmm.range`.

Set up autorange through the remote interface

Autorange is enabled by setting the `dmm.autorange` attribute (see [dmm.autorange](#) (on page 8-158)) to either `dmm.ON` or `1`.

When autorange is enabled, the range is changed automatically for the selected range value.

To disable autorange, either set the `dmm.autorange` attribute to `dmm.OFF` or `0`, or send a valid `dmm.range` attribute (see [dmm.range](#) (on page 8-225)).

When autorange is disabled, the instrument remains at the selected range.

Scanning

Each channel of scan configuration can be associated with a unique digital multimeter (DMM) configuration (which includes a range setting). When a scan completes, the DMM remains in the configuration associated with the last completed measurement step. For remote programming, the channel list parameter is used to configure channels for a scan.

See [dmm.configure.set\(\)](#) (on page 8-178), [dmm.setconfig\(\)](#) (on page 8-239), [scan.create\(\)](#) (on page 8-324), and [scan.add\(\)](#) (on page 8-317) commands, and the [Scanning and triggering](#) (on page 3-1) section for more details, including front panel operation.

Optimizing measurement speed

Rate

The integration time (measurement speed) of the A/D converter controls how long the input signal is measured (also known as aperture). The integration time affects the amount of reading noise, as well as the ultimate reading rate of the instrument.

The integration time is specified in parameters based on a number of power line cycles (NPLC), where 1 PLC for 60 Hz is 16.67 ms (1/60) and 1 PLC for 50 Hz is 20 ms (1/50).


In general, the fastest integration time is 0.1 PLC using the front panel **RATE** key, or 0.0005 PLC from the remote interface or through the **DMM > CONFIG NPLC** menu. This results in increased reading noise and fewer usable digits.

The slowest integration time is 5 PLC using the front panel **RATE** key, or 15 PLC from the remote interface or through the **DMM > CONFIG NPLC** menu. This provides the best common-mode and normal-mode rejection.

In-between settings are a compromise between speed and noise.

The Model 3706A has a parabola-like shape for its speed versus noise characteristics. The Model 3706A is optimized for the 1 PLC to 5 PLC reading rate. At these rates (lowest noise region in graph), the Model 3706A will make corrections for its own internal drift and will still be fast enough to settle a step response of less than 100 ms.

Figure 4-21: Speed compared to noise characteristics



You can use unique rate settings for each function when using the front panel or the remote interface. Rate cannot be set for continuity. The continuity rate is fixed at 0.006 PLC.

NOTE

The Model 3706A uses internal references to calculate an accurate and stable reading. When the NPLC setting is changed, each reference is automatically updated to the new NPLC setting before a reading is generated. Therefore, frequent NPLC setting changes can result in slower measurement speed.

Setting Rate from the front panel

The **RATE** key is used to set measurement speed from the front panel. Press the **RATE** key until the desired speed message is displayed. The second line of the display will contain the NPLC setting.

The front panel rate settings for all but the AC functions are as follows:

- **FAST** sets integration time to 0.1 PLC. Use **FAST** if speed is of primary importance (at the expense of increased reading noise and fewer usable digits).
- **MED** sets integration time to a medium rate of 1 PLC. Use **MED** when a compromise between noise performance and speed is acceptable.
- **SLOW** sets integration time to 5 PLC. **SLOW** provides better noise performance at the expense of speed.

For the AC functions (ACV, ACV dB, and ACI), the **RATE** key sets integration time and bandwidth. **FAST** sets NPLC to 1, while the **MED** and **SLOW** NPLC settings are ignored.

A summary of the rate settings are shown in the following table.

Function	Slow	Medium	Fast
DCV, DCI	NPLC=5	NPLC=1	NPLC=0.1
ACV, ACI	NPLC=X, BW=3	NPLC=X, BW=30	NPLC=1, BW=300
Ω 2, Ω 4, CS Ω	NPLC=5	NPLC=1	NPLC=0.1
FREQ, PERIOD	APER=0.250s	APER=0.1s	APER=0.01s
Continuity	X	X	NPLC=0.006
NOTES: NPLC = Number of power line cycles. BW = Bandwidth (in Hz). APER = Aperture in seconds. X = Setting ignored (fixed NPLC).			

You can also set the rate using the NPLC option in the function attribute menu. Press **CONFIG**, then **DMM** to display the function attribute menu. From the function attribute menu, select **NPLC** to select a specific value for NPLC.

Setting measurement speed from a remote interface

Use the [dmm.aperture](#) (on page 8-153) or [dmm.nplc](#) (on page 8-220) command to set the measurement speed (integration time) through the remote interface.

NOTE

For `dmm.nplc` settings that are less than 0.2 power line cycles, sending `dmm.AUTOZERO_ONCE` results in significant delays. For example, the delay time at a NPLC of 0.0005 is 2.75 s. The delay time at 0.199 is 5.45 s.

Bandwidth

There are three bandwidth settings for AC volt and AC current measurements. The RATE setting determines the bandwidth setting as follows:

- SLOW: 3 Hz to 30 Hz
- MEDIUM: 30 Hz to 300 Hz
- FAST: 300 Hz to 300 MHz

When the slow bandwidth is chosen, the signal goes through an analog root-mean-square (RMS) converter. The output of the RMS converter goes to a fast (1 kHz) sampling A/D and the RMS value is calculated from 1200 digitized samples (1.2 s).

When the medium bandwidth is chosen, the same converter is used. However, only 120 samples (120 ms) are needed for an accurate calculation because the analog RMS converter has turned most of the signal to DC.

In the fast bandwidth, the output of the analog RMS converter (nearly pure DC at these frequencies) is measured at 1 power line cycle (PLC) (16.6 ms). For remote programming, the integration rate can be set from 0.0005 PLC to 12 PLC or 15 PLC.

To achieve the best accuracy for AC volt and AC current measurements, use the bandwidth setting that best reflects the frequency of the input signal. For example, if the input signal is 40 Hz, a bandwidth setting of 30 should be used.

NOTE

A rate command ([dmm.nplc](#) (on page 8-220) or [dmm.aperture](#) (on page 8-153)) for AC volts and AC current is only valid if the bandwidth for that AC function is set to 300 (300 Hz to 300 kHz). Bandwidth is set using the [dmm.detectorbandwidth](#) (on page 8-182) remote command or the DETECTBW menu option under the function's attribute menu.

DC voltage, DC current, and resistance measurement speed

To optimize measurement speed, select:

- `dmm.autozero=dmm.OFF`
- `dmm.autodelay=dmm.OFF`
- `dmm.nplc=0.0005`
- `dmm.filter=dmm.OFF`
- `dmm.autorange=dmm.OFF`
- `dmm.measurecount>=1000`

For resistance, assumed two-wire ohm.

AC voltage and AC current optimize speed

Select:

- `dmm.detectorbandwidth=300`
- `dmm.autodelays=dmm.OFF`
- `dmm.autozero=dmm.OFF`
- `dmm.autorange=dmm.OFF`
- `dmm.filter=dmm.OFF`
- `dmm.nplc=0.0005`

Temperature optimize measurement speed

Select:

- `dmm.transducer=dmm.TEMP_THERMOCOUPLE`
- `dmm.opendetector=dmm.OFF`
- `dmm.nplc=0.0005`
- `dmm.autozero=dmm.OFF`
- `dmm.filter=dmm.OFF`
- `dmm.autodelay=dmm.OFF`

Optimizing measurement accuracy

The following two charts represent root-mean-square (RMS) noise versus aperture time (or NPLC) and reading rate versus aperture time (or NPLC). Refer to these charts when selecting best accuracy at a given reading rate. Generally, increasing the aperture time reduces the RMS noise. For aperture times more than 100 ms or 5 power line cycles, thermal offsets can increase the RMS noise.

Figure 4-22: Readings Rate versus Aperture Time





Figure 4-23: RMS Noise vs. Aperture Time



DC voltage, DC current, and resistance measurement accuracy

To optimize measurement accuracy:

- 1 or 5 NPLC, filter off, fixed range.
- Use relative offset on DC voltage and 2-wire resistance measurements when appropriate.
- Use four-wire, offset compensation on, and line sync on for resistance measurements, especially through a 3700A switch card, for best accuracy.

AC voltage and AC current optimize accuracy

Select Detectorbandwidth 3, autodelays On, and fixed range.

Temperature optimize accuracy

1 or 5 NPLC.

Voltage

DC volts input divider

Normally, the input resistance for the 100 mVDC, 1 VDC, and 10 VDC ranges is more than 10 G Ω . You can set the input resistance for the three lower DC volt ranges to 10 M Ω by enabling the input divider.

When you enable the input divider:

- The measurement INPUT HI is connected to INPUT LO
- Some external devices (such as a high voltage probe) must be terminated to a 10 M Ω load
- The measurement of open leads is maintained near 0 V
- Internal I_{BIAS} through the 10 M Ω causes an open input to read less than -0.4 mV. With a short circuit (and the input divider on or off), the short circuit to read less than ± 0.9 μ V.

The input divider can be enabled from the front panel when function is "dcvolts" by pressing the **CONFIG** key, then the **DMM** key.

To control the divider over the remote interface, use the [dmm.inputdivider](#) (on page 8-193) command.

Low level considerations

For sensitive measurements, external considerations affect the accuracy. Effects that are not noticeable when working with higher voltages are significant in microvolt signals. The Model 3706A reads only the signal received at its input; therefore, it is important that this signal be properly transmitted from the source. The following paragraphs indicate factors that affect accuracy, including stray signal pick-up and thermal offsets.

Shielding

AC voltages that are extremely large compared with the DC signal to be measured may produce an erroneous output. Therefore, to minimize AC interference, the circuit should be shielded, with the shield connected to the Model 3706A input low (particularly for low level sources). Improper shielding can cause the Model 3706A to behave in one or more of the following ways:

- Unexpected offset voltages
- Inconsistent readings between ranges
- Sudden shifts in reading

To minimize pick-up, keep the voltage source and the Model 3706A away from strong AC magnetic sources. The voltage induced due to magnetic flux is proportional to the area of the loop formed by the input leads. Therefore, minimize the loop area of the input leads and connect each signal at only one point.

Thermal EMFs

Thermal EMFs (thermoelectric potentials) are generated by temperature differences between the junctions of dissimilar metals. These can be large compared to the signals that the Model 3706A can measure. Thermal EMFs can cause the following conditions:

- Instability or zero offset is much higher than expected.
- The reading is sensitive to (and responds to) temperature changes. This effect can be demonstrated by touching the circuit, by placing a heat source near the circuit, or by a regular pattern of instability (corresponding to changes in sunlight or the activation of heating and air conditioning systems).

To minimize the drift caused by thermal EMFs, use copper leads to connect the circuit to the Model 3706A.

A clean, oxidized-free, copper conductor such as #10 bus wire is ideal. For switching modules, use #20 AWG copper wire to make connections. The leads to the Model 3706A may be shielded or unshielded, as necessary.

Widely varying temperatures within the circuit can also create thermal EMFs. Therefore, maintain constant temperatures to minimize these thermal EMFs. A shielded enclosure around the circuit under test also helps by minimizing air currents.

The relative offset control can be used to null out constant offset voltages.

AC voltage offset

The Model 3706A, at 5½ digits resolution, will typically display 100 counts of offset on AC volts with the input shorted. This offset is caused by the offset of the T_{RMS} converter. This offset will not affect reading accuracy and should not be zeroed out using the relative offset feature. The following equation expresses how this offset (V_{OFFSET}) is added to the signal input (V_{IN}):

$$\text{Displayed reading} = \sqrt{(V_{IN})^2 + (V_{OFFSET})^2}$$

Example:

Range= 1 VAC, Offset = 100 counts (1.0 mV), Input = 100 mV_{RMS}

$$\text{Displayed reading} = \sqrt{(100\text{mV})^2 + (1.0\text{mV})^2}$$

Therefore, the displayed reading is 0.100005 V.

The offset is seen as the last digit, which is not displayed. Therefore, the offset is negligible. If relative offset were used to zero the display, the 100 counts of offset would be subtracted from V_{IN} , resulting in an error of 100 counts in the displayed reading.

Resistance

Optimizing low ohm measurement and speed

When measuring resistance of 100 ohms or less, cable, connectors, and Model 3706A switch cards can have thermal offsets, which can result in additional reading uncertainties.

Auto delays for 100 ohms or less have been optimized for throughput and settling, resulting in the best measurement. If thermal offsets cause additional uncertainty, adding a delay of 10 ms can improve accuracies. Refer to the Auto Delay table for additional details. If the application requires additional settling delay, send the following commands to the channel or slot of interest:

```
channel.setdelay("4004", 0.010)
```

Adds 10 ms of delay after closing channel 4 in slot 4.

```
channel.setdelay("slot4", 0.010)
```

Adds 10 ms of delay to all channels in slot 4.

Dry circuit ohms (DRY+)

Standard resistance measurements have open-circuit voltage levels from 6.4 V to 14.7 V, depending on the selected range. Dry circuit ohms limits open-circuit voltage to between 20 mV and 27 mV. This allows you to perform resistance measurements that require low open-circuit voltage, such as power and low-glitch resistance measurements.

Dry circuit ohms can be used on the 1 Ω , 10 Ω , 100 Ω , 1 k Ω , and 10 k Ω ranges (maximum resistance of 2.4 k Ω) for the four-wire ohm function.

Offset-compensated ohms (OC+) can be used with dry circuit ohms to cancel the effect of thermal EMFs. When dry circuit is enabled, offset compensation is automatically set to on.

Measuring contact resistance (oxide film build-up)

The ideal resistance between switch connectors, or relay contacts is 0 Ω . However, an oxide film may be present on the switch or relay contacts. This oxide film could add resistance on the order of several hundred milliohms. Also, this oxide film changes the contact resistance over time and with changes in the environmental conditions (such as temperature and humidity).

Typically, the four-wire ohm function of the Model 3706A or a standard DMM is used to measure low resistance. However, if standard resistance measurements are performed, the relatively high open-circuit voltage may puncture the oxide film, and render the test meaningless.

Dry circuit ohms limit voltage to 20 mV to minimize any physical and electrical changes in a measured contact junction. This low open-circuit voltage will not puncture the film, and will therefore provide a resistance measurement that includes the resistance of the oxide film.

Oxide films may also build up in connections on a semiconductor wafer. To accurately measure the resistance introduced by the oxide film, dry circuit ohms should be used to prevent oxide film puncture.

Measuring resistance of voltage-sensitive devices

Dry circuit ohms should be used for any device that could be damaged by high open circuit voltage. If you are not sure the slightly degraded accuracy is a consideration, it is good practice to use dry circuit ohms to measure low resistance.

Dry circuit ohms measurement considerations

Dry circuit ohms uses a constant current source with voltage monitoring that is used to clamp the current source voltage. The current source will remain constant as long as the monitoring voltage is less than 20 mV. When the voltage exceeds 20 mV, the current source shunts current internal to the DMM until 20 mV is maintained at the DUT.

When using dry circuit ohms, the DUT is shunted by 100 k Ω and 0.9 μ F for the 1, 10, and 100 ohm ranges. For the 1 K and 10 K ranges, it is shunted by a 10 M Ω and 0.015 μ F. This allows the current source to have minimal overshoot voltage under transient conditions. When used with a switching system, the overshoot is less than 40 mV in 20 μ s.

Enable or disable dry circuit ohms from the front panel

Dry circuit ohms is an attribute set for the 4-wire ohm DMM function.

NOTE


When the dry circuit ohms attribute is enabled, the offset-compensated ohms attribute is automatically enabled (OC+ annunciator). If you do not wish to use offset-compensated ohms, after setting dry circuit ohms, disable offset-compensated ohms using the information in [Enabling/disabling offset-compensated ohms](#) (on page 4-63).

NOTE

If the Model 3706A is being controlled remotely, press the **EXIT** key to place it in local mode.

To enable offset-compensated ohms, the Model 3706A DMM function must be set to four-wire ohms. The Model 3706A is in 4-wire ohm mode when **4W Ω** is displayed. Dry Circuit is active when the **DRY+** is displayed (see the figure below).

Figure 4-24: Enabling dry-circuit ohms

**To enable/disable dry circuit ohms from the front panel:**

1. Press the **CONFIG** key ①.
2. Press the **DMM** key ②.
3. Turn the navigation wheel ③ to scroll to the "DRYCIRCUIT" menu item.
4. Press the navigation wheel ③ to display ON/OFF settings for dry circuit ohms.
5. Select "ON" or "OFF" and press the navigation wheel ③ again.
6. Press the **EXIT** key to leave the menu.

Figure 4-25: Four-wire Ohm ATTR MENU: DRYCIRCUIT

**NOTE**

When enabled, the dry circuit ohms annunciator is on (DRY+).

Enable or disable dry circuit ohms through the remote interface

To enable dry circuit ohms through the remote interface, send the commands:

```
dmm.func = "fourwireohms"  
dmm.drycircuit = dmm.ON
```

To disable dry circuit ohms through the remote interface, send the command:

```
dmm.drycircuit = dmm.OFF
```

Performing dry circuit ohms measurements

Make sure you use four-wire connections to the DUT as detailed in [Analog backplane connector \(rear panel\)](#) (on page 4-19) or specific to the module used for switching.

To perform dry circuit ohms measurements:**NOTE**

Do not make connections to the device under test (DUT) until after the dry circuit ohms attribute is enabled in step 2.

1. Press the **OPENALL** key to open all switching channels.
2. If not already on, enable dry circuit ohms (see [Enabling/disabling dry circuit ohms](#) (see "[Enable or disable dry circuit ohms from the front panel](#)" on page 4-61)).
 - Dry circuit ohms enabled: DRY+
 - Dry circuit ohms disabled: DRY-

NOTE

When dry circuit measurement is enabled (DRY+), offset-compensated ohms will also enable (OC+ annunciator turns on). If you do not wish to use offset-compensated ohms, disable it (see [Enabling/disabling offset-compensated ohms](#) (on page 4-63)).

3. Make 4-wire connections to the DUT. See 4-wire connection information contained in [analog backplane connector \(rear panel\)](#) (on page 4-19) and [Switching module](#) (see "[Switching module connections](#)" on page 4-20).
4. Use the **RANGE** \blacktriangle and \blacktriangledown keys to select the 1 Ω , 10 Ω , 100 Ω , 1k Ω , or 10k Ω range, or press the **AUTO** key to enable auto range.
5. If using a switching module, perform the following steps to close the desired channel:
 - a. Use the navigation wheel to dial in the channel number.
 - b. Press the **CLOSE** key.
6. Press the **TRIG** key and observe the displayed reading. If the "Overflow" message is displayed, select a higher range until a normal reading is displayed (or press the **AUTO** key for autoranging). For manual ranging, use the lowest possible range for the best resolution.
7. To measure other switching channels, repeat steps 5 and 6.
8. When finished, press the **OPENALL** key to open all channels.

NOTE

The on or off states of dry circuit ohms and offset-compensated ohms are saved with four-wire ohm function. If you select a different measurement function, then select four-wire ohms again, the previous attribute states of dry circuit ohms and offset-compensated ohms will be restored.

Offset-compensated ohms

The presence of thermal EMFs (V_{EMF}) can adversely affect low-resistance measurement accuracy. To overcome these unwanted offset voltages, you can use offset-compensated ohms (OCOMP). Offset-compensated ohms measurements can be performed on the 1 Ω , 10 Ω , 100 Ω , 1 k Ω , and 10 k Ω ranges for the four-wire ohm measurement function. It cannot be done on the two-wire ohm measurement function.

NOTE

The various instrument operations, including offset-compensated ohms, are performed on the input signal in a sequential manner.

For a normal resistance measurement, the Model 3706A sources a current (I) and measures the voltage (V). The resistance (R) is then calculated as ($R=V/I$) and the reading is displayed.

For offset-compensated ohms, two measurements are performed: one normal resistance measurement, and one using the lowest current source setting.

The offset-compensated ohms reading is then calculated as follows:

$$\text{Offset-compensated ohms reading} = \Delta V / \Delta I$$

where:

$$\Delta V = V_2 - V_1$$

$$\Delta I = I_2 - I_1$$

V_1 is the voltage measurement with the current source at its normal level.


V_2 is the voltage measurement using the lowest current source setting.

This 2-point measurement process and reading calculation eliminates the resistance contributed by the presence of V_{EMF} .

Enabling/disabling offset-compensated ohms

Offset-compensated ohms is an attribute that can be set for the 4-wire ohms measurement function. To enable or disable it from the front panel:

Figure 4-26: Enabling offset-compensated ohms



NOTE

The Model 3706A is in 4-wire ohm mode when $4W\Omega$ is displayed. Offset compensation is active when the OC+ is displayed (OC- is shown in the above figure).

1. Set the Model 3706A for the 4-wire ohm measurement function.
2. Press the **CONFIG** key ①.
3. Press the **DMM** key ②.
4. Turn the navigation wheel ③ to scroll to the "OFFSETCOMP" menu item. Press the navigation wheel to select.
5. Turn the navigation wheel to select the ON/OFF settings for Offset Compensation as desired and press the navigation wheel to set.
6. Press the **EXIT** key to leave the menu.

Figure 4-27: Four-wire Ohm ATTR MENU: OFFSETCOMP



Performing offset-compensated ohms measurements

Make sure you use 4-wire connections to the DUT as detailed in [analog backplane connector \(rear panel\)](#) (on page 4-19) or if using a module for switching, the connections specific to the module.

1. Press the **OPENALL** key to open all switching channels.
2. If not already on, enable offset compensated ohms (OC+ annunciator is lit). See [Enabling/disabling offset-compensated ohms](#) (on page 4-63).
3. Use the **RANGE** \blacktriangle and \blacktriangledown keys to select the range, or press the **AUTO** key to enable auto range. If using auto range, offset-compensated ohms measurements will not be performed if the instrument goes to the 100 k Ω (or higher) range.
4. Perform steps 4 through 8 of the [Standard resistance measurements](#) (see "[Resistance measurements from the front panel](#)" on page 4-22) procedure.

Offset compensation can be enabled for any 4-wire range. The internal DMM will perform offset compensation for the $\leq 10\text{k-ohm}$ ranges and automatically disable for $\geq 100\text{K-ohm}$ ranges. Send the following remote commands and the Series 3700A returns the reading and a "1" or a logic "True", but the DMM only performed a standard 4-wire measurement.

```
dmm.func="fourwireohms"
dmm.range=100e3
dmm.offsetcompensation=1
print(dmm.measure())
print(dmm.offsetcompensation)
```

With dry circuit ohms enabled, the 10 k Ω range (measuring a maximum resistance of 2.4 k Ω) is the highest offset-compensated ohms range that can be selected.

For buffer recall, there is no way to distinguish between a normal ohms reading and an offset-compensated ohms reading. The OC annunciator (– or +) has no significance for recalled resistance readings that are displayed.

The offset-compensated ohms setting is saved with the measurement function. If you change measurement functions, then return to the previous function, the offset-compensated ohms will be at the same setting it was previously.

`dmm.offsetcompensation` is a common command and is shared with `fourwireohms`, `drycircuit`, `threertd` and `fourrtd`. To activate `dmm.offsetcompensation`, select the desired function first, and then send `dmm.offsetcompensation = dmm.ON` or `OFF`.

Filter

You can use the digital filter to stabilize noisy measurements. When the filter is applied, the displayed, stored, or transmitted reading is a windowed-average of a number of reading conversions (from 1 to 100).

The filter setup is saved specific to each measurement function (DC volts, AC volts, DC current, AC current, two-wire ohms, four-wire ohms, commonside ohms, and temperature). When you select a function, the instrument will return to the last filter that was set up for that function.

NOTE

The various instrument operations, including filter, are performed on the input signal in a specific, predetermined order. For example, if both relative offset and MXB (a math operation) are enabled, the relative offset operation will always be performed before MXB.

Filter characteristics

In general, the digital filter places a specified number of A/D conversions (the filter count) into a memory stack. These A/D conversions must occur consecutively within a selected reading window (the filter window). The readings in the stack are then averaged to yield a single filtered reading. The stack can be filled using the moving or repeating average filters.


Digital filter types

There are two digital filter types: Moving and repeating.

Moving average filter

The moving average filter uses a first-in first-out stack, where the newest reading conversion replaces the oldest. An average of the stacked reading conversions yields a filtered reading. After the specified number of reading conversions (filter count) fill the stack, the moving filter gives a new reading for every new conversion.

Figure 4-28: Moving average filter




Repeating average filter

The repeating filter takes a specified number of conversions, averages them, and yields a filtered reading. It then clears its stack and starts over. This setting is useful when scanning because readings for other channels are not averaged with the present channel. The stack is then cleared and the process starts over.

NOTE

The moving filter cannot be used when scanning (see Scanning). If a scan channel is set up to use the moving filter, the filter will not turn on.

Figure 4-29: Repeating average filter




Digital filter window

The digital filter uses a noise window to control the filter threshold. As long as the input signal remains within the selected window, A/D conversions continue to be placed in the stack. If the signal changes to a value outside the window, the filter resets and starts processing again, starting with a new initial conversion value from the A/D converter.

The noise window, which is expressed as a percentage of range (or maximum temperature reading), allows a faster response time to large signal step changes (for example, scanned readings). A reading conversion outside the plus or minus noise window fills the filter stack immediately.

If the noise does not exceed the selected window, the reading is based on the average of the reading conversions. If the noise does exceed the selected window, the reading is a single reading conversion and new averaging starts from this point. The noise window for the two filter types are compared in the filter window below.

Figure 4-30: Filter window



For both front panel and remote programming, the window can be set to any value from 0.0% to 10%, where 0.0% represents no window being applied.

For voltage, current, and resistance, the filter window is expressed as a percent of range. For example, on the 10V range, a 10% window means that the filter window is $\pm 1V$.

For temperature, the filter window is expressed as a percent of the maximum temperature reading. The maximum temperature depends on which thermocouple is being used. For example, for a Type J thermocouple, the maximum reading is 760 °C; a 10 % window means that the filter window is ± 76 °C. For temperatures below 0 °C, the overflow point is -200 °C, so a 10% filter window is ± 20 °C. If using °F units, a 20% filter window is calculated as follows: $9/5 \times 20 = 36$. The filter window for the 20% window is ± 36 °C.

Theory of Operation

In this section:


DMM	5-1
Understanding Precision Time Protocol (PTP).....	5-23

DMM

Rear panel, backplane, and DMM connect relays schematic

Refer to the following figure for a schematic of the rear panel, backplane, and DMM connect relays with a typical card.

Figure 5-1: Rear panel to backplane to DMM connect relays schematic



Line cycle synchronization

Synchronizing A/D conversions with the frequency of the power line increases common mode and normal mode noise rejection. When line cycle synchronization is enabled, the measurement is initiated at the first positive-going zero crossing of the power line cycle after the trigger.


The following figure shows a measurement process that consists of two A/D conversions. If the trigger occurs during the positive cycle of the power line (Trigger #1), the A/D conversion starts with the positive-going zero crossing of the power line cycle. If the next trigger (Trigger #2) occurs during the negative cycle, then the measurement process also starts with the positive-going zero crossing.

NOTE

Line synchronization is not available for the AC functions (ACV, ACI, FREQ, or PERIOD). Line synchronization can be enabled for any DC function and any NPLC measurement, increasing NMRR and CMRR.


See [dmm.linesync](#) (on page 8-206) in the Reference Manual for remote programming information.

Figure 5-2: Line cycle synchronization




4-Wire Ohms are sensitive to 50 / 60Hz power line noise, due to cabling and Model 3700A switch card loop area.

Figure 5-3: 4-Wire Line Synchronization Block Diagram




Traditional DMM 4-wire measurements are made in two phases, S HI and S LO. If the `dmm.nplc` is set to 1 or a multiple of the power line, theoretically, the average AC noise is 0. Refer to the 4W-Rdg calculation (http://www.maxim-ic.com/appnotes.cfm/appnote_number/1041/).

Figure 5-4: 1plc Line Synchronization Block Diagram



For Line Synchronization off and $<1\text{plc}$, reading rate increases, but measurement uncertainty and noise increases due to the Average AC noise during the S HI phase not canceling with the S LO phase. With line synchronization ON, the S HI and S LO measurement phases are triggered at the rising edge of the power line zero crossing. This improves reading uncertainty and noise by $>30\times$ while minimal reading rate reduction.

Figure 5-5: Line Sync Off and On <1plc



AC voltage measurements and crest factor

The root-mean-square (RMS) value of any periodic voltage or current is equal to the value of the DC voltage or current which delivers the same power to a resistance as the periodic waveform does. Crest factor is the ratio of the peak value to the RMS value of a particular waveform. This is represented by the following equations:

$$CF = \frac{V_P}{V_{RMS}} \quad \text{or} \quad CF = \frac{I_P}{I_{RMS}}$$

The crest factor of various waveforms is different, because the peak-to-RMS ratios are variable. For example, the crest factor for a pulse waveform is related to the duty cycle; as the duty cycle decreases, the crest factor increases. The RMS calculations and crest factor (CF) for various waveforms are shown in the following figures.

Figure 5-6: ACV measurements: sine waves









Figure 5-7: ACV measurements: square, pulse, and sawtooth waves

	<p>AC coupled RMS: $V_{RMS} = V_P$</p>	<p>Crest Factor: $CF = 1$</p>
	<p>AC coupled RMS: $V_{RMS} = \frac{V_P}{2}$</p>	<p>Crest Factor: $CF = 2$</p>
	<p>AC coupled RMS: $V_{RMS} = V_P \sqrt{D(1-D)}$ where: D (duty cycle) = t/T</p>	<p>Crest Factor: $CF = \frac{1}{\sqrt{D(1-D)}}$</p>
	<p>AC coupled peak: $+V = V_P(1 - D)$ $-V = -V_P D$</p>	<p>when: $0 < D \leq 0.5$ $CF = \sqrt{\frac{1}{D} - 1}$ when: $0.5 < D \leq 1$ $CF = \sqrt{\frac{1}{1 - D} - 1}$</p>
	<p>RMS: $V_{RMS} = 0.557V_P$</p>	<p>Crest Factor: $CF = 1.733$</p>

The Model 3706A is an AC-coupled RMS meter. For an AC waveform with DC content, the DC component is removed before the RMS is calculated. This affects the crest factor because the peak value for the DC-coupled waveform is different than the peak value for the AC-coupled waveform. In an AC-coupled waveform, the peak value is measured from the original DC average value, not DC zero. For example, if a voltage pulse is measured on the AC function of the Model 3706A with a peak voltage of VP and a low voltage of zero volts, the AC-coupled peak value will be calculated as follows:

$$\text{ACPEAK} = \text{VP} \cdot (1 - \text{duty cycle})$$

Therefore, the AC-coupled crest factor will differ from the DC-coupled waveform. The RMS function will calculate the RMS value based on the pulsed waveform with an average value of zero.

The reason to consider crest factor in accuracy of RMS measurements is because the meter has a limited bandwidth. Theoretically, a sine wave can be measured with a finite bandwidth because all of its energy is contained in a single frequency. Most other common waveforms have a number of spectral components requiring an almost infinite bandwidth above the fundamental frequency to measure the signal exactly. Because the amount of energy contained in the harmonics becomes smaller with increasing frequency, very accurate measurements can be made with a limited bandwidth meter, as long as enough spectral components are captured to produce an acceptable error.

Crest factor is a relative measurement of the harmonic content of a particular waveform and reflects the accuracy of the measurement. For a rectangular pulse train, the higher the crest factor, the higher the harmonic content of the waveform. This is not always true when making spectral comparisons between different types of waveforms. A sine wave, for example, has a crest factor of 1.414, and a square wave has a crest factor of 1. The sine wave has a single spectral component and the square wave has components at all odd harmonics of the fundamental.

The Model 3706A RMS AC volts and AC amps accuracies are specified for sine waves of different frequency ranges.

Additional error uncertainties are also specified for non-sinusoidal waveforms of specific crest factors and frequencies. The Model 3706A has capabilities of measuring AC waveforms of crest factors up to 5.

DMM resistance measurement methods

The method that the Model 3706A uses to measure resistance depends on the resistance range. For resistance ranges from 1 Ω to 1 M Ω , the Model 3706A uses the constant-current method to measure resistance. For resistance ranges from 10 M Ω to 100 M Ω ranges, the ratiometric method is used.

When the constant-current method is used, the Model 3706A sources a constant current (I) to the device under test and measures the voltage (V). Resistance (R) is then calculated and displayed using the known current and measured voltage ($R = V/I$).

When the ratiometric method is used, test current is generated by a 6.4 V reference through a 10 M Ω reference resistance (R_{REF}).

For more detail on these methods, see [Constant-current source method](#) (on page 5-9) and [Ratiometric method](#) (on page 5-9).

The Model 3706A uses four methods to detect open leads. For detail, see [Open lead detection](#) (on page 5-14).


Constant-current source method

For the 1 Ω to 1 M Ω ranges, the Model 3706A uses the constant-current method to measure resistance. The Model 3706A sources a constant current (I_{SOUR}) to the device under test (DUT) and measures the voltage (V_{MEAS}). Resistance (R_{DUT}) is then calculated (and displayed) using the known current and measured voltage ($R_{\text{DUT}} = V_{\text{MEAS}}/I_{\text{SOUR}}$).

The constant-current method is shown below. The test current sourced to the DUT depends on the selected measurement range. For example, for the 100 Ω range, the test current is 1 mA. Because the voltmeter of the Model 3706A has very high input impedance (>10 G Ω), virtually all the test current (1 mA) flows through the DUT. For DUT \leq 1 k Ω , 4-wire ohms measurements should be used as shown. Because the voltage is measured at the DUT, voltage drop in the test leads is eliminated (this voltage could be significant when measuring low-ohm DUT).


The 2-wire constant-current method is shown below.

Figure 5-8: Two-wire constant-current source method



The 4-wire constant-current method is shown below.

Figure 5-9: Four-wire constant-current source method




Ratiometric method

For the 10 M Ω and 100 M Ω ranges, the ratiometric method is used to measure resistance. Test current for this method is generated by a 6.4V voltage source through a 10 M Ω reference resistance (R_{REF}), as shown.

Basic circuit theory dictates that I_{REF} is equal to the I_{DUT} . Because the voltmeter of the Model 3706A (V_{MEAS}) has very high input impedance (>10G Ω), current through the voltmeter branch is insignificant and can be discounted. Therefore, as shown in the following Figures Equation 1, $I_{\text{REF}} = I_{\text{DUT}}$

Figure 5-10: Two-wire ratiometric method



Because $I = V/R$, Equation 1 is modified using the V/R equivalents in place of I_{REF} and I_{DUT} . Therefore:

$$I_{SOUR} = (V_{MEAS} / R_{REF}) + (V_{MEAS} / R_{DUT})$$

Note that V_{MEAS} is measured by the Model 3706A. With V_{MEAS} , I_{SOUR} , R_{REF} known, the Model 3706A calculates the resistance of the DUT and displays the result. R_{REF} is learned during calibration and V_{SOUR} is routinely self-calibrated when the `dmm.autozero` attribute is enabled (`dmm.autozero = dmm.ON`).

As shown, the four-wire ohm function can also be used to measure ohms for the 10MΩ and 100 MΩ ranges. To minimize the effects of charge injection when `dmm-autozero` is enabled, the 10 MΩ to 100 MΩ is actually a 3-wire ohm measurement. SENSE HI is not used. SENSE HI is connected to the DUT but is not required (it can be left open). The measurement method is similar to the ratiometric method for two-wire ohms, but it performs an extra voltage measurement (V_{LEAD}) to compensate for voltage drop in the input test leads.

Note that V_{MEAS} includes the voltage drops of the input test leads (Input HI and Input LO). Therefore, the actual voltage drop across the DUT is V_{MEAS} minus the two voltage drops in the test leads. Because matched inputs are used, the voltage drop is $2 \times V_{LEAD}$. Therefore:

$$V_{DUT} = V_{MEAS} - 2(V_{LEAD}).$$

Figure 5-11: Four-wire ratiometric method





Figure 5-12: Fast Alternating Scan block diagram



Reference junctions

A reference junction is the cold junction in a thermocouple circuit that is held at a stable, known temperature. The cold junction is where dissimilar wire connections must be made. As long as the temperature of the cold junction is known, the Model 3706A can factor in the reference temperature to calculate the actual temperature reading at the thermocouple.

The standard reference temperature is the ice point (0°C). The ice point can be precisely controlled, and the National Institute of Standards and Technology (NIST) uses it as the fundamental reference for its voltage-to-temperature conversion tables. However, other known temperatures can be used.

There are two ways for the Model 3706A to acquire the cold junction temperature. It can measure the cold junction using a thermistor or 4-wire RTD, or the known temperature value can be entered by the user.

There are two reference junction types supported by the Model 3706A:

- Simulated reference junction
- Internal reference junction
- External reference junction

These reference junctions are explained in the following paragraphs.

Simulated reference junction

An example of a simulated reference junction is an ice bath as shown in the paragraph titled [Thermocouple connections](#) (on page 4-26). The copper wire to thermocouple wire connections are immersed (but electrically isolated) in the ice bath, and the user enters the 0 °C simulated reference temperature into the Model 3706A. The simulated reference temperature for the Model 3706A can be set from 0 °C to 65 °C.

The Model 3706A measures the input voltage and factors in the simulated reference temperature to calculate the temperature reading at the thermocouple.

NOTE

The most accurate temperature measurements are achieved by using a simulated reference junction using an ice point reference.

Internal reference junction

"Internal" implies that temperature transducers are used to measure the cold junction. For specific switching modules, the cold junction can be the switching module's screw terminals with voltage temperature sensors strategically placed to measure the temperature of the cold junction (see [Thermocouple connections](#) (on page 4-26)).

The Model 3706A measures the temperature of the cold junction (screw terminals), measures the input voltage, and then calculates the temperature reading at the thermocouple.

To help maintain stability and accuracy over time and changes in temperature, the Model 3706A periodically measures internal voltages corresponding to offsets (zero) and amplifier gains. For thermocouple temperature measurements using the internal reference junction, the internal temperature is also measured. These measurements are used in the algorithm to calculate the reading of the input signal. This process is known as autozeroing. Note that internal temperature references are collected regardless of whether or not autozero is enabled.

External reference junction

Thermocouple readings may be configured to use an external reference junction setting. The Series 3700 assumes the external reference junction is connected to channel 1 of a slot. It is recommended that this channel be configured for thermistor or RTD temperature reading. However, the unit does not error check against this. Each time a reading is taken on the external reference junction channel (channel 1 of a slot) it will be used as the new external reference junction value in subsequent external reference readings. External reference readings work with `dmm.close` as well as scanning.

For non-simulated thermocouple measurements, first perform a thermistor or RTD measurement prior to enabling external reference junction.

Open lead detection

The Model 3706A has four methods to detect open lead conditions:

- I_{SOUR} open voltage
- V_{MEAS} open voltage
- Calculated measurement
- `dmm.opendetector`

The following figures show open lead detection schematics for various measurements.

Figure 5-13: Simplified normal 4-wire ohm open detection schematic





Figure 5-14: Model 3706A Internal DMM



ISOUR open voltage

1 Ω through 1 MΩ ranges: A hardware detector detects an open input lead. The hardware detector uses a comparator circuit to monitor the voltage on the ohm $I_{SOUR} V_{OPEN-HI-LEAD}$ terminal.

- For the lower ohms ranges (1 Ω, 10 Ω, and 10 kΩ), open circuit voltage on the ohm $I_{SOUR} V_{OPEN-HI-LEAD}$ terminal is more than 7.1 V.
- For the higher ohms ranges (100 kΩ through 1 MΩ), open circuit voltage on the ohm $I_{SOUR} V_{OPEN-HI-LEAD}$ terminal is more than 12.8 V.

When an input lead (HI or LO) is open, as shown, voltage rises to the open-circuit level, then the A/D will abort in less than 100 μsec and the "Overflow" message is displayed.

VMEAS open voltage


If either Input Sense HI or Sense LO V_{MEAS} is outside the enclosed table voltages, the A/D will stop in less than 100 μsec and return an overflow reading.

Range	V_{MEAS} SHI or SLO high limit open lead detection	V_{MEAS} SHI or SLO low limit open lead detection
1 Ω to 100 Ω	> 128 mV	< -10 mV
1 kΩ to 100 kΩ	> 1.28 V	< -100 mV
1 MΩ	> 12.8 V	< -1.0 V

Calculated measurement open voltage

A calculated measurement that exceeds 120 percent of the range returns an overflow reading.

Figure 5-15: 4-wire open detector with Series 3700A card



dmm.opendetector open voltage

With `dmm.opendetector = dmm.ON`, a separate $-1.5 \text{ A } I_{\text{OPENLEAD}}$ SHI and a separate SLO current source will pulse on and off before the start of each measurement while I_{SOUR} remains enabled. The A/D will monitor SHI for 2 ms, then switch to SLO for an additional 2 ms. During either phase, if the input voltage exceeds the above table, the A/D will stop in less than $100 \mu\text{s}$ and return an overflow reading. If there are no open leads detected during the I_{OPENLEAD} phase, the I_{OPENLEAD} is disabled and standard 4-wire is enabled.

V_{MEAS} with open input:

If Sense HI is disconnected, V_{MEAS} will drop less than -1V , causing an A/D overflow.

V_{MEAS} with valid connections:

For valid connections, INPUT Sense HI, V_{MEAS} , will dip during the 4 ms I_{OPENLEAD} phase. The amount of the voltage dip is the sum of I_{OPENLEAD} and the range I_{SOUR} and R_{DUT} load. For example, if measuring a $100 \text{ k}\Omega$ on the $100 \text{ k}\Omega$ range, the V_{MEAS} across the $100 \text{ k}\Omega$ will be 0.85 V (10 A to $1.5 \mu\text{A}$) $\times 100 \text{ K}\Omega$ during I_{OPENLEAD} and 1 V during measurement phase.

The tables below note timing with `dmm.opendetector = dmm.ON`.

Range	SHI and SLO IOPENLEAD Phase (ms) ¹	SHI Settle Time (ms)	Line Freq (Hz)	SHI Measurement Time (ms)	
				min	max
1-10 k Ω	4.0	0.5	60	0.0083	250
			50	0.010	240
100 k Ω	4.0	2.0	60	0.0083	250
			50	0.010	240
1 M Ω	4.0	30.0	60	0.0083	250
			50	0.010	240
10 M Ω to 100 M Ω	4.0	5.0 ¹	60	0.0083	250

Range	Internal DMM Comm. (ms)	SLO Settle Time (ms)	SLO Measurement Time (ms)		Internal DMM Comm.
			min	max	
1 to 10 k Ω	0.06	0.5	0.0083	250	0.06
			0.010	240	
			0.0083	250	
100 k Ω	0.06	1.0	0.0083	250	0.06
			0.010	240	
1 M Ω	0.06	1.0	0.0083	250	0.06
			0.010	240	


1. For 10 M Ω and 100 M Ω , $V_{\text{measurement}}$ is made on Input HI. Input Sense HI is unused.
2. Default condition for 4-wire is `dmm.opendetector=dmm.ON`.
3. For `dmm.drycircuit=dmm.ON`, I_{OPENLEAD} is disabled, but `print(dmm.opendetector)` returns 1.0.
4. Additional cable and Series 3700A card capacitance can increase settling times, resulting in additional measurement uncertainty. Keithley Instruments recommend the use of Teflon or other low-dielectric absorption wire insulation for these measurements.

4-wire dry-circuit open lead detection

The Model 3706A dry-circuit resistance measurement circuitry was designed for low power, low glitch, and low open voltage applications such as GMRR head testing and air bag / squib testing that require low energy resistance sourcing. For this reason, `dmm.opendetector = dmm.ON` is disabled when `dmm.drycircuit = dmm.ON`. The I_{OPENLEAD} current pulse would exceed the dry-circuit voltage application.

The follow schematic provides a simplified view of the Model 3706A 4-wire dry-circuit open lead detection.

Figure 5-16: Simplified Dry-Circuit open V-clamp feedback loop schematic



Dry-clamp open lead detector (dry-circuit)

A hardware detector is used to detect an open input lead. The hardware detector uses an internal circuit to monitor the voltage on the $V_{DRY-CLAMP}$ terminal. The circuit will stop the A/D in less than 100 μ s and return an overflow reading if the voltage is greater than 1 V.

VMEAS open voltage (dry-circuit)

If either Input Sense HI or Sense LO V_{MEAS} is outside the enclosed table voltages, the A/D will stop in less than 100 μ s and return an overflow reading.

Range	V_{MEAS} SHI or SLO High Limit Open Lead Detection	V_{MEAS} SHI or SLO Low Limit Open Lead Detection
1 Ω	> 27 mV	< -10 mV
10 Ω to 2 k Ω	> 20 mV	< -10 mV

Calculated measurement open voltage (dry-circuit)

A calculated measurement that exceeds 120% of the range will return an overflow reading.

NOTE

INPUT Sense HI is internally connected to INPUT HI. The connection allows proper open circuit voltage, even with Sense HI disconnected. With INPUT Sense HI disconnected, and the other inputs properly connected, the measurement will read the V_{DUT} and $R_{LEADVOLTAGE}$ drop.

For `dmm.drycircuit = dmm.ON` and `dmm.opendetector = dmm.ON`, $I_{OPENLEAD}$ will be disabled, but a `print(dmm.opendetector)` will still return 1.0.

Open thermocouple detection

The Model 3706A open thermocouple detection works in similar fashion to the open lead detection. Refer to [Open lead detection](#) (on page 5-14). The open thermocouple detection performs as follows:

- V_{MEAS} open voltage: If Input HI V_{MEAS} is outside ± 120 mV, the A/D will stop in less than 100 μ s and return an overflow reading.
- A calculated measurement outside of the ranges in the following table will cause the "Overflow" message to be displayed.

Type	Range
J	-200 °C to +760 °C
K	-200 °C to +1372 °C
N	-200 °C to +1300 °C
T	-200 °C to +400 °C
E	-150 °C to +1000 °C
R	0 °C to +1768 °C
S	0 °C to +1786 °C
B	+350 °C to +1820 °C

- If during a measurement cycle, with `dmm.opendetector = dmm.ON`, the ohm's function $100\ \mu$ A I_{SOUR} is pulsed on and off before the start of each measurement. The A/D will monitor V_{MEAS} for 0.8 ms. During the IONPHASE, if a resistance of more than 1.15 k Ω is detected, or the input voltage is greater than 120 mV, the A/D will stop in less than 100 μ s and return an overflow reading. If less than 1.15 k Ω is detected and the input voltage is in the range of ± 120 mV, the open lead detection current is turned off and a normal thermocouple temperature measurement is performed (see [Thermocouple connections](#) (on page 4-26)).
- I_{SOUR} open voltage with `dmm.opendetector`. A hardware detector is used to continuously detect for open input lead. The hardware detector uses a comparator circuit to monitor the voltage on the ohm I_{SOUR} $V_{OPEN-HI-LEAD}$ terminal. If during a measurement cycle, the input voltage on I_{SOUR} $V_{OPEN-HI-LEAD}$ terminal is greater than 7.1 V, the A/D will stop in less than 100 μ s and return an overflow reading. The following table notes timing with `dmm.opendetector = dmm.ON`.


The thermocouple open detection times are listed in the following table.

Ion source settle (ms)	I _{OPENLEAD} measure (ms)	Phase internal DMM comm. (ms)	I _{off} source settle (ms)	Line freq (Hz)	T/C measurement time (ms)		Internal DMM comm. (ms)
					min	max	
1.0	0.8	0.4	1.0	60	0.0083	250	0.06
				50	0.010	240	

1. Default condition is `dmm.opendetector=dmm.ON` or 1.
2. For `dmm.transducer=dmm.TEMP_THERMISTOR`, `dmm.TEMP_THREERTD`, and `dmm.TEMP_FOURRTD`, `IOPENLEAD` phase is disabled, but `print(dmm.opendetector)` returns 1.0.
3. `dmm.opendetector` is a common remote command, shared with `fourwireohms`. To enable or disable `dmm.opendetector` for either function, the appropriate function must be selected before applying the new `dmm.opendetector` state. For example, to disable thermocouple open detection, send `dmm.func="temperature"` then `dmm.opendetector=0`.

The following figure is a schematic representation of the Model 3706A open thermocouple detection.

Figure 5-17: Thermocouple Open Detector drawing



Accuracy calculations

The following information discusses how to calculate accuracy for both DC and AC characteristics.

Calculating DC characteristics accuracy

DC characteristics accuracy is calculated as follows:

$$\text{For } \geq 1\text{plc, Accuracy} = \pm(\text{ppm of reading} + \text{ppm of range})$$

(ppm = parts per million and 10ppm = 0.001%)

As an example of how to calculate the actual reading limits, assume that you are measuring 5V on the 10V range. You can compute the reading limit range from one-year DCV accuracy specifications as follows:

$$\begin{aligned} \text{Accuracy} &= \pm(25\text{ppm of reading} + 2\text{ppm of range}) \\ &= \pm[(25\text{ppm} \times 5\text{V}) + (2\text{ppm} \times 10\text{V})] \\ &= \pm(125\mu\text{V} + 20\mu\text{V}) \\ &= \pm 145\mu\text{V} \end{aligned}$$

Thus, the actual reading range is 5V \pm 320 μ V or from 4.99968V to 5.00032V. Thus, the actual reading range is: 5V \pm 145 μ V or from 4.999855V to 5.000145V.

$$\text{For } \leq 1\text{plc, Accuracy} = \pm/-(\text{ppm of reading} + \text{ppm of range} + \text{rms noise addr})$$

For example, to calculate the accuracy of the above example at 0.006plc:

$$\begin{aligned} \text{Accuracy} &= \pm/-((25\text{ppm of reading}) + (2\text{ppm of range}) + (2.5 \times 7\text{ppm of range})) \\ &= \pm/-((25\text{ppm} \times 5\text{V}) + (2\text{ppm} \times 10\text{V}) + (2.5 \times 7\text{ppm} \times 10\text{V})) \\ &= \pm/-(125\mu\text{V} + 20\mu\text{V} + 175\mu\text{V}) \\ &= \pm/-(320\mu\text{V} \end{aligned}$$

DC current and resistance calculations are performed in exactly the same manner using the pertinent specifications, ranges, and input signal values.

Calculating AC characteristics accuracy

AC characteristics accuracy is calculated similarly, except that AC specifications are given as follows:

$$\text{Accuracy} = (\% \text{ of reading} + \% \text{ of range})$$

As an example of how to calculate the actual reading limits, assume that you are measuring 120V, 60Hz on the 300V range. You can compute the reading limit range from ACV one-year accuracy specifications as follows:

$$\begin{aligned} \text{Accuracy} &= \pm(0.06\% \text{ of reading} + 0.03\% \text{ of range}) \\ &= \pm[(0.0006 \times 120\text{V}) + (0.0003 \times 300\text{V})] \\ &= \pm(0.072\text{V} + 0.09\text{V}) \\ &= \pm 0.162\text{V} \end{aligned}$$

In this case, the actual reading range is: 120V \pm 0.162V or from 119.838V to 120.162V.

AC current calculations are performed in exactly the same manner using the pertinent specifications, ranges, and input signal values.

Calculating dB characteristics accuracy

The relationship between voltage and dB is as follows:

$$\text{dBm} = 20_{\log} \left(\frac{V_{\text{in}}}{V_{\text{ref}}} \right)$$

As an example of how to calculate the actual readings limits for dB, with a user-defined VREF of 10V, you must calculate the voltage accuracy and apply it to the above equation.

To calculate a -60dB measurement, assume 10mV RMS for a VREF of 10V. Using the 100mV range, one-year, 10Hz - 20kHz frequency band, and SLOW rate, the voltage limits are as follows:

$$\begin{aligned} \text{Accuracy} = & \quad \pm[(0.06\% \text{ of reading}) + (0.03\% \text{ of range})] \\ & \quad \pm[(0.0006 \times 10\text{mV}) + (0.0003 \times 100\text{mV})] \\ & \quad \pm(6\mu\text{V} + 30\mu\text{V}) \\ & \quad \pm 36\mu\text{V} \end{aligned}$$

Thus, the actual reading accuracy is 10mV \pm 36mV or 10.036mV to 9.964mV. Applying the voltage reading accuracy into the dB equation yields:

$$\text{dBm} = 20_{\log} \left(\frac{10.036\text{mV}}{10\text{V}} \right) = -59.96879\text{dB}$$

$$\text{dBm} = 20_{\log} \left(\frac{9.964\text{mV}}{10\text{V}} \right) = -60.03133\text{dB}$$

Thus, the actual reading accuracy is -60dB + 0.031213dB to -60dB - 0.031326dB.

dBm and dB for other voltage inputs can be calculated in exactly the same manner using pertinent specifications, ranges, and other reference voltages.

Additional derating factors

In some cases, additional derating factors must be applied to calculate certain accuracy values. For example, an additional derating for the following conditions:

1. -0.4mV with open inputs and the 10M-ohm divider enabled
2. +/- (8ppm or reading + 5uV) with autozero off for +/- 1 degree C and <= 10 minutes
3. For 2-wire ohms, add 100m-ohm to "ppm of range" with REL
4. Add 0.1% to 10M-ohm range when measuring through a Series 3700A card >50% relative humidity

Before calculating accuracy, study the associated specifications very carefully to see if any derating factors apply.

Understanding Precision Time Protocol (PTP)

The Precision Time Protocol (PTP) is a time standard that does not have any discontinuities (that is, no leap seconds, time zones, or daylight savings). This is important for computing time deltas between events. Currently, the difference between PTP and UTC is 32 seconds.

The Model 3706A is not time-zone aware, just like your watch. For a stand-alone Model 3706A, PTP = UTC = local time. However, things can get confusing if the Model 3706A is synchronized to a device that is time-zone aware. The Model 3706A will still present UTC, but the other device will present UTC +/- offset as the local time, and so they will be different. As a result, you should always use PTP if possible. Programs using PTP will work correctly, regardless of the presence of time-zone aware devices.

The Model 3706A has two versions of time for most commands, `.seconds` and `.ptpseconds`, which represent UTC and PTP time. Use the `ptp.utcoffset` value to move between the two times.

NOTE

This value is zero unless the master clock populates it otherwise based on its information.

The following two statements produce the same value:

```
print(buffer.seconds[1] + ptp.utcoffset)
print(buffer.ptpseconds[1])
```

Example:

Run five scans once every hour starting at 3 a.m. tomorrow.

Assume tomorrow is Sept. 27, 2007. The first step is to convert the date and time to UTC format, and then to PTP.

```
-- convert to UTC time
Start_time = os.time{year=2007, month=9, day=27, hour=3}
-- convert to PTP time
Start_time = Start_time + ptp.utcoffset
```

Set up the alarm as follows:

```
schedule.alarm[1].ptpseconds = Start_time
schedule.alarm[1].fractionseconds = 0
schedule.alarm[1].repetition = 5
-- 1 hr = 60 sec.s x 60 mins
schedule.alarm[1].period = 60*60
schedule.alarm[1].enable = 1
```

Tie the above time event to a simple scan of DCV on channels 1 to 5 (in slot 1):

```
dmm.setconfig("1001:1005", "dcvolts")
scan.create("1001:1005")
-- 5 scans of 5 channels
buf = dmm.makebuffer(25)
-- initiates the scan start
scan.trigger.arm.stimulus = schedule.alarm[1].EVENT_ID
scan.scancount = 5
scan.background(buf)
```

The scan will initiate once the time condition is met.

Check the scan progress with the following command:

```
scan.state()
```

Remote commands

In this section:

Introduction to remote operation	6-1
About remote commands	6-4

Introduction to remote operation

Keithley Instruments Test Script Processor (TSP[®]) enabled instruments operate like conventional instruments by responding to a sequence of commands sent by the controller. You can send individual commands to the TSP-enabled instrument the same way you would using any other instrument.

Unlike conventional instruments, TSP-enabled instruments can execute automated test sequences independently, without a controller. You can load a series of remote commands into the instrument and store these commands as a script that can be run later by sending a single command message to the instrument. You do not have to choose between using “conventional” control or “script” control. You can combine these forms of instrument control in the way that works best for your particular test application.

Controlling the instrument by sending individual command messages

The simplest method of controlling an instrument through the communication interface is to send it a message that contains remote commands. You can use a test program that resides on a computer (the controller) to sequence the actions of the instrument.

Remote commands can be function-based or attribute-based. Function-based commands are commands that control actions or activities. Attribute-based commands define characteristics of an instrument feature or operation.

Functions

Function-based commands control actions or activities. For example, performing a channel closure is a function. A function-based command is not always directly related to instrument operation. For example, the `bit.bitand()` function will perform a logical AND operation on two numbers. Each function consists of a function name followed by a set of parentheses (). If the function does not have a parameter, the parentheses are left empty. If the function takes one or more parameters, they are placed between the parentheses and separated by commas.

Example 1

```
digio.writeport(15)
digio.writebit(3, 0)
reset()
digio.readport()
```

Sets digital I/O lines 1, 2, 3, and 4 high.
Sets line 3 to low (0).
Returns the instrument to its default settings.
Reads the digital I/O port.

Example 2

You can use the results of a function-based command directly or assign variables to the results for later access. The following code saves the value you enter from the front panel and prints it.

```
value = display.inputvalue("+0.00")
print(value)
```

If the operator enters 2.36 from the front panel, the resulting output is:
2.36000e+00

Attributes

Attribute-based commands are commands that set the characteristics of an instrument feature or operation. For example, some characteristics of TSP-enabled instruments are the model number (`localnode.model`) and the number of errors in the error queue (`errorqueue.count`).

To set the characteristics, attribute-based commands define a value. For many attributes, the value is in the form of a number or a predefined constant.

Example 1: Set an attribute using a number

```
format.data = 3
```

This attribute sets the format of data printed by other commands. Setting this attribute to 3 sets the print format to double precision floating point format.

Example 2: Set an attribute using a constant

```
format.data = format.REAL64
```

Using the constant `REAL64` instead of 3 also sets the print format to double precision floating point format.

To read an attribute, you can use the attribute as the parameter of a function, or assign it to another variable.

Example 1: Read an attribute using a function

```
print(format.data)
```

Reads the data format by passing the attribute to the print function. If the data format is set to 3, the output is:
3.00000e+00
This shows that the data format is set to double precision floating point.

Example 2: Read an attribute using a variable

```
fd = format.data
```

This reads the data format by assigning the attribute to a variable named `fd`.

Queries

Test Script Processor (TSP®) enabled instruments do not have inherent query commands. Like any other scripting environment, the `print()` command and other related commands generate output in the form of response messages. Each `print()` command creates one response message.

Example

```
x = 10
print(x)
```

Example of an output response message:

```
1.00000e+01
```

Note that your output might be different if you set your ASCII precision setting to a different value.

Data retrieval commands

You can send data retrieval commands that return a comma-delimited string. For example, `channel.getcount(channelList)` returns a count for each item passed to it through its parameter, `channelList`.

The comma-delimited string that is returned starts with the lowest channel and goes to the highest channel on Slot 1. It then lists each subsequent slot until the highest slot is reached. After the channels are listed, the analog backplane relays are listed, starting with Bank 1 followed by each subsequent bank.

For example, assume there is a Model 3720 card installed in slot 4, returning 72 comma-delimited values. Send the following command:

```
print(channel.getclose("slot4"))
```

The first 60 values returned are the closed channel specifiers, starting with 1 and increasing to 60. The next six values are for analog backplane relays in Bank 1 (starting at 1 and increasing to 6). The final six values are for analog backplane relays in Bank 2 (starting at 1 and increasing to 6).

If the command was `channel.getstate()` instead of `channel.getclose()`, 72 zero (0) or one (1) values would be returned, with a 0 indicating that the channel or backplane is open, and a 1 indicating that it is closed. The first 60 values are for Channels 1 to 60 (starting at 1 and increasing to 60). The last 12 values are the backplane relays (starting with Bank 1, Relay 1, and increasing to Bank 2, Relay 6).

NOTE

If a channel is paired for 4-wire operation by its pole setting, the paired channel state is returned in parenthesis () after the primary channel. For example, if the card in Slot 4 is a Model 3720 and has the 4-pole attribute for all channels set, querying for the states of "slot4" returns 72 zero (0) and one (1) values, with the first 60 shown as the primary channel state (paired channel state); the 12 backplane relays follow.

Sample code and output:

```
channel.setpole("slot4", 4)
print(channel.getstate("slot4"))
```

Output from above code:

```
0(0),0(0),0(0),0(0),0(0),0(0),0(0),0(0),0(0),0(0),0(0),0(0),0(0),0(0),0(0),
0(0),0(0),0(0),0(0),0(0),0(0),0(0),0(0),0(0),0(0),0(0),0(0),0(0),0(0),0(0),
0,0,0,0,0,0,0,0,0,0,0,0
```

The Model 3721 card has three additional backplane relays for commonside ohms functionality. Use "slotX" or "allslots" to query settings on this card to return information for channels 1 to 40, 911 to 916, 921 to 926, and then 917, 927, and 928 in the response message (the three additional commonside ohms backplane relays are listed last).

For example, to print out the channel images on this card when it is in slot 2 after a reset, send the following:

```
reset()
print(channel.getimage('slot2'))
```

Output from above code:

```
2001;2002;2003;2004;2005;2006;2007;2008;2009;2010;2011;2012;2013;2014;2015;
2016;2017;2018;2019;2020;2021;2022;2023;2024;2025;2026;2027;2028;2029;2030;
2031;2032;2033;2034;2035;2036;2037;2038;2039;2040;2041;2042;2911;2912;2913;
2914;2915;2916;2921;2922;2923;2924;2925;2926;2917;2927;2928
```

NOTE

The commonside ohms backplane relays (2917, 2927, and 2928) are listed last (except for the Model 3721 card; for details see the Series 3700 Switch and Control Cards Reference Manual).

Information on scripting and programming

If you need information about using scripts with Series 3700A, see [Fundamentals of scripting for TSP](#) (on page 7-1).

If you need information about using the Lua programming language with Series 3700A, see [Fundamentals of programming for TSP](#) (on page 7-15).

About remote commands

This section contains an overview of the instrument commands organized into groups, with a brief description of each group. Each section contains links to the detailed command descriptions for each command in the [Command reference](#) (see "[Commands](#)" on page 8-10) section of this manual.

Alarms

[schedule.alarm\[N\].enable](#) (on page 8-349)
[schedule.alarm\[N\].EVENT_ID](#) (on page 8-350)
[schedule.alarm\[N\].fractionalseconds](#) (on page 8-351)
[schedule.alarm\[N\].period](#) (on page 8-352)
[schedule.alarm\[N\].ptpseconds](#) (on page 8-352)
[schedule.alarm\[N\].repetition](#) (on page 8-353)
[schedule.alarm\[N\].seconds](#) (on page 8-354)
[schedule.disable\(\)](#) (on page 8-354)

Bit manipulation and logic operations

The bit functions perform bitwise logic operations on two given numbers, and bit operations on one given number. Logic and bit operations truncate the fractional part of given numbers to make them integers.

Logic operations

The `bit.bitand()`, `bit.bitor()`, and `bit.bitxor()` functions in this group perform bitwise logic operations on two numbers. The Test Script Processor (TSP[®]) scripting engine performs the indicated logic operation on the binary equivalents of the two integers. This means that the logical AND, OR, or XOR operation is performed on bit B1 of the first number and bit B1 of the second number. The logical AND, OR, or XOR operation is performed on bit B2 of the first number and bit B2 of the second number. This bitwise logic operation is performed on all corresponding bits of the two numbers. The result of a logic operation is returned as an integer.

Bit operations

The rest of the functions in this group are used for operations on the bits of a given number. These functions can be used to:

- Clear a bit
- Toggle a bit
- Test a bit
- Set a bit or bit field
- Retrieve the weighted value of a bit or field value

All these functions use an index parameter to specify the bit position of the given number. The least significant bit of a given number has an index of 1, and the most significant bit has an index of 32.

NOTE

The Test Script Processor (TSP) scripting engine stores all numbers internally as IEEE Std 754 double-precision floating point values. The logical operations work on 32-bit integers. Any fractional bits are truncated. For numbers larger than 4294967295, only the lower 32 bits are used.

[bit.bitand\(\)](#) (on page 8-11)
[bit.bitor\(\)](#) (on page 8-11)
[bit.bitxor\(\)](#) (on page 8-12)
[bit.clear\(\)](#) (on page 8-12)
[bit.get\(\)](#) (on page 8-13)
[bit.getfield\(\)](#) (on page 8-14)
[bit.set\(\)](#) (on page 8-14)
[bit.setfield\(\)](#) (on page 8-15)
[bit.test\(\)](#) (on page 8-16)
[bit.toggle\(\)](#) (on page 8-17)

Channel

Channel functions and attributes allow you to adjust, select, open, and close channels. You can also set common channel attributes and set up channel patterns.

The channel functions and attributes are:

- [channel.calibration.adjustcount\(\)](#) (on page 8-41)
- [channel.calibration.adjustdate\(\)](#) (on page 8-42)
- [channel.calibration.lock\(\)](#) (on page 8-43)
- [channel.calibration.password\(\)](#) (on page 8-44)
- [channel.calibration.save\(\)](#) (on page 8-45)
- [channel.calibration.step\(\)](#) (on page 8-46)
- [channel.calibration.unlock\(\)](#) (on page 8-47)
- [channel.calibration.verifydate\(\)](#) (on page 8-48)
- [channel.clearforbidden\(\)](#) (on page 8-49)
- [channel.close\(\)](#) (on page 8-50)
- [channel.connectrule](#) (on page 8-52)
- [channel.connectsequential](#) (on page 8-53)
- [channel.createspecifier\(\)](#) (on page 8-54)
- [channel.exclusiveclose\(\)](#) (on page 8-56)
- [channel.exclusiveslotclose\(\)](#) (on page 8-57)
- [channel.getbackplane\(\)](#) (on page 8-59)
- [channel.getclose\(\)](#) (on page 8-61)
- [channel.getcount\(\)](#) (on page 8-63)
- [channel.getdelay\(\)](#) (on page 8-64)
- [channel.getforbidden\(\)](#) (on page 8-66)
- [channel.getimage\(\)](#) (on page 8-68)
- [channel.getlabel\(\)](#) (on page 8-69)
- [channel.getmatch\(\)](#) (on page 8-70)
- [channel.getmatchtype\(\)](#) (on page 8-71)
- [channel.getmode\(\)](#) (on page 8-72)
- [channel.getoutputenable\(\)](#) (on page 8-73)
- [channel.getpole\(\)](#) (on page 8-74)
- [channel.getpowerstate\(\)](#) (on page 8-75)
- [channel.getstate\(\)](#) (on page 8-76)
- [channel.getstatelatch\(\)](#) (on page 8-78)
- [channel.gettype\(\)](#) (on page 8-79)
- [channel.open\(\)](#) (on page 8-80)
- [channel.pattern.catalog\(\)](#) (on page 8-81)
- [channel.pattern.delete\(\)](#) (on page 8-82)
- [channel.pattern.getimage\(\)](#) (on page 8-82)
- [channel.pattern.setimage\(\)](#) (on page 8-83)
- [channel.pattern.snapshot\(\)](#) (on page 8-85)
- [channel.read\(\)](#) (on page 8-87)
- [channel.reset\(\)](#) (on page 8-88)
- [channel.resetstatelatch\(\)](#) (on page 8-89)
- [channel.setbackplane\(\)](#) (on page 8-90)
- [channel.setdelay\(\)](#) (on page 8-93)
- [channel.setforbidden\(\)](#) (on page 8-94)
- [channel.setlabel\(\)](#) (on page 8-94)
- [channel.setmatch\(\)](#) (on page 8-96)
- [channel.setmatchtype\(\)](#) (on page 8-97)
- [channel.setmode\(\)](#) (on page 8-98)
- [channel.setoutputenable\(\)](#) (on page 8-100)
- [channel.setpole\(\)](#) (on page 8-101)
- [channel.setpowerstate\(\)](#) (on page 8-103)
- [channel.setstatelatch\(\)](#) (on page 8-104)
- [channel.trigger\[N\].clear\(\)](#) (on page 8-105)
- [channel.trigger\[N\].EVENT_ID](#) (on page 8-105)

[channel.trigger\[N\].get\(\)](#) (on page 8-106)
[channel.trigger\[N\].set\(\)](#) (on page 8-107)
[channel.trigger\[N\].wait\(\)](#) (on page 8-108)
[channel.write\(\)](#) (on page 8-109)

Data queue

Use the data queue commands to:

- Share data between test scripts running in parallel
- Access data from a remote group or a local node on a TSP-Link[®] network at any time

The data queue in the Test Script Processor (TSP[®]) scripting engine is first-in, first-out (FIFO).

You can access data from the data queue even if a remote group or a node has overlapped operations in process.

[dataqueue.add\(\)](#) (on page 8-115)
[dataqueue.CAPACITY](#) (on page 8-116)
[dataqueue.clear\(\)](#) (on page 8-117)
[dataqueue.count](#) (on page 8-117)
[dataqueue.next\(\)](#) (on page 8-118)

Digital I/O

The digital I/O port of the Series 3700A can control external circuitry (such as a component handler for binning operations).

The I/O port has 14 lines. Each line can be at TTL logic state 1 (high) or 0 (low). See the pinout diagram in [Digital I/O port](#) (on page 2-29) for additional information.

There are commands to read and write to each individual bit, and commands to read and write to the entire port.

[digio.readbit\(\)](#) (on page 8-120)
[digio.readport\(\)](#) (on page 8-120)
[digio.trigger\[N\].assert\(\)](#) (on page 8-121)
[digio.trigger\[N\].clear\(\)](#) (on page 8-122)
[digio.trigger\[N\].EVENT_ID](#) (on page 8-122)
[digio.trigger\[N\].mode](#) (on page 8-123)
[digio.trigger\[N\].overrun](#) (on page 8-124)
[digio.trigger\[N\].pulsewidth](#) (on page 8-125)
[digio.trigger\[N\].release\(\)](#) (on page 8-125)
[digio.trigger\[N\].reset\(\)](#) (on page 8-126)
[digio.trigger\[N\].stimulus](#) (on page 8-127)
[digio.trigger\[N\].wait\(\)](#) (on page 8-129)
[digio.writebit\(\)](#) (on page 8-130)
[digio.writeport\(\)](#) (on page 8-130)
[digio.writeprotect](#) (on page 8-131)

Display

`display.smuX.limit.func`
`display.smuX.measure.func`
[display.clear\(\)](#) (on page 8-132)
[display.getannunciators\(\)](#) (on page 8-132)
[display.getcursor\(\)](#) (on page 8-134)
[display.getlastkey\(\)](#) (on page 8-135)
[display.gettext\(\)](#) (on page 8-136)
[display.inputvalue\(\)](#) (on page 8-138)
[display.loadmenu.add\(\)](#) (on page 8-139)
[display.loadmenu.catalog\(\)](#) (on page 8-141)
[display.loadmenu.delete\(\)](#) (on page 8-141)
[display.locallockout](#) (on page 8-142)
[display.menu\(\)](#) (on page 8-142)
[display.prompt\(\)](#) (on page 8-143)
[display.screen](#) (on page 8-144)
[display.sendkey\(\)](#) (on page 8-145)
[display.setcursor\(\)](#) (on page 8-147)
[display.settext\(\)](#) (on page 8-148)
[display.trigger.EVENT_ID](#) (on page 8-149)
`display.waitkey()`

DMM

[dmm.adjustment.count](#) (on page 8-151)
[dmm.adjustment.date](#) (on page 8-152)
[dmm.aperture](#) (on page 8-153)
[dmm.appendbuffer\(\)](#) (on page 8-155)
[dmm.autodelay](#) (on page 8-157)
[dmm.autorange](#) (on page 8-158)
[dmm.autozero](#) (on page 8-160)
[dmm.buffer.catalog\(\)](#) (on page 8-161)
[dmm.buffer.info\(\)](#) (on page 8-162)
[dmm.buffer.maxcapacity](#) (on page 8-163)
[dmm.buffer.usedcapacity](#) (on page 8-163)
[dmm.calibration.ac\(\)](#) (on page 8-164)
[dmm.calibration.dc\(\)](#) (on page 8-165)
[dmm.calibration.lock\(\)](#) (on page 8-166)
[dmm.calibration.password](#) (on page 8-167)
[dmm.calibration.save\(\)](#) (on page 8-168)
[dmm.calibration.unlock\(\)](#) (on page 8-168)
[dmm.calibration.verifydate](#) (on page 8-169)
[dmm.close\(\)](#) (on page 8-170)
[dmm.configure.catalog\(\)](#) (on page 8-172)
[dmm.configure.delete\(\)](#) (on page 8-173)
[dmm.configure.query\(\)](#) (on page 8-174)
[dmm.configure.recall\(\)](#) (on page 8-176)
[dmm.configure.set\(\)](#) (on page 8-178)
[dmm.connect](#) (on page 8-180)
[dmm.dbreference](#) (on page 8-181)
[dmm.detectorbandwidth](#) (on page 8-182)
[dmm.displaydigits](#) (on page 8-183)
[dmm.drycircuit](#) (on page 8-184)
[dmm.filter.count](#) (on page 8-185)
[dmm.filter.enable](#) (on page 8-186)
[dmm.filter.type](#) (on page 8-187)
[dmm.filter.window](#) (on page 8-188)
[dmm.fourrtd](#) (on page 8-189)
[dmm.func](#) (on page 8-190)
[dmm.getconfig\(\)](#) (on page 8-192)
[dmm.inputdivider](#) (on page 8-193)
[dmm.limit\[Y\].autoclear](#) (on page 8-194)
[dmm.limit\[Y\].clear\(\)](#) (on page 8-195)
[dmm.limit\[Y\].enable](#) (on page 8-196)
[dmm.limit\[Y\].high.fail](#) (on page 8-198)
[dmm.limit\[Y\].high.value](#) (on page 8-200)
[dmm.limit\[Y\].low.fail](#) (on page 8-202)
[dmm.limit\[Y\].low.value](#) (on page 8-204)
[dmm.linesync](#) (on page 8-206)
[dmm.makebuffer\(\)](#) (on page 8-207)
[dmm.math.enable](#) (on page 8-209)
[dmm.math.format](#) (on page 8-211)
[dmm.math.mxb.bfactor](#) (on page 8-212)
[dmm.math.mxb.mfactor](#) (on page 8-213)
[dmm.math.mxb.units](#) (on page 8-214)
[dmm.math.percent](#) (on page 8-215)
[dmm.measure\(\)](#) (on page 8-216)
[dmm.measurecount](#) (on page 8-217)
[dmm.measurewithptp\(\)](#) (on page 8-219)
[dmm.measurewithtime\(\)](#) (on page 8-218)
[dmm.nplc](#) (on page 8-220)
[dmm.offsetcompensation](#) (on page 8-221)

[dmm.open\(\)](#) (on page 8-222)
[dmm.opendetector](#) (on page 8-224)
[dmm.range](#) (on page 8-225)
[dmm.refjunction](#) (on page 8-226)
[dmm.rel.acquire\(\)](#) (on page 8-227)
[dmm.rel.enable](#) (on page 8-228)
[dmm.rel.level](#) (on page 8-229)
[dmm.reset\(\)](#) (on page 8-230)
[dmm.rtdalpha](#) (on page 8-231)
[dmm.rtdbeta](#) (on page 8-233)
[dmm.rtddelta](#) (on page 8-235)
[dmm.rtdzero](#) (on page 8-236)
[dmm.savebuffer\(\)](#) (on page 8-238)
[dmm.setconfig\(\)](#) (on page 8-239)
[dmm.simreftemperature](#) (on page 8-241)
[dmm.thermistor](#) (on page 8-242)
[dmm.thermocouple](#) (on page 8-243)
[dmm.threertd](#) (on page 8-244)
[dmm.threshold](#) (on page 8-245)
[dmm.transducer](#) (on page 8-246)
[dmm.units](#) (on page 8-247)

Error queue

When errors occur, the error messages are placed in the error queue. Use the error queue commands to request error message information.

[errorqueue.clear\(\)](#) (on page 8-248)
[errorqueue.count](#) (on page 8-248)
[errorqueue.next\(\)](#) (on page 8-248)

Event log

You can use the event log to view specific details about LAN triggering events.

[eventlog.all\(\)](#) (on page 8-250)
[eventlog.clear\(\)](#) (on page 8-250)
[eventlog.count](#) (on page 8-251)
[eventlog.enable](#) (on page 8-251)
[eventlog.next\(\)](#) (on page 8-252)
[eventlog.overwritemethod](#) (on page 8-253)

File I/O

You can use the file I/O commands to open and close directories and files, write data, or to read a file on an installed USB flash drive. File I/O commands are organized into two groups:

- Commands that reside in the `fs` and `io` table, for example: `io.open()`, `io.close()`, `io.input()`, and `io.output()`. These commands manage file system directories; open and close file descriptors; and perform basic I/O operations on a pair of default files (one input and one output).
- Commands that reside in the file descriptors (for example: `fileVar.seek()`, `fileVar.write()`, and `fileVar.read()`) operate exclusively on the file with which they are associated.

The root folder of the USB flash drive has the absolute path:

```
/usb1/
```

NOTE

Both slash (/) and backslash (\) are supported as directory separators.

For basic information about navigation and directory listing of files on a flash drive, see [File system navigation](#) (on page 6-11).

NOTE

File descriptor commands (represented by `fileVar`) for file I/O use a colon (:) to separate the command parts rather than a period (.), like the `io` commands.

File descriptors cannot be passed between nodes in a TSP-Link® system, so the `io.open()`, `fileVar::read()`, and `fileVar::write` commands are not accessible to the TSP-Link system. However, the default input and output files mentioned above allow for the execution of many file I/O operations without any reference to a file descriptor.

[fileVar:close\(\)](#) (on page 8-254)

[fileVar:flush\(\)](#) (on page 8-255)

[fileVar:read\(\)](#) (on page 8-255)

[fileVar:seek\(\)](#) (on page 8-256)

[fileVar:write\(\)](#) (on page 8-257)

[fs.chdir\(\)](#) (on page 8-260)

[fs.cwd\(\)](#) (on page 8-260)

[fs.is_dir\(\)](#) (on page 8-261)

[fs.is_file\(\)](#) (on page 8-261)

[fs.mkdir\(\)](#) (on page 8-262)

[fs.readdir\(\)](#) (on page 8-262)

[fs.rmdir\(\)](#) (on page 8-262)

[io.close\(\)](#) (on page 8-264)

[io.flush\(\)](#) (on page 8-265)

[io.input\(\)](#) (on page 8-265)

[io.open\(\)](#) (on page 8-266)

[io.output\(\)](#) (on page 8-267)

[io.read\(\)](#) (on page 8-267)

[io.type\(\)](#) (on page 8-268)

[io.write\(\)](#) (on page 8-268)

The following standard I/O commands are not supported at this time:

File	I/O
<ul style="list-style-type: none"> <code>fileVar:lines()</code> <code>fileVar:setvbuf()</code> 	<ul style="list-style-type: none"> <code>io.lines()</code> <code>io.popen()</code>

File system navigation

Use supported commands from the Lua `fs` library to navigate and list available files on a flash drive. The instrument encapsulates this set of commands as an `fs` logical instrument. This makes the file system of any given node available to the entire TSP-Link® system. For example, the command `node[5].fs.readdir(". ")` can be used to read the contents of the current working directory on node 5.

The root folder of the USB flash drive has the absolute path:

```
"/usb1/"
```

NOTE

Both slash (/) and backslash (\) are supported as directory separators.

The following Lua `fs` commands, which support basic navigation and directory listing, are included for your reference:

```
fs.chdir
fs.cwd
fs.is_dir
fs.is_file
fs.mkdir
fs.readdir
fs.rmdir
```

The following Lua `fs` commands are not supported at this time:

```
fs.chmod
fs.chown
fs.stat
```

GPIB

These commands store the GPIB address and indicate whether GPIB communication is enabled.

[comm.gpib.enable](#) (on page 8-110)

[gpib.address](#) (on page 8-263)

Instrument identification

These commands store strings that describe the instrument.

[localnode.description](#) (on page 8-293)

[localnode.model](#) (on page 8-296)

[localnode.revision](#) (on page 8-300)

[localnode.serialNo](#) (on page 8-300)

LAN and LXI

The LAN commands have options that allow you to review and configure network settings.

The `lan.config.*` commands allow you to configure LAN settings over the remote interface. Note that you must send `lan.applysettings()` for the configuration settings to take effect.

The `lan.status.*` commands help you determine the status of the LAN.

The `lan.trigger[N].*` commands allow you to set up and assert trigger events that are sent over the LAN.

Other LAN commands allow you to reset the LAN, restore defaults, check LXI domain information, and enable or disable the Nagle algorithm.

[comm.lan.enable](#) (on page 8-110)
[comm.lan.rawsockets.enable](#) (on page 8-111)
[comm.lan.telnet.enable](#) (on page 8-112)
[comm.lan.vxi11.enable](#) (on page 8-113)
[comm.lan.web.enable](#) (on page 8-114)
[lan.applysettings\(\)](#) (on page 8-269)
[lan.config.dns.address\[N\]](#) (on page 8-270)
[lan.config.dns.domain](#) (on page 8-270)
[lan.config.dns.dynamic](#) (on page 8-271)
[lan.config.dns.hostname](#) (on page 8-272)
[lan.config.dns.verify](#) (on page 8-272)
[lan.config.gateway](#) (on page 8-273)
[lan.config.ipaddress](#) (on page 8-273)
[lan.config.method](#) (on page 8-274)
[lan.config.subnetmask](#) (on page 8-275)
[lan.lxidomain](#) (on page 8-275)
[lan.nagle](#) (on page 8-276)
[lan.reset\(\)](#) (on page 8-276)
[lan.restoredefaults\(\)](#) (on page 8-276)
[lan.status.dns.address\[N\]](#) (on page 8-277)
[lan.status.dns.name](#) (on page 8-278)
[lan.status.duplex](#) (on page 8-278)
[lan.status.gateway](#) (on page 8-279)
[lan.status.ipaddress](#) (on page 8-279)
[lan.status.macaddress](#) (on page 8-280)
[lan.status.port.dst](#) (on page 8-280)
[lan.status.port.rawsocket](#) (on page 8-281)
[lan.status.port.telnet](#) (on page 8-281)
[lan.status.port.vxi11](#) (on page 8-282)
[lan.status.speed](#) (on page 8-282)
[lan.status.subnetmask](#) (on page 8-283)
[lan.trigger\[N\].assert\(\)](#) (on page 8-283)
[lan.trigger\[N\].clear\(\)](#) (on page 8-284)
[lan.trigger\[N\].connect\(\)](#) (on page 8-285)
[lan.trigger\[N\].connected](#) (on page 8-285)
[lan.trigger\[N\].disconnect\(\)](#) (on page 8-286)
[lan.trigger\[N\].EVENT_ID](#) (on page 8-286)
[lan.trigger\[N\].ipaddress](#) (on page 8-287)
[lan.trigger\[N\].mode](#) (on page 8-287)
[lan.trigger\[N\].overrun](#) (on page 8-288)
[lan.trigger\[N\].protocol](#) (on page 8-289)
[lan.trigger\[N\].pseudostate](#) (on page 8-290)
[lan.trigger\[N\].stimulus](#) (on page 8-290)
[lan.trigger\[N\].wait\(\)](#) (on page 8-292)
[localnode.description](#) (on page 8-293)
[localnode.password](#) (on page 8-296)

[localnode.passwordmode](#) (on page 8-297)

Local node

Commands that allow you to set and read from the local node.

[localnode.define.*](#) (on page 8-293)
[localnode.description](#) (on page 8-293)
[localnode.linefreq](#) (on page 8-295)
[localnode.model](#) (on page 8-296)
[localnode.password](#) (on page 8-296)
[localnode.passwordmode](#) (on page 8-297)
[localnode.prompts](#) (on page 8-297)
[localnode.prompts4882](#) (on page 8-298)
[localnode.reset\(\)](#) (on page 8-299)
[localnode.revision](#) (on page 8-300)
[localnode.serialno](#) (on page 8-300)
[localnode.showerrors](#) (on page 8-301)
[node\[N\].execute\(\)](#) (on page 8-305)
[node\[N\].getglobal\(\)](#) (on page 8-305)
[node\[N\].setglobal\(\)](#) (on page 8-306)
[settime\(\)](#) (on page 8-364)

PTP

Use these functions and attributes to configure the IEEE Std 1588 Precision Time Protocol (PTP). IEEE-1588 allows multiple devices to synchronize time to a less than 10 ms accuracy. Further information on the protocol, operation, and terminology is available from the IEEE organization documentation and other third-party sources.

The Series 3700A commands support the 2008 IEEE-1588 standards, as indicated below.

[ptp.domain](#) (on page 8-310)
[ptp.ds.info\(\)](#) (on page 8-311)
[ptp.enable](#) (on page 8-313)
[ptp.portstate](#) (on page 8-314)
[ptp.slavepreferred](#) (on page 8-315)
[ptp.time\(\)](#) (on page 8-315)
[ptp.utcoffset](#) (on page 8-316)

Reading buffer

Reading buffers capture measurements, ranges, instrument status, and output states of the Keithley Instruments Series 3700A.

[bufferVar.appendmode](#) (on page 8-17)
[bufferVar.basetimefractional](#) (on page 8-18)
[bufferVar.basetimeseconds](#) (on page 8-19)
[bufferVar.cachemode](#) (on page 8-20)
[bufferVar.capacity](#) (on page 8-20)
[bufferVar.channels](#) (on page 8-21)
[bufferVar.clear\(\)](#) (on page 8-23)
[bufferVar.clearcache\(\)](#) (on page 8-23)
[bufferVar.collectchannels](#) (on page 8-24)
[bufferVar.collecttimestamps](#) (on page 8-25)
[bufferVar.dates](#) (on page 8-26)
[bufferVar.formattedreadings](#) (on page 8-28)
[bufferVar.fractionalseconds](#) (on page 8-29)
[bufferVar.n](#) (on page 8-30)
[bufferVar.ptpseconds](#) (on page 8-30)
[bufferVar.readings](#) (on page 8-31)
[bufferVar.relativetimestamps](#) (on page 8-33)
[bufferVar.seconds](#) (on page 8-34)
[bufferVar.statuses](#) (on page 8-35)
[bufferVar.times](#) (on page 8-36)
[bufferVar.timestampresolution](#) (on page 8-37)
[bufferVar.timestamps](#) (on page 8-38)
[bufferVar.units](#) (on page 8-39)

Reset

Resets settings to their default settings.

[digio.trigger\[N\].reset\(\)](#) (on page 8-126)
[lan.reset\(\)](#) (on page 8-276)
[localnode.reset\(\)](#) (on page 8-299)
[reset\(\)](#) (on page 8-316)
[timer.reset\(\)](#) (on page 8-418)
[trigger.blender\[N\].reset\(\)](#) (on page 8-421)
[trigger.timer\[N\].reset\(\)](#) (on page 8-430)
[tsplink.trigger\[N\].reset\(\)](#) (on page 8-442)

Queries and response messages

You can use the `print()`, `printbuffer()`, and `printnumber()` functions to query the instrument and generate response messages. The format attributes control how the data is formatted for the print functions used.

The `localnode` commands determine if generated errors are automatically sent and if prompts are generated.

[format.asciiprecision](#) (on page 8-257)

[format.byteorder](#) (on page 8-258)

[format.data](#) (on page 8-259)

[localnode.prompts](#) (on page 8-297)

[localnode.prompts4882](#) (on page 8-298)

[localnode.showerrors](#) (on page 8-301)

[print\(\)](#) (on page 8-307)

[printbuffer\(\)](#) (on page 8-308)

[printnumber\(\)](#) (on page 8-309)

Saved setups

Use the saved setups commands to save and restore the configuration of the instrument. You can restore (or save) configurations from the instrument's nonvolatile memory or an installed USB flash drive. You can use the `setup.poweron` attribute to specify which setup is recalled when the instrument is turned on.

[createconfigscript\(\)](#) (on page 8-115)

[setup.cards\(\)](#) (on page 8-366)

[setup.poweron](#) (on page 8-367)

[setup.recall\(\)](#) (on page 8-368)

[setup.save\(\)](#) (on page 8-368)

Scan

The scan functions and attributes allow you to set up scanning over the remove interface.

[scan.abort\(\)](#) (on page 8-317)
[scan.add\(\)](#) (on page 8-317)
[scan.addimagestep\(\)](#) (on page 8-320)
[scan.addwrite\(\)](#) (on page 8-321)
[scan.background\(\)](#) (on page 8-322)
[scan.bypass](#) (on page 8-323)
[scan.create\(\)](#) (on page 8-324)
[scan.execute\(\)](#) (on page 8-326)
[scan.list\(\)](#) (on page 8-327)
[scan.measurecount](#) (on page 8-329)
[scan.mode](#) (on page 8-330)
[scan.nobufferbackground\(\)](#) (on page 8-331)
[scan.nobufferexecute\(\)](#) (on page 8-332)
[scan.reset\(\)](#) (on page 8-333)
[scan.scancount](#) (on page 8-334)
[scan.state\(\)](#) (on page 8-335)
[scan.stepcount](#) (on page 8-336)
[scan.trigger.arm.clear\(\)](#) (on page 8-336)
[scan.trigger.arm.set\(\)](#) (on page 8-337)
[scan.trigger.arm.stimulus](#) (on page 8-337)
[scan.trigger.channel.clear\(\)](#) (on page 8-339)
[scan.trigger.channel.set\(\)](#) (on page 8-340)
[scan.trigger.channel.stimulus](#) (on page 8-340)
[scan.trigger.clear\(\)](#) (on page 8-342)
[scan.trigger.measure.clear\(\)](#) (on page 8-343)
[scan.trigger.measure.set\(\)](#) (on page 8-343)
[scan.trigger.measure.stimulus](#) (on page 8-344)
[scan.trigger.sequence.clear\(\)](#) (on page 8-345)
[scan.trigger.sequence.set\(\)](#) (on page 8-346)
[scan.trigger.sequence.stimulus](#) (on page 8-347)

Scripting

Scripting helps you combine commands into a block of code that the instrument can run. Scripts help you communicate with the instrument efficiently. These commands describe how to create, load, modify, run, and exit scripts.

[createconfigscript\(\)](#) (on page 8-115)
[script.anonymous](#) (on page 8-354)
[script.delete\(\)](#) (on page 8-355)
[script.load\(\)](#) (on page 8-356)
[script.new\(\)](#) (on page 8-357)
[script.newautorun\(\)](#) (on page 8-358)
[script.restore\(\)](#) (on page 8-358)
[script.run\(\)](#) (on page 8-359)
[script.user.catalog\(\)](#) (on page 8-359)
[scriptVar.autorun](#) (on page 8-360)
[scriptVar.list\(\)](#) (on page 8-361)
[scriptVar.name](#) (on page 8-361)
[scriptVar.run\(\)](#) (on page 8-362)
[scriptVar.save\(\)](#) (on page 8-363)
[scriptVar.source](#) (on page 8-363)

Status model

The status model is a set of status registers and queues. You can use the following commands to manipulate and monitor these registers and queues to view and control various instrument events.

[status.condition](#) (on page 8-389)
[status.measurement.*](#) (on page 8-391)
[status.node_enable](#) (on page 8-393)
[status.node_event](#) (on page 8-394)
[status.operation.*](#) (on page 8-396)
[status.operation.user.*](#) (on page 8-398)
[status.questionable.*](#) (on page 8-400)
[status.request_enable](#) (on page 8-402)
[status.request_event](#) (on page 8-404)
[status.reset\(\)](#) (on page 8-406)
[status.standard.*](#) (on page 8-406)
[status.system.*](#) (on page 8-408)
[status.system2.*](#) (on page 8-410)
[status.system3.*](#) (on page 8-412)
[status.system4.*](#) (on page 8-414)
[status.system5.*](#) (on page 8-416)

Slot

The slot attributes configure and read the settings of the cards in the slots. You can also set up pseudocards.

[slot\[X\].banks.matrix](#) (on page 8-369)
[slot\[X\].columns.matrix](#) (on page 8-370)
[slot\[X\].commonsideohms](#) (on page 8-370)
[slot\[X\].digio](#) (on page 8-371)
[slot\[X\].endchannel.*](#) (on page 8-371)
[slot\[X\].idn](#) (on page 8-375)
[slot\[X\].isolated](#) (on page 8-378)
[slot\[X\].matrix](#) (on page 8-378)
[slot\[X\].maxvoltage](#) (on page 8-379)
[slot\[X\].multiplexer](#) (on page 8-379)
[slot\[X\].poles.four](#) (on page 8-380)
[slot\[X\].poles.one](#) (on page 8-381)
[slot\[X\].poles.two](#) (on page 8-382)
[slot\[X\].pseudocard](#) (on page 8-382)
[slot\[X\].startchannel.*](#) (on page 8-384)
[slot\[X\].tempsensor](#) (on page 8-388)
[slot\[X\].thermal.state](#) (on page 8-388)

Time

[bufferVar.collecttimestamps](#) (on page 8-25)
[bufferVar.timestampresolution](#) (on page 8-37)
[delay\(\)](#) (on page 8-119)
[gettimezone\(\)](#) (on page 8-263)
[settime\(\)](#) (on page 8-364)
[settimezone\(\)](#) (on page 8-365)
[timer.measure.t\(\)](#) (on page 8-418)
[timer.reset\(\)](#) (on page 8-418)

Top level instrument controls

These commands work with other commands to control general instrument functions. They are also used to set and gather instrument information.

The `beeper` commands allow you to enable or disable and sound the instrument beeper.

`delay()` stops instrument operation for a specified period of time. It is typically used to soak a device at a specific voltage or current for a period of time.

`memory.available()` and `memory.used()` allow you to determine the amount of memory in the instrument.

The `os` commands are Lua functions that allow you to change directory and file names.

`opc()` sets the operation complete status bit when all overlapped commands are completed.

The `upgrade` functions allow you to upgrade or downgrade the Model 3706A firmware.

The `userstring` commands allow you to manage user-defined strings in nonvolatile memory.

`waitcomplete()` allows you to send a command to wait for all overlapped operations in a group to complete.

[beeper.beep\(\)](#) (on page 8-10)

[beeper.enable](#) (on page 8-10)

[delay\(\)](#) (on page 8-119)

[memory.available\(\)](#) (on page 8-303)

[memory.used\(\)](#) (on page 8-304)

[opc\(\)](#) (on page 8-307)

[upgrade.previous\(\)](#) (on page 8-458)

[upgrade.unit\(\)](#) (on page 8-459)

[userstring.add\(\)](#) (on page 8-459)

[userstring.catalog\(\)](#) (on page 8-460)

[userstring.delete\(\)](#) (on page 8-460)

[userstring.get\(\)](#) (on page 8-461)

[waitcomplete\(\)](#) (on page 8-461)

Triggering

[digio.trigger\[N\].assert\(\)](#) (on page 8-121)
[digio.trigger\[N\].clear\(\)](#) (on page 8-122)
[digio.trigger\[N\].EVENT_ID](#) (on page 8-122)
[digio.trigger\[N\].mode](#) (on page 8-123)
[digio.trigger\[N\].overrun](#) (on page 8-124)
[digio.trigger\[N\].pulsewidth](#) (on page 8-125)
[digio.trigger\[N\].release\(\)](#) (on page 8-125)
[digio.trigger\[N\].reset\(\)](#) (on page 8-126)
[digio.trigger\[N\].stimulus](#) (on page 8-127)
[digio.trigger\[N\].wait\(\)](#) (on page 8-129)
[display.trigger.EVENT_ID](#) (on page 8-149)
[lan.trigger\[N\].assert\(\)](#) (on page 8-283)
[lan.trigger\[N\].clear\(\)](#) (on page 8-284)
[lan.trigger\[N\].connect\(\)](#) (on page 8-285)
[lan.trigger\[N\].connected](#) (on page 8-285)
[lan.trigger\[N\].disconnect\(\)](#) (on page 8-286)
[lan.trigger\[N\].EVENT_ID](#) (on page 8-286)
[lan.trigger\[N\].ipaddress](#) (on page 8-287)
[lan.trigger\[N\].mode](#) (on page 8-287)
[lan.trigger\[N\].overrun](#) (on page 8-288)
[lan.trigger\[N\].protocol](#) (on page 8-289)
[lan.trigger\[N\].pseudostate](#) (on page 8-290)
[lan.trigger\[N\].stimulus](#) (on page 8-290)
[lan.trigger\[N\].wait\(\)](#) (on page 8-292)
[trigger.blender\[N\].clear\(\)](#) (on page 8-419)
[trigger.blender\[N\].EVENT_ID](#) (on page 8-419)
[trigger.blender\[N\].orenable](#) (on page 8-420)
[trigger.blender\[N\].overrun](#) (on page 8-421)
[trigger.blender\[N\].reset\(\)](#) (on page 8-421)
[trigger.blender\[N\].stimulus\[M\]](#) (on page 8-422)
[trigger.blender\[N\].wait\(\)](#) (on page 8-424)
[trigger.clear\(\)](#) (on page 8-425)
[trigger.EVENT_ID](#) (on page 8-425)
[trigger.timer\[N\].clear\(\)](#) (on page 8-426)
[trigger.timer\[N\].count](#) (on page 8-426)
[trigger.timer\[N\].delay](#) (on page 8-427)
[trigger.timer\[N\].delaylist](#) (on page 8-427)
[trigger.timer\[N\].EVENT_ID](#) (on page 8-428)
[trigger.timer\[N\].overrun](#) (on page 8-428)
[trigger.timer\[N\].passthrough](#) (on page 8-429)
[trigger.timer\[N\].reset\(\)](#) (on page 8-430)
[trigger.timer\[N\].stimulus](#) (on page 8-430)
[trigger.timer\[N\].wait\(\)](#) (on page 8-432)
[trigger.wait\(\)](#) (on page 8-432)
[tsplink.trigger\[N\].assert\(\)](#) (on page 8-437)
[tsplink.trigger\[N\].clear\(\)](#) (on page 8-438)
[tsplink.trigger\[N\].EVENT_ID](#) (on page 8-438)
[tsplink.trigger\[N\].mode](#) (on page 8-439)
[tsplink.trigger\[N\].overrun](#) (on page 8-441)
[tsplink.trigger\[N\].pulsewidth](#) (on page 8-441)
[tsplink.trigger\[N\].release\(\)](#) (on page 8-442)
[tsplink.trigger\[N\].reset\(\)](#) (on page 8-442)
[tsplink.trigger\[N\].stimulus](#) (on page 8-443)
[tsplink.trigger\[N\].wait\(\)](#) (on page 8-445)

TSP-Link

These functions and attributes allow you to set up and work with a system that is connected by a TSP-Link® network.

[tsplink.group](#) (on page 8-433)
[tsplink.master](#) (on page 8-434)
[tsplink.node](#) (on page 8-434)
[tsplink.readbit\(\)](#) (on page 8-435)
[tsplink.readport\(\)](#) (on page 8-435)
[tsplink.reset\(\)](#) (on page 8-436)
[tsplink.state](#) (on page 8-436)
[tsplink.trigger\[N\].assert\(\)](#) (on page 8-437)
[tsplink.trigger\[N\].clear\(\)](#) (on page 8-438)
[tsplink.trigger\[N\].EVENT_ID](#) (on page 8-438)
[tsplink.trigger\[N\].mode](#) (on page 8-439)
[tsplink.trigger\[N\].overrun](#) (on page 8-441)
[tsplink.trigger\[N\].pulsewidth](#) (on page 8-441)
[tsplink.trigger\[N\].release\(\)](#) (on page 8-442)
[tsplink.trigger\[N\].reset\(\)](#) (on page 8-442)
[tsplink.trigger\[N\].stimulus](#) (on page 8-443)
[tsplink.trigger\[N\].wait\(\)](#) (on page 8-445)
[tsplink.writebit\(\)](#) (on page 8-445)
[tsplink.writeport\(\)](#) (on page 8-446)
[tsplink.writeprotect](#) (on page 8-447)

TSP-Net

The TSP-Net module provides a simple socket-like programming interface to Test Script Processor (TSP®) enabled instruments.

[tspnet.clear\(\)](#) (on page 8-447)
[tspnet.connect\(\)](#) (on page 8-448)
[tspnet.disconnect\(\)](#) (on page 8-449)
[tspnet.execute\(\)](#) (on page 8-450)
[tspnet.idn\(\)](#) (on page 8-451)
[tspnet.read\(\)](#) (on page 8-451)
[tspnet.readavailable\(\)](#) (on page 8-452)
[tspnet.reset\(\)](#) (on page 8-453)
[tspnet.termination\(\)](#) (on page 8-453)
[tspnet.timeout](#) (on page 8-454)
[tspnet.tsp.abort\(\)](#) (on page 8-455)
[tspnet.tsp.abortonconnect](#) (on page 8-455)
[tspnet.tsp.rhtablecopy\(\)](#) (on page 8-456)
[tspnet.tsp.runscript\(\)](#) (on page 8-457)
[tspnet.write\(\)](#) (on page 8-457)

Userstrings

Use the functions in this group to store and retrieve user-defined strings in nonvolatile memory. These strings are stored as key-value pairs. You can use the `userstring` functions to store custom, instrument-specific information in the instrument, such as department number, asset number, or manufacturing plant location.

[userstring.add\(\)](#) (on page 8-459)
[userstring.catalog\(\)](#) (on page 8-460)
[userstring.delete\(\)](#) (on page 8-460)
[userstring.get\(\)](#) (on page 8-461)

Instrument programming

In this section:

Fundamentals of scripting for TSP	7-1
Fundamentals of programming for TSP	7-15
Using Test Script Builder (TSB)	7-35
Advanced scripting for TSP	7-37
TSP-Link system expansion interface	7-45
TSP-Net	7-54

Fundamentals of scripting for TSP

NOTE

The next few sections of the documentation describe scripting and programming features of the instrument. You do not need to review this information if you do not need to use scripting and programming.

Scripting helps you combine commands into a block of code that the instrument can run. Scripts help you communicate with the instrument more efficiently. In the instrument, the Test Script Processor (TSP®) scripting engine processes and runs scripts.

Scripts offer several advantages over sending individual commands from the control computer:

- Scripts are easier to save, refine, and implement than individual commands.
- The instrument performs faster and more efficiently when processing scripts.
- You can incorporate features such as looping and branching into scripts.
- Scripts allow the controller to perform other tasks while the instrument is running a script, enabling some parallel operation.
- Scripts eliminate repeated data transfer times from the controller.

Though it can improve your process to use scripts, you do not have to create scripts to use the instrument. Most of the examples in the documentation can be run by sending individual command messages.

This section describes how to create, load, modify, and run scripts.

What is a script?

A script is a collection of instrument control commands and programming statements. Scripts that you create are referred to as **user scripts**.

Your scripts can be interactive. Interactive scripts display messages on the front panel of the instrument to prompt the operator to enter parameters.

Runtime and nonvolatile memory storage of scripts

Scripts are loaded into the runtime environment of the instrument. From there, they can be stored in the nonvolatile memory.

The runtime environment is a collection of global variables, which include scripts, that the user has defined. A global variable can be used to remember a value as long as the instrument is turned on and the variable has not been assigned a new value. After scripts are loaded into the runtime environment, you can run and manage them from the front panel of the instrument or from a computer.

Nonvolatile memory is where information is stored even when the instrument is turned off. To save a script when the instrument is turned off, you must save it to nonvolatile memory. The scripts that are in nonvolatile memory are loaded into the runtime environment when the instrument is turned on.

Information in the runtime environment is lost when the instrument is turned off.

Scripts are placed in the runtime environment when:

- The instrument is turned on. All scripts that are saved to nonvolatile memory are copied to the runtime environment when the instrument is turned on.
- They are loaded into the runtime environment.

For detail on the amount of memory available in the runtime environment, see [Memory considerations for the runtime environment](#) (on page 7-43).

NOTE

If you make changes to a script in the runtime environment, the changes are lost when the instrument is turned off. To save the changes, you must save them to nonvolatile memory. See [Working with scripts in nonvolatile memory](#) (on page 7-10).

What can be included in scripts?

Scripts can include combinations of commands and Lua code. Commands tell the instrument to do one thing and are described in the [Command reference](#) (see "[Commands](#)" on page 8-10). Lua is a scripting language that is described in [Fundamentals of programming for TSP](#) (on page 7-15).

Commands that cannot be used in scripts

Though an instrument accepts the following commands, you cannot use these commands in scripts.

Commands that cannot be used in scripts

General commands	IEEE Std 488.2 common commands	
abort	*CLS	*RST
endflash	*ESE	*SRE
endscript	*ESE?	*SRE?
flash	*ESR?	*STB?
loadscript	*IDN?	*TRG
loadandrunscript	*OPC	*TST?
password	*OPC?	*WAI

Manage scripts

This section describes how to create scripts by sending commands over the remote interface and using TSB Embedded. Topics include:

- [Tools for managing scripts](#) (on page 7-3)
- [Create and load a script](#) (on page 7-3)
- [Run scripts](#) (on page 7-5)
- [Scripts that run automatically](#) (on page 7-6)
- [Save the anonymous script as a named script](#) (on page 7-7)

Tools for managing scripts

To manage scripts, you can send messages to the instrument, use your own development tool or program, use the Keithley Test Script Builder Integrated Development Environment (TSB IDE), or use TSB Embedded.

The TSB IDE is a programming tool that is included on the Product Information CD-ROM that came with your Series 3700A. You can use it to create, modify, debug, and store Test Script Processor (TSP[®]) scripting engine scripts. For more information about using the TSB IDE, see [Using Test Script Builder \(TSB\)](#) (on page 7-35).

TSB Embedded is a tool with a reduced set of features from the complete Keithley TSB IDE. TSB Embedded has both script-building functionality and console functionality (single-line commands). It is accessed from an Internet browser.

Create and load a script

You create scripts by loading them into the instrument's runtime environment. You can load a script as a named script or as the anonymous script.

Once a script is loaded into the instrument, you can execute it remotely or from the front panel.

Anonymous scripts

If a script is created with the `loadscript` or `loadandrunscript` command with no name defined, it is called the *anonymous* script. There can only be one anonymous script in the runtime environment. If another anonymous script is loaded into the runtime environment, it replaces the existing anonymous script.

Named scripts

A named script is a script with a unique name. You can have as many named scripts as needed in the instrument (within the limits of the memory available to the runtime environment). When a named script is loaded into the runtime environment with the `loadscript` or `loadandrunscript` commands, a global variable with the same name is created to reference the script.

Key points regarding named scripts:

- If you load a new script with the same name as an existing script, the existing script becomes an unnamed script, which in effect removes the existing script if there are no other variables that reference it.
- Sending revised scripts with different names will not remove previously loaded scripts.
- Unlike other scripts, named scripts can be saved to internal nonvolatile memory. Saving a named script to nonvolatile memory allows the instrument to be turned off without losing the script. See [Working with scripts in nonvolatile memory](#) (on page 7-10).

Load a script by sending commands over the remote interface


You can send commands over the remote interface instead of using TSB Embedded. To load a script over the remote interface, you can use the `loadscript`, `loadandrunscript`, and `endscript` commands.

The `loadscript` and `loadandrunscript` commands start the collection of messages that make up the script. When the instrument receives either of these commands, it starts collecting all subsequent messages. Without these commands, the instrument would run them immediately as individual commands.

The `endscript` command tells the instrument to compile the messages. It compiles the messages into one group of commands. This group of commands is loaded into the runtime environment.

The following figure shows an example of how to load a script named “test.” The first command tells the instrument to start collecting the messages for the script named “test.” The last command marks the end of the script. When this script is run, the message “This is a test” will be displayed on the instrument and sent to the computer.

Figure 7-1: Loadscript and endscript example



To load a named script by sending commands:

1. Send the command `loadscript scriptName`, where `scriptName` is the name of the script. The name must be a legal Lua variable name (see [Lua reserved words](#) (on page 7-16)).
2. Send the commands that need to be included in the script.
3. Send the command `endscript`.
4. You can now run the script. See [Run scripts](#) (on page 7-5).

NOTE

To run the script immediately, use `loadandrunscript scriptName` instead of `loadscript`.

Create a script using TSB Embedded**NOTE**

If you are using TSB Embedded to create scripts, you do not need to use the commands `loadscript` or `loadandrunscript` and `endscript`. For information on using TSB Embedded, select the **Help** button on a web page or the Help option from the navigation pane on the left side.

You can create a script from the instrument web page with TSB Embedded. When you save the script in TSB Embedded, it is loaded into the runtime environment and saved in the nonvolatile memory of the instrument.

To create a script using TSB Embedded:

1. In the TSP Script box, enter a name for the script.
2. In the input area, enter the sequence of commands to be included in the script. Line numbers are automatically assigned.
3. Click **Save Script**. The name is added to the User Scripts list on the left.

Create a script using the create configuration script feature

The create configuration script feature captures the present settings of the instrument. Once saved, you can use this script to return to that configuration, or use it as a starting point to create your own scripts.

Once created, the configuration script is a normal TSP script — you can use it as you do any other script.

For detail on creating a configuration script, see [Save the present configuration](#) (on page 2-100).

Run scripts

This section describes how to run the anonymous and named scripts.

NOTE

If the instrument is in local control when the script is started, it switches to remote control (REM is displayed) while the script is running. The instrument is returned to local control when the script completes. If you press the front panel **EXIT (LOCAL)** key while the script is running, the script is stopped.

Run the anonymous script

The anonymous script can be run many times without reloading it. It remains in the runtime environment until a new anonymous script is created or until the instrument is turned off.

To run the anonymous script, use any one of these commands:

- `run()`
- `script.run()`
- `script.anonymous()`
- `script.anonymous.run()`

Run a named script

Any named script that is in the runtime environment can be run using one of the following commands:

- `scriptVar()`
- `scriptVar.run()`

Where: *scriptVar* is the user-defined name of the script.

To run a named script from TSB Embedded, select the script from the User Scripts list and click **Run**.

When a script is named, it can be accessed using the global variable *scriptVar*.

Example: Run a named script

```
test3()
```

If the script `test3` is loaded into the runtime environment, the instrument executes `test3`.

Scripts that run automatically

The autorun scripts and the autoexec script run automatically when the instrument is turned on.

Autorun scripts

Autorun scripts run automatically when the instrument is turned on. You can set any number of scripts to autorun. The run order for autorun scripts is arbitrary, so make sure the run order is not important.

As shown in the example below, you can set a script to run automatically by settings the script's `.autorun` attribute to "yes" and then saving the script.

Example:

```
scriptVar.autorun = "yes"  
scriptVar.save()
```

Where: *scriptVar* is the user-defined name of the script.

To disable autorun, set the script's `.autorun` attribute to "no" and then save the script.

NOTE

The `scriptVar.save()` command saves the script to nonvolatile memory, which makes the change persistent through a power cycle. See [Save a user script to nonvolatile memory](#) (on page 7-10) for more detail.

Example: Set a script to run automatically

```
test5.autorun = "yes"
test5.save()
```

Assume a script named `test5` is in the runtime environment. The next time the instrument is turned on, `test5` script automatically loads and runs.

Autoexec script

The autoexec script runs automatically when the instrument is turned on. It runs after all the scripts have loaded and any scripts marked as `autorun` have run.

To create a script that executes automatically, create and load a new script and name it `autoexec`. See [Create and load a script](#) (on page 7-3).

NOTE

You need to save the autoexec script to nonvolatile memory to save the script when the instrument is turned off. See [Save a user script to nonvolatile memory](#) (on page 7-10) for more detail.

Example: Autoexec script with loadscript command

```
loadscript autoexec
display.clear()
display.settext("Hello from autoexec")
endscript
autoexec.save()
```

Creates the script `autoexec`. Saves the `autoexec` script to nonvolatile memory. The next time the instrument is turned on, "Hello from autoexec" is displayed.

Example: TSB Embedded

```
display.clear()
display.settext("Hello from autoexec")
```

In the TSP Script box, enter `autoexec`. Enter the code in the entry box. Click **Save Script**. Creates a new script that clears the display when the instrument is turned on and displays "Hello from autoexec."

Save the anonymous script as a named script**To save the anonymous script as a named script:**

1. To name the script, send the following command:

```
script.anonymous.name = "myTest"
```

Where `myTest` is the name of the script

2. Send the command `script.anonymous.save()` to save `myTest` to nonvolatile memory.

Retrieve a user script

There are several ways to retrieve the source code of a user script:

- Line by line: Use `scriptVar.list()` to retrieve the source code line by line
- Entire script: Use the `print(scriptVar.source)` command to retrieve the script source code as a single string
- Use TSB Embedded

After retrieving a script, see [Create and load a script](#) (on page 7-3) for information about recreating the script and loading it back into the instrument.

NOTE

To get a list of scripts that are in nonvolatile memory, see [script.user.catalog\(\)](#) (on page 8-359).

Retrieve source code one line at a time

To retrieve the source code one line at a time, use the `scriptVar.list()` command. The output for this method includes the `loadscript` or `loadandrunscript` and `endscript` keywords.

After retrieving the source code, you can modify and save the command lines as a user script under the same name or a new name.

To retrieve the source code of a script one line at a time, send the command:

```
scriptVar.list()
```

Where `scriptVar` is the name of the script.

NOTE

To retrieve the commands in the anonymous script, use `script.anonymous.list()`.

Example: Retrieve source code one line at a time

```
test7.list()
```

Retrieve the source of a script named "test7".

Retrieve a script as a single string

To retrieve the entire user script source code as a single string, use the `scriptVar.source` attribute. The `loadscript` or `loadandrunscript` and `endscript` keywords are not included.

To retrieve the source code as a single string, send the command:

```
print(scriptVar.source)
```

Where `scriptVar` is the name of the script.

Example: Retrieve the source code as a single string

```
print(test1.source)
```

Retrieve the source of a script named "test1".

Retrieve a script using TSB Embedded

In TSB Embedded, from the User Scripts list, select the script you want to retrieve. The contents of the script are displayed. See Working with TSB Embedded for more information.

Script example: Retrieve the content of scripts

This set of examples:

- Retrieves the source of a script using `scriptVar.source`
- Retrieves the source of a script using `scriptVar.list()`

Example: Retrieve the content of a script with `scriptVar.source`

```
print(scriptVarTest.source)
```

Request a listing of the source of `scriptVarTest`. The instrument outputs the following (note that the `loadscript` and `endscript` commands are not included).

Output:

```
listTones = {100, 400, 800}
for index in listTones do
  beeper.beeper(.5, listTones[index])
end
```

Example: Retrieve the content of a script with `scriptVar.list()`

```
scriptVarTest.list()
```

Request a listing of the source of `scriptVarTest`. The instrument outputs the following (note that the `loadscript` and `endscript` commands are included).

Output:

```
loadscript scriptVarTest
listTones = {100, 400, 800}
for index in listTones do
  beeper.beeper(.5, listTones[index])
end
endscript
```

Working with scripts in nonvolatile memory

The [Fundamentals of scripting for TSP](#) (on page 7-1) section in this manual describes working with scripts, primarily in the runtime environment.

Scripts can also be stored in nonvolatile memory. Information in nonvolatile memory is stored even when the instrument is turned off. The scripts that are in nonvolatile memory are loaded into the runtime environment when the instrument is turned on.

The runtime environment and nonvolatile memory are separate storage areas in the instrument. The runtime environment is wiped clean when the instrument is turned off. The nonvolatile memory remains intact when the instrument is turned off. When the instrument is turned on, information in nonvolatile memory is loaded into the runtime environment.

This section describes how to work with the scripts in nonvolatile memory, including how to:

- [Save a user script to nonvolatile memory](#) (on page 7-10)
- [Retrieve a user script](#) (on page 7-8)
- [Restore a script to the runtime environment](#) (on page 7-41)
- [Delete user scripts](#) (on page 7-10)

Save a user script

You can save scripts to nonvolatile memory using commands or TSB Embedded.

Only named scripts can be saved to nonvolatile memory. The anonymous script must be named before it can be saved to nonvolatile memory.

NOTE

If a script is not saved to nonvolatile memory, the script is lost when the instrument is turned off.

To save a script to nonvolatile memory:

1. Create and load a named script (see [Create and load a script](#) (on page 7-3)).
2. Do one of the following:
 - Send the command `scriptVar.save()`, where `scriptVar` is the name of the script.
 - In TSB Embedded, click **Save Script**.

Example: Save a user script to nonvolatile memory

```
test1.save()
```

Assume a script named `test1` has been loaded. `test1` is saved into nonvolatile memory.

Delete user scripts

NOTE

These steps remove a script from nonvolatile memory. To completely remove a script from the system, there are additional steps you must take. See [Delete user scripts from the instrument](#) (on page 7-43).

You can delete the script from nonvolatile memory by sending either of the following commands:

- `script.delete("name")`
- `script.user.delete("name")`

Where: *name* is the user-defined name of the script.

To delete a script from nonvolatile memory using TSB Embedded:

1. In TSB Embedded, select the script from the User Scripts list.
2. Click **Delete**. There is no confirmation message.

Example: Delete a user script from nonvolatile memory

```
script.delete("test8")
```

Delete a user script named `test8` from nonvolatile memory.

Run a user script from the instrument front panel

From the instrument front panel, you can load and run a user script.

To run the code from the front panel and add it to the USER menu:

1. Press the **LOAD** key.
2. Select **USER**.
3. Select the user chunk from list and press the **ENTER** key. The chunk is loaded into the runtime environment.

NOTE

If you are used to using `print` in Test Script Builder, note that the output of the prints using this procedure will not function the same as when you are in Test Script Builder. You may find that it makes more sense to use Test Script Builder to get the output you need.

4. Press the **RUN** key to execute.

To run a script directly without adding it to the USER menu:

1. Press the **LOAD** key.
2. Select **SCRIPTS** and press the **ENTER** key. There may be a short pause before a menu is displayed that represents the scripts in the instrument.
3. Select the script from the list and press the **ENTER** key. Now the script is loaded for front panel execution.

NOTE

If you are used to using `print` in Test Script Builder, note that the output of the prints using this procedure will not function the same as when you are in Test Script Builder. You may find that it makes more sense to use Test Script Builder to get the output you need.

4. Press the **RUN** key to execute.

Load a script from the instrument front panel

You can load scripts to the runtime environment of the instrument from a USB flash drive.

When you load a named script from the flash drive, the script is named using the name that follows the `loadscript` shell keyword (not the filename on the flash drive). The script is loaded into the `script.user.scripts` table.

If the loaded file does not contain `loadscript` and `endscript` shell keywords, the code is loaded as the anonymous script. Loading an unnamed script overwrites the existing anonymous script.

The file must be a valid script file. If not, an error message is posted and no further action is taken. You can view the errors on the front panel of the instrument.

To load a script from a USB flash drive:

1. Insert the flash drive into the USB port on the instrument.
2. Press the **MENU** key.
3. Select the **SCRIPT** option.
4. Select the **LOAD** option.
5. Select the **USB** option. A menu is displayed that lists the `.tsp` files and directories on the flash drive.
6. If the files are in a directory, use the navigation wheel to select the directory. A new menu is displayed that lists the `.tsp` files and directories in that directory.
7. Use the navigation wheel to select the `.tsp` file you want to load.
8. If the script has the same name as a script that is already in memory, you are prompted to overwrite the script.
 - Select "Yes" to continue.
 - Select "No" to return to the list of files. You must select a file to continue.
9. The **SCRIPT ACTION** menu is displayed.
10. Select **SAVE_INTERNAL**.
11. The **SAVE SCRIPT INTERNAL** prompt is displayed. Select **Yes** to save the file to nonvolatile memory. (This is the same as sending `scriptVar.save()` with no parameters.)
12. The **SCRIPT ACTION** menu is displayed again.
13. If you would like to set the script to run from the **RUN** button:
 - a. Select **ACTIVE_FOR_RUN**. **MAKE ACTIVE SCRIPT** is displayed.
 - b. Select **YES**.
14. Loading is complete. To return to the **MAIN** menu, press **EXIT (LOCAL)** until the **MAIN** menu is displayed.
15. If you selected **ACTIVE_FOR_RUN**, you can select **RUN** to run the script.

Save a script from the instrument front panel

You can save scripts from the runtime environment to nonvolatile memory from the instrument front panel.

NOTE

If you want to save the anonymous script to nonvolatile memory, you must name it first. See [Save the anonymous script as a named script](#) (on page 7-7).

To save a script to nonvolatile memory from the front panel:

1. Press the **MENU** key.
2. Select the **SCRIPT** option.
3. Select the **SAVE** option.

A list of the scripts available to save is displayed. It may take a few seconds to display. The displayed list is from the `script.user.scripts` table in the instrument.

4. Turn the navigation wheel to select the script that you want to save.
5. Select **INTERNAL**. Press the navigation wheel. The script is saved to nonvolatile memory using the script's name attribute.
6. Press **EXIT (LOCAL)** several times to return to the Main Menu.

Interactive script

An interactive script prompts the operator to input values using the instrument front panel. The following example script uses display messages to prompt the operator to:

- Enter the digital I/O line on which to output a trigger
- Enter the output trigger pulsewidth

After the output trigger occurs, the front display displays a message to the operator.

When an input prompt is displayed, the script waits until the operator inputs the parameter or presses the **ENTER** key.

```
-- Clear the display.
display.clear()

-- Prompt user for digital I/O line on which to output trigger.
myDigioLine = display.menu(
    "Select digio line", "1 2 3 4 5 6 7 8 9")

-- Convert user input to a number.
intMyDigioLine = tonumber(myDigioLine)

-- Prompt user for digital output trigger mode.
myDigioEdge = display.menu(
    "Select digio mode", "Rising Falling")
if myDigioEdge == "Rising" then
    edgeMode = digio.TRIG_RISING
else
    edgeMode = digio.TRIG_FALLING
end

-- Prompt user for output trigger pulsewidth.
myPulseWidth = display.prompt(
    "000.0", "us", "Enter trigger pulsewidth", 10, 10, 100)

-- Scale the entered pulsewidth
myPulseWidth = myPulseWidth * 1e-6

-- Generate the pulse.
digio.trigger[intMyDigioLine].mode = edgeMode
digio.trigger[intMyDigioLine].pulsewidth = myPulseWidth
digio.trigger[intMyDigioLine].assert()

-- Alert the user through the display that the
-- output trigger has occurred.
display.setcursor(1, 1)
display.settext(
    "Trigger asserted $Non digital I/O line " .. intMyDigioLine)

-- Wait five seconds and then return to main screen.
delay(5)
display.screen = display.MAIN
```

Fundamentals of programming for TSP

Introduction

To conduct a test, a computer (controller) is programmed to send sequences of commands to an instrument. The controller orchestrates the actions of the instrumentation. The controller is typically programmed to request measurement results from the instrumentation and make test sequence decisions based on those measurements.

To take advantage of the advanced features of the instrument, you can add programming commands to your scripts. Program statements control script execution and provide tools such as variables, functions, branching, and loop control.

The Test Script Processor (TSP[®]) scripting engine is a Lua interpreter. In TSP-enabled instruments, the Lua programming language has been extended with Keithley-specific instrument control commands.

What is Lua?

Lua is a programming language that can be used with TSP-enabled instruments. Lua is an efficient language with simple syntax that is easy to learn.

Lua is also a scripting language, which means that scripts are compiled and run when they are sent to the instrument. You do not compile them before sending them to the instrument.

Lua basics

This section contains the basics about the Lua programming language to allow you to start adding Lua programming commands to your scripts quickly.

For more information about Lua, see the [Lua website](http://www.lua.org) (see Lua website - <http://www.lua.org>). Another source of useful information is the [Lua users group](http://lua-users.org) (see Lua users group - <http://lua-users.org>), created for and by users of Lua programming language.

Comments

Comments start anywhere outside a string with a double hyphen (--). If the text immediately after a double hyphen (--) is anything other than double left brackets ([[), the comment is a short comment, which continues only until the end of the line. If double left brackets ([[) follow the double hyphen (--), it is a long comment, which continues until the corresponding double right brackets (]) close the comment. Long comments may continue for several lines and may contain nested [[. . .]] pairs. The table below shows how to use code comments.

Using code comments

Type of comment	Comment delimiters	Usage	Example
Short comment	--	Use when the comment text is short enough that it will not wrap to a second line.	--Disable the front-panel LOCAL key. display.locallockout = display.LOCK
Long comment	--[[]]	Use when the comment text is long enough that it wraps to additional lines. The double left brackets signal the beginning of the multi-line comment, and the double right brackets signal the end of the comment.	--[[Displays a menu with three menu items. If the second menu item is selected, the selection will be given the value Test2.]] selection = display.menu("Sample Menu", "Test1 Test2 Test3") print(selection)

Lua reserved words

You cannot use the following words for function or variable names.

Lua reserved words		
and	for	or
break	function	repeat
do	if	return
else	in	then
elseif	local	true
end	nil	until
false	not	while

In addition to the Lua reserved words, you also cannot use command group names as variable names. Doing so will result in the loss of use of the command group. For example, if you send the command `digio = 5`, you cannot access the `digio.*` commands until you cycle the power to the instrument. These groups include:

Command group names	
beeper	lan
bit	localnode
channel	opc
dataqueue	reset
delay	scan
digio	slot
display	status
eventlog	timer
errorqueue	trigger
exit	tsplink
format	tspnet
fs	userstring
gpib	waitcomplete
io	

Values and variable types

In Lua, you use variables to store values in the runtime environment for later use.

Lua is a dynamically typed language; the type of the variable is determined by the value that is assigned to the variable.

Variables in Lua are assumed to be global unless they are explicitly declared to be local. A global variable is accessible by all commands. Global variables do not exist until they have been used.

NOTE

Do not create variable names that are the same as the base names of Series 3700A remote commands. Doing so will result in the loss of use of those commands. For example, if you send the command `digio = 5`, you cannot access the `digio.*` commands until the power to the instrument is turned off and then back on.

Variables can be one of the following types.

Variable types and values

Variable type returned	Value	Notes
"nil"	not declared	Nil is the type of the value <code>nil</code> , whose main property is to be different from any other value; usually it represents the absence of a useful value.
"boolean"	true or false	Boolean is the type of the values <code>false</code> and <code>true</code> . In Lua, both <code>nil</code> and <code>false</code> make a condition <code>false</code> ; any other value makes it <code>true</code> .
"number"	number	All numbers are real numbers; there is no distinction between integers and floating-point numbers.
"string"	sequence of words or characters	
"function"	a block of code	Functions can carry out a task or compute and return values.
"table"	an array	New tables are created with <code>{}</code> braces. For example, <code>{1, 2, 3.00e0}</code> .

To determine the type of a variable, you can call the `type()` function, as shown in the examples below.

Example: Nil

<pre>x = nil print(x, type(x))</pre>	<pre>nil nil</pre>
--------------------------------------	-------------------------

Example: Boolean

<pre>y = false print(y, type(y))</pre>	<pre>false boolean</pre>
--	-----------------------------

Example: String and number

<pre>x = "123" print(x, type(x))</pre>	<pre>123 string</pre>
<pre>x = x + 7 print(x, type(x))</pre>	<pre>Adding a number to x forces its type to number 1.30000e+02 number</pre>

Example: Function

<pre>function add_two(parameter1, parameter2) return parameter1 + parameter2 end print(add_two(3, 4), type(add_two))</pre>	<pre>7.00000e+00 function</pre>
--	------------------------------------

Example: Table

<pre>atable = {1, 2, 3, 4} print(atable, type(atable)) print(atable[1]) print(atable[4])</pre>	<p>Defines a table with four numeric elements. Note that the "table" value (shown here as a096cd30) will vary.</p> <pre>table: a096cd30 table 1.00000e+00 4.00000e+00</pre>
--	--

To delete a global variable, assign `nil` to the global variable. This removes the global variable from the runtime environment.

Functions

Lua makes it simple to group commands and statements using the `function` keyword. Functions can take zero, one, or multiple parameters, and they return zero, one, or multiple parameters.

Functions can be used to form expressions that calculate and return a value; they also can act as statements that execute specific tasks.

Functions are first-class values in Lua. That means that functions can be stored in variables, passed as arguments to other functions, and returned as results. They can also be stored in tables.

Note that when a function is defined, it is a global variable in the runtime environment. Like all global variables, the functions persist until they are removed from the runtime environment, are overwritten, or the instrument is turned off.

Create functions using the function keyword

Functions are created with a message or Lua code in the form:

```
myFunction = function (parameterX) functionBody end
```

Where:

- *myFunction*: The name of the function.
- *parameterX*: Parameter values. You can have multiple parameters. Change the value defined by *X* for each parameter and use a comma to separate the values.
- *functionBody* is the code that is executed when the function is called.

To execute a function, substitute appropriate values for *parameterX* and insert them into a message formatted as:

```
myFunction(valueForParameterX, valueForParameterY)
```

Where *valueForParameterX* and *valueForParameterY* represent the values to be passed to the function call for the given parameters.

Example 1

```
function add_two(parameter1, parameter2)
    return parameter1 + parameter2
end
print(add_two(3, 4))
```

Creates a variable named `add_two` that has a variable type of function.

Output:
7.000000000e+00

Example 2

```
add_three = function(parameter1,
    parameter2, parameter3)
    return parameter1 + parameter2 +
        parameter3
end
print(add_three(3, 4, 5))
```

Creates a variable named `add_three` that has a variable type of function.

Output:
1.200000000e+01

Example 3

```
function sum_diff_ratio(parameter1,
    parameter2)
    psum = parameter1 + parameter2
    pdif = parameter1 - parameter2
    prat = parameter1 / parameter2
    return psum, pdif, prat
end
sum, diff, ratio = sum_diff_ratio(2, 3)
print(sum)
print(diff)
print(ratio)
```

Returns multiple parameters (sum, difference, and ratio of the two numbers passed to it).

Output:
5.000000000e+00
-1.000000000e+00
6.666666667e-01

Create functions using scripts

You can use scripts to define functions. Scripts that define a function are like any other script: They do not cause any action to be performed on the instrument until they are executed. The global variable of the function does not exist until the script that created the function is executed.

A script can consist of one or more functions. Once a script has been run, the computer can call functions that are in the script directly.

NOTE

The following steps use TSB Embedded. You can also use the `loadscript` and `endscript` commands to create the script. See [Load a script by sending commands over the remote interface](#) (on page 7-4).

Steps to create a function using a script

Steps	Example
1. In TSB Embedded, enter a name into the TSP Script box	MakeMyFunction
2. Enter the function as the body of the script	This example concatenates two strings: <pre>MyFunction = function (who) print("Hello " .. who) end</pre>
3. Click Save Script	MakeMyFunction now exists on the instrument in a global variable with the same name as the script (MakeMyFunction). However, the function defined in the script does not yet exist because the script has not been executed.
4. Run the script as a function	MakeMyFunction() This instructs the instrument to run the script, which creates the MyFunction global variable (which is also a function).
5. Run the new function with a value	MyFunction("world") The response message is: Hello world

Group commands using the function keyword

The following script contains instrument commands that display the name of the person that is using the script on the front panel of the instrument. It takes one parameter to represent this name. When this script is run, the function is loaded in memory. Once loaded into memory, you can call the function outside of the script to execute it.

When calling the function, you must specify a string for the *name* argument of the function. For example, to set the name to **John**, call the function as follows:

```
myDisplay("John")
```

Example: User script

User script created in Test Script Builder	User script created in user's own program
<pre>function myDisplay(name) display.clear() display.settext(name .. "\$N is here!") end</pre>	<pre>loadscript function myDisplay(name) display.clear() display.settext(name .. " \$N is here!") end endscript</pre>

NOTE

If you are using TSB Embedded, do not include the `loadscript` and `endscript` commands.

Operators

Lua variables and constants can be compared and manipulated using operators.

Arithmetic operators

Operator	Description
+	addition
-	subtraction
*	multiplication
/	division
-	negation (for example, $c = -a$)
^	exponentiation

Relational operators

Operator	Description
<	less than
>	greater than
<=	less than or equal
>=	greater than or equal
~=	not equal
==	equal

Logical operators

The logical operators in Lua are `and`, `or`, and `not`. All logical operators consider both `false` and `nil` as false and anything else as true.

The operator `not` always returns `false` or `true`.

The conjunction operator `and` returns its first argument if this value is `false` or `nil`; otherwise, `and` returns its second argument. The disjunction operator `or` returns its first argument if this value is different from `nil` and `false`; otherwise, `or` returns its second argument. Both the `and` and the `or` logical operators use shortcut evaluation, that is, the second operand is evaluated only if necessary.

Example

<code>print(10 or errorqueue.next())</code>	1.00000e+01
<code>print(nil or "a")</code>	a
<code>print(nil and 10)</code>	nil
<code>print(false and errorqueue.next())</code>	false
<code>print(false and nil)</code>	false
<code>print(false or nil)</code>	nil
<code>print(10 and 20)</code>	2.00000e+01

String concatenation

String operators

Operator	Description
..	Concatenates two strings. If both operands are strings or number, they are converted to strings according to Lua coercion rules, as follows: <ul style="list-style-type: none"> Any arithmetic operation applied to a string tries to convert that string to a number, following the usual rules. Whenever a number is used where a string is expected, the number is converted to a string, in a reasonable format.

Example: Concatenation

<pre>print(2 .. 3)</pre>	23
<pre>print("Hello " .. "World")</pre>	Hello World

Operator precedence

Operator precedence in Lua follows the order below (from higher to lower priority).

Operator precedence

Precedence	Operator
Highest	^ (exponentiation)
.	not, - (unary)
.	*, /
.	+, -
.	.. (concatenation)
.	<, >, <=, >=, ~=, ==
.	and
Lowest	or

You can use parentheses to change the precedences in an expression. The concatenation (". .") and exponentiation ("^") operators are right associative. All other binary operators are left associative. The examples below show equivalent expressions.

Equivalent expressions

<code>reading + offset < testValue/2+0.5</code>	=	<code>(reading + offset) < ((testValue/2)+0.5)</code>
<code>3+reading^2*4</code>	=	<code>3+((reading^2)*4)</code>
<code>Rdg < maxRdg and lastRdg <= expectedRdg</code>	=	<code>(Rdg < maxRdg) and (lastRdg <=expectedRdg)</code>
<code>-reading^2</code>	=	<code>-(reading^2)</code>
<code>reading^testAdjustment^2</code>	=	<code>reading^(testAdjustment^2)</code>

Conditional branching

Lua uses the `if`, `else`, `elseif`, `then`, and `end` keywords to do conditional branching.

Note that in Lua, `nil` and `false` are `false` and everything else is `true`. Zero (0) is `true` in Lua.

The syntax of a conditional block is as follows:

```
if expression then
  block
elseif expression then
  block
else
  block
end
```

Where:

- *expression* is Lua code that evaluates to either `true` or `false`
- *block* consists of one or more Lua statements

Example: If

```
if 0 then
  print("Zero is true!")
else
  print("Zero is false.")
end
```

Output:
Zero is true!

Example: Comparison

```
x = 1
y = 2
if x and y then
  print("Both x and y are true")
end
```

Output:
Both x and y are true

Example: If and else

```
x = 2
if not x then
  print("This is from the if block")
else
  print("This is from the else block")
end
```

Output:
This is from the else block

Example: Else and elseif

```
x = 1
y = 2
if x and y then
    print("'if' expression 2 was not false.")
end

if x or y then
    print("'if' expression 3 was not false.")
end

if not x then
    print("'if' expression 4 was not false.")
else
    print("'if' expression 4 was false.")
end

if x == 10 then
    print("x = 10")
elseif y > 2 then
    print("y > 2")
else
    print("x is not equal to 10, and y is not less than 2.")
end
```

Output:

```
'if' expression 2 was not false.
'if' expression 3 was not false.
'if' expression 4 was false.
x is not equal to 10, and y is not less than 2.
```

Loop control

If you need to repeat code execution, you can use the Lua `while`, `repeat`, and `for` control structures. To exit a loop, you can use the `break` keyword.

While loops

To use conditional expressions to determine whether to execute or end a loop, you use `while` loops. These loops are similar to [Conditional branching](#) (on page 7-24) statements.

```
while expression do
    block
end
```

Where:

- *expression* is Lua code that evaluates to either `true` or `false`
- *block* consists of one or more Lua statements

Example: While

```
list = {
  "One", "Two", "Three", "Four", "Five", "Six"}
print("Count list elements on numeric index:")
element = 1
while list[element] do
  print(element, list[element])
  element = element + 1
end
```

This loop will exit when
list[element] = nil.

Output:

```
Count list elements on
  numeric index:
1.000000000e+00   One
2.000000000e+00   Two
3.000000000e+00   Three
4.000000000e+00   Four
5.000000000e+00   Five
6.000000000e+00   Six
```

Repeat until loops

To repeat a command, you use the `repeat ... until` statement. The body of a `repeat` statement always executes at least once. It stops repeating when the conditions of the `until` clause are met.

```
repeat
  block
until expression
```

Where:

- *block* consists of one or more Lua statements
- *expression* is Lua code that evaluates to either `true` or `false`

Example: Repeat until

```
list = {
  "One", "Two", "Three", "Four", "Five", "Six"}
print("Count elements in list using repeat:")
element = 1
repeat
  print(element, list[element])
  element = element + 1
until not list[element]
```

Output:

```
Count elements in list
  using repeat:
1.000000000e+00   One
2.000000000e+00   Two
3.000000000e+00   Three
4.000000000e+00   Four
5.000000000e+00   Five
6.000000000e+00   Six
```

For loops

There are two variations of `for` statements supported in Lua: numeric and generic.

NOTE

In a `for` loop, the loop expressions are evaluated once, before the loop starts.

Example: Numeric for

```
list = {"One", "Two", "Three", "Four", "Five", "Six"}
----- For loop -----
print("Counting from one to three:")
for element = 1, 3 do
    print(element, list[element])
end
print("Counting from one to four, in steps of two:")
for element = 1, 4, 2 do
    print(element, list[element])
end
```

The numeric `for` loop repeats a block of code while a control variable runs through an arithmetic progression.

Output:

```
Counting from one to three:
1.000000000e+00  One
2.000000000e+00  Two
3.000000000e+00  Three
Counting from one to four, in steps of two:
1.000000000e+00  One
3.000000000e+00  Three
```

Example: Generic for

```
days = {"Sunday",
        "Monday",   "Tuesday",
        "Wednesday", "Thursday",
        "Friday",   "Saturday"}

for i, v in ipairs(days) do
    print(days[i], i, v)
end
```

The generic `for` statement works by using functions called *iterators*. On each iteration, the iterator function is called to produce a new value, stopping when this new value is nil.

Output:

```
Sunday    1.000000000e+00    Sunday
Monday    2.000000000e+00    Monday
Tuesday   3.000000000e+00    Tuesday
Wednesday 4.000000000e+00    Wednesday
Thursday  5.000000000e+00    Thursday
Friday    6.000000000e+00    Friday
Saturday  7.000000000e+00    Saturday
```

Break

The `break` statement can be used to terminate the execution of a `while`, `repeat`, or `for` loop, skipping to the next statement after the loop. A `break` ends the innermost enclosing loop.

Return and `break` statements can only be written as the last statement of a block. If it is really necessary to return or `break` in the middle of a block, then an explicit inner block can be used.

Example: Break with while statement

```
local numTable = {5, 4, 3, 2, 1}
local k = table.getn(numTable)
local breakValue = 3
while k > 0 do
    if numTable[k] == breakValue then
        print("Going to break and k = ", k)
        break
    end
    k = k - 1
end
if k == 0 then
    print("Break value not found")
end
```

This example defines a break value (breakValue) so that the break statement is used to exit the while loop before the value of k reaches 0.

Output:

```
Going to break and i =
3.00000e+00
```

Example: Break with while statement enclosed by comment delimiters

```
local numTable = {5, 4, 3, 2, 1}
local k = table.getn(numTable)
--local breakValue = 3
while k > 0 do
    if numTable[k] == breakValue then
        print("Going to break and k = ", k)
        break
    end
    k = k - 1
end
if k == 0 then
    print("Break value not found")
end
```

This example defines a break value (breakValue), but the break value line is preceded by comment delimiters so that the break value is not assigned, and the code reaches the value 0 to exit the while loop.

Output:

```
Break value not found
```

Example: Break with infinite loop

```

a, b = 0, 1
while true do
  print(a,b)
  a, b = b, a + b
  if a > 500 then
    break
  end
end
end

```

This example uses a `break` statement that causes the while loop to exit if the value of `a` becomes greater than 500.

Output:

```

0.00000e+00  1.00000e+00
1.00000e+00  1.00000e+00
1.00000e+00  2.00000e+00
2.00000e+00  3.00000e+00
3.00000e+00  5.00000e+00
5.00000e+00  8.00000e+00
8.00000e+00  1.30000e+01
1.30000e+01  2.10000e+01
2.10000e+01  3.40000e+01
3.40000e+01  5.50000e+01
5.50000e+01  8.90000e+01
8.90000e+01  1.44000e+02
1.44000e+02  2.33000e+02
2.33000e+02  3.77000e+02
3.77000e+02  6.10000e+02

```

Tables and arrays

Lua makes extensive use of the data type table, which is a flexible array-like data type. Table indices start with 1. Tables can be indexed not only with numbers, but with any value (except `nil`). Tables can be heterogeneous, which means that they can contain values of all types (except `nil`).

Tables are the sole data structuring mechanism in Lua; they may be used to represent ordinary arrays, symbol tables, sets, records, graphs, trees, and so on. To represent records, Lua uses the field `name` as an index. The language supports this representation by providing `a.name` as an easier way to express `a["name"]`.

Example: Loop array

```

atable = {1, 2, 3, 4}
i = 1
while atable[i] do
  print(atable[i])
  i = i + 1
end

```

Defines a table with four numeric elements.

Loops through the array and prints each element.

The Boolean value of `atable[index]` evaluates to `true` if there is an element at that index. If there is no element at that index, `nil` is returned (`nil` is considered to be `false`).

Output:

```

1.00000e+00
2.00000e+00
3.00000e+00
4.00000e+00

```

Standard libraries

In addition to the standard programming constructs described in this document, Lua includes standard libraries that contain useful functions for string manipulation, mathematics, and related functions. Test Script Processor (TSP[®]) scripting engine instruments also include instrument control extension libraries, which provide programming interfaces to the instrumentation that can be accessed by the TSP scripting engine. These libraries are automatically loaded when the TSP scripting engine starts and do not need to be managed by the programmer.

The following topics provide information on some of the basic Lua standard libraries. For additional information, see the [Lua website](http://www.lua.org) (see Lua website - <http://www.lua.org>).

NOTE

When referring to the Lua website, please be aware that the TSP scripting engine uses Lua 5.0.2.

Base library functions

Base library functions

Function	Description
<code>collectgarbage()</code> <code>collectgarbage(<i>limit</i>)</code>	Sets the garbage-collection threshold to the given limit (in kilobytes) and checks it against the byte counter. If the new threshold is smaller than the byte counter, then Lua immediately runs the garbage collector. If there is no limit parameter, it defaults to zero (0) (which forces a garbage-collection cycle). See Lua memory management (on page 7-31) for more information.
<code>gcinfo()</code>	Returns the number of kilobytes of dynamic memory that the Test Script Processor (TSP [®]) scripting engine is using, and returns the current garbage collector threshold (also in kilobytes). See Lua memory management (on page 7-31) for more information.
<code>print(<i>e1, e2, ...</i>)</code>	Receives any number of arguments, and generates a response message, using the <code>tostring()</code> function to convert them to strings (note that numbers are converted to scientific notation using <code>format.asciiprecision</code>). The output is not formatted. For formatted output, you can use the <code>string.format()</code> command (see String library functions (on page 7-32)). Also see print() (on page 8-307).

Base library functions

Function	Description
<code>tonumber(x)</code> <code>tonumber(x, base)</code>	Returns <code>x</code> converted to a number. If <code>x</code> is already a number, or a convertible string, then the number is returned; otherwise, it returns <code>nil</code> . An optional argument specifies the base to interpret the numeral. The base may be any integer between 2 and 36, inclusive. In bases above 10, the letter <code>A</code> (in either upper or lower case) represents 10, <code>B</code> represents 11, and so forth, with <code>Z</code> representing 35. In base 10, the default, the number may have a decimal part, as well as an optional exponent. In other bases, only unsigned integers are accepted.
<code>tostring(x)</code>	Receives an argument of any type and converts it to a string in a reasonable format.
<code>type(v)</code>	The possible results of this function are "nil" (a string, not the value nil), "number", "string", "boolean", "table", "function", "thread", and "userdata".

Lua does automatic memory management, which means you do not have to allocate memory for new objects and free it when the objects are no longer needed. Lua manages memory automatically by occasionally running a garbage collector to collect all objects that are no longer accessible from Lua. All objects in Lua are subject to automatic management, including tables, variables, functions, threads, and strings.

Lua uses two numbers to control its garbage-collection cycles. One number counts how many bytes of dynamic memory Lua is using; the other is a threshold. When the number of bytes crosses the threshold, Lua runs the garbage collector, which reclaims the memory of all inaccessible objects. The byte counter is adjusted and the threshold is reset to twice the new value of the byte counter.

String library functions

This library provides generic functions for string manipulation, such as finding and extracting substrings. When indexing a string in Lua, the first character is at position 1 (not 0, as in ANSI C). Indices may be negative and are interpreted as indexing backward from the end of the string. Thus, the last character is at position -1, and so on.

String library functions

Function	Description
<code>string.byte(s)</code> <code>string.byte(s, i)</code> <code>string.byte(s, i, j)</code>	Returns the internal numeric codes of the characters <code>s[i]</code> , <code>s[i+1]</code> , ..., <code>s[j]</code> . The default value for <code>i</code> is 1; the default value for <code>j</code> is <code>i</code> . Note that numeric codes are not necessarily portable across platforms.
<code>string.char(...)</code>	Receives zero or more integers. Returns a string with length equal to the number of arguments, in which each character has the internal numeric code equal to its corresponding argument. Note that numeric codes are not necessarily portable across platforms.
<code>string.format(</code> <code>formatstring,</code> <code>...)</code>	Returns a formatted version of its variable number of arguments following the description given in its first argument, which must be a string. The format string follows the same rules as the <code>printf</code> family of standard C functions. The only differences are that the modifiers <code>*</code> , <code>l</code> , <code>L</code> , <code>n</code> , <code>p</code> , and <code>h</code> are not supported and there is an extra option, <code>q</code> . The <code>q</code> option formats a string in a form suitable to be safely read back by the Lua interpreter; the string is written between double quotes, and all double quotes, newlines, embedded zeros, and backslashes in the string are correctly escaped when written. For example, the call: <pre>string.format('%q', 'a string with "quotes" and \n new line')</pre> will produce the string: <pre>"a string with \"quotes\" and \ new line"</pre> The options <code>c</code> , <code>d</code> , <code>E</code> , <code>e</code> , <code>f</code> , <code>g</code> , <code>G</code> , <code>i</code> , <code>o</code> , <code>u</code> , <code>X</code> , and <code>x</code> all expect a number as argument. <code>q</code> and <code>s</code> expect a string. This function does not accept string values containing embedded zeros, except as arguments to the <code>q</code> option.
<code>string.len(s)</code>	Receives a string and returns its length. The empty string "" has length 0. Embedded zeros are counted, so <code>"a\000bc\000"</code> has length 5.
<code>string.lower(s)</code>	Receives a string and returns a copy of this string with all uppercase letters changed to lowercase. All other characters are left unchanged. The definition of what an uppercase letter is depends on the current locale.
<code>string.rep(s, n)</code>	Returns a string that is the concatenation of <code>n</code> copies of the string <code>s</code> .
<code>string.sub(s, i)</code> <code>string.sub(s, i, j)</code>	Returns the substring of <code>s</code> that starts at <code>i</code> and continues until <code>j</code> ; <code>i</code> and <code>j</code> can be negative. If <code>j</code> is absent, it is assumed to be equal to -1 (which is the same as the string length). In particular, the call <code>string.sub(s, 1, j)</code> returns a prefix of <code>s</code> with length <code>j</code> , and <code>string.sub(s, -i)</code> returns a suffix of <code>s</code> with length <code>i</code> .

String library functions

Function	Description
<code>string.upper(s)</code>	Receives a string and returns a copy of this string with all lowercase letters changed to uppercase. All other characters are left unchanged. The definition of what a lowercase letter is depends on the current locale.

Math library functions

This library is an interface to most of the functions of the ANSI C math library. All trigonometric functions work in radians. The functions `math.deg()` and `math.rad()` convert between radians and degrees.

Math library functions

Function	Description
<code>math.abs(x)</code>	Returns the absolute value of x .
<code>math.acos(x)</code>	Returns the arc cosine of x .
<code>math.asin(x)</code>	Returns the arc sine of x .
<code>math.atan(x)</code>	Returns the arc tangent of x .
<code>math.atan2(y, x)</code>	Returns the arc tangent of y/x , but uses the signs of both parameters to find the quadrant of the result. (It also handles correctly the case of x being zero.)
<code>math.ceil(x)</code>	Returns the smallest integer larger than or equal to x .
<code>math.cos(x)</code>	Returns the cosine of x .
<code>math.deg(x)</code>	Returns the angle x (given in radians) in degrees.
<code>math.exp(x)</code>	Returns the value e^x .
<code>math.floor(x)</code>	Returns the largest integer smaller than or equal to x .
<code>math.frexp(x)</code>	Returns m and e such that $x = m2^e$, where e is an integer and the absolute value of m is in the range $[0.5, 1]$ (or zero when x is zero).
<code>math.ldexp(x, n)</code>	Returns $m2^e$ (e should be an integer).
<code>math.log(x)</code>	Returns the natural logarithm of x .
<code>math.log10(x)</code>	Returns the base-10 logarithm of x .
<code>math.max(x, ...)</code>	Returns the maximum value among its arguments.
<code>math.min(x, ...)</code>	Returns the minimum value among its arguments.
<code>math.pi</code>	The value of π (3.141592654).
<code>math.pow(x, y)</code>	Returns x^y (you can also use the expression x^y to compute this value).
<code>math.rad(x)</code>	Returns the angle x (given in degrees) in radians.
<code>math.random()</code> <code>math.random(m)</code> <code>math.random(m, n)</code>	This function is an interface to the simple pseudorandom generator function <code>rand</code> provided by ANSI C. When called without arguments, returns a uniform pseudorandom real number in the range $[0, 1]$. When called with an integer number m , <code>math.random()</code> returns a uniform pseudorandom integer in the range $[1, m]$. When called with two integer numbers m and n , <code>math.random()</code> returns a uniform pseudorandom integer in the range $[m, n]$.
<code>math.randomseed(x)</code>	Sets x as the "seed" for the pseudorandom generator: equal seeds produce equal sequences of numbers.
<code>math.sin(x)</code>	Returns the trigonometric sine function of x .
<code>math.sqrt(x)</code>	Returns the square root of x . (You can also use the expression $x^{0.5}$ to compute this value.)
<code>math.tan(x)</code>	Returns the tangent of x .

Programming example

Script with a for loop

The following script puts a message on the front panel display slowly — one character at a time. The intent of this example is to demonstrate:

- The use of a `for` loop
- Simple display remote commands
- Simple Lua string manipulation

NOTE

When creating a script using the TSB Embedded, you do not need the shell commands `loadscript` and `endscript`, as shown in the examples below.

Example: User script

User script created in TSB Embedded	User script created in user's own program
<pre>display.clear() myMessage = "Hello World!" for k = 1, string.len(myMessage) do x = string.sub(myMessage, k, k) display.settext(x) print(x) delay(1) end</pre>	<pre>loadscript display.clear() myMessage = "Hello World!" for k = 1, string.len(myMessage) do x = string.sub(myMessage, k, k) display.settext(x) print(x) delay(1) end endscript</pre>

Using Test Script Builder (TSB)


Test Script Builder is a supplied software tool that can be used to perform the following operations:

- Send remote commands and Lua statements
- Receive responses (data) to commands and scripts
- Create and run user scripts

The following figure shows an example of the Test Script Builder. As shown, the workspace is divided into three panes:

- Project Navigator
- [Script Editor](#) (on page 7-37)
- [Programming interaction](#) (on page 7-37)

Figure 7-2: Using Test Script Builder (TSB)



Installing the TSB software

To install the TSB software:

1. Close all programs.
2. Place the Test Script Builder Software Suite CD (Keithley Instruments part number KTS-850B01 or greater) into your CD-ROM drive.
3. Follow the on-screen instructions.

If your web browser does not start automatically and display a screen with software installation links, open the installation file (`setup.exe`) found on the CD to initiate installation.

Project Navigator

The Project Navigator is located on the left side of the workspace. The navigator consists of project folders and the script files (.tsp) created for each project. Each project folder can have one or more script files.

Script Editor

The script is written and modified in the Script Editor. Notice that there is a tab available for each opened script file. A script project is then downloaded to the instrument, where it can be run.

Programming interaction

Up to seven tabs can be displayed in the lower pane of the workspace (the script editor) to provide programming interaction between the Test Script Builder and the instrument. The instrument console shown in [Using Test Script Builder \(TSB\)](#) (on page 7-35) is used to send commands to the connected instrument. Retrieved data (for example, readings) from commands and scripts appear in the instrument console.

Advanced scripting for TSP

Global variables and the `script.user.scripts` table

When working with script commands, it can be helpful to understand how scripts are handled in the instrument.

Scripts are loaded into the runtime environment from nonvolatile memory when you turn the instrument on. They are also added to the runtime environment when you load them into the instrument.

There are several types of scripts in the runtime environment:

- Named scripts
- Unnamed scripts
- The anonymous script

When a named script is loaded into the runtime environment:

- A global variable with the same name is created to reference the script more conveniently.
- An entry for the script is added to the `script.user.scripts` table.


When an unnamed script is loaded using the [`script.new\(\)`](#) (on page 8-357) function, a global variable is added. Nothing is added to the `script.user.scripts` table.

When the anonymous script is loaded, it does not have a global variable or an entry in the `script.user.scripts` table. If there is an existing anonymous script, it is replaced by the new one.

When the instrument is turned off, everything in the runtime environment is deleted, including the scripts and global variables.

See the figure below to see how the scripts, global variables, and `script.user.scripts` table interrelate.

Figure 7-3: Global variables and scripts in the runtime environment



Create a script using the `script.new()` command

Use the `script.new()` function to copy an existing script from the local node to a remote node. This enables parallel script execution.

You can create a script with the `script.new()` function using the command:

```
scriptVar = script.new(code, name)
```

Where:

`scriptVar` = Name of the variable created when the script is loaded into the runtime environment
`code` = Content of the script
`name` = Name that is added to the `script.user.scripts` table

For example, to set up a two-second beep, you could send the command:


```
beepTwoSec = script.new("beeper.enable = 1 beeper.beep(2, 2400)", "beepTwoSec")
```

To run the new script, send the command:

```
beepTwoSec()
```

When you add `beepTwoSec`, the global variable and `script.user.script` table entries are made to the runtime environment as shown in the following figure.

Figure 7-4: Runtime environment after creating a script



Create an unnamed script using `script.new()`

NOTE

Unnamed scripts are not available from the front panel display of the instrument. Only the anonymous script and named scripts are available from the front panel display.

When you create a script using `script.new()`, if you do not include `name`, the script is added to the runtime environment as an unnamed script. The `script.new()` function returns the script. You can assign it to a global variable, a local variable, or ignore the return value. A global variable is not automatically created.

For example, if you sent the command:


```
hello = script.new('display.clear() display.settext("hello")')
```

A script is created in the runtime environment and a global variable is created that references the script.

To run the script, send the command:

```
hello()
```

Figure 7-5: Create an unnamed script



Unnamed scripts are also created if you create a new script with the name attribute of a script that is already in the `script.user.scripts` table. In this case, the name of the script in the `script.user.scripts` table is set to an empty string before it is replaced by the new script.

For example, if `beepTwoSec` already exists in the `script.user.scripts` table and you sent:

```
beepTwoSec1200 = script.new("beeper.enable = 1 beeper.beep(2, 1200)", "beepTwoSec")
```

The following actions occur:

- `beepTwoSec1200` is added as a global variable.
- The global variable `beepTwoSec` remains in the runtime environment unchanged (it points to the now unnamed script).
- The script that was in the runtime environment as `beepTwoSec` is changed to an unnamed script (the name attribute is set to an empty string).
- A new script named `beepTwoSec` is added to the runtime environment.


In this example, you can access the new script by sending either of the following commands:

```
beepTwoSec1200 ()
script.user.scripts.beepTwoSec ()
```

To access the unnamed script, you can send the command:

```
beepTwoSec ()
```

Figure 7-6: Change a named script with an unnamed script



Restore a script to the runtime environment

You can retrieve a script that was removed from the runtime environment but is still saved in nonvolatile memory.

To restore a script from nonvolatile memory back into the runtime environment:

```
script.restore("scriptName")
```

Where: *scriptName* is the user-defined name of the script to be restored.

For example, to restore a user script named "test9" from nonvolatile memory:

```
script.restore("test9")
```

Rename a script

You can rename a script. You might want to rename a script if you need to name another script the same name as the existing script. You could also rename an existing script to be the autoexecute script.

To change the name of a script, use the command:

```
scriptVar.name = "renamedScript"
```

Where:

<i>scriptVar</i>	=	The global variable name
"renamedScript"	=	The new name of the user script that was referenced by the <i>scriptVar</i> global variable

After changing the name, you need to save the original script to save the change to the name attribute.

For example:

```
beepTwoSec.name = "beep2sec"
beepTwoSec.save()
```

beep2sec can be run using the command:


```
script.user.scripts.beep2sec()
```

NOTE

If the new name is the same as a name that is already used for a script, the name of the existing script is removed and that script becomes unnamed. This removes the existing script if there are no other variables that reference the previous script. If variables do reference the existing script, the references remain intact.

Changing the name of a script does not change the name of any variables that reference that script. After changing the name, the script can be found in the `script.user.scripts` table under its new name.

Figure 7-7: Rename script



For example, to change the name of the script named `test2` to be `autoexec`:

```
test2.name = "autoexec"
test2.save()
```

The `autoexec` script runs automatically when the instrument is turned on. It runs after all the scripts have loaded and any scripts marked as `autorun` have run.

NOTE

You can also use the `script.new()` and the `scriptVar.source` attribute commands to create a script with a new name. For example, if you had an existing script named `test1`, you could create a new script named `test2` by sending the command:

```
test2 = script.new(test1.source, "test2")
```

See [script.new\(\)](#) (on page 8-357).

Delete user scripts from the instrument

In most cases, you can delete the script using `script.delete()` as described in [Delete user scripts](#) (on page 7-10) and then turning the instrument off and then back on again. However, if you cannot turn the instrument off, you can use the following steps to completely remove a script from the instrument.

When you completely remove a script, you delete all references to the script from the runtime environment, the `script.user.scripts` table, and nonvolatile memory.

To completely remove a script:

1. **Remove the script from the runtime environment.** Set any global variables that refer to the script to `nil` or assign the variables a different value. For example, to remove the script "beepTwoSec" from the runtime environment, send the following code:

```
beepTwoSec = nil
```

2. **Remove the script from the `script.user.scripts` table.** Set the name attribute to an empty string (""). This makes the script nameless, but does not make the script become the anonymous script. For example, to remove the script named "beepTwoSec", send the following code:

```
script.user.scripts.beepTwoSec.name = ""
```

3. **Remove the script from nonvolatile memory.** To delete the script from nonvolatile memory, send the command:

```
script.delete("name")
```

where *name* is the name that the script was saved as. For example, to delete `beepTwoSec`, you would send:

```
script.delete("beepTwoSec")
```

You can also use TSB Embedded to delete a script from nonvolatile memory. In the TSB Embedded page, select the script from the User Scripts list and click **Delete**.

Memory considerations for the runtime environment

The runtime environment has a fixed amount of memory for storing user scripts, channel patterns, DMM configurations, and other run-time information.

You can check the amount of memory in the instrument using the `memory.used()` and `memory.available()` functions. These functions return the percentage of memory that is used or available. When you send this command, memory used or available is returned as a comma-delimited string with percentages for used memory.

The format is `systemMemory, scriptMemory, patternMemory, configurationMemory`, where:

- `systemMemory`: The percentage of memory used or available in the instrument
- `scriptMemory`: The percentage of memory used or available in the instrument to store user scripts
- `patternMemory`: The percentage of memory used or available in the instrument to store channel patterns
- `configurationMemory`: The percentage of memory available to store DMM configurations.

For example, if you send the command:

```
MemUsed = memory.used()
print(MemUsed)
```

You will get back a value such as 69.14, 0.16, 12.74, where 69.14 is the percentage of memory used in the instrument, 0.16 is the percentage used for script storage, and 12.74 is the percentage used for channel pattern storage, and 1.04 is the percentage used for DMM configurations.

See [memory.available\(\)](#) (on page 8-303) and [memory.used\(\)](#) (on page 8-304) for more detail on using these functions.15.35, where 69.14 is the percentage of memory used in the instrument, 0.16 is the percentage used for script storage, and 12.74 is the percentage used for channel pattern storage, and 15.35 is the percentage used for DMM configuration storage.

See [memory.available\(\)](#) (on page 8-303) and [memory.used\(\)](#) (on page 8-304) for more detail on using these functions.<AIT_DELETE_END>

If the amount of memory used is over 95 percent, or if you receive out-of-memory errors, you should reduce the amount of memory that is used.

Some suggestions for increasing the available memory:

- Turn the instrument off and on. This deletes scripts that have not been saved and reloads only scripts that have been stored in nonvolatile memory.
- Remove unneeded scripts from nonvolatile memory. Scripts are loaded from nonvolatile memory into the runtime environment when the instrument is turned on. See [Delete user scripts from the instrument](#) (on page 7-43).
- Reduce the number of TSP-Link[®] nodes.
- Delete unneeded channel patterns (this affects only pattern memory, not instrument memory). See [Channel patterns](#) (on page 2-96).
- Delete unneeded DMM configurations (this affects only configuration memory, not instrument memory). See [Save DMM configurations](#) (on page 4-7).
- Delete unneeded global variables from the runtime environment by setting them to `nil`.
- Set the source attribute of all scripts to `nil`.
- Adjust the `collectgarbage()` settings in Lua. See [Lua memory management](#) (on page 7-31) for more information.
- Review scripts to optimize their memory usage. In particular, you can see memory gains by changing string concatenation lines into a Lua table of string entries. You can then use the `table.concat()` function to create the final string concatenation.

The example below shows an example of optimizing a channel pattern that consists of five channels.

Example

String concatenation lines	Optimized with the <code>table.concat</code> function
<pre>ch1 = "" .. 5 * 1000 + 15 .. "," ch2 = "" .. 5 * 1000 + 25 .. "," ch3 = "" .. 5 * 1000 + 35 .. "," ch4 = "" .. 5 * 1000 + 915 .. "," ch5 = "" .. 5 * 1000 + 925 testPattern = ch1 .. ch2 .. ch3 .. ch4 .. ch5 print(testPattern)</pre>	<pre>testTable = { } testTable[1] = "5015," testTable[2] = "5025," testTable[3] = "5035," testTable[4] = "5915," testTable[5] = "5925" testPattern = table.concat(testTable) print(testPattern)</pre>
<p>The output is: 5015,5025,5035,5915,5925</p>	<p>The output is: 5015,5025,5035,5915,5925</p>



CAUTION

If the instrument encounters memory allocation errors when the memory used is above 95 percent, the state of the instrument cannot be guaranteed. After attempting to save any important data, it is recommended that you turn off power to the instrument and turn it back on to return the instrument to a known state. Cycling power resets the runtime environment. Unsaved scripts and channel patterns will be lost.

TSP-Link system expansion interface

Overview

The TSP-Link[®] expansion interface allows the Series 3700A instrument to communicate with other Test Script Processor (TSP[®]) enabled instruments. The test system can be expanded to include up to 32 TSP-Link enabled instruments.



CAUTION

Combining two Series 3700A instruments to achieve greater currents in both source voltage and source current applications requires specific precautions including configuration settings. Make sure you adequately understand the risks involved and the measures needed to accommodate the combination of two Series 3700A instruments. To prevent damage to the Series 3700A, connected instruments, as well as the device under test, make sure proper procedures are not used. For further information, visit the [Keithley Instruments website \(http://www.keithley.com\)](http://www.keithley.com) for application notes on combining two Series 3700A instruments' channels.

Combining two Series 3700A instruments to achieve greater currents in both source voltage and source current applications requires specific precautions including configuration settings. For further information, visit the [Keithley Instruments website \(http://www.keithley.com\)](http://www.keithley.com) for application notes on combining two Series 3700A instruments' channels.

Master and subordinates

In a TSP-Link[®] system, one of the nodes (instruments) is the master node and the other nodes are the subordinate nodes.

The master node can control the other nodes (subordinates) in the system. When any node transitions from local operation to remote, it becomes the master of the system; all other nodes also transition to remote operation, and become its subordinates. When any node transitions from remote operation to local, all other nodes also transition to local operation, and the master/subordinate relationship between nodes is dissolved. For more information about remote and local operations, see Factory scripts.

TSP-Link system

You can use the TSP-Link[®] expansion interface to expand your test system to include up to 64 addressable TSP-Link enabled instruments (32 instruments at a time). The expanded system can be stand-alone or computer-based.

Stand-alone system: You can run a script from the front panel of any instrument (node) connected to the system. When a script is run, all nodes in the system go into remote operation (REM indicators turn on). The node running the script becomes the master and can control all of the other nodes, which become its subordinates. When the script is finished running, all the nodes in the system return to local operation (REM indicators turn off), and the master/subordinate relationship between nodes is dissolved.

Computer-based system: You can use a computer and a LAN, GPIB, or RS-232 interface to any single node in the system. This node becomes the interface to the entire system. When a command is sent through this node, all nodes go into remote operation (REM indicators turn on). The node that receives the command becomes the master and can control all of the other nodes, which become its subordinates. In a computer-based system, the master/subordinate relationship between nodes can only be dissolved by performing an abort operation.

TSP-Link nodes

Each instrument or enclosure (node) attached to the TSP-Link bus must be identified. Identify each node by assigning a unique TSP-Link node number.

In test script programs, nodes look like tables. There is one global table named `node` that contains all the actual nodes that are themselves tables. An individual node is accessed as `node[N]` where `N` is the node number assigned to the node. Each node has certain attributes that can be accessed as elements of its associated table. These are listed as follows:

- `model`: The product model number string of the node.
- `revision`: The product revision string of the node.
- `serialno`: The product serial number string of the node.

There is also an entry for each logical instrument on the node (see [Logical instruments](#) (on page 8-3)).

It is not necessary to know the node number of the node running a script. The variable `localnode` is an alias for the node entry the script is running on. For example, if a script is running on node 5, the global variable `localnode` will be an alias for `node[5]`.

Connections

Connections for an expanded system are shown in the following figure. As shown, one unit is optionally connected to the computer using the GPIB, LAN, or RS-232 interface. Details about these computer communication connections are described in Communications interfaces.

As shown, all the units in the system are connected in a sequence (daisy-chained) using LAN crossover cables.

Initialization

Before a TSP-Link[®] system can be used, it must be initialized. For initialization to succeed, each instrument in a TSP-Link system must be assigned a different node number.

Assigning node numbers

At the factory, each Series 3700A instrument is assigned as node 1. The node number for each unit is stored in its nonvolatile memory and will not be lost when the instrument is turned off. You can assign a node number (1 to 64) to a Series 3700A using the front panel or through programming.

To assign a node number from the front panel of the instrument:

1. Press the **MENU** key, then select **TSPLINK > NODE**.
2. Press the navigation wheel  and select the desired number.
3. Press the **ENTER** key to select the node number.

To assign a node number through remote programming:

Set the `tsplink.node` attribute of the instrument:

```
tsplink.node = N
```

Where: $N = 1$ to 64

The node number of an instrument can be determined by reading the `tsplink.node` attribute as follows:

```
print(tsplink.node)
```

The above `print` command will output the node number. For example, if the node number is 1, the value `1.000000e+00` will be displayed.

Resetting the TSP-Link network

After all the node numbers are set, you must initialize the system by performing a TSP-Link[®] network reset. For initialization to succeed, all units must be turned on when the TSP-Link network reset is performed.

NOTE

If you change the system topology after initialization, you must reinitialize the system by performing a TSP-Link network reset. Changes that affect the system topology include powering down or rebooting any unit in the system, or rearranging or disconnecting the LAN cable connections between units.

Front panel operation

To reset the TSP-Link[®] network from the front panel:

1. Press the **MENU** key, select **TSPLINK**, and then press the **ENTER** key.
2. Turn the navigation wheel  to select **RESET**, and then press the **ENTER** key.

Remote programming

The commands associated with the TSP-Link[®] system reset are listed in the following table.

TSP-Link reset commands

Command	Description
<code>tsplink.reset()</code>	Initializes the TSP-Link network
<code>tsplink.state</code>	“online” if the most recent TSP-Link reset was successful; “offline” if the reset operation failed

An attempted TSP-Link reset operation will fail if any of the following conditions are true:

- Two or more instruments in the system have the same node number
- There are no other instruments connected to the unit performing the reset (only if the expected number of nodes was not provided in the reset call)
- One or more of the units in the system is not powered on
- If the actual number of nodes is less than the expected number

The programming example below illustrates a TSP-Link reset operation and displays its state:

```
tsplink.reset()
print(tsplink.state)
```

If the reset operation is successful, `online` will be output to indicate that communications with all nodes have been established.

Using the expanded system

Accessing nodes

A TSP-Link[®] `reset()` command populates the node table. Each unit in the system corresponds to an entry in this table. Each entry is indexed by the node number of the unit. The variable `node[N]` (where N is the node number) is used to access any node in the system. For example, node 1 is represented as entry `node[1]` in the node table.

Each of these entries is a table holding all of the logical instruments (and associated commands) shared by the corresponding unit.

The variable `localnode` is an alias for `node[N]`, where N is the node number of the node on which the code is running. For example, if node 1 is running the code, `localnode` can be used instead of `node[1]`.

The following programming examples illustrate how to access instruments in the TSP-Link system (shown in TSP-Link connections):

- Any of the following three commands can be used to reset all channels of node 1 (which, in this example, is the master). The other nodes in the system are not affected.

```
channel.reset("allslots")
localnode.channel.reset("allslots")
node[1].channel.reset("allslots")
```

- The following command will reset all channels of node 4, which is a subordinate. The other nodes are not affected.

```
node[4].channel.reset("allslots")
```

System behavior

Using the reset () command

While most TSP-Link® system operations target a single node in the system, the `reset ()` command affects the system as a whole by resetting all nodes to their default settings:

```
-- Resets all nodes in a TSP-Link system.
reset ()
```

`node[N]` and `localnode` can be used with `reset ()` to reset only one of the nodes. The other nodes are not affected. The following programming example illustrates this type of reset operation.

```
-- Resets node 1 only.
node[1].reset ()
-- Resets node 1 only.
localnode.reset ()
-- Resets node 4 only.
node[4].reset ()
```

Abort

An `abort` command will terminate an executing script and return all nodes to local operation (REM indicators turn off), dissolving the master/subordinate relationships between nodes. An abort operation is invoked by either issuing an `abort` command to the master node or pressing the EXIT (LOCAL) key on any node in the system.

An abort operation can also be performed by pressing the OUTPUT ON/OFF control on any node. The results are the same as above, with the addition that all outputs in the system are turned off.

Triggering with TSP-Link

The TSP-Link® expansion interface has three synchronization lines that function similarly to the digital I/O synchronization lines. See [Digital I/O](#) (on page 3-42) and Triggering for more information.

TSP advanced features

Use the Test Script Processor (TSP®) scripting engine's advanced features to run test scripts simultaneously, to manage resources allocated to test scripts running in simultaneously, and to use the data queue to facilitate real-time communication between nodes on the TSP-Link® network.

Running test scripts simultaneously improves functional testing, provides higher throughput, and expands system flexibility.

There are two methods you can use to run test scripts simultaneously:

- Create multiple TSP-Link networks
- Use a single TSP-Link network with groups

The following figure displays the first method, which consists of multiple TSP-Link networks. Each TSP-Link network has a master node and a GPIB connection to the computer.

The second method to run parallel test scripts is to use groups with a single TSP-Link network. A group consists of one or more nodes with the same group number. Each group on the TSP-Link network can run different test scripts at the same time (in parallel).

The following figure displays a single TSP-Link network with groups. This method requires one TSP-Link network and a single GPIB connection to the computer.

The following table describes the functions of a single TSP-Link network. Each group in this example runs multiple test scripts at the same time (parallel processing).

Using groups to manage nodes on TSP-Link network

The primary purpose of a group is to assign each node to run different test scripts at the same time (in parallel). Each node must belong to a group; a group can consist of one or more members. Group numbers are not assigned automatically; you must use remote commands to assign each node to a group.

Master node overview

The master node is always the node that coordinates activity on the TSP-Link[®] network. All nodes assigned to group 0 belong to the same group as the master node.

The following list describes the functionality of the master node:

- The only node that can send the `execute()` command on a remote node
- Cannot initiate remote operations on any node in a remote group if any node in that remote group is performing an overlapped operation
- Sends the `waitcomplete()` command to wait for the local group that the master node belongs to, to wait for a remote group, or to wait for all nodes on the TSP-Link network to complete overlapped operations

Group leader overview

Each group has a dynamic group leader. The last node in a group running any operation initiated by the master node is the group leader.

The following list describes the functionality of the group leader:

- Runs operations initiated by the master node
- Initiates remote operations on any node with the same group number
- Cannot initiate remote operations on any node with a different group number
- Can use the `waitcomplete()` command without a parameter to wait for all overlapped operations running on nodes in the same group

Assigning groups

Group numbers can range from zero (0) to 64. The default group number is 0. You can change the group number at any time.

Use the following code to dynamically assign nodes to a group.

Note the following:

- Each time the node powers off, the group number for that node changes to 0
- Replace *N* with the node number
- *N* represents the node number that runs the test scripts and the Lua code
- Each time the node powers off, the group number for that node changes to 0
- Replace *G* with the group number

```
-- Assigns the node to a group.
node[N].tsplink.group = G
```

Reassigning groups

Use the following code to change group assignment. You can add or remove a node to a group at anytime.

```
-- Assigns the node to a different group.
node[N].tsplink.group = G
```

Running parallel test scripts

You can send the `execute()` command from the master node to initiate test script and Lua code on a remote node. The `execute()` command places the remote node in the overlapped operation state. As a test script runs on the remote node, the master node continues to process other commands in parallel. Use the following code to send the `execute()` command on a remote node.

Note the following:

- The *N* parameter represents the node number that runs the test script (replace *N* with the node number).

To set the global variable on node *N* equal to 2.5:

```
node[N].execute("setpoint = 2.5")
```

The following code demonstrates how to run a test script defined on a remote node.

NOTE

For this example, `scriptVar` is defined on the local node.

To run `scriptVar` on node *N*:

```
node[N].execute(scriptVar.source)
```

The programming example below demonstrates how to run a test script defined on a remote node.

NOTE

For this example, `scriptVar` is defined on the remote node.

To run a script defined on the remote node:

```
node[N].execute("scriptVar()")
```

It is recommended that you copy large scripts to a remote node to improve system performance. See [Copying test scripts across the TSP-Link network](#) (on page 7-53) for more information.

Coordinating overlapped operations in remote groups

Errors occur if you send a command to a node in a remote group running an overlapped operation. All nodes in a group must be in the overlapped idle state before the master node can send a command to the group.

Use the `waitcomplete()` command to:

- **Group leader and master node:** To wait for all overlapped operations running in the local group to complete
- **Master node only:** To wait for all overlapped operations running on a remote group to complete on the TSP-Link[®] network
- **Master node only:** To wait for all groups to complete overlapped operations

For additional information, see [waitcomplete\(\)](#) (on page 8-461).

The following code is an example of how to send the `waitcomplete()` command from the master node:

```
-- Waits for each node in group N to complete all overlapped operations.
waitcomplete(N)
-- Waits for all groups on the TSP-Link network to complete overlapped operations.
waitcomplete(0)
```

The group leader can issue the `waitcomplete()` command to wait for the local group to complete all overlapped operations.

The following code is an example of how to send the `waitcomplete()` command:

```
-- Waits for all nodes in a local group to complete all overlapped operations.
waitcomplete()
```

Using the data queue for real-time communication

You cannot access the reading buffers or global variables from any node in a remote group while a node in that group is performing an overlapped operation. You can use the data queue to retrieve data from any node in a group performing an overlapped operation. In addition, the master node and the group leaders can use the data queue as a way to coordinate activities.

The data queue uses the first-in, first-out (FIFO) structure to store data. Nodes running test scripts in parallel can store data in the data queue for real-time communication. Each Series 3700A has an internal data queue. You can access the data queue from any node at any time.

You can use the data queue to post numeric values, strings, and tables. Tables in the data queue consume one entry. A new copy of the table is created when the table is retrieved from the data queue. The copy of the table does not contain any references to the original table or any subtables.

To add or retrieve values from the data queue and view the capacity, see the [Command reference](#) (see "[Commands](#)" on page 8-10).

Copying test scripts across the TSP-Link network

To run a large script on a remote node, it is recommended that you copy the test script to the remote node to increase the speed of test script initiation.

Use the code below to copy test scripts across the TSP-Link[®] network. This example creates a copy of a script on the remote node with the same name.

Note the following:

- Replace *N* with the number of the node that receives a copy of the script
- Replace *scriptName* with the name of the script that you want to copy from the local node

```
-- Adds the source code from scriptName to the data queue.
node[N].dataqueue.add(scriptName.source)
-- Creates a new script on the remote node
-- using the source code from scriptName.
node[N].execute(scriptName.name ..
    "= script.new(dataqueue.next(), [{" .. scriptName.name .. }])")
```

Removing stale values from the reading buffer

The node that acquires the data stores the data for the reading buffer. To optimize data access, all nodes can cache data from the node that stores the reading buffer data.

Running Lua code remotely can cause reading buffer data held in the cache to become stale. If the values in the reading buffer change while the Lua code runs remotely, another node can hold stale values. Use the `clearcache()` command to clear the cache.

The following code demonstrates how stale values occur and how to use the `clearcache()` command to clear the cache.

Note the following:

- Replace *N* with the node number
- Replace *G* with the group number

```
-- Creates a reading buffer on a node in a remote group.
node[N].tsplink.group = G
node[N].execute("rbremote = dmm.makebuffer(20)" ..
    "dmm.measure.count = 20 " ..
    "dmm.measure(rbremote)")
-- Creates a variable on the local node to
-- access the reading buffer.
rblocal = node[N].getglobal("rbremote")
-- Access data from the reading buffer.
print(rblocal[1])
-- Runs code on the remote node that updates the reading buffer.
node[N].execute("dmm.measure(rbremote)")
-- Use the clearcache command if the reading buffer contains cached data.
rblocal.clearcache()
-- If you do not use the clearcache command, the data buffer
-- values will never update. Every time the print command is
-- issued after the first print command, the same data buffer
-- values will print.
print(rblocal[1])
```

TSP-Net

Overview

The TSP-Net[®] library allows the Series 3700A to control LAN-enabled devices directly through its LAN port. This enables the Series 3700A to communicate directly with a non-TSP[®] enabled device without the use of a controlling computer.

TSP-Net capabilities

For both Test Script Processor (TSP[®]) and non-TSP devices, the TSP-Net library permits the Series 3700A to control a remote device through the LAN port. Using TSP-Net library methods, you can transfer string data to and from a remote device, transfer and format data into Lua variables, and clear input buffers. The TSP-Net library is only accessible using commands from a remote command interface and is not available from the front panel.

You can use TSP-Net commands to communicate with any Ethernet-enabled device. However, specific TSP-Net commands exist for TSP-enabled devices to allow for support of features unique to the TSP scripting engine. These features include script downloads, reading buffer access, wait completion, and handling of TSP scripting engine prompts.

Using TSP-Net commands with TSP-enabled instruments, a Series 3700A can download a script to another TSP-enabled device and have both devices run scripts independently. The Series 3700A can read the data from the remote device and either manipulate the data or send the data to a different remote device on the LAN. You can simultaneously connect to a maximum of 32 devices using standard TCP/IP networking techniques through the LAN port of the Series 3700A.

Using TSP-Net with any Ethernet-enabled device

NOTE

Refer to the [Command reference](#) (see "[Commands](#)" on page 8-10) for more details about the commands presented in this section.

To communicate to a remote Ethernet-enabled device from the Series 3700A, perform the following steps:

1. Connect to the remote device through the LAN port. If you are connecting:
 - Directly from the Series 3700A to an Ethernet-enabled device: Use an Ethernet crossover cable.
 - The Series 3700A to any other device on the LAN: Use a straight-through Ethernet cable and a hub.
2. Establish a new connection to a remote device at a specific IP address using `tspnet.connect()`.
3. If the device is not TSP-enabled, you must also provide the port number. If not, the Series 3700A assumes the remote device is TSP-enabled and enables TSP prompts and error handling. If the Series 3700A is not able to make a connection to the remote device, it generates a timeout error. Use `tspnet.timeout` to set the timeout value. The default timeout value is 20 seconds.

NOTE

Set `tspnet.tsp.abortonconnect` to 1 to abort any script currently running on a remote TSP device.

4. Use `tspnet.write()` or `tspnet.execute()` to send strings to a remote device. `tspnet.write()` sends strings to the device exactly as indicated, and you must supply any needed termination characters or other lines. Use `tspnet.termination()` to specify the termination character. If you use `tspnet.execute()` (on page 8-450) instead, the Series 3700A appends termination characters to all strings sent to the command.
5. Retrieve responses from the remote device using `tspnet.read()`. The Series 3700A suspends operation until data is available or a timeout error is generated. You can check if data is available from the remote device using `tspnet.readavailable()`.

Disconnect from the remote device using `tspnet.disconnect()`. Terminate all remote connections using `tspnet.reset()`.

Example script

The following example demonstrates how to connect to a remote device that is not Test Script Processor (TSP[®]) enabled, and send and receive data from this device:

```
-- Disconnect all existing TSP-Net connections.
tspnet.reset()
-- Set tspnet timeout to 5 seconds.
tspnet.timeout = 5
-- Establish connection to another device with
-- IP address 192.168.1.51 at port 1394.
id_instr = tspnet.connect("192.168.1.51",1394, "*rst\r\n")
-- Print the device ID from connect string.
print("ID is: ", id_instr)
-- Set termination character to CRLF. You must do this
-- on a per connection basis after connection has been made.
tspnet.termination(id_instr, tspnet.TERM_CRLF)
-- Send the command string to the connected device
tspnet.write(id_instr, "*idn?" .. "\r\n")
-- Read the data available, then prints it.
print("instrument write/read returns:: , tspnet.read(id_instr))
-- Disconnect all existing TSP-Net sessions.
tspnet.reset()
```

Using TSP-Net with any Ethernet-enabled device**NOTE**

Refer to [Remote Commands](#) (on page 6-1) for more details about the commands presented in this section.

To communicate to a remote Ethernet-enabled device from the Series 3700A:

1. Connect to the remote device through the LAN port:
 - The Series 3700A has Auto-MDIX, so you can use either a LAN crossover cable or a LAN straight-through cable to connect directly from the Series 3700A to an Ethernet-enabled device, or to a hub.
2. Establish a new connection to a remote device at a specific IP address using the `tspnet.connect()` function. For non-TSP[®] enabled devices, you must also provide the port number, or the Series 3700A assumes the remote device to be TSP-capable and enables TSP prompts and error handling.

If the Series 3700A is not able to make a connection to the remote device, it generates a timeout error. Use `tspnet.timeout` to set the timeout value. The default timeout value is 20 seconds.

NOTE

Set `tspnet.tsp.abortonconnect` to 1 to abort any script currently running on a remote TSP-enabled device.

3. Use `tspnet.write()` or `tspnet.execute()` to send strings to a remote device. Using `tspnet.write()` sends strings to the device exactly as indicated, and you must supply any needed termination characters or other lines. Use `tspnet.termination()` to specify the termination character. If you use `tspnet.execute()` instead, the Series 3700A appends termination characters to all strings sent to the command.
4. Retrieve responses from the remote device using `tspnet.read`. The Series 3700A suspends operation until data is available or a timeout error is generated. You can check if data is available from the remote device using `tspnet.readavailable()`.
5. Disconnect from the remote device using `tspnet.disconnect()`. Terminate all remote connections using `tspnet.reset()`.

Example script

The following example demonstrates how to connect to a remote non-TSP[®] enabled device, and send and receive data from this device:

```
-- Disconnect all existing TSP-Net connections.
tspnet.reset()
-- Set tspnet timeout to 5 seconds.
tspnet.timeout = 5
-- Establish connection to another device with IP address 192.168.1.51
-- at port 1394.
id_instr = tspnet.connect("192.168.1.51", 1394, "*rst\r\n")
-- Print the device ID from connect string.
print("ID is: ", id_instr)
-- Set termination character to CRLF. You must do this on a per
-- connection basis after connection has been made.
tspnet.termination(id_instr, tspnet.TERM_CRLF)
-- Send the command string to the connected device.
tspnet.write(id_instr, "*idn?" .. "\r\n")
-- Read the data available, then print it.
print("instrument write/read returns: ", tspnet.read(id_instr))
-- Disconnect all existing TSP-Net sessions.
tspnet.reset()
```

TSP-Net versus TSP-Link to communicate with TSP-enabled devices

The TSP-Link[®] network interface is the preferred communication method when communicating between the Series 3700A and another TSP-enabled instrument. The advantages of using the TSP-Link network interface over using TSP-Net[®] commands include:

- **Error checking:** When connected to a TSP-enabled device, all errors that occur on the remote device are transferred to the error queue of the Series 3700A. The Series 3700A indicates errors from the remote device by prefacing these errors with “Remote Error”.
For example, if the remote device generates error number 4909, the Series 3700A generates the error string “Remote Error: (4909) Reading buffer not found within device.”
- **TSP-Link triggering:** TSP-Link connections have three synchronization lines that are available to each device on the TSP-Link network. You can use any one of the synchronization lines to perform hardware triggering between devices on the TSP-Link network. Refer to [Hardware trigger modes](#) (on page 3-9) for more details.

These advantages make using TSP-Link connections to control another TSP-enabled device the best choice for most applications. However, if the distance between the Series 3700A and the TSP-enabled device is longer than 15 feet, use TSP-Net commands.

To establish a remote TSP-Net connection with a TSP-enabled device, use `tspnet.connect()` without specifying a port number. The Series 3700A enables TSP prompt and error handling for the remote device, which allows you to successfully use the commands listed in [Instrument commands: TSP-enabled device control](#) (on page 7-57) to load and run scripts and retrieve reading buffers.

Abort any operation on the remote TSP-enabled device using the `tspnet.tsp.abort()` command.

Instrument commands: General device control

The following instrument commands provide general device control:

[tspnet.clear\(\)](#) (on page 8-447)
[tspnet.connect\(\)](#) (on page 8-448)
[tspnet.disconnect\(\)](#) (on page 8-449)
[tspnet.execute\(\)](#) (on page 8-450)
[tspnet.idn\(\)](#) (on page 8-451)
[tspnet.read\(\)](#) (on page 8-451)
[tspnet.readavailable\(\)](#) (on page 8-452)
[tspnet.reset\(\)](#) (on page 8-453)
[tspnet.termination\(\)](#) (on page 8-453)
[tspnet.timeout](#) (on page 8-454)
[tspnet.write\(\)](#) (on page 8-457)

Instrument commands: TSP-enabled device control

The following instrument commands provide TSP-enabled device control:

[tspnet.tsp.abort\(\)](#) (on page 8-455)
[tspnet.tsp.abortonconnect](#) (on page 8-455)
[tspnet.tsp.rhtablecopy\(\)](#) (on page 8-456)
[tspnet.tsp.runscript\(\)](#) (on page 8-457)

Example: Using tspnet commands

```
function telnetConnect(ipAddress, userName, password)
-- Connect through telnet to a computer
id = tspnet.connect(ipAddress, 23, "")
-- Read the title and login prompt from the computer
print(string.format("from computer--> (%s)", tspnet.read(id, "%n")))
print(string.format("from computer--> (%s)", tspnet.read(id, "%s")))
-- Send the login name
tspnet.write(id, userName .. "\r\n")
-- Read the login echo and password prompt from the computer
print(string.format("from computer--> (%s)", tspnet.read(id, "%s")))
-- Send the password information
tspnet.write(id, password .. "\r\n")
-- Read the telnet banner from the computer
print(string.format("from computer--> (%s)", tspnet.read(id, "%n")))
end

function test_tspnet ()
tspnet.reset()
-- Connect to a computer via telnet
telnetConnect("192.0.2.1", "my_username", "my_password")
-- Read the prompt back from the computer
print(string.format("from computer--> (%s)", tspnet.read(id, "%n")))
-- Change directory and read the prompt back from the computer
tspnet.write(id, "cd c:\\\r\n")
print(string.format("from computer--> (%s)", tspnet.read(id, "%s")))
-- Make a directory and read the prompt back from the computer
tspnet.write(id, "mkdir TEST_TSP\r\n")
print(string.format("from computer--> (%s)", tspnet.read(id, "%s")))
-- Change to the newly created directory
tspnet.write(id, "cd c:\\TEST_TSP\r\n")
print(string.format("from computer--> (%s)", tspnet.read(id, "%s")))
-- if you have a data print it to the file
-- 11.2 is an example of data collected
cmd = "echo " .. string.format("%g", 11.2) .. " >> datafile.dat\r\n"
tspnet.write(id, cmd)
print(string.format("from computer--> (%s)", tspnet.read(id, "%s")))
tspnet.disconnect(id)
end
test_tspnet()
```

Command reference

In this section:

Command programming notes.....	8-1
Using the command reference	8-6
Commands.....	8-10

Command programming notes

Placeholder text

This manual uses italicized text to represent the parts of remote commands that must be replaced by user specified values. The following examples show typical uses of italicized text:

Example 1:

```
gpib.address = address
```

Where:

address is an integer (0 to 30) that you specify. For example, to set this attribute to 15 you would send:

```
gpib.address = 15
```

Example 2:

```
digio.trigger[N].assert()
```

Where:

N is an integer (1 to 14) that you specify. For example, to assert trigger line 7 you would send:

```
digio.trigger[7].assert()
```

To assert a trigger line with a variable as the integer, you would send:

```
triggerline = 7
```

```
digio.trigger[triggerline].assert()
```

Syntax rules

The following table lists syntax requirements to build well-formed instrument control commands.

Syntax rules for instrument commands

Syntax rule	Details	Examples
<p>Case sensitivity: Instrument commands are case sensitive.</p>	Function and attribute names should be in lowercase characters.	An example of the <code>scriptVar.save()</code> function (where <code>test8</code> is the name of the script): <code>test8.save()</code>
For best results, simply match the case shown in the command reference descriptions.	Parameters can use a combination of lowercase and uppercase characters. Attribute constants use uppercase characters	In the command below, which sets the format of data transmitted from the instrument to double-precision floating point, <code>format.REAL64</code> is the attribute constant and <code>format.data</code> is the attribute command: <code>format.data = format.REAL64</code>
White space: Not required in a function.	Functions can be sent with or without white spaces.	The following functions, which set digital I/O line 3 low, are equivalent: <code>digio.writebit(3,0)</code> <code>digio.writebit (3, 0)</code>
<p>Function parameters: All functions are required to have a set of parentheses () immediately following the function.</p>	You can specify the function parameters by placing them between the parentheses. Note that the parentheses are required even when there are no parameters specified.	<p>The following function specifies all overlapped commands in the nodes in group G must complete before commands from other groups can execute:</p> <pre>waitcomplete(G)</pre> <p>The command below reads the value of the local time zone (no parameters are needed):</p> <pre>timezone = gettimezone()</pre>
<p>Multiple parameters: Must be separated by commas (.).</p>	Some commands require multiple parameters, which must be separated by commas (.).	This command sets the beeper to emit a double-beep at 2400 Hz, with a beep sequence of 0.5 seconds on, 0.25 seconds off, and then 0.5 seconds on: <code>beeper.beep(0.5, 2400)</code> <code>delay(0.250)</code> <code>beeper.beep(0.5, 2400)</code>
<p>Parameter range: Range values must be separated with a colon (:).</p>	Place a colon (:) between two values to specify a range in a parameter.	The command below replaces the active scan list with an empty scan list, and then adds channels 1 through 10 on slot 1: <code>scan.create("1001:1010")</code>

Logical instruments

You would normally refer to all instrumentation in one enclosure or node as a single instrument. In the context of Test Script Processor (TSP[®]) scripting engine and instrument commands, it is useful to think of each individual subdivision in an enclosure, such as a card slot or the channels, as a stand-alone instrument. To avoid confusion, all subdivisions of the instrumentation in an enclosure are referred to as "logical instruments."

Each logical instrument is given a unique identifier in a system. These identifiers are used as part of all commands that control a given logical instrument.

The logical instruments are:

- beeper
- bit
- channel
- dataqueue
- digio
- display
- dmm
- errorqueue
- eventlog
- format
- fs
- gpib
- io
- lan
- memory
- ptp
- scan
- schedule
- setup
- slot
- status
- timer
- trigger
- tsplink
- tspnet
- upgrade
- userstring

NOTE

Do not create variable names that are the same as names of logical instruments. Doing so will result in the loss of use of the logical instrument and its associated commands. For example, if you send the command `digio = 5`, you cannot access the `digio.*` commands until you turn off the power to the instrument, and then turn it on again.

Using channel.*() commands

Unless otherwise noted, `channel.*()` remote commands use the channel list syntax described below.

- The channel list is specified according to the syntax presented in the channel list legend. Not all remote commands support the fully described syntax. Any exclusions are noted in the documentation for a specific command.
- There are five different types of channels available on the supported Series 3700A cards. These include switch (or relay), backplane, totalizer, DAC, and digital I/O. Even though the channels are specified in an identical manner, not all remote commands act on all channel types. The description of each remote command provides more information.
- When acting on a range of channels is necessary or more convenient, use the ":" notation. For example, to specify channels 1 through 20 on slot 4, use `4001:4020`.

```
print(channel.getlabel("4001:4020"))
```
- When acting on an entire slot is necessary or more convenient, use the `slotX` notation. For example, to specify all channels on slot 4, use `slot4`.

```
print(channel.getlabel("slot4"))
```
- When acting on an entire instrument is necessary or more convenient, use the `allslots` notation. For example, to specify channels on all slots (1 through 6), use `allslots`.

```
print(channel.getlabel("allslots"))
```
- When a range (including `slotX` and `allslots` notation) includes mixed channel types, the invalid channel types are ignored. If an invalid channel type is individually specified, then an error is generated.

The following errors can occur because of invalid channel list syntax or specification.

Error Message	Description
<code>invalid specified channel</code>	The channel is specified with the correct syntax, but does not exist on the card.
<code>invalid character in channel list</code>	The channel list contains an invalid character or syntax sequence.
<code>invalid slot in channel list</code>	The slot specified in the channel list is empty.
<code>invalid channel type in channel list</code>	The channel is specified with the correct syntax, but the channel type is not supported by the specified remote command.
<code>no valid channels in channel list</code>	After processing, no valid channels remain in the command to act upon.
<code>invalid label or pattern name</code>	A string was found in the channel list that does not specify any known label or pattern name.
<code>no patterns accepted</code>	A pattern was specified for a remote command that does not support patterns as input.
<code>no multiple channels accepted</code>	Multiple channels were specified for a remote command that acts only on a single channel.
<code>no range specifier accepted</code>	A range was specified for a remote command that does not support a range as input.
<code>no slot specifier accepted</code>	An entire slot was specified using <code>slotX</code> (for example, <code>slot1</code>) for a remote command that does not support <code>slotX</code> as input.
<code>no all slots specifier accepted</code>	All slots were specified using <code>allslots</code> for a remote command that does not support <code>allslots</code> as input.
<code>no labels accepted</code>	A label was specified for a remote command that does not support labels as input.
<code>no paired channels accepted</code>	A channel was specified for a remote command that does not act on paired channels.
<code>no single channels accepted</code>	A single channel was specified for a remote command that only supports acting on groups of channels.
<code>no multiple specifiers accepted</code>	Multiple descriptions were specified for a remote command that does not support multiple descriptions in a list.
<code>channels all must be of same type</code>	The provided channel list contains channels of various channel types, but the remote command supports only channel lists that contain a single, consistent channel type.
<code>forbidden channel</code>	The channel specified is forbidden to be closed.

Time and date values

Time and date values are represented as a number of UTC seconds since 12:00 a.m. Jan. 1, 1970. The `os.time()` command returns values in this format. Use `os.date()` to return values in month, day, year, hours, and minutes format, or to access the timestamp table. The only exception to this is the use of the `ptpseconds` recall attribute, which has the seconds in PTP format.

Time and date values are represented as the number of seconds since some base. Representing time as a number of seconds is referred to as “standard time format.” The three time bases used for the Series 3700A are:

- **UTC 12:00 am Jan 1, 1970.** Some examples of UTC time are reading buffer seconds, adjustment dates, and the value returned by `os.time()`.
- **Instrument on.** References time to when the instrument was turned on. The value returned by `os.clock()` is referenced to the turn-on time.
- **Event.** Time referenced to an event, such as the first reading stored in a reading buffer.

Using the command reference

The command reference contains detailed descriptions of each of the commands you can use to control your Series 3700A. Each command description is broken into several standardized subsections. The figure below shows an example of a command description.

Figure 8-1: Example instrument control library description

beeper.enable

This attribute allows you to turn the beeper on or off.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	System reset	Create configuration script	beeper.ON

Usage

```
state = beeper.enable
beeper.enable = state
```

<code>state</code>	<code>beeper.OFF</code> or <code>0</code> : Beeper disabled <code>beeper.ON</code> or <code>1</code> : Beeper enabled
--------------------	--

Details

Disabling the beeper also disables front panel key clicks.

Example

<code>beeper.enable = beeper.ON</code> <code>beeper.beep(2, 2400)</code>	Enables the beeper and generates a two-second, 2400 Hz tone
---	---

Also see

[beeper.beep\(\)](#) (on page 7-74)

Each command listing is divided into five major categories of information about the command:


- Command name and standard parameters table
- Usage
- Details
- Example
- Also see

The content of each of these categories is described in the following topics.

Command name and standard parameters summary

Each instrument command description starts with the command name, followed by a table with relevant information for each command. Definitions for the numbered items in the figure below are listed following the figure.

Figure 8-2: Command name and standard parameters summary




1. **Instrument command name.** Signals the beginning of the command description and is followed by a brief description of what the command does.
2. **Type of command.** Options are:
 - **Function.** Function-based commands control actions or activities, but are not always directly related to instrument operation. Function names are always followed by a set of parentheses, for example, `digio.writeport(15)`. If the function does not need a parameter, the parentheses set remains empty, for example, `exit()`.
 - **Attribute (R), (RW), or (W).** Attribute-based commands set or read the characteristics of an instrument feature or operation by defining a value. For example, a characteristic of a TSP-enabled instrument is the model number (`localnode.model`); another characteristic is the number of errors in the error queue (`errorqueue.count`). For many attributes, the defined value is a number or predefined constant. Attributes can be read-only (R), read-write (RW), or write-only (W), and can be used as a parameter of a function or assigned to another variable.
 - **Constant.** A constant command represents a fixed value when used in a script.
3. **TSP-Link accessible.** **Yes** or **No**; indicates whether or not the command can be accessed through a TSP-Link network.
4. **Affected by.** Commands or actions that have a direct effect on the instrument command.
 - **DMM configuration recall**
 - **DMM function change**
 - **DMM reset**
 - **LAN reset**
 - **Recall setup**

- **Reset:** Reset commands affect commands in different ways, depending on the type of reset. Types of reset include:
 - Channel reset
 - Digital I/O trigger reset
 - Instrument reset
 - Local node reset
 - Scan reset
 - Status reset
 - Trigger blender reset
 - Trigger timer reset
 - TSP-Link trigger reset
5. **Where saved.** Indicates where the command settings reside once they are used on an instrument. Options include:
- **Create configuration script:** This command is saved as part of the configuration script if you save the current configuration into a script with the `createconfigscript()` command or the MENU > SCRIPT > CREATE-CONFIG option from the front panel.
 - **Not saved:** Command is not saved anywhere and must be typed each time you use it.
 - **Nonvolatile memory:** Storage area in the instrument where information is saved when the instrument is turned off.
 - **Saved setup**
 - **Setup:** Instrument settings are captured in an internal or external setup file to be recalled later.
6. **Default value:** Lists the default value or constant for the command. The parameter values are defined in the Usage or Details sections of the command description.

Command usage

The Usage section of the remote command listing shows how to properly structure the command. Each line in the Usage section is a separate variation of the command usage; all possible command usage options are shown here.

Figure 8-3: Command usage section



1. **Structure of command usage:** Shows how the parts of the command should be organized.
2. **User-defined parameters:** Indicated by italics. For example, for the function `beeper.beep(duration, frequency)`, replace *duration* with the number of seconds and *frequency* with the frequency of the tone. For example, `beeper.beep(2, 2400)` generates a two-second, 2400 Hz tone.

NOTE


Some commands have optional parameters. Optional parameters are presented on separate lines in the Usage section, presented in the required order with each valid permutation of optional parameters. For example:

```
text = display.gettext()
text = display.gettext(embellished)
text = display.gettext(embellished, row)
text = display.gettext(embellished, row, columnStart)
text = display.gettext(embellished, row, columnStart, columnEnd)
```

3. **Parameter value options:** Descriptions of the options that are available for the user-defined parameter.

Command details

This section lists additional information you need to know to successfully use the remote commands.

Figure 8-4: Details section of command listing**Example section**

The Example section of the remote command description shows some simple examples of how the command can be used.

Figure 8-5: Code examples in command listings

1. Actual example code that you can copy from this table and paste into your own programming application.
2. Description of the code and what it does. This may also contain the output of the code.

Related commands and information

The Also see section of the remote command description lists commands that are related to the command being described.

Figure 8-6: Links to related commands and information

Commands

beeper.beep()

This function generates an audible tone.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
beeper.beep(duration, frequency)
```

<i>duration</i>	The amount of time to play the tone in seconds; the allowable range is 0.1 s to 100 s
<i>frequency</i>	The frequency of the tone in Hertz (Hz)

Details

The beeper will not sound if it is disabled. It can be disabled or enabled with the `beeper.enable` attribute, or through the front-panel Main Menu.

Example

```
beeper.enable = beeper.ON
beeper.beep(2, 2400)
```

Enables the beeper and generates a two-second, 2400 Hz tone.

Also see

[beeper.enable](#) (on page 8-10)

beeper.enable

This attribute allows you to turn the beeper on or off.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Recall setup	Saved setups Create configuration script	beeper.ON

Usage

```
state = beeper.enable
beeper.enable = state
```

<i>state</i>	Disable the beeper (<code>beeper.OFF</code> or 0) Enable the beeper (<code>beeper.ON</code> or 1)
--------------	--

Details

Disabling the beeper also disables front-panel key clicks.

Example

```
beeper.enable = beeper.ON
beeper.beep(2, 2400)
```

Enables the beeper and generates a two-second, 2400 Hz tone.

Also see

[beeper.beep\(\)](#) (on page 8-10)

bit.bitand()

This function performs a bitwise logical AND operation on two numbers.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
result = bit.bitand(value1, value2)
```

<i>result</i>	Result of the logical AND operation
<i>value1</i>	Operand for the logical AND operation
<i>value2</i>	Operand for the logical AND operation

Details

Any fractional parts of *value1* and *value2* are truncated to form integers. The returned *result* is also an integer.

Example

<pre>testResult = bit.bitand(10, 9) print(testResult)</pre>	<p>Performs a logical AND operation on decimal 10 (binary 1010) with decimal 9 (binary 1001), which returns a value of decimal 8 (binary 1000).</p> <p>Output: 8.00000e+00</p>
--	--

Also see

[bit.bitor\(\)](#) (on page 8-11)
[bit.bitxor\(\)](#) (on page 8-12)
[Logical operators](#) (on page 7-22)

bit.bitor()

This function performs a bitwise logical OR operation on two numbers.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
result = bit.bitor(value1, value2)
```

<i>result</i>	Result of the logical OR operation
<i>value1</i>	Operand for the logical OR operation
<i>value2</i>	Operand for the logical OR operation

Details

Any fractional parts of *value1* and *value2* are truncated to make them integers. The returned *result* is also an integer.

Example

```
testResult = bit.bitor(10, 9)

print(testResult)
```

Performs a bitwise logical OR operation on decimal 10 (binary 1010) with decimal 9 (binary 1001), which returns a value of decimal 11 (binary 1011).

Output: 1.10000e+01

Also see

[bit.bitand\(\)](#) (on page 8-11)
[bit.bitxor\(\)](#) (on page 8-12)
[Logical operators](#) (on page 7-22)

bit.bitxor()

This function performs a bitwise logical XOR (exclusive OR) operation on two numbers.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
result = bit.bitxor(value1, value2)
```

<i>result</i>	Result of the logical XOR operation
<i>value1</i>	Operand for the logical XOR operation
<i>value2</i>	Operand for the logical XOR operation

Details

Any fractional parts of *value1* and *value2* are truncated to make them integers. The returned *result* is also an integer.

Example

```
testResult = bit.bitxor(10, 9)

print(testResult)
```

Performs a logical XOR operation on decimal 10 (binary 1010) with decimal 9 (binary 1001), which returns a value of decimal 3 (binary 0011).

Output:
3.00000e+00

Also see

[bit.bitand\(\)](#) (on page 8-11)
[bit.bitor\(\)](#) (on page 8-11)
[Logical operators](#) (on page 7-22)

bit.clear()

This function clears a bit at a specified index position.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
result = bit.clear(value, index)
```

<i>result</i>	Result of the bit manipulation
<i>value</i>	Specified number
<i>index</i>	One-based bit position within value to clear (1 to 32)

Details

Any fractional part of *value* is truncated to make it an integer. The returned *result* is also an integer. The least significant bit of *value* is at *index* position 1; the most significant bit is at *index* position 32.

Example

```
testResult = bit.clear(15, 2)

print(testResult)
```

The binary equivalent of decimal 15 is 1111. If you clear the bit at *index* position 2, the returned decimal value is 13 (binary 1101).
Output:
1.30000e+01

Also see

[bit.get\(\)](#) (on page 8-13)
[bit.set\(\)](#) (on page 8-14)
[bit.test\(\)](#) (on page 8-16)
[bit.toggle\(\)](#) (on page 8-17)
[Logical operators](#) (on page 7-22)

bit.get()

This function retrieves the weighted value of a bit at a specified index position.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
result = bit.get(value, index)
```

<i>result</i>	Result of the bit manipulation
<i>value</i>	Specified number
<i>index</i>	One-based bit position within <i>value</i> to get (1 to 32)

Details

This function returns the value of the bit in *value* at *index*. This is the same as returning *value* with all other bits set to zero (0).

The least significant bit of *value* is at *index* position 1; the most significant bit is at *index* position 32.

If the indexed bit for the number is set to zero (0), the result will be zero (0).

Example

```
testResult = bit.get(10, 4)

print(testResult)
```

The binary equivalent of decimal 10 is 1010. If you get the bit at *index* position 4, the returned decimal value is 8.
Output:
8.00000e+00

Also see

[bit.clear\(\)](#) (on page 8-12)
[bit.set\(\)](#) (on page 8-14)
[bit.test\(\)](#) (on page 8-16)
[bit.toggle\(\)](#) (on page 8-17)
[Logical operators](#) (on page 7-22)

bit.getfield()

This function returns a field of bits from the value starting at the specified index position.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
result = bit.getfield(value, index, width)
```

<i>result</i>	Result of the bit manipulation
<i>value</i>	Specified number
<i>index</i>	One-based bit position within <i>value</i> to get (1 to 32)
<i>width</i>	The number of bits to include in the field (1 to 32)

Details

A field of bits is a contiguous group of bits. This function retrieves a field of bits from *value* starting at *index*. The *index* position is the least significant bit of the retrieved field. The number of bits to return is specified by *width*.

The least significant bit of *value* is at *index* position 1; the most significant bit is at *index* position 32.

Example

```
myResult = bit.getfield(13, 2, 3)
```

```
print(myResult)
```

The binary equivalent of decimal 13 is 1101.

The field at *index* position 2 and *width* 3 consists of the binary bits 110. The returned value is decimal 6 (binary 110).

Output:

```
6.00000e+00
```

Also see

[bit.get\(\)](#) (on page 8-13)
[bit.set\(\)](#) (on page 8-14)
[bit.setfield\(\)](#) (on page 8-15)
[Logical operators](#) (on page 7-22)

bit.set()

This function sets a bit at the specified index position.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
result = bit.set(value, index)
```

<i>result</i>	Result of the bit manipulation
<i>value</i>	Specified number
<i>index</i>	One-based bit position within <i>value</i> to set (1 to 32)

Details

This function returns *result*, which is *value* with the indexed bit set. The *index* must be between 1 and 32. The least significant bit of *value* is at *index* position 1; the most significant bit is at *index* position 32. Any fractional part of *value* is truncated to make it an integer.

Example

```
testResult = bit.set(8, 3)
print(testResult)
```

The binary equivalent of decimal 8 is 1000. If the bit at *index* position 3 is set to 1, the returned value is decimal 12 (binary 1100).

Output:
1.20000e+01

Also see

[bit.clear\(\)](#) (on page 8-12)
[bit.get\(\)](#) (on page 8-13)
[bit.getfield\(\)](#) (on page 8-14)
[bit.setfield\(\)](#) (on page 8-15)
[bit.test\(\)](#) (on page 8-16)
[bit.toggle\(\)](#) (on page 8-17)
[Logical operators](#) (on page 7-22)

bit.setfield()

This function overwrites a bit field at a specified index position.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
result = bit.setfield(value, index, width, fieldValue)
```

<i>result</i>	Result of the bit manipulation
<i>value</i>	Specified number
<i>index</i>	One-based bit position in <i>value</i> to set (1 to 32)
<i>width</i>	The number of bits to include in the field (1 to 32)
<i>fieldValue</i>	Value to write to the field

Details

This function returns *result*, which is *value* with a field of bits overwritten, starting at *index*. The *index* specifies the position of the least significant bit of *value*. The *width* bits starting at *index* are set to *fieldValue*.

The least significant bit of *value* is at *index* position 1; the most significant bit is at *index* position 32.

Before setting the field of bits, any fractional parts of *value* and *fieldValue* are truncated to form integers.

If *fieldValue* is wider than *width*, the most significant bits of the *fieldValue* that exceed the width are truncated. For example, if *width* is 4 bits and the binary value for *fieldValue* is 11110 (5 bits), the most significant bit of *fieldValue* is truncated and a binary value of 1110 is used.

Example

```
testResult = bit.setfield(15, 2, 3, 5)
print(testResult)
```

The binary equivalent of decimal 15 is 1111. After overwriting it with a decimal 5 (binary 101) at *index* position 2, the returned *value* is decimal 11 (binary 1011).

Output:
1.10000e+01

Also see

[bit.get\(\)](#) (on page 8-13)
[bit.set\(\)](#) (on page 8-14)
[bit.getfield\(\)](#) (on page 8-14)
[Logical operators](#) (on page 7-22)

bit.test()

This function returns the Boolean value (*true* or *false*) of a bit at the specified index position.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
result = bit.test(value, index)
```

<i>result</i>	Result of the bit manipulation
<i>value</i>	Specified number
<i>index</i>	One-based bit position within <i>value</i> to test (1 to 32)

Details

This function returns *result*, which is the result of the tested bit.

The least significant bit of *value* is at *index* position 1; the most significant bit is at *index* position 32.

If the indexed bit for *value* is 0, *result* is *false*. If the bit of *value* at *index* is 1, the returned value is *true*.

If *index* is bigger than the number of bits in *value*, the result is *false*.

Example

```
testResult = bit.test(10, 4)
print(testResult)
```

The binary equivalent of decimal 10 is 1010. Testing the bit at *index* position 4 returns a Boolean value of *true*.

Output:
true

Also see

[bit.clear\(\)](#) (on page 8-12)
[bit.get\(\)](#) (on page 8-13)
[bit.set\(\)](#) (on page 8-14)
[bit.toggle\(\)](#) (on page 8-17)
[Logical operators](#) (on page 7-22)

bit.toggle()

This function toggles the value of a bit at a specified index position.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
result = bit.toggle(value, index)
```

<i>result</i>	Result of the bit manipulation
<i>value</i>	Specified number
<i>index</i>	One-based bit position within <i>value</i> to toggle (1 to 32)

Details

This function returns *result*, which is the result of toggling the bit *index* in *value*. Any fractional part of *value* is truncated to make it an integer. The returned value is also an integer. The least significant bit of *value* is at *index* position 1; the most significant bit is at *index* position 32. The indexed bit for *value* is toggled from 0 to 1, or 1 to 0.

Example

```
testResult = bit.toggle(10, 3)

print(testResult)
```

The binary equivalent of decimal 10 is 1010. Toggling the bit at *index* position 3 returns a decimal value of 14 (binary 1110).
Output:
1.40000e+01

Also see

[bit.clear\(\)](#) (on page 8-12)
[bit.get\(\)](#) (on page 8-13)
[bit.set\(\)](#) (on page 8-14)
[bit.test\(\)](#) (on page 8-16)
[Logical operators](#) (on page 7-22)

bufferVar.appendmode

This attribute sets the state of the reading buffer's append mode.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Instrument reset Recall setup	Create configuration script Saved setup	See Details

Usage

```
state = bufferVar.appendmode
bufferVar.appendmode = state
```

<i>state</i>	The reading buffer append mode; set to one of the following: <ul style="list-style-type: none"> 0: Append mode off; new measure data overwrites the previous buffer content 1: Append mode on; appends new measure data to the present buffer content
<i>bufferVar</i>	The reading buffer

Details

Assigning a value to this attribute enables or disables the buffer append mode. This value can only be changed with an empty buffer. Use `bufferVar.clear()` to empty the buffer.

When a buffer is created over a remote interface, the append mode attribute default setting is off (0). However, when using the front panel or web interface, the default setting is on (1) to allow triggered readings to fill a buffer without clearing the previous readings.

If the append mode is set to 0, any stored readings in the buffer are cleared before new ones are stored. If append mode is set to 1, any stored readings remain in the buffer and new readings are added to the buffer after the stored readings.

With append mode on, the first new measurement is stored at `rb[n+1]`, where `n` is the number of readings stored in buffer `rb`.

Example

```
buffer1.appendmode = 1
```

Append new readings to contents of the reading buffer named `buffer1`.

Also see

[bufferVar.clear\(\)](#) (on page 8-23)

[Reading buffers](#) (on page 3-56, on page 3-50)

bufferVar.basetimefractional

When enabled by the `bufferVar.collecttimestamps` attribute, this attribute contains the fractional portion of the timestamp (in seconds) for the first reading stored in the reading buffer.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Buffer storage settings Clearing the buffer Instrument reset Recall setup	USB flash drive using <code>dmm.savebuffer</code> or <code>dmm.appendbuffer</code>	Not applicable

Usage

```
value = bufferVar.basetimefractional
```

<i>value</i>	The fractional seconds of the timestamp
<i>bufferVar</i>	The reading buffer

Details

The `bufferVar.basetimefractional` information from a reading buffer is only available if the `bufferVar.collecttimestamps` attribute is set to 1 (default setting). If it is set to 0, you will not be able to access any time information from a reading buffer. You may change the collect timestamps setting when the buffer is empty (`bufferVar.clear()`).

A read-only attribute for each existing reading buffer in the instrument.

The attribute represents the fractional seconds of the timestamp when reading 1 was stored in the buffer

Example

```
baseFractional = buffer1.basetimefractional
```

Read the `basetimefractional` attribute for `buffer1` and store it in a variable called `baseFractional`.

Also see

[bufferVar.clear\(\)](#) (on page 8-23)
[bufferVar.collecttimestamps](#) (on page 8-25)
[Reading buffers](#) (on page 3-50)

bufferVar.basetimeseconds

When enabled by the `bufferVar.collecttimestamps` attribute, this attribute represents the nonfractional seconds of the timestamp for the first reading stored in the reading buffer.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Buffer storage settings Clearing the buffer Instrument reset Recall setup	USB flash drive using <code>dmm.savebuffer</code> or <code>dmm.appendbuffer</code>	Not applicable

Usage

```
value = bufferVar.basetimeseconds
```

<code>value</code>	The nonfractional seconds of the timestamp
<code>bufferVar</code>	The reading buffer

Details

The basetime seconds information from a reading buffer is only available if the `bufferVar.collecttimestamps` attribute is set to 1 (default setting). If it is set to 0, you will not be able to access any time information from a reading buffer. You may change the collect timestamps setting when the buffer is empty (`bufferVar.clear()`).

This attribute is a read-only attribute for each existing reading buffer in the instrument.

This attribute represents the nonfractional seconds of the timestamp when reading 1 was stored in the buffer.

Example

```
basedSeconds = buffer1.basetimeseconds
```

Read the `basetimeseconds` attribute for `buffer1` and store in a variable called `baseSeconds`.

Also see

[bufferVar.clear\(\)](#) (on page 8-23)
[bufferVar.collecttimestamps](#) (on page 8-25)
[Reading buffers](#) (on page 3-50)

bufferVar.cachemode

This attribute enables or disables the reading buffer cache (on or off).

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Clearing the buffer cache Instrument reset Recall setup	Not saved	1 (enabled)

Usage

```
cacheMode = bufferVar.cachemode
bufferVar.cachemode = cacheMode
```

<i>cacheMode</i>	The reading buffer cache mode; set to one of the following: <ul style="list-style-type: none"> 0: Cache mode disabled (off) 1: Cache mode enabled (on)
<i>bufferVar</i>	The reading buffer

Details

Assigning a value to this attribute enables or disables the reading buffer cache. When enabled, the reading buffer cache improves access speed to reading buffer data.

If you run successive operations that overwrite reading buffer data, the reading buffer may return stale cache data. To avoid this, make sure that you include commands that automatically invalidate the cache as needed (for example, explicit calls to the `bufferVar.clearcache()` function) or disable the cache using this attribute (`bufferVar.cachemode`).

Example

```
buffer1.cachemode = 1
```

Enables reading buffer cache.

Also see

[bufferVar.clearcache\(\)](#) (on page 8-23)

bufferVar.capacity

This attribute contains the capacity of the buffer.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Instrument reset Recall setup	Create configuration script Save setup	Not applicable

Usage

```
maxNumber = bufferVar.capacity
```

<i>maxNumber</i>	The maximum number of readings the buffer can store
<i>bufferVar</i>	The reading buffer

Details

This read-only attribute reads the number of readings that can be stored in the buffer.

The buffer's capacity does not change as readings fill the buffer. A dedicated reading buffer that only collects basic items can store over 140,000 readings. Turning on additional collection items, such as timestamps and source values, decreases the capacity of a dedicated reading buffer (for example, `smua.nvbuffer1`), but does not change the capacity of a user-defined dynamically allocated buffer. A user-defined dynamically allocated buffer has a fixed capacity that is set when the buffer is created.

See the `smuX.nvbufferY` attribute for details on accessing dedicated reading buffers. See the `smuX.makebuffer()` function for information on creating user-defined dynamically allocated reading buffers. <AIT_DELETE_END>

Example

```
maxNumber = buffer1.capacity
print(capacity)
```

Reads the capacity of a reading buffer named `buffer1`.

Output:

```
1.00000e+05
```

The above output indicates that the buffer can hold 100000 readings.

Also see

[Reading buffers](#) (on page 3-56, on page 3-50)

bufferVar.channels

When enabled by the `bufferVar.collectchannels` attribute, this buffer recall attribute gets the channel, backplane relay, or channel pattern information stored with readings in the buffer.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Buffer storage settings Clearing the buffer Instrument reset Recall setup	USB flash drive using <code>dmm.savebuffer</code> or <code>dmm.appendbuffer</code>	Not applicable

Usage

```
channels = bufferVar.channels[N]
```

<code>bufferVar</code>	The reading buffer
<code>N</code>	The reading number (1 to <code>bufferVar.n</code>)

Details

The channels information from a reading buffer is only available if the `bufferVar.collectchannels` attribute is set to 1 (default setting). If it is set to 0, you will not be able to access the channels information from a reading buffer. You may change the collect channels setting when the buffer is empty (`bufferVar.clear()`).

This read-only attribute is an array (a Lua table) of strings indicating the channel or channel pattern associated with the measurement.

The returned value provides different information, based on what was opened or closed when the reading was acquired:

- If no channel or channel pattern is closed when the reading was acquired, `None` is displayed.
- If only a single channel or backplane relay was closed, the channel number is displayed (for example, `5003` or `5915`).
- If a channel or backplane relay plus another backplane relay or other channel is closed, then the channel number is displayed followed by a plus sign (+) (for example, `3005+` or `3915+`). The channel is in the image unless the last close operation involved only backplane relays.
- If multiple channels and backplane relays were closed in a channel list, the last channel specified is stored. Channels take precedence over backplane relays when stored. However, if only multiple backplane relays are specified, then the first one is stored.
- If a channel pattern was closed, then the first eight characters of the channel pattern name are returned (for example, `mypattern1` is shown as `mypatter`).

Example

```
reset()
testData = dmm.makebuffer(1000)
testData.collectchannels = 1
dmm.nplc = 0.5
dmm.range = 0
dmm.configure.set("Dcv_100mV")
dmm.setconfig("slot2", "Dcv_100mV")
scan.create("2035:2040")
scan.execute(testData)

print(testData.channels[1])

printbuffer(1, 6, testData.channels)
```

This example creates a reading buffer named `testData`, configures the buffer to collect channel data, sets and saves the DMM configuration, creates a scan list, and then runs the scan.

The `print()` command then outputs the first measurement channel.

Output:
2035+

The `printbuffer()` command then outputs the channels for measurements 1 to 6 in the reading buffer.

Output:
2035+, 2036+, 2037+, 2038+, 2039+,
2040+

Also see

- [bufferVar.clear\(\)](#) (on page 8-23)
- [bufferVar.collectchannels](#) (on page 8-24)
- [Reading buffers](#) (on page 3-50)

bufferVar.clear()

This function clears the buffer.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
bufferVar.clear()
```

<i>bufferVar</i>	The reading buffer
------------------	--------------------

Details

This function clears all readings and associated recall attributes (for example, time, status, channels, and units) from the specified buffer.

Example

```
testData = dmm.makebuffer(50)
testData.appendmode = 1
dmm.measurecount = 3
dmm.measure(testData)
```

```
printbuffer(1,testData.n, testData )
```

```
testData.clear()
print("Readings in buffer after clear ="
      .. testData.n)
```

```
dmm.measurecount = 3
dmm.measure(testData)
printbuffer(1,testData.n, testData )
```

Create a reading buffer named `testData` and enable append mode for it. Take three readings and store them in `testData`, and then view the readings.

Output:

```
3.515871341e-07, 5.596728126e-07,
3.944283032e-07
```

Next, clear the data and verify there are no readings in buffer.

Output:

```
Readings in buffer after clear = 0
```

Store three new readings in the buffer and view those when done.

Output:

```
4.923509754e-07, 3.332266330e-07,
3.974883867e-07
```

Also see

[Reading buffers](#) (on page 3-56, on page 3-50)

bufferVar.clearcache()

This function clears the cache.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
bufferVar.clearcache()
```

<i>bufferVar</i>	The reading buffer
------------------	--------------------

Details

This function clears all readings from the specified cache.

If you run successive operations that overwrite reading buffer data, the reading buffer may return stale cache data. This can happen when initiating successive scans without reconfiguring the scan measurements. Watch for this when running test script language (TSL) code remotely on more than one node, because values in the reading buffer cache may change while the TSL code is running. To avoid this, you can include explicit calls to the `bufferVar.clearcache()` function to remove stale values from the reading buffer cache.

Example

```
testData.clearcache()
```

Clears the reading buffer cache for a user-defined buffer named `testData`.

Also see

[bufferVar.cachemode](#) (on page 8-20)

[Reading buffers](#) (on page 3-56, on page 3-50)

bufferVar.collectchannels

This attribute sets the storage state of channel information with the readings in the buffer.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Instrument reset Recall setup	Create configuration script Save setup	1 (enabled)

Usage

```
state = bufferVar.collectchannels
bufferVar.collectchannels = state
```

<code>state</code>	The reading buffer collect channels mode; set to one of the following: <ul style="list-style-type: none"> 0: Collect channels mode disabled (off); channel information is not stored in the reading buffer 1: Collect channels mode enabled (on); channel information is stored in the reading buffer
<code>bufferVar</code>	The reading buffer

Details

Assigning a value to this attribute enables or disables the storage of channel information, which includes channel, backplane relay, or channel pattern information associated with the reading. Reading this attribute returns the state of channel information collection.

When on, channel information is stored with readings in the buffer. This requires eight extra bytes of storage per reading.

This value, off (0) or on (1), can only be changed when the buffer is empty. Empty the buffer using the `bufferVar.clear()` function.

Example

```

reset()
testData = dmm.makebuffer(1000)
testData.collectchannels = 1
dmm.nplc = 0.5
dmm.range = 0
dmm.configure.set("Dcv_100mV")
dmm.setconfig("slot2", "Dcv_100mV")
scan.create("2035:2040")
scan.execute(testData)

print(testData.channels[1])

printbuffer(1, 6, testData.channels)

```

This example creates a reading buffer named `testData`, configures the buffer to collect channel data, sets and saves the DMM configuration, creates a scan list, and then runs the scan.

The `print()` command then outputs the first measurement channel.

Output:
2035+

The `printbuffer()` command then outputs the channels for measurements 1 to 6 in the reading buffer.

Output:
2035+, 2036+, 2037+, 2038+, 2039+,
2040+

Also see

[bufferVar.clear\(\)](#) (on page 8-23)
[bufferVar.channels](#) (on page 8-21)
[Reading buffers](#) (on page 3-50)

bufferVar.collecttimestamps

This attribute sets whether or not timestamp values will be stored with the readings in the buffer.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Instrument reset Recall setup	Create configuration script Save setup	1 (enabled)

Usage

```

state = bufferVar.collecttimestamps
bufferVar.collecttimestamps = state

```

<code>state</code>	Timestamp value collection status; set to one of the following: <ul style="list-style-type: none"> 0: Timestamp value collection disabled (off) 1: Timestamp value collection enabled (on)
<code>bufferVar</code>	The reading buffer

Details

Assigning a value to this attribute enables or disables the storage of timestamps. Reading this attribute returns the state of timestamp collection.

When on, timestamp values will be stored with readings in the buffer. This requires four extra bytes of storage per reading.

This value, off (0) or on (1), can only be changed when the buffer is empty. Empty the buffer using the `bufferVar.clear()` function.

Example

```

reset()
testData = dmm.makebuffer(1000)
testData.collecttimestamps = 1
dmm.nplc = 0.5
dmm.range = 0
dmm.configure.set("Dcv_100mV")
dmm.setconfig("slot2", "Dcv_100mV")
scan.create("2035:2040")
scan.execute(testData)

print(testData.timestamps[1])

printbuffer(1, 6, testData.timestamps)

```

This example creates a reading buffer named `testData`, configures the buffer to collect timestamp data, sets and saves the DMM configuration, creates a scan list, and then runs the scan.

The `print()` command then outputs the first measurement timestamp.

Output:

```
07/11/2011 09:14:48.509762161
```

The `printbuffer()` command then outputs the timestamps for measurements 1 to 6 in the reading buffer.

Output:

```

07/11/2011 09:14:48.509762161,
07/11/2011 09:14:48.528708001,
07/11/2011 09:14:48.547659196,
07/11/2011 09:14:48.566612446,
07/11/2011 09:14:48.585565606,
07/11/2011 09:14:48.681325966

```

Also see

- [bufferVar.clear\(\)](#) (on page 8-23)
- [bufferVar.timestamps](#) (on page 8-38)
- [Reading buffers](#) (on page 3-56, on page 3-50)

bufferVar.dates

When enabled by the `bufferVar.collecttimestamps` attribute, this attribute contains the dates (month, day, and year) of readings stored in the reading buffer.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Buffer storage settings Clearing the buffer Instrument reset Recall setup	USB flash drive using <code>dmm.savebuffer</code> or <code>dmm.appendbuffer</code>	Not applicable

Usage

```
dates = bufferVar.dates[N]
```

<code>bufferVar</code>	The reading buffer
<code>N</code>	The reading number (1 to <code>bufferVar.n</code>)

Details

The `bufferVar.dates` information from a reading buffer is only available if the `bufferVar.collecttimestamps` attribute is set to 1 (default setting). If it is set to 0, you will not be able to access any time information from a reading buffer. You may change the collect timestamps setting when the buffer is empty (`bufferVar.clear()`).

This read-only attribute is an array (a Lua table) of strings indicating the date of the reading, formatted in month, day, and year format.

Example

```
reset()
testData = dmm.makebuffer(1000)
testData.collecttimestamps = 1
dmm.nplc = 0.5
dmm.range = 0
dmm.configure.set("Dcv_100mV")
dmm.setconfig("slot2", "Dcv_100mV")
scan.create("2035:2040")
scan.execute(testData)

print(testData.dates[1])

printbuffer(1, 6, testData.dates)
```

This example creates a reading buffer named `testData`, configures the buffer to collect time and date data, sets and saves the DMM configuration, creates a scan list, and then runs the scan.

The `print()` command then outputs the first measurement date.

Output:

```
07/11/2011
```

The `printbuffer()` command then outputs the dates for measurements 1 to 6 in the reading buffer.

Output:

```
07/11/2011, 07/11/2011,
07/11/2011, 07/11/2011,
07/11/2011, 07/11/2011
```

Also see

[bufferVar.clear\(\)](#) (on page 8-23)

[bufferVar.collecttimestamps](#) (on page 8-25)

[Reading buffers](#) (on page 3-50)

bufferVar.formattedreadings

This attribute contains the stored readings formatted as they appear on the front-panel display.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Clearing the buffer Instrument reset Recall setup	USB flash drive using dmm.savebuffer or dmm.appendbuffer	Not applicable

Usage

```
readings = bufferVar.formattedreadings[N]
```

<i>bufferVar</i>	The reading buffer
<i>N</i>	The reading number (1 to <i>bufferVar.n</i>)

Details

This read-only attribute is an array (a Lua table) of strings indicating the formatted reading as viewed on the front-panel display.

Use this attribute to access the reading elements *N* as they appear on the front panel.

Example

```
reset()
testData = dmm.makebuffer(1000)
dmm.nplc = 0.5
dmm.range = 0
dmm.configure.set("Dcv_100mV")
dmm.setconfig("slot2", "Dcv_100mV")
scan.create("2035:2040")
scan.execute(testData)

print(testData.formattedreadings[1])

printbuffer(1, 6, testData.formattedreadings)
```

This example creates a reading buffer named `testData`, sets and saves the DMM configuration, creates a scan list, and then runs the scan.

The `print()` command then outputs the first reading formatted as it appears on the front-panel display.

Output:
+000.0006e-3

The `printbuffer()` command then outputs readings 1 to 6 in the reading buffer as they appear on the front-panel display.

Output:
6.000000000e-07, 7.000000000e-07,
5.000000000e-07, 7.000000000e-07,
7.000000000e-07, 6.000000000e-07

Also see

[bufferVar.readings](#) (on page 8-31)

[Reading buffers](#) (on page 3-50)

bufferVar.fractionalseconds

When enabled by the `bufferVar.collecttimestamps` attribute, this attribute contains the fractional portion of the timestamp (in seconds) of when each reading occurred.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Buffer storage settings Clearing the buffer Instrument reset Recall setup	USB flash drive using <code>dmm.savebuffer</code> or <code>dmm.appendbuffer</code>	Not applicable

Usage

```
fractionalseconds = bufferVar.fractionalseconds[N]
```

<code>bufferVar</code>	The reading buffer
<code>N</code>	The reading number (1 to <code>bufferVar.n</code>)

Details

The `bufferVar.fractionalseconds` information from a reading buffer is only available if the `bufferVar.collecttimestamps` attribute is set to 1 (default setting). If it is set to 0, you will not be able to access any time information from a reading buffer. You may change the collect timestamps setting when the buffer is empty (`bufferVar.clear()`).

This read-only attribute is an array (a Lua table) of the fractional portion of the timestamps, in seconds, of when each reading occurred. These are absolute fractional times.

Example

```
reset()
testData = dmm.makebuffer(1000)
testData.collecttimestamps = 1
dmm.nplc = 0.5
dmm.range = 0
dmm.configure.set("Dcv_100mV")
dmm.setconfig("slot2", "Dcv_100mV")
scan.create("2035:2040")
scan.execute(testData)

print(testData.fractionalseconds[1])

printbuffer(1, 6, testData.fractionalseconds)
```

This example creates a reading buffer named `testData`, configures the buffer to collect time and date data, sets and saves the DMM configuration, creates a scan list, and then runs the scan.

The `print()` command then outputs the fractional portion of the timestamp for the first measurement in the buffer.

Output:
5.097621610e-01

The `printbuffer()` command then outputs the fractional portion of the timestamp for the first six measurements in the buffer.

Output:
5.097621610e-01, 5.287080010e-01,
5.476591960e-01, 5.666124460e-01,
5.855656060e-01, 6.813259660e-01

Also see

[bufferVar.clear\(\)](#) (on page 8-23)
[bufferVar.collecttimestamps](#) (on page 8-25)
[Reading buffers](#) (on page 3-50)

bufferVar.n

This attribute contains the number of readings in the buffer.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Clearing the buffer Reset Recall setup	Not saved	Not applicable

Usage

```
numberOfReadings = bufferVar.n
```

<i>numberOfReadings</i>	The number of readings stored in the buffer
<i>bufferVar</i>	The reading buffer

Details

This read-only attribute contains the number of readings presently stored in the buffer.

Example

<pre>numberOfReadings = buffer1.n print(numberOfReadings)</pre>	<p>Reads the number of readings stored in a reading buffer named <code>buffer1</code>.</p> <p>Output: 1.250000+02</p> <p>The above output indicates that there are 125 readings stored in the buffer.</p>
---	---

Also see

[bufferVar.formattedreadings](#) (on page 8-28)
[bufferVar.fractionalseconds](#) (on page 8-29)
[bufferVar.readings](#) (on page 8-31)
[bufferVar.relativetimestamps](#) (on page 8-33)
[bufferVar.seconds](#) (on page 8-34)
[bufferVar.statuses](#) (on page 8-35)
[bufferVar.times](#) (on page 8-36)
[bufferVar.units](#) (on page 8-39)
[Reading buffers](#) (on page 3-56, on page 3-50)

bufferVar.ptpseconds

When enabled by the `bufferVar.collecttimestamps` attribute, this attribute contains the absolute seconds portion of the timestamp of when the reading was stored, in ptp format.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Buffer storage settings Clearing the buffer Instrument reset Recall setup	USB flash drive using <code>dmm.savebuffer</code> or <code>dmm.appendbuffer</code>	Not applicable

Usage

```
value = bufferVar.ptpseconds [N]
```

<i>bufferVar</i>	The reading buffer
<i>N</i>	The reading number (1 to <i>bufferVar.n</i>)

Details

The `ptp` seconds information from a reading buffer is only available if the `bufferVar.collecttimestamps` attribute is set to 1 (default setting). If it is set to 0, you will not be able to access any time information from a reading buffer. You may change the collect timestamps setting when the buffer is empty (`bufferVar.clear()`).

These seconds are absolute and in PTP format.

Example

```
reset()
testData = dmm.makebuffer(1000)
testData.collecttimestamps = 1
dmm.nplc = 0.5
dmm.range = 0
dmm.configure.set("Dcv_100mV")
dmm.setconfig("slot2", "Dcv_100mV")
scan.create("2035:2040")
scan.execute(testData)

print(testData.ptpseconds[1])

printbuffer(1, 6, testData.ptpseconds)
```

This example creates a reading buffer named `testData`, configures the buffer to collect time and date data, sets and saves the DMM configuration, creates a scan list, and then runs the scan.

The `print()` command then outputs the absolute seconds portion of the timestamp of first measurement in the buffer, in ptp format. Output:

```
1.310375688e+09
```

The `printbuffer()` command then outputs the absolute seconds portion of the timestamp for measurements 1 to 6 in the reading buffer, in ptp format.

Output:

```
1.310375688e+09, 1.310375688e+09,
1.310375688e+09, 1.310375688e+09,
1.310375688e+09, 1.310375688e+09
```

Also see

[bufferVar.clear\(\)](#) (on page 8-23)
[bufferVar.collecttimestamps](#) (on page 8-25)
[Reading buffers](#) (on page 3-50)

bufferVar.readings

This attribute contains the readings stored in a specified reading buffer.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Clearing the buffer Instrument reset Recall setup	USB flash drive using <code>dmm.savebuffer</code> or <code>dmm.appendbuffer</code>	Not applicable

Usage

```
reading = bufferVar.readings[N]
```

<code>reading</code>	The value of the reading in the specified reading buffer
<code>bufferVar</code>	The reading buffer
<code>N</code>	The reading number (1 to <code>bufferVar.n</code>)

Details

The `readings` buffer recall attribute is like an array (a Lua table) of the readings stored in the reading buffer. This array holds the same data that is returned when the reading buffer is accessed directly; that is, `rb[2]` and `rb.readings[2]` access the same value.

Example

```
reset()
testData = dmm.makebuffer(1000)
testData.collectchannels = 1
dmm.nplc = 0.5
dmm.range = 0
dmm.configure.set("Dcv_100mV")
dmm.setconfig("slot2", "Dcv_100mV")
scan.create("2035:2040")
scan.execute(testData)

print(testData.readings[1])

printbuffer(1, 6, testData.readings)
```

This example creates a reading buffer named `testData`, configures the buffer to collect channel data, sets and saves the DMM configuration, creates a scan list, and then runs the scan.

The `print()` command then outputs the first reading in the reading buffer.

Output:

```
6.239269805e-07
```

The `printbuffer()` command then outputs the readings for measurements 1 to 6 in the reading buffer.

Output:

```
6.239269805e-07, 6.943093615e-07,
4.954026325e-07, 7.432710179e-07,
6.943093615e-07, 6.331072911e-07
```

NOTE:

An alternative way to use the `printbuffer()` command for this example is `printbuffer(1, 6, testData)`, because "readings" is an optional parameter and is assumed if it has not been specified.

Also see

[bufferVar.formattedreadings](#) (on page 8-28)
[bufferVar.fractionalseconds](#) (on page 8-29)
[bufferVar.relativetimestamps](#) (on page 8-33)
[bufferVar.seconds](#) (on page 8-34)
[bufferVar.statuses](#) (on page 8-35)
[bufferVar.times](#) (on page 8-36)
[bufferVar.units](#) (on page 8-39)
[Reading buffers](#) (on page 3-56, on page 3-50)

bufferVar.relativetimestamps

When enabled by the `bufferVar.collecttimestamps` attribute, this attribute contains the timestamps, in seconds, of when each reading occurred relative to the timestamp of reading buffer entry number 1.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Buffer storage settings Clearing the buffer Reset Recall setup	USB flash drive using <code>dmm.savebuffer</code> or <code>dmm.appendbuffer</code>	1

Usage

```
relativetimestamp = bufferVar.relativetimestamp[N]
```

<code>bufferVar</code>	The reading buffer
<code>N</code>	The reading number (1 to <code>bufferVar.n</code>)

Details

The relative timestamps information from a reading buffer is only available if the `bufferVar.collecttimestamps` attribute is set to 1 (default setting). If it is set to 0, you will not be able to access any time information from a reading buffer. You may change the collect timestamps setting when the buffer is empty (`bufferVar.clear()`).

This read-only attribute is an array (a Lua table) of timestamps, in seconds, of when each reading occurred relative to the timestamp of reading buffer entry number 1. These timestamps are equal to the time that has lapsed for each reading since the first reading was stored in the buffer. Therefore, the relative timestamp for entry number 1 in the buffer will equal 0.

Example

```
reset()
testData = dmm.makebuffer(1000)
testData.collecttimestamps = 1
dmm.nplc = 0.5
dmm.range = 0
dmm.configure.set("Dcv_100mV")
dmm.setconfig("slot2", "Dcv_100mV")
scan.create("2035:2040")
scan.execute(testData)

print(testData.relativetimestamps[1])

printbuffer(1, 6, testData.relativetimestamps)
```

This example creates a reading buffer named `testData`, configures the buffer to collect time and date data, sets and saves the DMM configuration, creates a scan list, and then runs the scan.

The `print()` command then outputs the relative timestamp of the first measurement in the reading buffer.

Output:
0.000000000e+00

The `printbuffer()` command then outputs the relative timestamp for measurements 1 to 6 in the reading buffer.

Output:
0.000000000e+00, 1.894584000e-02,
3.789703500e-02, 5.685028500e-02,
7.580344500e-02, 1.715638050e-01

Also see

[bufferVar.clear\(\)](#) (on page 8-23)
[bufferVar.collecttimestamps](#) (on page 8-25)
[Reading buffers](#) (on page 3-50)

bufferVar.seconds

When enabled by the `bufferVar.timestamps` attribute, this attribute contains the nonfractional seconds portion of the timestamp when the reading was stored, in UTC format.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Buffer storage settings Clearing the buffer Instrument reset Recall setup	USB flash drive using <code>dmm.savebuffer</code> or <code>dmm.appendbuffer</code>	Not applicable

Usage

```
seconds = bufferVar.seconds[N]
```

<code>bufferVar</code>	The reading buffer
<code>N</code>	The reading number (1 to <code>bufferVar.n</code>)

Details

The `bufferVar.seconds` information from a reading buffer is only available if the `bufferVar.collecttimestamps` attribute is set to 1 (default setting). If it is set to 0, you will not be able to access any time information from a reading buffer. You may change the collect timestamps setting when the buffer is empty (`bufferVar.clear()`).

This read-only attribute is an array (a Lua table) of the seconds portion of the timestamp when the reading was stored, in seconds. These seconds are absolute and in UTC format.

Example

```

reset()
testData = dmm.makebuffer(1000)
testData.collecttimestamps = 1
dmm.nplc = 0.5
dmm.range = 0
dmm.configure.set("Dcv_100mV")
dmm.setconfig("slot2", "Dcv_100mV")
scan.create("2035:2040")
scan.execute(testData)

print(testData.seconds[1])

printbuffer(1, 6, testData.seconds)

```

This example creates a reading buffer named `testData`, configures the buffer to collect time and date data, sets and saves the DMM configuration, creates a scan list, and then runs the scan.

The `print()` command then outputs the seconds portion of the timestamp of the first reading in the reading buffer.

Output:

```
1.310375688e+09
```

The `printbuffer()` command then outputs the seconds portion of the timestamps for measurements 1 to 6 in the reading buffer.

Output:

```
1.310375688e+09, 1.310375688e+09,
1.310375688e+09, 1.310375688e+09,
1.310375688e+09, 1.310375688e+09
```

Also see

[bufferVar.clear\(\)](#) (on page 8-23)
[bufferVar.collecttimestamps](#) (on page 8-25)
[Reading buffers](#) (on page 3-56, on page 3-50)

bufferVar.statuses

This attribute contains the status values of readings in the reading buffer.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Clearing the buffer Instrument reset Recall setup	USB flash drive using <code>dmm.savebuffer</code> or <code>dmm.appendbuffer</code>	Not applicable

Usage

```
statusInformation = bufferVar.statuses[N]
```

<code>statusInformation</code>	A Lua table of status values
<code>bufferVar</code>	The reading buffer
<code>N</code>	The reading number (1 to <code>bufferVar.n</code>)

Details

This read-only buffer recall attribute is like an array (a Lua table) of the status values for all of the readings in the buffer. The status values are floating-point numbers that encode the status value into a floating-point value; see the following table for values.

Buffer status bits

Bit	Name	Hex value	Remote command
B0	Low limit 1	0x01	dmm.buffer.LIMIT1_LOW_BIT
B1	High limit 1	0x02	dmm.buffer.LIMIT1_HIGH_BIT
B2	Low limit 2	0x04	dmm.buffer.LIMIT2_LOW_BIT
B3	High limit 2	0x08	dmm.buffer.LIMIT2_HIGH_BIT
B6	Measure overflow	0x40	dmm.buffer.MEAS_OVERFLOW_BIT
B7	Measure connect question	0x80	dmm.buffer.MEAS_CONNECT_QUESTION_BIT

Example

```

reset()
testData = dmm.makebuffer(1000)
testData.collectchannels = 1
dmm.nplc = 0.5
dmm.range = 0
dmm.configure.set("Dcv_100mV")
dmm.setconfig("slot2", "Dcv_100mV")
scan.create("2035:2040")
scan.execute(testData)

print(testData.statuses[1])

printbuffer(1, 6, testData.statuses)

```

This example creates a reading buffer named `testData`, configures the buffer to collect channel data, sets and saves the DMM configuration, creates a scan list, and then runs the scan.

The `print()` command then outputs the status value of the first measurement channel in the reading buffer.

Output:
0.000000000e+00

The `printbuffer()` command then outputs the status values for measurements 1 to 6 in the reading buffer.

Output:
0.000000000e+00, 0.000000000e+00,
0.000000000e+00, 0.000000000e+00,
0.000000000e+00, 0.000000000e+00

Also see

- [bufferVar.readings](#) (on page 8-31)
- [bufferVar.timestamps](#) (on page 8-38)
- [Reading buffers](#) (on page 3-56, on page 3-50)

bufferVar.times

When enabled by the `bufferVar.collecttimestamps` attribute, this attribute contains the time of the readings (in hours, minutes, and seconds format) in the reading buffer.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Buffer storage settings Clearing the buffer Instrument reset Recall setup	USB flash drive using <code>dmm.savebuffer</code> or <code>dmm.appendbuffer</code>	Not applicable

Usage

```
time = bufferVar.times[N]
```

<i>bufferVar</i>	The reading buffer
<i>N</i>	The reading number (1 to <i>bufferVar.n</i>)

Details

The times information from a reading buffer is only available if the *bufferVar.collecttimestamps* attribute is set to 1 (default setting). If it is set to 0, you will not be able to access any time information from a reading buffer. You may change the collect timestamps setting when the buffer is empty (*bufferVar.clear()*).

This read-only attribute is an array (a Lua table) of strings indicating the time of the reading formatted in hours, minutes, and seconds.

These seconds are absolute and in UTC format.

Example

```
reset()
testData = dmm.makebuffer(1000)
testData.collecttimestamps = 1
dmm.nplc = 0.5
dmm.range = 0
dmm.configure.set("Dcv_100mV")
dmm.setconfig("slot2", "Dcv_100mV")
scan.create("2035:2040")
scan.execute(testData)

print(testData.times[1])

printbuffer(1, 6, testData.times)
```

This example creates a reading buffer named *testData*, configures the buffer to collect time and date data, sets and saves the DMM configuration, creates a scan list, and then runs the scan.

The `print()` command then outputs the time of the first reading in the reading buffer.
Output:
09:14:48

The `printbuffer()` command then outputs the time of readings 1 to 6 in the reading buffer.
Output:
09:14:48, 09:14:48, 09:14:48,
09:14:48, 09:14:48, 09:14:48

Also see

[bufferVar.clear\(\)](#) (on page 8-23)
[bufferVar.collecttimestamps](#) (on page 8-25)
[Reading buffers](#) (on page 3-50)

bufferVar.timestampresolution

This attribute contains the timestamp's resolution.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Buffer storage settings Clearing the buffer Reset Recall setup	Not saved	Not applicable

Usage

```
resolution = bufferVar.timestampresolution
```

<i>resolution</i>	Timestamp resolution in seconds
<i>bufferVar</i>	The reading buffer

Details

Reading this attribute returns the timestamp resolution value.

The finest timestamp resolution is 0.000001 seconds (1 μ s). At this resolution, the reading buffer can store unique timestamps for up to 71 minutes. This value can be increased for very long tests.

The value specified when setting this attribute will be rounded to an even power of 2 μ s.

Example

```
buffer1.timestampresolution = 0.000008
```

Sets the timestamp resolution of reading buffer 1 to 8 μ s.

Also see

[bufferVar.clear\(\)](#) (on page 8-23)

[bufferVar.collecttimestamps](#) (on page 8-25)

[Reading buffers](#) (on page 3-56, on page 3-50)

bufferVar.timestamps

When enabled by the *bufferVar.collecttimestamps* attribute, this attribute contains the timestamp (in seconds) of when each reading saved in the specified reading buffer occurred.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Buffer storage settings Clearing the buffer Instrument reset Recall setup	USB flash drive using dmm.savebuffer or dmm.appendbuffer	Not applicable

Usage

```
timestamp = bufferVar.timestamps[N]
```

<i>timestamp</i>	A Lua table of timestamps
<i>bufferVar</i>	The reading buffer
<i>N</i>	The reading number (1 to <i>bufferVar.n</i>)

Details

The *bufferVar.timestamps* information from a reading buffer is only available if the *bufferVar.collecttimestamps* attribute is set to 1 (default setting). If it is set to 0, you will not be able to access any time information from a reading buffer.

If enabled, this buffer recall attribute is an array-like variable (a Lua table) containing timestamps, in seconds, of when each reading occurred. These are relative to the *bufferVar.basetimestamp* for the buffer. See Reading buffer commands for more information.

Example

```
printbuffer(1, 6, buffer1.timestamps)
```

Print the timestamp of the first 6 readings stored in buffer 1.

Example output:

```
07/11/2011 09:14:48.509762161,
07/11/2011 09:14:48.528708001,
07/11/2011 09:14:48.547659196,
07/11/2011 09:14:48.566612446,
07/11/2011 09:14:48.585565606,
07/11/2011 09:14:48.681325966
```

Also see

[bufferVar.clear\(\)](#) (on page 8-23)
[bufferVar.collecttimestamps](#) (on page 8-25)
[bufferVar.readings](#) (on page 8-31)
[bufferVar.statuses](#) (on page 8-35)
[Reading buffers](#) (on page 3-56, on page 3-50)

bufferVar.units

This attribute contains the unit of measure stored with readings in the reading buffer.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Clearing the buffer Instrument reset Recall setup	USB flash drive using dmm.savebuffer or dmm.appendbuffer	1

Usage

```
units = bufferVar.units[N]
```

<i>bufferVar</i>	The reading buffer
<i>N</i>	The reading number (1 to <i>bufferVar.n</i>)

Details

This read-only attribute is an array (Lua table) of the strings indicating the unit of measure stored with readings in the buffer. Units may be designated as one of the following: Volts AC, Volts DC, Amps AC, Amps DC, dB VAC, dB VDC, Ohms 2wire, Ohms 4wire, Ohms ComSide, Fahrenheit, Kelvin, Celsius, Hertz, Seconds, and Continuity.

Example

```
reset()
testData = dmm.makebuffer(1000)
dmm.nplc = 0.5
dmm.range = 0
dmm.configure.set("Dcv_100mV")
dmm.setconfig("slot2", "Dcv_100mV")
scan.create("2035:2040")
scan.execute(testData)

print(testData.units[1])

printbuffer(1, 6, testData.units)
```

This example creates a reading buffer named `testData`, sets and saves the DMM configuration, creates a scan list, and then runs the scan.

The `print()` command then outputs the units of the first reading in the reading buffer.

Output:
Volts DC

The `printbuffer()` command then outputs the units of readings 1 to 6 in the reading buffer.

Output:
Volts DC, Volts DC, Volts DC,
Volts DC, Volts DC, Volts DC

Also see

[Reading buffers](#) (on page 3-50)

channel.calibration.adjustcount()

This function gets the number of times that a card has been adjusted.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
count = channel.calibration.adjustcount(channelList)
```

<i>count</i>	Return value representing the number of times the instrument has been adjusted
<i>channelList</i>	A string contains slot <i>x</i> , where <i>x</i> is a number from 1 to 6

Details

This command can be used with channels that are locked or unlocked. If no *channelList* is provided, the currently unlocked channels are assumed.

There is only one adjustment count per card. Therefore, with no channel unlocked, the only acceptable values for *channelList* are "slot1", "slot2", and so on. An error is generated if any other values are used.

Example

```
Count = channel.calibration.adjustcount("slot1")
print(Count)
```

Assign the number of times the card in slot 1 has been adjusted to a user variable named Count.

Output the value.

```
3
```

This shows that the instrument has been adjusted 3 times.

Also see

Channel list notation
[channel.calibration.adjustdate\(\)](#) (on page 8-42)

channel.calibration.adjustdate()

This function sets or gets the adjustment date in UTC format (number of seconds since January 1, 1970) on the unlocked channel.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
returnDate = channel.calibration.adjustdate(channelList)
returnDate = channel.calibration.adjustdate(channelList, date)
```

<i>returnDate</i>	The adjustment date in UTC format
<i>channelList</i>	A string contains slot <i>x</i> , where <i>x</i> is a number from 1 to 6
<i>date</i>	The date of the adjustment (UTC formatted)

Details

This command can get the adjust date whether calibration is currently locked or unlocked. If the *channelList* parameter is not specified, it uses the currently unlocked card.

This command can only set the adjustment date on a previously unlocked card. The date is not permanently saved until the `channel.calibration.save()` command is sent.

There is only one adjustment date per card. Therefore, the only acceptable values for *channelList* are slot*x*. An error is generated if any other values are used.

Example 1

```
adjustmentDate =
  channel.calibration.adjustdate("slot2")
```

Gets the adjustment date for the card in slot 2.

Example 2

```
NewAdjustDate = os.time{year=2010, month=12, day=28, hour=17, min=35, sec=0}
channel.calibration.unlock("slot5", "KI3706")
myDate = channel.calibration.adjustdate("slot5", NewAdjustDate)
channel.calibration.save()
channel.calibration.lock()
print(os.date("%c", myDate))
```

Assign the UTC time for December 28, 2010 at 17:35:00 GMT to NewAdjustDate.

Unlock the calibration for the card in slot 5, assuming the default password.

Set the adjustment date using NewAdjustDate for the card in slot 5.

Save the adjustment date on the card on slot 5.

Lock the calibration for the card in slot 5.

View the date for myDate.

Also see

ChannelList notation

[Lua date and time](http://www.lua.org/pil/22.1.html) (see Lua date and time - <http://www.lua.org/pil/22.1.html>)

[UTC Calculator](http://www.mbari.org/staff/rich/utccalc.htm) (see UTC Calculator - <http://www.mbari.org/staff/rich/utccalc.htm>)

[channel.calibration.adjustcount\(\)](#) (on page 8-41)

[channel.calibration.save\(\)](#) (on page 8-45)

[channel.calibration.verifydate\(\)](#) (on page 8-48)

channel.calibration.lock()

This function prevents further calibration on the currently unlocked card.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
channel.calibration.lock()
```

Details

Calibration data is locked during normal operation. To perform calibration, calibration must be unlocked (`channel.calibration.unlock()`) for the card.

Only one card can be calibrated at a time. Therefore, `channel.calibration.lock()` works only on the currently unlocked card. Once locked, you must unlock calibration to perform it again.

This command locks calibration on the card being calibrated, but does not save calibration data.



CAUTION

Calibration data is lost if it is not saved before locking. Refer to `channel.calibration.save()` for more information.

An error is generated if this command is issued when calibration is already locked.

Example

```
channel.calibration.unlock("slot1","KI3706")
-- Perform operations to generate the calibration data
channel.calibration.save()
channel.calibration.lock()
```

Unlock the card calibration for slot 1 using the default password.

Use the `channel.calibration.step` command to generate the calibration data.

Save the calibration data for the card in slot 1, if no errors occurred while generating the calibration data.

Lock the calibration data for the card in slot 1.

Also see

[channel.calibration.save\(\)](#) (on page 8-45)

[channel.calibration.step\(\)](#) (on page 8-46)

[channel.calibration.unlock\(\)](#) (on page 8-47)

channel.calibration.password()

This function sets the password needed to unlock the calibration functionality of a card.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No	Not applicable	Card nonvolatile memory	KI3706

Usage

```
channel.calibration.password(password)
```

password

A string of characters that contain the desired password

Details

There is only one password per card. Therefore, `channel.calibration.password()` works only on the currently unlocked card.

Make note of the `password`, because there is no command to query for the password once it has been set on the instrument. The password is not permanently saved until the `channel.calibration.save()` command is sent. Passwords are alphanumeric and case-sensitive.

This command generates an error if calibration is locked or if the password string length is greater than six characters.

The default password from the factory is KI3706. The first two characters in the password are capital K capital I (for Keithley Instruments).

Example

```
channel.calibration.unlock("slot3", "KI3706"
)
channel.calibration.password("Unlock")
channel.calibration.save()
channel.calibration.lock()
```

Unlock the calibration for the card in slot 3, assuming the default password is still valid. Set the password to "Unlock" for the card in slot 3. Saved the password for the card in slot 3 for subsequent unlocks. Lock the calibration for the card in slot 3.

Also see

[channel.calibration.lock\(\)](#) (on page 8-43)

[channel.calibration.unlock\(\)](#) (on page 8-47)

channel.calibration.save()

This function saves the calibration data to the card.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
channel.calibration.save()
```

Details

Only one card can be calibrated at a time. Therefore, `channel.calibration.save()` works only on the presently unlocked card. An error is generated if this command is issued when calibration is already locked. The system must receive this command before the `channel.calibration.lock()` command or the calibration data will be lost.

This command saves the present values of the calibration constants and calibration date, and increases the calibration count by one, regardless of errors in the data. You should not issue `channel.calibration.save()` unless the calibration procedure was performed with no errors.

If no calibration date was specified using either `channel.calibration.adjustdate()` or `channel.calibration.verifydate()`, the date is automatically assigned based on the system date.

Example

```
channel.calibration.unlock("slot1","KI3706")
-- Perform operations to generate the calibration data
channel.calibration.save()
channel.calibration.lock()
```

Unlock the card calibration for slot 1 using the default password.

Use the `channel.calibration.step` command to generate the calibration data.

Save the calibration data for the card in slot 1, if no errors occurred while generating the calibration data.

Lock the calibration data for the card in slot 1.

Also see

[channel.calibration.adjustcount\(\)](#) (on page 8-41)

[channel.calibration.adjustdate\(\)](#) (on page 8-42)

[channel.calibration.lock\(\)](#) (on page 8-43)

[channel.calibration.unlock\(\)](#) (on page 8-47)

[channel.calibration.verifydate\(\)](#) (on page 8-48)

channel.calibration.step()

This function sends a calibration command.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
channel.calibration.step(channel, step)
channel.calibration.step(channel, step, value)
```

<i>channel</i>	The channel to be calibrated
<i>step</i>	The number corresponding to the specified step
<i>value</i>	The measured value for the specified step when the step value is even

Details

The specified channel must be on the unlocked slot. Only DAC and totalizer channels can be calibrated. It is best to calibrate a single channel sequentially to completion before changing channels.

The card assumes that the given voltage or current value is exactly what it is sourcing for the given step. This command generates an error if the step is out of sequence, does not exist, or the calibration is locked. Also, an error is generated if the calibration step does not complete successfully, if the value passed is invalid or out of range for the step, or not needed.

For DAC channels, a calibration sequence includes these steps:

1. Set voltage, -12 V to +12 V range, generate negative point 1.
2. Send reading.
3. Set voltage, -12 V to +12 V range, generate negative point 2.
4. Send reading.
5. Set voltage, -12 V to +12 V range, generate positive point 1.
6. Send reading.
7. Set voltage, -12 V to +12 V range, generate positive point 2.
8. Send reading.
9. Set current, 0 mA to +20 mA range, generate point 1.
10. Send reading.
11. Set current, 0 mA to +20 mA range, generate point 2.
12. Send reading.
13. Set current, +4 mA to +20 mA range, generate point 1.
14. Send reading.
15. Set current, +4 mA to +20 mA range, generate point 2.
16. Send reading.

For totalizer channels, a calibration sequence includes these steps:

1. Calibrate 0 V totalizer threshold
2. Calibrate 1.5 V totalizer threshold

You must save the calibration after calibrating and before locking. Use `channel.calibration.save()` to save the calibration.

NOTE

All calibration progress is lost if the calibration data is not saved before you lock the channel.

After calibration, the channel must be locked using `channel.calibration.lock()`.

Also see

ChannelList notation
[channel.calibration.lock\(\)](#) (on page 8-43)
[channel.calibration.save\(\)](#) (on page 8-45)
[channel.calibration.unlock\(\)](#) (on page 8-47)

channel.calibration.unlock()

This function unlocks calibration functionality for a card so that calibration operations can be performed.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
channel.calibration.unlock(slotX, password)
```

<i>slotX</i>	A string containing <i>slotX</i> , where X is a slot number from 1 to 6
<i>password</i>	The password that unlocks calibration

Details

Calibration data is locked during normal operation. This command enables calibration functionality. When calibration is completed, calibration functionality must once again be locked (`channel.calibration.lock()`). Only one card at a time may be unlocked.

There is only one password per card. Therefore, the only acceptable values for channel list are "slot1", "slot2", and so on. Otherwise, an error is generated.

An error is generated if the password that is entered does not match the one that was saved with `channel.calibration.password()`.

The password can only contain six case-sensitive, alphanumeric characters.

The default password from the factory is **KI3706**. The first two characters in the password are capital K capital I (for Keithley Instruments).

Example

```
channel.calibration.unlock("slot1","KI3706")
-- Perform operations to generate the calibration data
channel.calibration.save()
channel.calibration.lock()
```

Also see

[channel.calibration.lock\(\)](#) (on page 8-43)
[channel.calibration.password\(\)](#) (on page 8-44)
[channel.calibration.save\(\)](#) (on page 8-45)

channel.calibration.verifydate()

This function gets or sets the date the calibration was verified in UTC format (number of seconds since January 1, 1970).

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
returnDate = channel.calibration.verifydate(slotX)
returnDate = channel.calibration.verifydate(slotX, date)
```

<i>returnDate</i>	The verification date returned from the function call
<i>slotX</i>	A string containing slotX, where X is 1 to 6
<i>date</i>	UTC formatted date to which to set the calibration verification date

Details

This command gets the verification date whether calibration is currently locked or unlocked. If the slot is not defined, the unlocked channel is assumed.

This command can only set the verification date on a previously unlocked card. The date is not permanently saved until `channel.calibration.save()` is issued.

There is only one verification date per card. If more than one slot is defined, an error is generated.

Example

```
channel.calibration.unlock("slot1", "KI3706")
print(channel.calibration.verifydate(os.time{year=2010, month=8, day=5}))
channel.calibration.save()
channel.calibration.lock()
print(os.date("%m/%d/%Y", channel.calibration.verifydate("slot1")))
```

Unlock the calibration for the card in slot 1 using the default password.

Set the verify calibration date to August 5, 2010.

Get the newly set verification date in a user-readable format.

Save the new verification date.

Lock the calibration.

Output:

```
1281009600
08/05/2010
```

Also see

[Lua date and time](http://www.lua.org/pil/22.1.html) (see Lua date and time - <http://www.lua.org/pil/22.1.html>)

[UTC calculator](http://www.mbari.org/staff/rich/utccalc.htm) (see UTC Calculator - <http://www.mbari.org/staff/rich/utccalc.htm>)

[channel.calibration.adjustdate\(\)](#) (on page 8-42)

[channel.calibration.save\(\)](#) (on page 8-45)

channel.clearforbidden()

This function clears the list of channels specified from being forbidden to close.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
channel.clearforbidden(channelList)
```

<i>channelList</i>	String that specifies a list of channels, using channel list notation
--------------------	---

Details

The *channelList* parameter indicates the channels that will no longer be forbidden to close, and may include:

- `allslots` or `slotX` (where *x* equals 1 to 6)
- Channel ranges or individual channels
- Analog backplane relays

This function allows all items contained in the *channelList* parameter to be closed. It removes the "forbidden to close" attribute that can be applied to a channel using `channel.setforbidden()`.

Command processing stops as soon as an error is detected. If an error is found, the channels are not cleared from being forbidden to close.

Example

<code>channel.clearforbidden("2002,2004,2006,2008")</code>	Clears channels 2, 4, 6, and 8 on slot 2 from being forbidden to close.
<code>channel.clearforbidden("allslots")</code>	Clears all channels from being forbidden to close.
<code>channel.clearforbidden("3005:3010")</code>	Clears channels 5 through 10 on slot 3 from being forbidden to close.

Also see

[channel.getforbidden\(\)](#) (on page 8-66)

[channel.setforbidden\(\)](#) (on page 8-94)

channel.close()

This function closes the channels, analog backplane relays, and channel patterns that are specified by the channel list parameter without opening any channels.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
channel.close(channelList)
```

<i>channelList</i>	A string that lists the channels, analog backplane relays, and channel patterns to close
--------------------	--

Details

Channels closed with this command are appended to the already closed channels (no previously closed channels are opened by this command).

The *channelList* parameter can include channels with analog backplane relays. If this is the case, `channel.close` closes the specified channels and any associated analog backplane relays. For channel patterns, the analog backplane relays that are closed are the ones that were specified when the pattern was created. However, for channels, they are the ones specified with the `channel.setbackplane()` function. Another option for closing analog backplane relays with this command is to include them in the *channelList* parameter.

This command has no effect on how the DMM is configured.

Actions associated with this function include:

- Close the specified items in *channelList*
- Incur the settling time and any user-specified delay

This command is not available for digital I/O, DAC, and totalizer channels. Calling on a specific channel generates an error. If the digital I/O, DAC, or totalizer channel is in the range of channels, the channel is ignored.

- For delay time, see `channel.setdelay()`
- For analog backplane relays with channels, see `channel.setbackplane()`
- For channels associated with a channel, see `channel.getimage()`
- For channels associated with a channel pattern, see `channel.pattern.getimage()`
- For channel states (open/close), see `channel.getstate()`
- For closed channels, see `channel.getclose()`.

An error is generated if:

- The parameter string contains `slotX`, where *X* is 1 to 6, or `allslots`
- A forbidden item is specified
- Specified channel does not support being closed, such as a digital I/O channel
- Channel is paired with another bank for a multiwire application

Once an error is detected, the command stops processing and no channels are closed.

Example

<code>channel.close("1001:1005, 3003, Chans")</code>	Close channels 1 to 5 on slot 1, channel 3 on slot 3, and the channel pattern or label <i>Chans</i> .
<code>channel.close("2001, 2913")</code>	Close channel 1 on slot 2 and analog backplane relay 3 in bank 1 on slot 2.

Also see

[channel.exclusiveclose\(\)](#) (on page 8-56)
[channel.exclusiveslotclose\(\)](#) (on page 8-57)
[channel.getclose\(\)](#) (on page 8-61)
[channel.open\(\)](#) (on page 8-80)
[channel.getimage\(\)](#) (on page 8-68)
[channel.getstate\(\)](#) (on page 8-76)
[channel.pattern.getimage\(\)](#) (on page 8-82)
[channel.pattern.snapshot\(\)](#) (on page 8-85)
[channel.pattern.setimage\(\)](#) (on page 8-83)
[channel.setbackplane\(\)](#) (on page 8-90)
[channel.setdelay\(\)](#) (on page 8-93)
[dmm.close\(\)](#) (on page 8-170)

channel.connectrule

This attribute controls the connection rule for closing and opening channels in the instrument.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Instrument reset Recall setup	Create configuration script Save setup	channel.BREAK_BEFORE_MAKE

Usage

```
rule = channel.connectrule
channel.connectrule = rule
```

rule

- `channel.BREAK_BEFORE_MAKE` or 1: Break-before-make (BBM) connections for relays in the instrument
- `channel.MAKE_BEFORE_BREAK` or 2: Make-before-break (MBB) connections for relays in the instrument
- `channel.OFF` or 0: Does not guarantee a connection rule. The instrument closes relays as efficiently as possible to improve speed performance without applying a rule

Details

The connection rule describes the order in which switch channels are opened and closed when using `channel.exclusiveclose()`, `channel.exclusiveslotclose()`, `dmm.close()`, and scanning commands like `scan.execute()` and `scan.background()`. These commands may both open and close switch channels in a single command. The connection rule dictates the algorithm used by the instrument to order the opening and closing of switches.

The connection rule affects the operating time of these commands. These commands do not allow the instrument to continue execution until the settle time of the relays has expired.

When the connection rule is set to `channel.BREAK_BEFORE_MAKE`, the instrument ensures that all switch channels open before any switch channels close. When switch channels are both opened and closed, this command executes not less than the addition of both the open and close settle times of the indicated switch channels.

When the connection rule is set to `channel.MAKE_BEFORE_BREAK`, the instrument ensures that all switch channels close before any switch channels open. This behavior should be applied with caution because it will connect two test devices together for the duration of the switch close settle time. When switch channels are both opened and closed, the command executes not less than the addition of both the open and close settle times of the indicated switch channels.

With no connection rule (set to `channel.OFF`), the instrument attempts to simultaneously open and close switch channels in order to minimize the command execution time. This results in faster performance at the expense of guaranteed switch position. During the operation, multiple switch channels may simultaneously be in the close position. Make sure your device under test can withstand this possible condition. When switch channels are both opened and closed, the command executes not less than the greater of either the open or close settle times of the indicated switch channels.

NOTE

You cannot guarantee the sequence of open and closure operations when the channel connect rule set to OFF. It is highly recommended that you implement cold switching when the channel connect rule is set to OFF.

In general, the settling time of single commands that open and close switch channels depends on several factors, such as card type and channel numbers. However, the opening and closing of two sequential channels including no others can be guaranteed as follows:

- `channel.BREAK_BEFORE_MAKE` open settle time + close settle time
- `channel.MAKE_BEFORE_BREAK` close settle time + open settle time
- `channel.OFF` maximum of open settle time or close settle time

This behavior is also affected by `channel.connectsequential` and any additional user delay times.



WARNING

Make-before-break (also known as hot switching) can dry-weld reed relays so that they will always be on. Hot switching is recommended only when external protection is provided.

Example

```
channel.connectrule = channel.BREAK_BEFORE_MAKE
```

Sets the connect rule in the instrument to `channel.BREAK_BEFORE_MAKE`

Also see

[channel.connectsequential](#) (on page 8-53)
[channel.exclusiveclose\(\)](#) (on page 8-56)
[channel.exclusiveslotclose\(\)](#) (on page 8-57)
[dmm.close\(\)](#) (on page 8-170)
[scan.background\(\)](#) (on page 8-322)
[scan.execute\(\)](#) (on page 8-326)

channel.connectsequential

This attribute controls whether or not channels are closed sequentially.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Instrument reset Recall setup	Create configuration script	channel.OFF

Usage

```
sequential = channel.connectsequential
channel.connectsequential = sequential
```

<code>sequential</code>	<ul style="list-style-type: none"> <code>channel.OFF</code> or 0: Disable sequential connections <code>channel.ON</code> or 1: Enable sequential connections
-------------------------	--

Details

When `channel.connectsequential` is enabled, the list of channel actions is acted on sequentially. No two relays are opened or closed simultaneously.

Using a sequential close allows you to determine the time for a close operation to happen. For example, if you close three channels and each takes 4 ms to close (assuming no additional user delay times), with sequential on, it will take 12 ms. With sequential off, it may be 4, 8 or 12 ms, depending on whether or not the card can close multiple channels at once.

The order in which channels are opened or closed is not guaranteed with sequential off.

The sequential setting affects all channels in the instrument.

Example

```
channel.connectsequential = channel.ON
```

Specifies that channels close sequentially.

Also see

[channel.connectrule](#) (on page 8-52)
[Switch operation](#) (on page 2-77)

channel.createspecifier()

This function creates a string channel descriptor from a series of card-dependent integer arguments.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

There are five variants of this function that can be used, depending upon the type of card in the specified slot:

Variant 1	<string> = channel.createspecifier(<slot>, <bank>, <row>, <column>)
Variant 2	<string> = channel.createspecifier(<slot>, <row>, <column>)
Variant 3	<string> = channel.createspecifier(<slot>, <bank>, <index>)
Variant 4	<string> = channel.createspecifier(<slot>, <index>)
Variant 5	<string> = channel.createspecifier(<slot>, <backplane>)

<i>slot</i>	Specifies the slot number to use
<i>bank</i>	Specifies the bank number to use (if applicable)
<i>row</i>	Specifies the row number to use
<i>column</i>	Specifies the column number to use
<i>index</i>	Specifies the index to use
<i>backplane</i>	Specifies the backplane to use

Details

The arguments are dependent upon the card type in the specified slot. This command can only create valid channel descriptors; if an illegal argument is sent for the type of card in the specified slot, an error is generated. Variants of this function can be used, depending on the type of card in the specified slot:

Type of card in slot	Code variants to use
Matrix card containing banks	Variant 1 or 5
Matrix card without banks	Variant 2 or 5
Multiplexer cards	Variant 3, 4, or 5

Example 1

```
cd = channel.createspecifier(3, 1, 2, 101)
print(cd)
```

Creates a channel descriptor on the Model 3732 card configured as a single 4x112 matrix in slot 3, bank 1, row 2, column 101.
Output:
312A1

Example 2

```
for row = 1,8 do
  for col = 1,28 do
    ch = channel.createspecifier(1,1,row,col)
    channel.setpole(ch, 2)
  end
end
end
```

Sets the pole setting to 2 for all channels in bank 1 on a Model 3732 card configured as a dual 8x28 matrix in slot 1.

Example 3

```
cd = createspecifier(2, 2, 1)
print(cd)
```

Creates a channel descriptor on the Model 3724 multiplexer card in slot 2, bank 2, index 1.

Output:
2031

Example 4

```
cd = createspecifier(1, 911)
print(cd)
```

Creates a channel descriptor on the Model 3724 multiplexer card in slot 1, backplane 911.

Output:
1911

channel.exclusiveclose()

This function closes the specified channels so that they are the only channels that are closed on the instrument.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
channel.exclusiveclose(channelList)
```

<i>channelList</i>	A string listing the channels (including analog backplane relays) and channel patterns to exclusively close
--------------------	---

Details

This command allows you to close specific channels and open any other channels on the instrument. When you send this command, any presently closed channel opens if it is not specified to be closed in the parameter. For channel patterns, the analog backplane relays that are closed or opened are the ones that were specified when the pattern was created with `channel.pattern.setimage()` or `channel.pattern.snapshot()`. For channels, the analog backplane relays that are closed or opened are the ones specified with `channel.setbackplane()`, or that are specified in *channelList*.

When you send this command:

- Any presently closed channels and analog backplane relays that are not specified in *channelList* are opened.
- The channels and analog backplane relays in *channelList* are closed.
- Settling and user-specified delay times are applied as defined by the connection rules and delay settings.

This function has no affect on how the DMM is configured and does not use analog backplane relays associated with DMM configuration.

If the *channelList* parameter is an empty string or a string of spaces, all channels and analog backplane relays are opened. Therefore, sending `channel.exclusiveclose("")` is equivalent to `channel.open(channel.getclose("allslots"))`. However, sending the equivalent commands when nothing is closed generates an error because `nil` (the response of `channel.getclose("allslots")`) is being sent to the open command.

An error is generated if:

- The parameter string contains `slotX`, where `X = 1 to 6` or `allslots`
- A specified channel or channel pattern is invalid
- Channel number does not exist for slot specified
- Slot is empty
- A forbidden item is specified
- Channel is paired with another bank for a multi-wire application

Once an error is detected, the command stops processing. Channels open or close only if no errors are found.

This command is not available for digital I/O, DAC, and totalizer channels. Calling on a specific channel for these channels generates an error. If the digital I/O, DAC, or totalizer channel is in the range of specified channels, the channel is ignored.

Example 1

```
channel.setbackplane("3003", "3913")
channel.exclusiveclose("3003")
```

Associate analog backplane relay 3 in bank 1 on slot 3 with channel 3 on slot 3.

Open all channels and close slot 3, channel 3 and its associated analog backplane relay (3 in bank 1 on slot 3), if it is not already closed.

Example 2

```
channel.exclusiveclose("3003, 3913")
```

Close channel 3 on slot 3 and its associated analog backplane relay 3 in bank 1 on slot 3. By specifying the backplane relay directly, you eliminate the need for associating the backplane with `channel.setbackplane`.

Also see

[channel.close\(\)](#) (on page 8-50)
[channel.connectrule](#) (on page 8-52)
[channel.connectsequential](#) (on page 8-53)
[channel.exclusiveslotclose\(\)](#) (on page 8-57)
[channel.getclose\(\)](#) (on page 8-61)
[channel.getimage\(\)](#) (on page 8-68)
[channel.getstate\(\)](#) (on page 8-76)
[channel.open\(\)](#) (on page 8-80)
[channel.pattern.getimage\(\)](#) (on page 8-82)
[channel.setbackplane\(\)](#) (on page 8-90)
[channel.pattern.setimage\(\)](#) (on page 8-83)
[channel.pattern.snapshot\(\)](#) (on page 8-85)
[channel.setdelay\(\)](#) (on page 8-93)
[dmm.close\(\)](#) (on page 8-170)

channel.exclusiveslotclose()

This function closes the specified channels and channel patterns on the associated slots and opens any channels that are not specified.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
channel.exclusiveslotclose(channelList)
```

channelList

A string that lists the channels and channel patterns to exclusively close on the cards in associated slots (you can specify analog backplane relays)

Details

This command allows you to bundle the closing of channels with the opening of channels. Any currently closed channels or analog backplane relays open if they are not specified to be closed on the slots related to the channels in *channelList*. Using this command guarantees that only the specified channels and channel patterns are closed on the slots associated with channels in the *channelList*.

For channel patterns, the analog backplane relays that are closed or opened are the ones that were specified when the pattern was created (see `channel.pattern.setimage()` or `channel.pattern.snapshot()`). For channels, the analog backplane relays are the ones specified with the `channel.setbackplane()` command. If you do not want to use the `channel.setbackplane()` command, you can close the analog backplane relays by including them in the *channelList* parameter. When this command is sent:

- Closed channels or analog backplane relays for the associated slots are opened if they are not specified in the *channelList*
- Channels or analog backplane relays specified by the items in *channelList* are closed
- Any settling times and user-specified delay times are incurred before command processing is complete

This function has no effect on how the DMM is configured

For example, if channel 1 is closed on each of the six slots, specifying a *channelList* parameter of "2002, 4004" with this command opens channel 1 on slots 2 and 4 only. Then, channel 2 on slot 2 and channel 4 on slot 4 close. Channel 1 remains closed on slots 1, 3, 5, and 6.

The command is not available for digital I/O, DAC, and totalizer channels. Calling on one of these channels generates an error. If the digital I/O, DAC, or totalizer channel is in the range of channels, the channel is ignored. An error is generated if:

- The parameter string contains slot x (where $x = 1$ to 6) or allslots
- The parameter string is empty or parameter string with just spaces
- A specified channel is invalid or does not exist for the slot
- Channel pattern does not exist or the image of the pattern is an empty channel list
- A forbidden item is specified
- Channel is paired with another bank for a multi-wire application

Once an error is detected, the command stops processing. Channels open or close only if no errors are found and remain unchanged with any parsing or syntax error.

Example

<pre>channel.exclusiveslotclose("3003")</pre>
<pre>channel.exclusiveslotclose("1005, 2005")</pre>
<pre>channel.pattern.setimage("5007, 5017, 5027, 5915," "RouteA")</pre>
<pre>channel.exclusiveslotclose("RouteA")</pre>
Close channel 3 on slot 3 and open all other channels on slot 3 without affecting any other slot.
Close channel 5 on slots 1 and 2 and open all other channels on slots 1 and 2 without affecting any other slots.
Create a channel pattern called RouteA that includes channels 7, 17, and 27 on slot 5. Analog backplane relay 5 in bank 1 on slot 5 is also in the pattern. Have only the RouteA channels close on slot 5 (channels 7, 17, and 27, and analog backplane relay 5 in bank 1 on slot 5).

Also see

Channel list notation
[channel.close\(\)](#) (on page 8-50)
[channel.connectrule](#) (on page 8-52)
[channel.connectsequential](#) (on page 8-53)
[channel.exclusiveclose\(\)](#) (on page 8-56)
[channel.getclose\(\)](#) (on page 8-61)
[channel.getimage\(\)](#) (on page 8-68)
[channel.open\(\)](#) (on page 8-80)
[channel.pattern.getimage\(\)](#) (on page 8-82)
[channel.setbackplane\(\)](#) (on page 8-90)
[channel.setdelay\(\)](#) (on page 8-93)

channel.getbackplane()

Returns a string that lists the analog backplane relays that are controlled when the specified channels are used with switching operations.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Instrument reset Channel reset Recall setup Pole setting change	Create configuration script Save setup	None or nil

Usage

```
analogBusList = channel.getbackplane(channelList)
```

<i>analogBusList</i>	A string listing analog backplane relays associated with items in <i>channelList</i> .
<i>channelList</i>	A string listing the channels being queried.

Details

The response indicates the analog backplane relays that are used during processing of the command:

- `channel.close()`
- `channel.exclusiveclose()`
- `channel.open()`
- `scan.execute()` or `scan.background()` if the channel is configured for switching

The response will be changed by `channel.setbackplane()`, replacing the analog backplane relays with the new specified list.

The response will be cleared if `channel.setpole()` sets a new pole selection.

The analog backplane relays indicated by this response are not used or affected by:

- `dmm.close()` or `dmm.open()`
- `scan.execute()` or `scan.background()` if channel is configured for measuring

The parameter string can contain "slotX", where X equals 1 to 6, or "allslots".

An error is generated if:

- A specified channel does not exist for the card installed in a slot
- A channel pattern is specified in parameter list
- A specified channel does not have analog backplane relays associated with it, such as digital I/O
- An analog backplane relay is specified in parameter list

When *channelList* contains multiple items, the string returned includes the analog backplane relay channels of a single channel separated by a comma. A semicolon is used to delineate channels.

For channel patterns, the analog backplane relays must be specified when creating the pattern in the channel list parameter — see `channel.pattern.setimage()` or `channel.pattern.snapshot()`. Therefore, to see the channels and analog backplane relays associated with a channel pattern, use the `channel.pattern.getimage()` function.

Command processing stops as soon as an error is detected and a `nil` response is then returned. No partial list is returned.

For digital I/O, DAC, and totalizer channels, nothing is returned.

Example

```
channel.setpole("slot5", 4)
channel.setbackplane("slot5", "5911, 5922")
print(channel.getbackplane("slot5"))
```

Assume a Model 3720 in slot 5.
Set all channels on the card in slot 5 to be 4-pole, which makes the card have 30 4-pole channels.

Set all channels in slot 5 to have associated analog backplane relays 911 and 922 on slot 5.

Get the associated analog backplane relays for channels on slot 5.

Output:

```
5911, 5922, 5911, 5922, 5911, 5922, 5
 911, 5922, 5911, 5922, 5911, 5922
, 5911, 5922, 5911, 5922, 5911, 59
22, 5911, 5922, 5911, 5922, 5911,
5922, 5911, 5922, 5911, 5922, 591
1, 5922, 5911, 5922, 5911, 5922, 5
911, 5922, 5911, 5922, 5911, 5922
, 5911, 5922, 5911, 5922, 5911, 59
22, 5911, 5922, 5911, 5922, 5911,
5922, 5911, 5922, 5911, 5922, 591
1, 5922
```

Also see

Channel list notation

[Data retrieval commands](#) (on page 6-3)

[channel.close\(\)](#) (on page 8-50)

[channel.exclusiveclose\(\)](#) (on page 8-56)

[channel.open\(\)](#) (on page 8-80)

[channel.pattern.getimage\(\)](#) (on page 8-82)

[channel.pattern.setimage\(\)](#) (on page 8-83)

[channel.pattern.snapshot\(\)](#) (on page 8-85)

[channel.setbackplane\(\)](#) (on page 8-90)

[channel.setpole\(\)](#) (on page 8-101)

[dmm.close\(\)](#) (on page 8-170)

[dmm.open\(\)](#) (on page 8-222)

[scan.background\(\)](#) (on page 8-322)

[scan.execute\(\)](#) (on page 8-326)

channel.getclose()

This function queries for the closed channels indicated by the channel list parameter.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
closed = channel.getclose(channelList)
```

<i>closed</i>	A string listing the channels that are presently closed in the specified channel list parameter
<i>channelList</i>	A string representing the channels, channel patterns, and backplane relays that will be queried

Details

If more than one channel is closed, they are comma-delimited in the string. If *channelList* equals "slotX" (where X is 1 to 6), the response indicates the channels and backplane relays that are closed on that slot. Similarly, if *channelList* equals "allslots", the response indicates all channels and analog backplane relays that are closed in the instrument. The format of each channel returned is slot, row, column (matrix channels) or slot, channel (MUX channels). When the *channelList* contains a channel pattern, only the closed channels in that image are returned.

You can use "allslots" to query for all channels closed and not worry about an error if one of the slots is empty or does not support close channels.

An error message is generated if an empty parameter string is specified or if the specified channel list contains no valid channels that can be closed (for example, a channel list equaling "slotX" or "allslots").

If nothing is closed within the specified scope, a nil response is returned.

Example 1

```
channel.setpole("slot5", 4)
channel.setbackplane("slot5", "5911, 5922")
channel.close("5003, 5005")
closedSlot5 = channel.getclose("slot5")
print(closedSlot5)
```

Configure the channel on slot 5 to be four-pole. Associate the slot 5 channels with analog backplane relays 911 and 922 on slot 5. Close channels 3 and 5 on slot 5. Gets the channels and analog backplane relays that are closed on slot 5 and output the closed channels on slot 5.

Output:
5003 (5033) ; 5055 (5035) ; 5911 ; 5922

Example 2

```
allClosed = channel.getclose("allslots")
```

Gets all channels and analog backplane relays that are closed in the instrument.

Example 3

```
closedChans = channel.getclose("Chans")
```

Gets all channels closed in a pattern called "Chans".

Example 4

```
closedRange = channel.getclose("3001:3020")
```

Gets all channels that are closed on channels 1 to 20 on slot 3.

Example 5

```
closedOnes = channel.getclose("3001, 3002, 3003, 3005, 3911, 3912")
```

Gets all channels that are closed on channels 1, 2, 3, 5 and analog backplane relay 1 and 2 in bank 1 on slot 3.

Also see

Channel list notation
[channel.close\(\)](#) (on page 8-50)
[channel.exclusiveclose\(\)](#) (on page 8-56)
[channel.getstate\(\)](#) (on page 8-76)
[channel.open\(\)](#) (on page 8-80)
[Data retrieval commands](#) (on page 6-3)

channel.getcount()

This function returns a string with the close counts for the specified channels.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
counts = channel.getcount(channelList)
```

<i>counts</i>	A comma-delimited string listing the channel close counts
<i>channelList</i>	A string listing the items to query, which can include: <ul style="list-style-type: none"> • Channels • Backplane relays • Channel patterns (channels will be listed in the order in which they are listed in the pattern) • slotX, where X equals 1 to 6 • allslots

Details

A close count is the number of times a relay has been closed. The count values are returned in the order in which the channels are specified. The close counts for an analog backplane relay can be included in the *channelList* parameter.

If *channelList* includes a pattern, you can use `channel.pattern.getimage()` with the pattern name to see the channel order and the channels to which the close counts pertain.

When the *channelList* parameter for this function is "slotX", the response first lists the channels starting from lowest to highest (from slot 1 to slot 6). Because each slot is processed completely before going to the next, all slot 1 channels and backplane relays are listed before slot 2 channels.

An error is generated if:

- A specified channel is invalid
- The channel does not have a count closure associated with it

If an error is detected, a `nil` value is returned. No partial list of close counts is returned.

NOTE

Pseudocards do not support counts, so count values are generated numbers, not actual count values, if a pseudocard is used.

Example 1

```
counts = channel.getcount("2001:2005")
print(counts)
```

Gets the close counts for channels 1 to 5 on slot 2.
Example output for channels 2001, 2002, 2003, 2004, and 2005:
672,495,547,479,518

Example 2

```
counts = channel.getcount("slot2")
print(counts)
```

Get the close counts for all channels and analog backplane relays on slot 2 assuming a 3721 card is installed in the slot.

Sample output that shows the counts for channels 1 to 41, analog backplane relays 911 to 917, analog backplane relays 921 to 928:

```
672,495,547,479,518,459,522,599,452
,451,464,427,426,428,426,425,428
,424,424,425,5,3,3,3,4,3,3,5,3,3
3,33,33,33,33,33,32,32,32,32,32,
119,3,56,0,0,0,0,0,0,14,68,0,0,0
,0,16,0
```

Example 3

```
channel.pattern.setimage("2003, 2005, 2023,
2915", "Path")
PathList = channel.pattern.getimage("Path")
print(PathList)
print(channel.getcount(PathList))
print(channel.getcount("Path"))
```

Create the a pattern called Path, then get the close counts for channels and analog backplane relays in channel pattern called "Path"

Sample output:
2003, 2005,2023,2915
547,518,3,0
547,518,3,0

Also see

Channel list notation

[channel.pattern.getimage\(\)](#) (on page 8-82)

[channel.pattern.setimage\(\)](#) (on page 8-83)

[Data retrieval commands](#) (on page 6-3)

channel.getdelay()

This function queries for the additional delay time for the specified channels.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Instrument reset Channel reset Recall setup	Create configuration script Save setup	0

Usage

```
delayTimes = channel.getdelay(channelList)
```

<i>delayTimes</i>	A comma-delimited string consisting of the delay times (in seconds) for channels specified in <i>channelList</i>
<i>channelList</i>	A string listing the channels to query for their delay times

Details

The *channelList* parameter may contain *slotX* (where X equals 1 to 6) or *allslots*.

A command, after closing the state of channels, incurs the delay time indicated in the response for a channel before it completes. However, the internal settling time must elapse before the user delay is incurred. Therefore, the sequence is:

1. Command is processed
2. Channel closes
3. Settling time is incurred
4. User delay is incurred
5. Command completes

The delay times are comma-delimited in the same order that the items were specified in the *channelList* parameter. A value of zero (0) indicates that no additional delay time is incurred before a close command completes.

An error message is generated for the following reasons:

- The specified channels do not support a delay time
- A channel pattern is specified

Command processing stops as soon as an error is detected and a *nil* response is generated.

NOTE

Pseudocards do not support user delays, so this value is always zero (0) if a pseudocard is used.

Example

Example 1

```
delaytime = channel.getdelay("5001, 5003")
print(delaytime)
```

Query channels 1 and 3 on slot 5 for their delay times.

Example output:

```
0.000e+00,0.000e+00
```

Example 2

```
patternChannels =
  channel.pattern.get("chans")
DelayPatternTimes =
  channel.getdelay(patternChannels)
```

Gets the delay of the channels in the *chans* channel pattern if *chans* does not contain backplane relays. If it does contain backplane relays, you will receive the error 1115, "Parameter error invalid channel type in channel list."

Also see

Channel list notation

[channel.setdelay\(\)](#) (on page 8-93)

[Data retrieval commands](#) (on page 6-3)

channel.getforbidden()

This function returns a string listing the channels and analog backplane relays in the channel list that are forbidden to close.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Instrument reset Channel reset Recall setup	Create configuration script Save setup	Permitted to close

Usage

```
forbiddenList = channel.getforbidden(channelList)
```

<i>forbiddenList</i>	Comma-delimited string listing the channels and analog backplane relays in the channel list that are forbidden to close
<i>channelList</i>	A string listing the channels, backplane relays, and channel patterns that are to be checked to see if they are forbidden to close

Details

The *channelList* parameter indicates which channels to check, and may include:

- `allslots` or `slotX` (where *X* equals 1 to 6)
- Channel ranges or individual channels
- Analog backplane relays
- Channel patterns

If there are no channels in the scope of the *channelList* that are on the forbidden list, the string returned is empty or `nil`. The format of the channels in the response string is slot, channel for multiplexer channels or slot, row, column for matrix channels.

Example 1

```
Forbidden =  
channel.getforbidden("allslots")
```

Query for the channels and analog backplane relays that are forbidden to close in the instrument.

Example 2

```
channel.setforbidden("3003, 3005, 3925")  
Forbidden =  
channel.getforbidden("slot3")  
print(Forbidden)
```

Set channels 3 and 5 and analog backplane relay 5 in bank 2 to forbidden to close on slot 3.

Query for the channels and analog backplane relays that are forbidden to close on slot 3.

Sample output:

```
3003, 3005, 3925
```

Example 3

```
Forbidden =  
channel.getforbidden("1911:1916" ..  
", 2004, 2008, 2012")
```

Query for channels and analog backplane relays in a specified list. This list is only checking channels and analog backplane relays 1 to 6 on slot 1 and channels 4, 8 and 12 on slot 2 and returning the channels and analog backplane relays that are forbidden to close.

Also see

Channel list notation

[channel.clearforbidden\(\)](#) (on page 8-49)

[channel.setforbidden\(\)](#) (on page 8-94)

[Data retrieval commands](#) (on page 6-3)

channel.getimage()

This function queries a channel for items associated with that channel when used in a switching operation.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Instrument reset Channel reset Recall setup Related backplane relays Pole settings	Not applicable	channel identifier

Usage

```
channels = channel.getimage(channelList)
```

<i>channels</i>	A string listing the channels and analog backplane relays associated with the specified items
<i>channelList</i>	A string representing the channels and analog backplane relays to query

Details

The parameter string can contain "slotX" (where X equals 1 to 6) or "allslots".

The returned string lists the channels in slot, channel format or slot, row, column format. A request for multiple channels is delimited by a semicolon. Note that commas delimit the specific channels and analog backplane relays for an individual channel in the string.

If an error is detected, the response is `nil`.

An error is generated if:

- A channel pattern is specified
- An empty parameter string is specified
- `slotX` is empty or `allslots` parses to specify no valid channels because all slots are empty

Example 1

<pre>channel.setpole("2005", 2) channel.setbackplane("2005", "2911") channels = channel.getimage("2005") print(channels)</pre>	<p>Set channel 5 on slot 2 for a 2-wire switch application.</p> <p>Associate analog backplane relay 1 in bank 1 on slot 2 with channel 5 on slot 2.</p> <p>Query channel 5 on slot 2.</p> <p>Output: 2005,2911</p>
--	--

Example 2

<pre>channel.setpole("2003", 4) channel.setbackplane("2003", "2911,2922") channels = channel.getimage("2003") print(channels)</pre>	<p>Set channel 3 on slot 2 for a 4-wire switch application.</p> <p>Associate analog backplane relays 1 in bank 1 and 2 in slot 2 with channel 3 on slot 2.</p> <p>Query channel 3 on slot 2 (assuming channel 3 on slot 2 is on a 40-channel card).</p> <p>Output: 2003(2023),2911,2922</p>
---	---

Example 3

```
channels = channel.getimage("2003, 2005")
print(channels)
```

Query for channels 2003 and 2005 in a single call (assuming they are configured as shown in examples 1 and 2).

Output:

```
2003 (2023) , 2911, 2922; 2005, 2911
```

Example 4

```
channels = channel.getimage("2023")
print(channels)
```

Query channel 2023.

Query channel 3 on slot 2 (assuming channel 23 on slot 2 is on a 40-channel card).

Output:

```
nil
2023 is paired for 4-wire operation
```

Also see

Channel list notation
channel functions and attributes
[channel.pattern.getimage\(\)](#) (on page 8-82)
[Data retrieval commands](#) (on page 6-3)

channel.getlabel()

This function retrieves the label associated with one or more channels.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Instrument reset Channel reset Recall setup	Create configuration script Save setup	slot, row, column or slot, channel identifier

Usage

```
label = channel.getlabel(channelList)
```

<i>label</i>	A string listing the comma-delimited labels for items in <i>channelList</i>
<i>channelList</i>	A string listing the channels to query for the label associated with them

Details

The *channelList* parameter can contain more than one channel. If it does, a comma delimits the labels for the channels. The return string lists the labels in the same order that the channels were specified. The *channelList* parameter cannot be an empty string and must be a valid channel.

The *channelList* parameter can contain *slotX* (where X equals 1 to 6) or *allslots*. In this case, the channels are listed before the analog backplane relays.

An error is generated if:

- A specified channel does not exist
- The slot is empty
- The specified channel is not on the installed card
- A channel pattern is specified

Command processing stops as soon as an error is detected, and then a *nil* response is generated. No partial list of labels is returned.

Labels are also supported for digital I/O, DAC, and totalizer channels.

Example

```
channel.reset("5001")
print(channel.getlabel("5001"))
channel.setlabel("5001", "Device")
print(channel.getlabel("5001"))
```

Reset the channel.
Print the default label of the channel.
Set the label to "Device".
Return the new label.
Output:
5001
Device

Also see

Channel list notation
[channel.setlabel\(\)](#) (on page 8-94)
[Data retrieval commands](#) (on page 6-3)

channel.getmatch()

This function gets the match value.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Instrument reset Channel reset Recall setup	Create configuration script Save setup	0

Usage

```
matchValue = channel.getmatch(channelList)
```

<i>matchValue</i>	Return string listing the comma-delimited match values for channels in <i>channelList</i>
<i>channelList</i>	String specifying digital I/O or totalizer channels to query, using normal channel list syntax

Details

If a width greater than 1 is specified with `channel.setmatch()`, the *matchValue* contains the additional channel width specified at set time. For example, the value of 65535 with a width of 2 returns 65535. If the width is 1, 255 is returned.

DAC, backplane, and switch channels are not supported. If they are included in a range or slot specifier, they are ignored. If they are specified directly, an error is generated.

Example

```
print(channel.getmatch("slot6"))
```

Query the match values set for digital I/O channels 1 to 5 on slot 6 and totalizer channels 6 to 9 on slot 6, assuming a Model 3750 card.
Output (assuming defaults):
0,0,0,0,0,0,0,0,0

Also see

[channel.setmatch\(\)](#) (on page 8-96)

channel.getmatchtype()

Gets the match type.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Instrument reset Channel reset Recall setup	Create configuration script Save setup	4 (channel.MATCH_NONE)

Usage

```
matchType = channel.getmatchtype(channelList)
```

<i>matchType</i>	Return string listing the comma-delimited states for channels in <i>channelList</i>
<i>channelList</i>	String specifying the digital I/O or totalizer channels to query, using normal channel list syntax

Details

The channel match types are:

- 1 for match exactly
- 2 for match any
- 3 for match not exact
- 4 for match none

DAC, backplane, and switch channels are not supported. If these channels are included in a range or slot specifier, they are ignored; otherwise, an error is generated.

Example

```
print(channel.getmatchtype("6001:6009"))
```

Query the match type for digital I/O channels 1 through 5 and totalizer channels 6 through 9 on slot 6 (assuming a 3750 card).

Output:

```
4, 4, 4, 4, 4, 4, 4, 4, 4
```

Also see

Channel List notation
[channel.setmatchtype\(\)](#) (on page 8-97)

channel.getmode()

Gets the present mode attribute for a channel.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Instrument reset Channel reset Recall setup	Create configuration script Save setup	0 for digital I/O channels 3 for totalizer channels 49 for DAC channels

Usage

```
mode = channel.getmode(channelList)
```

<i>mode</i>	Return string of a comma-delimited list of modes
<i>channelList</i>	String specifying digital I/O, DAC, or totalizer channels to query, using normal channel list syntax

Details

For digital I/O channels, the following modes are supported:

- channel.MODE_INPUT (default) or 0
- channel.MODE_OUTPUT or 1
- channel.MODE_PROTECT_OUTPUT or 3

For totalizer channels, the following modes are supported:

- channel.MODE_RISING_EDGE or 1
- channel.MODE_FALLING_EDGE or 0
- channel.MODE_RISING_TTL_EDGE (default) or 3
- channel.MODE_FALLING_TTL_EDGE or 2
- channel.MODE_RISING_EDGE_READ_RESET or 5
- channel.MODE_FALLING_EDGE_READ_RESET or 4
- channel.MODE_RISING_TTL_EDGE_READ_RESET or 7
- channel.MODE_FALLING_TTL_EDGE_READ_RESET or 6

For DAC channels, the following modes are supported:

- channel.MODE_VOLTAGE_1 or 17
- channel.MODE_CURRENT_1 or 1
- channel.MODE_CURRENT_2 or 2
- channel.MODE_PROTECT_VOLTAGE_1 (default) or 49
- channel.MODE_PROTECT_CURRENT_1 or 33
- channel.MODE_PROTECT_CURRENT_2 or 34

Switch and analog backplane channels do not have modes. If included in a range or slot specifier, they are ignored. If they are specified directly, an error is generated.

Example

```
print(channel.getmode("slot6"))
```

Query the configuration of the channels on slot 6. Assuming a 3750, channels 1 to 5 are digital I/O, channels 6 to 9 are totalizers, and channels 10 to 11 are DACs.

Output:

```
0,0,0,0,0,3,3,3,3,49,49
```

Also see

Channel list notation
[channel.setmode\(\)](#) (on page 8-98)

channel.getoutputenable()

Gets the present output enable attribute for a channel.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Instrument reset Channel reset Recall setup	Create configuration script Save setup	0

Usage

```
outputEnable = channel.getoutputenable(channelList)
```

<i>outputEnable</i>	Return string of a comma-delimited list of output enable values
<i>channelList</i>	String specifying DAC channels to query, using normal channel list syntax

Details

For DAC channels, output enable indicates whether or not the DAC is driving the output. Response values are:

- 0: Output enable is OFF
- 1: Output enable is ON

Switch, digital I/O, totalizer, and backplane channels do not have modes. If they included in a range or slot specifier, they are ignored. If they are specified directly, an error is generated.

Example

```
print(channel.getoutputenable("slot1"))
```

Query the state of all DAC channels on slot 1 (assuming a Model 3750 card, this would be channels 10 and 11).
Output:
0, 0

Also see

[channel.setoutputenable\(\)](#) (on page 8-100)

channel.getpole()

Queries the pole settings for the specified channels.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Instrument reset Channel reset Recall setup	Create configuration script Save setup	Card dependent, typically 2

Usage

```
poles = channel.getpole(channelList)
```

<i>poles</i>	Returns a string consisting of the poles, comma separated, based on <i>channelList</i>
<i>channelList</i>	A string listing the channels to query for their pole settings

Details

channelList can contain "slotX", where X equals 1 to 6, or "allslots".

When the channel list parameter for this function is "slotX", the response first lists the channels starting from lowest to highest.

When the channel list parameter for this function is "allslots", the response starts with slot 1 and increases to slot 6. Each slot is processed completely before going to the next. Keeping this in mind, all slot 1 channels are listed before slot 2 channels.

The response is the numeric value representing the pole selection and not the text. For example, 4-pole selection is 4 and not `channel.POLES_FOUR`.

An error message is generated if:

- An empty parameter string is specified.
- The specified channel does not exist for card installed in slot.
- Parameter syntax error such as incorrect format for *channelList*.
- A channel pattern was specified.
- An analog backplane relay was specified.
- Channel does not support pole setting like a digital I/O.

Command processing stops as soon as an error is detected. No partial list is returned. If an error is detected or the slot is empty, the response is `nil`.

Digital I/O, DAC, backplane, and totalizer channels are not supported.

Example

```
channel.reset("slot5")
channel.setpole("5003, 5007", 4)
polesSlot5 = channel.getpole("5001, 5003,
    5005, 5007")
print(polesSlot5)
```

Reset the channels on slot 5 only.
Set the pole attribute for channels 3 and 7 on slot 5 to be 4.
Query channels 1, 3, 5, and 7 on slot 5 for pole settings.
View the pole attribute for the specified channels.
Output:
2, 4, 2, 4

Also see

[Data retrieval commands](#) (on page 6-3)
[channel.setpole\(\)](#) (on page 8-101)

channel.getpowerstate()

Gets the current power state attribute for a totalizer or DAC channel.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Instrument reset Channel reset Recall setup	Create configuration script Save setup	1

Usage

```
states = channel.getpowerstate(channelList)
```

<i>states</i>	Return string of a comma-delimited list of power states
<i>channelList</i>	String specifying the channels to query, using normal channel list syntax

Details

See card-specific documentation for important potential implications (warm-up times, effective coverage, use cases, and so on) when disabling or enabling power to a channel.

Not all channels can be disabled. If a channel that cannot be disabled is included in a range, it is ignored. If it is specified directly, an error is generated.

Example

```
print(channel.getpowerstate("1006"))
```

Get the current power state attribute for a totalizer channel 6 of slot 1 (assuming a Model 3750 card).

Output (assuming defaults):

```
1
```

Also see

[channel.setpowerstate\(\)](#) (on page 8-103)

channel.getstate()

Queries the state indicators of the channels in the instrument.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Instrument reset Channel reset Recall setup	Not saved	0

Usage

```
state = channel.getstate(channelList)
state = channel.getstate(channelList, indicatorMask)
```

<i>state</i>	Return string listing the comma-delimited states for the channels in <i>channelList</i>
<i>channelList</i>	String specifying the channels to query, using normal channel list syntax
<i>indicatorMask</i>	Value to specify only certain indicators; if omitted, all indicators are returned

Details

Each bit in the *state* represents a different indicator. Therefore, multiple indicators can be present (the OR operation is performed bitwise). All state or state latch commands behave in this manner.

Different channel types support different state information (indicators). The optional state *indicatorMask* can be used to return only certain indicators. If there is no *indicatorMask*, then all indicators are returned.

The following status indicators are defined:

- `channel.IND_CLOSED`
- `channel.IND_OVERLOAD`
- `channel.IND_MATCH`
- `channel.IND_OVERFLOW`

Indicators can be latched or unlatched, depending on other system settings. Latched indicators mean that the condition has occurred since the last reset command (or power cycle). Unlatched indicators mean that the condition occurred when the `channel.getstate()` command was issued. The overflow and overload indicators default to a latched condition.

Although the `channel.getstate()` command returns a string representing a number, this can be easily changed to a number and then compared to one of the provided Lua constants.

For switch channels, the only state information is an indicator of relay state (`channel.IND_CLOSED`).

For digital I/O channels, the state information includes an indicator for the state of auto protection and whether the match value has been matched (`channel.IND_OVERLOAD` and `channel.IND_MATCH`).

For totalizer channels, the state information includes an indicator for overflow and whether the match value has been matched (`channel.IND_OVERFLOW` and `channel.IND_MATCH`).

For DAC channels, the state information includes an indicator for the state of auto protection (`channel.IND_OVERLOAD`).

For more specific information about the overflow and overload indicators, refer to the documentation for the specific card on which the specified channel resides.

Example 1

```
channel.close("4005, 4007, 4017, 4003")
State = channel.getstate("4001:4020")
print(State)
```

Close channels 5, 7, 17, and 3 on slot 4.
Query the state of the first 20 channels on slot 4.
View the response assigned to State.
Output (assuming a Model 3720):
0,0,1,0,1,0,1,0,0,0,0,0,0,0,0,0,1,0
,0,0

Example 2

```
PathList = channel.pattern.getimage("Path")
print(Path)
print(channel.getstate(Path))
```

See the state of channels and analog backplane relays in the channel pattern called "Path".
Output:
4003,4005,4007,4017,4911,4922
1,1,1,1,1,1

Example 3

```
PathState = channel.getstate("Path")
print(PathState)
```

Another way to see the state of channels and analog backplane relays in channel pattern "Path" in Example 2 without getting the channels and analog backplane relays first.
Output:
1,1,1,1,1,1

Example 4

```
if bit.band(channel.IND_OVERLOAD,
tonumber(channel.getstate("4010"))) == 1
then
print("OVERLOAD")
end
```

Use the following command to check for an overload on a DAC channel.
In the previous example, `channel.getstate()` returns a string that is converted to a number using the Lua `tonumber()` command.
`channel.IND_OVERLOAD` equates to the number 2. Because the state is a bit-oriented value, a logical AND operation must be performed on the state and the overload constant to isolate it from other indicators.
The `tonumber()` command only works with a single channel. When multiple channels are returned (for example, `channel.getstate("slot4")`), this string must be parsed by the comma delimiter to find each value.

Also see

[channel.getclose\(\)](#) (on page 8-61)
[channel.setmatch\(\)](#) (on page 8-96)

channel.getstatelatch()

This function gets the mask representing the states that would be latched if they occurred.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Instrument reset Channel reset Recall setup	Create configuration script Save setup	14 for overload, match, and overflow

Usage

```
state = channel.getstatelatch(channelList)
```

<i>state</i>	Return string listing the comma-delimited latch states for channels in <i>channelList</i> : <ul style="list-style-type: none"> • 2: Channel overload • 4: Channel match • 8: Channel overflow
<i>channelList</i>	String specifying the channels to query, using normal channel list syntax

Details

Applicable to digital I/O, totalizer, and DAC channels only.
Each indicator is represented by a bit in the mask.

Example

```
myState = channel.getstatelatch("1001")
print(myState)
```

Queries the state event latch on digital I/O channel 1 in slot 1 assuming a Model 3750.

Example

```
channel.setstatelatch("6010", bit.bitor(channel.IND_OVERFLOW,
channel.IND_OVERLOAD))
print(channel.getstatelatch("6010"))
```

Generate either an overflow or overload event on DAC channel 10 in slot 6, assuming a Model 3750.
Query for the state latch for channel 10 on slot 6.
Output:
10

Also see

[channel.setstatelatch\(\)](#) (on page 8-104)

channel.gettype()

This function returns the type associated with a channel.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
type = channel.gettype(channelList)
```

<i>type</i>	Returns a string listing the comma-delimited types for channels in <i>channelList</i>
<i>channelList</i>	String specifying the channels to query, using normal <i>channelList</i> syntax

Details

The channel type is defined by the physical hardware of the card on which the channel exists. The following are valid channel types:

- `channel.TYPE_SWITCH` or 1
- `channel.TYPE_BACKPLANE` or 2
- `channel.TYPE_DAC` or 8
- `channel.TYPE_DIGITAL` or 4
- `channel.TYPE_TOTALIZER` or 16

Refer to the card-specific documentation for more information about the channel types available for your card.

Example 1

```
print(channel.gettype("1001, 1911"))
```

Query the channel type of channel 1 and analog backplane relay 1 of bank 1 in slot 1, assuming a Model 3720.

Output:

```
1,2
```

Example 2

```
print(channel.gettype("slot6"))
```

Query the channel types on slot 6, assuming a Model 3750.

Output:

```
4,4,4,4,4,16,16,16,16,8,8
```

This shows that channels 1 to 5 are digital I/O types, channels 6 to 9 are totalizer types, and channels 10 and 11 are DAC types.

Also see

None

channel.open()

This function opens the specified channels, analog backplane relays, and channel patterns.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
channel.open(channelList)
```

<i>channelList</i>	String listing the channels, analog backplane relays, and channel patterns to open
--------------------	--

Details

This function opens the specified channels based on the channel's switching configuration.

For the items specified to open, the channels associated with them open, as well as the associated analog backplane relays for each. For channel patterns, the analog backplane relays that get opened are the ones that are specified when the pattern is created (through `channel.pattern.setimage()` and `channel.pattern.snapshot()`). For channels, they are the ones specified with the `channel.setbackplane()` function. Another option for opening analog backplane relays with this command is to include them in the *channelList* parameter.

This command has no effect on how the DMM is configured.

The settling time associated with a channel must elapse before the command completes. User delay is not added when a relay opens.

For digital I/O, DAC, and totalizer channels, there is no valid behavior; calling on a specific channel generates an error. If a digital I/O, DAC, or totalizer channel is in the range of channels, the channel is ignored.

Example 1

<code>channel.open("1001:1005, 3003, Chans")</code>	Opens channels 1 to 5 on slot 1, channel 3 on slot 3, and the channel pattern or label Chans.
---	---

Example 2

<code>channel.open("slot3, slot5")</code>	Opens all channels on slots 3 and 5.
---	--------------------------------------

Example 3

<code>channel.open("allslots")</code>	Opens all channels on all slots.
---------------------------------------	----------------------------------

Also see

- [channel.close\(\)](#) (on page 8-50)
- [channel.exclusiveclose\(\)](#) (on page 8-56)
- [channel.exclusiveslotclose\(\)](#) (on page 8-57)
- [channel.getclose\(\)](#) (on page 8-61)
- [channel.getdelay\(\)](#) (on page 8-64)
- [channel.pattern.getimage\(\)](#) (on page 8-82)
- [channel.pattern.setimage\(\)](#) (on page 8-83)
- [channel.pattern.snapshot\(\)](#) (on page 8-85)
- [channel.getstate\(\)](#) (on page 8-76)
- [channel.setdelay\(\)](#) (on page 8-93)
- [channel.setforbidden\(\)](#) (on page 8-94)
- [channel.setbackplane\(\)](#) (on page 8-90)
- [dmm.close\(\)](#) (on page 8-170)
- [dmm.open\(\)](#) (on page 8-222)

channel.pattern.catalog()

This function creates a list of the user-created channel patterns.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
for name in channel.pattern.catalog() do
  ...
end
```

<i>name</i>	String representing the user-defined name of the channel pattern that is assigned by the catalog function during the <code>for</code> loop
-------------	--

Details

This function allows you to print or delete all user-created channel patterns in the runtime environment. The entries that are returned are listed in random order.

Example

```
channel.pattern.setimage("3001,3031",
  "patternA")
channel.pattern.setimage("3002,3032",
  "patternB")
channel.pattern.setimage("3003,3033",
  "patternC")

for name in channel.pattern.catalog() do
  print(name .. " = " ..
    channel.pattern.getimage(name))
  channel.pattern.delete(name)
end
```

This example prints the names and items associated with all user-created channel patterns. It then deletes the channel pattern.

```
patternC = 3003,3033
patternA = 3001,3031
patternB = 3002,3032
```

Also see

- [channel.pattern.delete\(\)](#) (on page 8-82)
- [channel.pattern.getimage\(\)](#) (on page 8-82)
- [channel.pattern.setimage\(\)](#) (on page 8-83)
- [channel.pattern.snapshot\(\)](#) (on page 8-85)

channel.pattern.delete()

This function deletes a channel pattern.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
channel.pattern.delete(name)
```

<i>name</i>	A string representing the name of the channel pattern to delete
-------------	---

Details

An error is generated if the name does not exist as a channel pattern.

Example

<code>channel.pattern.delete("Channels")</code>	Deletes a channel pattern called Channels.
---	--

Also see

[channel.pattern.catalog\(\)](#) (on page 8-81)
[channel.pattern.getimage\(\)](#) (on page 8-82)
[channel.pattern.setimage\(\)](#) (on page 8-83)
[channel.pattern.snapshot\(\)](#) (on page 8-85)

channel.pattern.getimage()

This function queries a channel pattern for associated channels and analog backplane relays.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Instrument reset Channel reset Recall setup Pole setting change	Create configuration script Save setup	Not applicable

Usage

```
channelList = channel.pattern.getimage(name)
```

<i>channelList</i>	A string specifying a list of channels and analog backplane relays that are represented by the name
<i>name</i>	A string representing the name of the channel pattern to query

Details

The returned string lists the channels in the slot, column or slot, row, column format, even if a channel pattern was used to create it. Results for multiple channel patterns are delimited by a semicolon (;). Commas delimit the specific channels and analog backplane relays in a single channel pattern in the string.

If you change a pole setting for a channel that is associated with a channel pattern, the channel pattern is deleted. Be sure to configure the pole setting for channels (`channel.setpole`) before creating a channel pattern.

Example

```
-- Set up two patterns
channel.pattern.setimage("4001:4005", "myPattern")
channel.pattern.setimage("2001,2003,2005", "myRoute")

-- Print images
myImage = channel.pattern.getimage("myPattern")
print(myImage)
print(channel.pattern.getimage("myRoute"))
print(channel.pattern.getimage("myRoute,
    myPattern"))
```

Using a Model 3721 (or similar model) card in slots 2 and 4, this example creates two channel patterns and then queries these patterns.

Output:

```
4001,4002,4003,4004,4005
2001,2003,2005
2001,2003,2005;4001,4002,4003,4004,4005
```

Also see

[channel.pattern.catalog\(\)](#) (on page 8-81)
[channel.pattern.delete\(\)](#) (on page 8-82)
[channel.pattern.setimage\(\)](#) (on page 8-83)
[channel.setpole\(\)](#) (on page 8-101)

channel.pattern.setimage()

This function creates a channel pattern and associates it with the specified name.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Instrument reset Channel reset Recall setup Pole setting change	Create configuration script Save setup	Not applicable

Usage

```
channel.pattern.setimage(channelList, name)
```

<i>channelList</i>	A string listing the channels, channel patterns, or analog backplane relays to use when creating the new channel pattern
<i>name</i>	A string representing the name to associate with the new channel pattern

Details

If *name* is used for an existing channel pattern, that pattern is overwritten with the new pattern channel image (if no errors occur). The previous image associated with the name is lost. The DMM configuration associated with the pattern remains unchanged in this scenario.

The channel pattern is not created if an error is detected. You can create a channel pattern with an empty *channelList* parameter. This will create a pattern that has no channels or analog backplane relays associated with it. The behavior of using an empty pattern in a channel list parameter is dependent on the command. For example:

<code>channel.pattern.setimage("", "Empty_pattern")</code>	Create an empty pattern
<code>channel.close("Empty_pattern")</code>	Generates error: 1115, Parameter error no valid channels in channel list
<code>channel.exclusiveslotclose("Empty_pattern")</code>	Generates error: 1115, Parameter error no valid channels in channel list
<code>channel.open("Empty_pattern")</code>	Generates error: 1115, Parameter error no valid channels in channel list
<code>channel.exclusiveclose("Empty_pattern")</code>	Opens any closed channels or analog backplane relays in the instrument
<code>channel.close("Empty_pattern, 5005")</code>	Closes channel 5005
<code>channel.exclusiveslotclose("Empty_pattern, 5003")</code>	Opens any closed channel on slot 5 and closes channel 3 on slot 5

A channel pattern must include the analog backplane relays and the desired channels. Once a channel pattern is created, the only way to add a channel or analog backplane relay to an existing pattern is to delete the old pattern and recreate the pattern with the new items.

If you change a pole setting for a channel that is associated with a channel pattern, the channel pattern is deleted. Be sure to configure the pole setting for channels (`channel.setpole`) before creating a channel pattern.

Channel patterns are stored when you run the `createconfigscript()` command or `setup.save()` command.

Channel patterns are lost when power is cycled. Use `setup.recall()` or a script created with `createconfigscript()` to restore them.

Including any channels of type digital I/O, DAC, and totalizer generates an error.

The following restrictions exist when naming a channel pattern:

- The name must contain only letters, numbers, or underscores
- The name must start with a letter
- The name is case sensitive

Examples of valid names:

- Channels
- Chans
- chans
- Path1
- Path20
- path_3

Examples of invalid names:

- 1path (invalid because it starts with a number)
- my chans (invalid because it contains a space)
- My,chans (invalid because it contains a comma)
- Path1:10 (invalid because it contains a colon)

An error is generated if:

- The *name* parameter already exists as a label
- Any channel is forbidden to close
- Insufficient memory exists to create the channel pattern
- The parameter string contains `slotX` (where *X* equals 1 to 6) or `allslots`
- The name parameter contains a space character
- The pattern name exceeds 19 characters

Example 1

```
channel.pattern.setimage("3001:3010", "Channels")

oldList = channel.pattern.getimage("Channels")
newList = oldList .. ", 3911"
channel.pattern.delete("Channels")
channel.pattern.setimage(newList, "Channels")
channel.open("slot3")
channel.close("Channels")
print(channel.getclose("slot3"))
```

For this example, assume there is a Keithley Model 3721 or similar card in slot 3.

Create a pattern.

Append a channel to the pattern by retrieving the pattern and recreating it. Recreate the pattern with the new image. Open all channels on slot 3 and close the pattern Channels.

Output:

```
3001;3002;3003;3004;3005;3006;3
007;3008;3009;3010;3911
```

Example 2

```
channel.pattern.setimage("3001:3010", "Channels")
channel.open("slot3")
channel.close("Channels, 3911")
print(channel.getclose("slot3"))
```

An alternate solution to the example above is to create the pattern, then add the analog backplane relay when you close the channel. This eliminates the need to get the image, delete the image and recreate it.

Output:

```
3001;3002;3003;3004;3005;3006;
3007;3008;3009;3010;3911
```

Also see

- [createconfigscript\(\)](#) (on page 8-115)
- [channel.pattern.catalog\(\)](#) (on page 8-81)
- [channel.pattern.delete\(\)](#) (on page 8-82)
- [channel.pattern.getimage\(\)](#) (on page 8-82)
- [channel.pattern.snapshot\(\)](#) (on page 8-85)
- [channel.setpole\(\)](#) (on page 8-101)
- [setup.save\(\)](#) (on page 8-368)
- [setup.recall\(\)](#) (on page 8-368)

channel.pattern.snapshot()

This function creates a channel pattern.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Instrument reset Channel reset Recall setup Pole setting change	Create configuration script Save setup	Not applicable

Usage

```
channel.pattern.snapshot (name)
```

<i>name</i>	A string representing the name to associate with the present state of channels and analog backplane relays
-------------	--

Details

This command stores an image of presently closed channels and analog backplane relays and associates them with the *name* parameter.

If *name* is already used for an existing channel pattern, that pattern is overwritten with the new pattern channel image (if no errors occur). The DMM configuration associated with the pattern remains unchanged.

The following restrictions exist when naming a channel pattern:

- The name must contain only letters, numbers, or underscores
- The name must start with a letter
- The name is case sensitive

Examples of valid names:

- Channels
- Chans
- chans
- Path1
- Path20
- path_3

Examples of invalid names:

- 1path (invalid because it starts with a number)
- my chans (invalid because it contains a space)
- My,chans (invalid because it contains a comma)
- Path1:10 (invalid because it contains a colon)

An error is generated if:

- The *name* parameter already exists as a label
- Insufficient memory exists to save the channel pattern and name in persistent memory
- The pattern name exceeds 19 characters or contains a space

Issuing this function on an existing pattern invalidates the existing scan list (the pattern may or may not be used in the current scan list). Creating a new pattern does not invalidate the existing scan list.

Channels of type DAC, totalizer, and digital I/O are ignored.

Channel patterns are stored when you run the `createconfigscript()` command or `setup.save()` command.

Channel patterns are lost when power is cycled. Use `setup.recall()` or a script created with `createconfigscript()` to restore them.

If you change a pole setting for a channel that is associated with a channel pattern, the channel pattern is deleted. Be sure to configure the pole setting for channels (`channel.setpole`) before creating a channel pattern.

Example

<pre>channel.pattern.snapshot("voltagePath")</pre>	Creates a pattern named <code>voltagePath</code> that contains the presently closed channels and analog backplane relays.
--	---

Also see

[createconfigscript\(\)](#) (on page 8-115)
[channel.pattern.catalog\(\)](#) (on page 8-81)
[channel.pattern.delete\(\)](#) (on page 8-82)
[channel.pattern.getimage\(\)](#) (on page 8-82)
[channel.pattern.setimage\(\)](#) (on page 8-83)
[channel.setpole\(\)](#) (on page 8-101)
[setup.save\(\)](#) (on page 8-368)
[setup.recall\(\)](#) (on page 8-368)

channel.read()

This function reads a value from a channel.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```

value = channel.read(channelList)
value = channel.read(channelList, width)
value = channel.read(channelList, width, readingBuffer)

```

<i>value</i>	Return string that lists the comma-delimited read values for the channels in <i>channelList</i>
<i>channelList</i>	String that specifies a list of channels, using channel list notation
<i>width</i>	Specifies reading over multiple consecutive channels (default 1)
<i>readingBuffer</i>	Reading buffer to store read values

Details

For digital I/O channels, only a width of 1, 2, 3, or 4 is supported. Any information (bits) greater than the specified *width* is returned as zero. For example, if channels 1 and 2 are both 255, a reading with a *width* of 1 returns 255 and a *width* of 2 with channel 1 returns 65535. Values read from outputs reflect their current setting. If the read channel is in the overload state, the read value is indeterminate.

For widths greater than 1, the specified channel occupies the least significant byte. For example, reading the value 4293844224 (hex ffeedd00) from channel 1 with a *width* of 4 indicates channel 1 is 0 (hex 0), channel 2 is 221 (hex dd), channel 3 is 238 (hex ee), and channel 4 is 255 (hex ff). Reading the value of 0 (hex 0) from channel 1 with a *width* of 1 indicates channel 1 is 0 (hex 0) and other channels are not included. Totalizer and DAC channels do not support a *width* other than 1 and result in an error if specified.

Switch and backplane channels are not supported.

For a channel with a power state of OFF, the returned value is DISABLED. The value into the reading buffer is indeterminate.

Example

```
count = channel.read("1006")
```

Read the count from the first totalizer channel (channel 6) in slot 1, assuming a Model 3750.

Also see

None

channel.reset()

This function resets the specified channel list items to factory default settings.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
channel.reset(channelList)
```

channelList

A string that lists the items to reset; the string can include:

- allslots
- slotX, where X is the slot number
- channel patterns
- channels, including a range of channels
- analog backplane relays

Details

For the items specified in *channelList*, the following actions occur:

- Any closed channels and analog backplane relays open
- Any 4-pole channels reset to 2-pole operation and their paired channels are changed to match
- Additional user delay is set to zero (0)
- Labels are removed
- Analog backplane relays specified by the `channel.setbackplane()` function are cleared
- If the channel is forbidden to close, it is cleared from being forbidden to close
- If the channels are used in channel patterns, the channel patterns that contain the channels are deleted.
- The DMM configurations of all channels are set to `nofunction`

Using this function to reset a channel or backplane relay involved in scanning invalidates the existing scan list. The list has to be recreated before scanning again.

For all channels, any trigger settings are removed.

For digital I/O channels, operation is set to input, the match is set to zero (0), and auto-protect is turned on.

For totalizer channels, operation is set to falling edge and TTL level.

For DAC channels, output is turned off and auto-protect is turned on. Operation is set to -12 V to + 12 V.

The rest of the instrument settings are unaffected. To reset the entire system to factory default settings, use the `reset()` command.

Example 1

```
channel.reset("allslots")
```

Performs a reset operation on all channels on the instrument.

Example 2

```
channel.reset("slot1")
```

Resets channels on slot 1 only.

Example 3

```
channel.reset("3001:3005")
```

Resets only channels 1 to 5 on slot 3.

Example 4

```
channel.reset("5005, 5915")
```

Resets only channel 5 and analog backplane relay 5 in bank 1 on slot 5

Also see

Channel functions and attributes
 Channel list notation
[channel.setbackplane\(\)](#) (on page 8-90)
[dmm.reset\(\)](#) (on page 8-230)
[reset\(\)](#) (on page 8-316)
[scan.reset\(\)](#) (on page 8-333)

channel.resetstatelatch()

This function resets the channel state.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
channel.resetstatelatch(channelList, state)
```

<i>channelList</i>	String that specifies the channels that need to have their states reset, using normal channel list syntax
<i>state</i>	String that lists the comma-delimited states for channels in <i>channelList</i> that are to have their states reset

Details

This function is applicable to digital I/O, totalizer, and DAC channels only.

The values for *state* are:

- `channel.IND_MATCH` or 4
- `channel.IND_OVERFLOW` or 8
- `channel.IND_OVERLOAD` or 2

Multiple states can be set by performing a logical OR operation on the values.

For *channelList*, use `channel.ALL` to reset all states.

States can be latched or unlatched, depending on other system settings. Latched states indicate that the condition occurred since the last reset (or power cycle). Unlatched states indicate that the condition has occurred when the `channel.getstate()` command was issued. The Overflow and Overload states default to latched.

If states are not cleared using `channel.resetstatelatch()`, you may not be reading the present state of the channel.

If the *state* is reset but the condition that caused the channel state to latch still exists, the state is reset, but a second event is generated through the channel trigger model.

Example

```
channel.resetstatelatch("1001",
  channel.IND_MATCH)
```

Clears out a match indicator that was latched on digital I/O channel 1 of slot 1, assuming a Model 3750.

Also see

[channel.getstate\(\)](#) (on page 8-76)
[channel.getstatelatch\(\)](#) (on page 8-78)
[channel.setstatelatch\(\)](#) (on page 8-104)

channel.setbackplane()

This function specifies the list of analog backplane relays to use with the specified channels when they are used in switching applications.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Instrument reset Channel reset Recall setup Pole setting change	Create configuration script Save setup	None

Usage

```
channel.setbackplane(channelList, abuslist)
```

<i>channelList</i>	A string that lists the channels to change
<i>abuslist</i>	A string that lists the analog backplane relays to set for the channels specified in <i>channelList</i>

Details

The parameter string *channelList* can contain "slotX", where X equals 1 to 6, or "allslots".

The *abuslist* parameter must specify the entire list of analog backplane relays that are needed.

The analog backplane relays specified in the *abuslist* parameter are used or affected by:

- `channel.close()`, used during the processing of the command
- `channel.exclusiveclose()`, used during the processing of the command
- `channel.open()`, used during the processing of the command
- `channel.setpole()` clears the analog backplane relays
- `scan.execute()` or `scan.background()`, if channels are configured for switching (the assigned DMM configuration has the function set to "nofunction")

The analog backplane relays specified in the *abuslist* parameter are not used or affected by:

- `dmm.close()`
- `dmm.open()`
- `scan.execute()` or `scan.background()` if the channels are configured for measuring (the DMM configuration has the function set to something other than "nofunction").

For channel patterns, the analog backplane relays are specified when the pattern is created (see [channel.pattern.getimage\(\)](#) (on page 8-82) and [channel.pattern.snapshot\(\)](#) (on page 8-85)). Channel patterns do not have a poles setting associated with them.

If this command is updated, the previous list is replaced with the new specified analog backplane relays in the *abuslist* parameter.

For channels, as their pole setting change, the list of analog backplane relays gets cleared. Therefore, after changing the pole settings, send `channel.setbackplane()` with the appropriate analog backplane relay channels. When clearing the backplane channels, this can involve clearing the paired channel, whether pairing or un-pairing channels. For example, on a 40-channel card, channels 1 and 21 are paired when the poles for channel 1 is set to 4. Therefore, setting the poles setting on channel 1 to 4 clears the backplane channels for channels 1 and 21. Likewise, they are both cleared when the poles setting is set back to 2 on channel 1.

Calling this function on an existing channel involved in scanning invalidates the existing scan list.
An error is generated if:

- An empty slot is specified.
- A specified channel or analog backplane relay does not exist for the card installed in a slot.
- An empty parameter string is received for *channelList*. An empty string is allowed for *abuslist*. A parameter string of just spaces is treated like an empty string.
- A specified channel does not have analog backplane relays associated with it, such as digital I/O.
- An analog backplane relay is specified in *channelList*.
- A channel is specified in *abuslist*.
- A channel pattern is specified.

If a syntax error occurs, command processing stops and no changes are made.

Example 1

```
channel.setbackplane("2002", "2913, 2914")
channel.open("allslots")
channel.close("2002")
print(channel.getclose("allslots"))
```

Use analog backplane relays 3 and 4 in bank 1 of slot 2 for a switching application on channel 2 of slot 2.
Open all channels in the instrument.
Close channel 2 on slot 2.
Query for all closed channels in the instrument.

Output (assuming channel 2002 is configured for 2-pole operation):
2002;2913;2914

Example 2

```
print(channel.getbackplane("2002"))
```

Query the analog backplane relays for channel 2 of slot 2, assuming the configuration of the previous example.

Output:

```
2913,2914
```

```
channel.open("slot2")  
channel.setpole("2002", 4)
```

Open all channels on slot 2 only.

Change the poles on channel 2 of slot 2 to 4 (this clears previously assigned backplanes to the channel).

```
channel.close("2002")  
print(channel.getclose("slot2"))
```

Close channel 2 on slot 2.

Query for closed channels on slot 2 (note that the backplane relays have been cleared and the paired channel, 2022, is in parentheses)

Output:

```
2002(2022)
```

```
channel.open("slot2")  
channel.setbackplane("2002", "2911, 2922")
```

Open all channels on slot 2 only.

Assign analog backplane relay 1 of bank 1 and relay 1 of bank 2 of slot 2 to channel 2 of slot 2.

```
channel.close("2002")  
print(channel.getclose("slot2"))
```

Close channel 2 on slot 2.

Query for closed channels on slot 2.

Output:

```
2002(2022);2911;2922
```

Also see

[channel.close\(\)](#) (on page 8-50)
[channel.exclusiveclose\(\)](#) (on page 8-56)
[channel.getbackplane\(\)](#) (on page 8-59)
[channel.open\(\)](#) (on page 8-80)
[channel.setpole\(\)](#) (on page 8-101)
[scan.background\(\)](#) (on page 8-322)
[scan.execute\(\)](#) (on page 8-326)

channel.setdelay()

This function sets additional delay time for specified channels.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Instrument reset Channel reset Recalls setup	Create configuration script Save setup	0

Usage

```
channel.setdelay(channelList, value)
```

<i>channelList</i>	A string listing the channels that need modifications to their delay time
<i>value</i>	Desired delay time for items in <i>channelList</i> . Minimum is 0 seconds

Details

Setting a delay only applies to switch channels. An error occurs for a read/write channel such as digital input/output. The delay being specified by value may be updated based on a card's resolution for delay. To see if the delay value was modified after setting, use the `channel.getdelay()` command to query.

Channel patterns get their delay from the channels that comprise the pattern. Therefore, specify the delay for a pattern through the channels. A pattern incurs the longest delay of all channels comprising that pattern.

An error message is generated if:

- The value is an invalid setting for the specified channel
- A channel pattern is specified
- The channel is for an empty slot
- An analog backplane relay is specified.

Command processing will stop as soon as an error is detected and no delay times will be modified.

NOTE

Pseudocards do not replicate the additional delay time.

Example 1

<code>channel.setdelay("5001, 5003" , 50e-6)</code>	Sets channels 1 and 3 on slot 5 for a delay time of 50 microseconds.
---	--

Example 2

<code>channel.setdelay ("slot3", 0)</code>	Sets the channels on slot 3 for 0 delay time.
--	---

Also see

[channel.getdelay\(\)](#) (on page 8-64)

channel.setforbidden()

This function prevents the closing of specified channels and analog backplane relays.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Instrument reset Channel reset Recall setup	Create configuration script Save setup	Not forbidden

Usage

```
channel.setforbidden(channelList)
```

<i>channelList</i>	A string that lists the channels and analog backplane relays to make forbidden to close
--------------------	---

Details

The *channelList* parameter indicates the scope of channels affected and may include:

- allslots or slotX (where X equals 1 to 6)
- Channel ranges or individual channels
- Analog backplane relays

This function prevents all items contained in the channel list parameter from closing. It applies the "forbidden to close" attribute to the specified channels. To remove the "forbidden to close" attribute, use `channel.clearforbidden()`.

If a channel that is being set to forbidden is used in a channel pattern, the channel pattern is deleted when the channel or analog backplane relay is set to forbidden. Note that if the *channelList* parameter includes a channel pattern, the channel pattern will be deleted when the channels in the patterns are successfully set to forbidden to close.

The channels or analog backplane relays in the *channelList* parameter must be installed in the instrument. If the scan list contains a channel or analog backplane relay that is forbidden, the scan list is invalidated.

Example

<code>channel.setforbidden("2002,2004,2006,2008")</code>	Marks channels 2, 4, 6, and 8 of slot 2 as forbidden to close.
<code>channel.setforbidden("slot3")</code>	Marks all channels and analog backplane relays on slot 3 as forbidden to close.

Also see

[channel.clearforbidden\(\)](#) (on page 8-49)

[channel.getforbidden\(\)](#) (on page 8-66)

channel.setlabel()

This function sets the label associated with a channel.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Instrument reset Channel reset Recall setup	Create configuration script Save setup	No label

Usage

```
channel.setlabel(channelList, label)
```

<i>channelList</i>	A string that lists the channel to which to set the label
<i>label</i>	A string that represents the label for the channel in <i>channelList</i> , up to 19 characters

Details

This command sets the label of the channel specified in *channelList* to the value specified in the *label* parameter. The channel attributes associated with each channel remain unchanged except for their labels. The *label* parameter must be unique. In addition, it cannot be the same as the name of a channel pattern. If you specify a label that already exists, an error message is generated that indicates a parameter error and channel that that is already associated the specified label.

For example, channel one on slot 4 has a label of *start*. If you send `channel.setlabel("5001", "start")`, the error message "1115, Parameter error label already used with channel 4001" is generated.

To clear the label, set *label* to an empty string ("") or to a string with a space as the first character.

After defining a label, you can use it to specify the channel instead of using the channel specifier.

An error is generated if:

- The card in the channel slot does not support a label setting
- The label contains a space; however, if the first character is a space, the label is cleared
- The label is already used to represent a channel pattern

The label does not persist through a power cycle.

Example 1

```
channel.setlabel("3001", "start")
channel.close("start")
print(channel.getclose("allslots"))
```

Sets the label for channel 1 on slot 3 to "start" and closes "start".

Output:
3001

Example 2

```
channel.setlabel("3001", "")
```

Clears the label for channel 1 on slot 3 back to "3001".

Example 3

```
channel.setlabel("3001", " ")
```

Also clears the label for channel 1 slot 3 back to "3001".

Also see

Channel list notation
channel functions and attributes

channel.setmatch()

This function sets the match value on a channel.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Instrument reset Channel reset Recall setup	Create configuration script Save setup	0

Usage

```
channel.setmatch(channelList, matchValue)
channel.setmatch(channelList, matchValue, mask)
channel.setmatch(channelList, matchValue, mask, width)
```

<i>channelList</i>	String that specifies the channels to query, using normal channel list syntax
<i>matchValue</i>	Channel value to compare on the specified channel
<i>mask</i>	Value to specify the bits used to mask <i>matchValue</i>
<i>width</i>	Value that specifies matches over multiple consecutive channels (default 1)

Details

A bitwise AND operation is performed on *mask* and *matchValue* to determine the final match value used on the channel.

The default mask is `channel.ALL` (all bits).

For digital I/O channels, a *width* of 1, 2, 3, or 4 channels is supported. Any bits greater than the specified *width* are ignored. If a *width* crosses channels, the match status indicator is only on the channel specified in the match value. For example, setting a value with a 2 *width* on channel 3 drives the indicator on channel 3, not channel 4. Match values for output channels are ignored.

Totalizer and DAC channels only support a *width* of 1, and *mask* is ignored.

Switch and backplane channels are not supported. If they are included in a range or slot specifier, they are ignored. If they are specified directly, an error is generated.

Example 1

```
channel.setmatchtype("1001",
    channel.MATCH_EXACT)
channel.setmatch("1001", 32)
```

Generates a match state event on bit B6 of digital I/O channel 1, assuming a Model 3750.

Example 2

```
channel.setmatchtype("6007", channel.MATCH_EXACT)
channel.setmatch("6007", 300)
```

Assuming a model 3750, configure the totalizer channel 7 on slot 6 to generate a match state event when it reaches 300.

Also see

[channel.getmatch\(\)](#) (on page 8-70)

channel.setmatchtype()

This function sets the match type on a channel.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Instrument reset Channel reset Recall setup	Create configuration script Save setup	4 (channel.MATCH_NONE)

Usage

```
channel.setmatchtype(channelList, type)
```

<i>channelList</i>	String specifying the channels to set, using normal channel list syntax
<i>type</i>	A value for setting the match operation used on this specific channel

Details

There are four types of match values:

- `channel.MATCH_EXACT` or 1
- `channel.MATCH_ANY` or 2
- `channel.MATCH_NOT_EXACT` or 3
- `channel.MATCH_NONE` or 4

For an EXACT match, the state match indicator only becomes TRUE when the match value AND match mask value EQUAL the channel read value.

For an ANY match, the state match indicator only becomes TRUE when the match value OR match mask value EQUAL the channel read value.

For a NOT_EXACT match, the state match indicator only becomes TRUE when the match value AND match mask value AND channel read value are NOT EQUAL to the match value AND match mask value AND last channel read value. In other words, the match value should be the current value, and if the value changes at all away from the original value, then a match is declared.

For NONE, matching is effectively disabled. This is the default.

For totalizer channels, only `MATCH_EXACT` and `MATCH_NONE` are supported.

This command is not supported on DAC, backplane, and switch channels.

Example

```
channel.setmatchtype("1001", channel.MATCH_EXACT)
```

Assuming a Model 3750, defines the match type for digital I/O channel 1 to be a `MATCH_EXACT` type.

Also see

[channel.getmatchtype\(\)](#) (on page 8-71)

channel.setmode()

This function sets the mode attribute on a channel.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Instrument reset Channel reset Recall setup	Create configuration script Save setup	Digital I/O: 0 (channel.MODE_INPUT) Totalizer: 3 (channel.MODE_RISING_TTL_EDGE) DAC: 49 (channel.MODE_PROTECT_VOLTAGE_1)

Usage

```
channel.setmode(channelList, mode)
```

<i>channelList</i>	String specifying the channels to set, using normal channel list syntax
<i>mode</i>	The value that sets the mode of a channel's operation

Details

Different channel types contain additional configurable settings. These settings are grouped together by channel type as described in the following paragraphs.

For digital I/O channels, the mode indicates the direction of the channel (input or output). The following modes are supported:

- `channel.MODE_INPUT` (default) or 0
- `channel.MODE_OUTPUT` or 1
- `channel.MODE_PROTECT_OUTPUT` or 3

For totalizer channels, the mode indicates the configuration of the channel (edge and reset). The following modes are supported:

- `channel.MODE_RISING_EDGE` or 1
- `channel.MODE_FALLING_EDGE` or 0
- `channel.MODE_RISING_TTL_EDGE` (default) or 3
- `channel.MODE_FALLING_TTL_EDGE` or 2
- `channel.MODE_RISING_EDGE_READ_RESET` or 5
- `channel.MODE_FALLING_EDGE_READ_RESET` or 4
- `channel.MODE_RISING_TTL_EDGE_READ_RESET` or 7
- `channel.MODE_FALLING_TTL_EDGE_READ_RESET` or 6

For DAC channels, the mode indicates the output of the channel (function and range). The output is switched off before any mode change is made, and remains off after the mode has changed. The following modes are supported:

- `channel.MODE_VOLTAGE_1` or 17
- `channel.MODE_CURRENT_1` or 1
- `channel.MODE_CURRENT_2` or 2
- `channel.MODE_PROTECT_VOLTAGE_1` (default) or 49
- `channel.MODE_PROTECT_CURRENT_1` or 33
- `channel.MODE_PROTECT_CURRENT_2` or 34

Changing the mode setting can impact the power consumption of the card. The instrument verifies that power is available before changing the mode. If an insufficient power capability exists, the command generates an error.

Consult the card-specific documentation for more detailed information on mode settings and functionality. For digital I/O channels, changing the mode from input to output or from output to input adds an additional channel delay (`channel.setdelay()`).

For switch and backplane channels, there is no valid mode setting. Setting a mode on a specific switch or backplane channel generates an error. If the switch or backplane channel is in the range of channels, the switch or backplane channel is ignored.

The specified channel list must use only one channel type. For example, channel list "1001:1004" is only valid if channels 1, 2, 3, and 4 are of the same type. If channel 3 is a different type of channel, the channel list is invalid and an error is generated.

Example

```
channel.setmode("6003:6005", channel.MODE_OUTPUT)
```

Assuming a Model 3750, set digital I/O channels 3 to 5 to be configured for output on slot 6, assuming a Model 3750.

```
channel.setmode("6007", channel.MODE_FALLING_TTL_EDGE)
```

Set the totalizer channel 7 on slot 6 to count the falling edges of a TTL signal.

Also see

[channel.setdelay\(\)](#) (on page 8-93)

channel.setoutputenable()

This function sets the output enable attribute on a channel.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Instrument reset Channel reset Recall setup	Create configuration script Save setup	0 (channel.OFF)

Usage

```
channel.setoutputenable(channelList, state)
```

<i>channelList</i>	String specifying the channels to set, using normal channel list syntax
<i>state</i>	A value representing the desired state of the channel's output

Details

For DAC channels, output enable indicates whether or not the DAC is driving the output. The following possible states are supported:

- `channel.ON`
- `channel.OFF` (default)

For DAC channels, changing the output state to ON adds an additional channel delay to `channel.setdelay()`.

Channels with output set to OFF consume less power.

Changing the output setting impacts the power consumption of the card. The instrument verifies that power is available before changing the mode. If there is insufficient power capability, the command generates an error. Consult the specific card documentation for information on a channel's output characteristics.

For switch, backplane, digital I/O, and totalizer channels, there is no valid output enable value. Setting output enable on a specific channel generates an error. If one of these channels is in the range of channels, the channel is ignored.

Example

```
channel.setoutputenable("1010",  
channel.OFF)
```

Assuming a Model 3750, turns the output off on the first DAC channel (channel 10) in slot 1.

Also see

[channel.getoutputenable\(\)](#) (on page 8-73)
[channel.setdelay\(\)](#) (on page 8-93)

channel.setpole()

This function specifies the pole setting for a list of channels.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Instrument reset Channel reset Recall setup	Create configuration script Save setup	Card dependent, but typically 2 (channel.POLES_TWO)

Usage

```
channel.setpole(channelList, value)
```

<i>channelList</i>	String that specifies a list of channels, using channel list notation
<i>value</i>	Desired pole setting for the channels in <i>channelList</i> . Use the following: <ul style="list-style-type: none"> For one-pole: channel.POLES_ONE or 1 For two-pole: channel.POLES_TWO or 2 For four-pole: channel.POLES_FOUR or 4

Details

The parameter string can contain `allslots` or `slotX`, where *X* equals 1 to 6.

Channel patterns do not have a pole setting associated with them. For channel patterns, the pole setting indicates if the paired channel should be used when the pattern is created and the analog backplane relays must be specified when creating the pattern (with `channel.pattern.setimage()` and `channel.pattern.snapshot()`). Channel patterns get deleted as the pole settings of the channels in the pattern image get changed.

You manipulate the analog backplane relays after setting the desired pole setting by using the `channel.setbackplane()` function for channels. For channels, as the pole setting changes, their analog backplane relays, specified by `channel.setbackplane()`, get cleared. Therefore, after a pole setting change, you need to add the desired analog backplane relays for the desired pole setting by using `channel.setbackplane()`.

When clearing the backplane channels, this can involve clearing the paired channel, whether pairing or unpairing channels. For example, on a 40-channel card, channels 1 and 21 are paired when the pole setting for channel 1 is set to 4. Therefore, when changing the pole setting on channel 1 to 4, the backplane channels for channels 1 and 21 are cleared. Likewise, they both are cleared when the pole setting is set back to 2 on channel 1.

Calling this function on an existing channel involved in scanning invalidates the existing scan list.

An error message is generated for the following reasons:

- An empty parameter string is specified.
- The value parameter is an invalid setting for the specified channel.
- The specified channel does not exist for the card installed in a slot.
- The channel is for an empty slot.
- The value parameter is invalid for command – parameter out of range error.
- A channel pattern or analog backplane relay was specified.

Command processing stops as soon as an error is detected and no pole settings are modified.

Example 1

```
channel.setpole("5001, 5003",  
channel.POLES_FOUR)
```

Sets channels 1 and 3 on slot 5 to four-pole.

Example 2

```

channel.reset("slot2")

channel.setpole("2001, 2003",
               channel.POLES_FOUR)
channel.close("2001, 2003")
print(channel.getclose("slot2"))

channel.open("slot2")

channel.setbackplane("2001", "2915")

channel.setbackplane("2003", "2925")

channel.close("2001, 2003")
print(channel.getclose("slot2"))

print(channel.getimage("2001, 2003"))

channel.open("slot2")
channel.setpole("slot2", 2)
print(channel.getimage("2001, 2003"))

```

Assuming a Model 3721, reset channels on slot 2 only.

Set channels 1 and 3 on slot 2 to 4-pole.

Close channels 1 and 3 on slot 2.

Query slot 2 for closed channels and analog backplane relays.

Output:

```
2001 (2021) ; 2003 (2023)
```

Note that the channels in parentheses are the paired channels because they are in a 4-pole configuration.

Open all channels and analog backplane relays on slot 2.

Associate analog backplane relay 5 in bank 1 of slot 2 with channel 1 on slot 2.

Associate analog backplane relay 5 in bank 2 of slot 2 with channel 3 on slot 2.

Close channels 1 and 3 on slot 2.

Query slot 2 for closed channels and analog backplane relays.

Output:

```
2001 (2021) ; 2003 (2023) ; 2915 ; 2925
```

Query for channels and analog backplane relays that are manipulated when open and close channels 1 and 3 on slot 2.

Output:

```
2001 (2021) , 2915 ; 2003 (2023) , 2925
```

Clear paired channels and analog backplane relays.

Output:

```
2001 ; 2003
```

Note that channels are no longer paired or have analog backplane relays associated with them.

Also see

[channel.getbackplane\(\)](#) (on page 8-59)

[channel.getpole\(\)](#) (on page 8-74)

[channel.pattern.setimage\(\)](#) (on page 8-83)

[channel.pattern.snapshot\(\)](#) (on page 8-85)

[channel.setbackplane\(\)](#) (on page 8-90)

channel.setpowerstate()

This function sets the power state on a channel.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Instrument reset Channel reset Recall setup	Create configuration script Save setup	Dependent on installed card, but usually 1 (channel.ON)

Usage

```
channel.setpowerstate(channelList, state)
```

<i>channelList</i>	String that specifies a list of channels, using channel list notation
<i>state</i>	<ul style="list-style-type: none"> channel.OFF or 0: Disable the power channel.ON or 1: Enable the power

Details

When a channel that was previously off is turned on, the channel attributes are reset to their default values (except the power state attribute).

Changing the output setting impacts the power consumption of the card. Channels with an off power state consume less power. Before enabling power, the instrument verifies that power is available before changing the state. If insufficient power capability exists, the command generates an error.

Consult the specific card documentation for information on a channel's power usage characteristics, including default state, possible warmup issues, especially for DAC channels, and effects on other channels.

When a channel with an off power state is used in a scan, results are undefined. No error notification is issued.

For switch, backplane, and digital I/O channels, there is no valid power state attribute. Setting the power state on a specific channel generates an error.

On some cards for totalizer channels, setting the power state of a single channel can affect the power state of other channels. If a single totalizer channel is turned on, all totalizer channels are reset to their defaults.

Example

```
channel.setpowerstate("1010", channel.ON)
```

Sets the power state for DAC channel 10 on the card in slot 1 to ON, assuming a Model 3750.

Also see

[channel.getpowerstate\(\)](#) (on page 8-75)

channel.setstatelatch()

This function sets the state indicators to either latching or nonlatching.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Instrument reset Channel reset Recall setup	Create configuration script Save setup	14 for overload, match, and overflow

Usage

```
channel.setstatelatch(channelList, stateLatchMask)
```

<i>channelList</i>	String that specifies a list of channels, using channel list notation
<i>stateLatchMask</i>	A value specifying the indicators to latch: <ul style="list-style-type: none"> channel.IND_MATCH or 4 channel.IND_OVERFLOW or 8 channel.IND_OVERLOAD or 2

Details

Applicable to digital I/O, totalizer, and DAC channels only.

Each indicator is represented by a bit in the mask.

For nonlatching applications, the state indicator clears automatically when the causing condition clears itself. For latching applications, the condition is cleared using the `channel.resetstatelatch()` command.

When using the trigger model, events are always nonlatching (or pulse oriented). However, in latching operation, the event is only generated once at the beginning. In nonlatching operation, the event is generated anytime the condition begins.

Set multiple states by performing a logical OR operation on the values.

Example 1

```
channel.setstatelatch("1001", channel.IND_MATCH)
```

Generate only a match state event on digital I/O channel 1 in slot 1, assuming a Model 3750.

Example 2

```
channel.setstatelatch("6010", bit.bitor(channel.IND_OVERFLOW,
channel.IND_OVERLOAD))
print(channel.getstatelatch("6010"))
```

Generate either an overflow or overload event on DAC channel 10 in slot 6, assuming a Model 3750.
Query for the state latch for channel 10 on slot 6.
Output:
10

Also see

[channel.getstate\(\)](#) (on page 8-76)
[channel.getstatelatch\(\)](#) (on page 8-78)
[channel.resetstatelatch\(\)](#) (on page 8-89)

channel.trigger[N].clear()

This function clears any pending events.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
channel.trigger[N].clear()
```

<i>N</i>	Number indicating the trigger line to clear (1 to 8)
----------	--

Details

This function clears any pending events for the channel trigger specified by *N*.

Example

```
channel.trigger[1].clear()
```

Clears any pending events on channel trigger 1

Also see

[channel.trigger\[N\].set\(\)](#) (on page 8-107)

channel.trigger[N].EVENT_ID

This constant indicates the trigger event generated by the channel trigger *N*.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Constant	Yes			

Usage

```
X = channel.trigger[N].EVENT_ID
```

<i>X</i>	The trigger event number
<i>N</i>	Number indicating the channel trigger event ID (1 to 8)

Example

```
scan.trigger.channel.stimulus = channel.trigger[1].EVENT_ID
```

Use channel trigger 1 events to pace the channel action of the scanning or set the trigger stimulus of the channel event detector to channel trigger 1.

Also see

[channel.trigger\[N\].set\(\)](#) (on page 8-107)

channel.trigger[N].get()

This function gets the channel status trigger information that is used to watch the state of a specific channel.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Instrument reset Channel reset Recall setup	Create configuration script Save setup	Empty channel list State match 0

Usage

```
channelList, stateMatch = channel.trigger[N].get()
```

<i>channelList</i>	Returns a string specifying the channels watched by this trigger
<i>stateMatch</i>	Returns a value specifying the state to match when triggering an event
<i>N</i>	Number indicating the channel trigger to get (1 to 8)

Details

This command works for DAC, digital I/O and totalizer channels. Switch channels are not supported.

Example

```
channel.trigger[1].set("1010", channel.IND_MATCH)
chan_list, state_match = channel.trigger[1].get()
print(chan_list, state_match)
```

Assuming a Model 3750, defines channel trigger event 1 to occur when totalizer channel 10 matches its defined match value.
Query for the channels and state conditions associated with channel trigger 1.
Output:
1010 4.000000000e+00

Example

```
channel.trigger[5].set("6003, 6005",
channel.IND_MATCH)
print(channel.trigger[5].get())
```

Assuming a Model 3750 card, define a channel trigger event 5 to occur when either digital I/O channel 3 or 5 on slot 6 match their defined values.
View the trigger information associated with channel trigger 5.
Output:
6003, 6005
4.000000000e+00

Also see

[channel.trigger\[N\].set\(\)](#) (on page 8-107)

channel.trigger[N].set()

This function sets the channel status trigger model to watch the state of a specific channel.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Instrument reset Channel reset Recall setup	Create configuration script Save setup	Empty channel list State match 0

Usage

```
channel.trigger[N].set(channelList, stateMatch)
```

<i>channelList</i>	String that specifies a list of channels, using channel list notation
<i>stateMatch</i>	Value specifying the status to match when triggering an event
<i>N</i>	Number indicating the channel trigger to set (1 to 8)

Details

If the channel list contains more than one channel, the trigger acts as a logical OR. When any one of the channels in the list matches the desired state, a trigger event is generated. Therefore, if an indicator is present in both the match and the actual state, an event is triggered. If the match contains more than one state indicator, only one of those indicators needs to be present to trigger the event.

There are a total of eight channel trigger events per TSP, defined by *N*. Using this mechanism, a trigger can be generated when a pattern is matched on an I/O, a totalizer matches a defined count, or an I/O has an overcurrent condition.

Latching functionality is not supported.

This command works for DAC, digital I/O and totalizer channels. Switch channels are not supported.

To clear a trigger that is no longer needed, pass an empty channel list (" " or " ").

Example 1

```
channel.trigger[1].set("1001", channel.IND_MATCH)
```

Assuming a Model 3750, defines a channel trigger event 1 to occur when digital I/O channel 1 matches its defined match value.

Example 2

```
channel.trigger[5].set("6003, 6005",
channel.IND_MATCH)
print(channel.trigger[5].get())

channel.trigger[5].set(" ", channel.IND_MATCH)
print(channel.trigger[5].get())
```

Assuming a Model 3750 card, define a channel trigger event 5 to occur when either digital I/O channel 3 or 5 on slot 6 match their defined values.

View the trigger information associated with channel trigger 5.
Clear the trigger information associated with channel trigger 5.
View the trigger information associated with channel trigger 5.

Output:

```
6003,6005
 4.000000000e+000
 0.000000000e+000
```

Also see

[channel.trigger\[N\].get\(\)](#) (on page 8-106)

channel.trigger[N].wait()

This function waits for the desired trigger or timeout period, whichever comes first.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
triggered = channel.trigger[N].wait(timeout)
```

<i>triggered</i>	Returns an indication that a trigger occurred
<i>N</i>	Number indicating the channel trigger to wait for (1 to 8)
<i>timeout</i>	The number of seconds to wait

Details

If one or more trigger events were detected since the last time `channel.trigger[N].wait` or `channel.trigger[N].clear` was called, this function returns immediately.

After waiting for a trigger with this function, the event detector is automatically reset and rearmed. This is true regardless of the number of events detected.

The value for `timeout` must be greater than zero and less than 10,000.

Example

```
channel.trigger[1].wait(5)
```

Wait 5 seconds for channel trigger event 1 to occur or timeout if trigger event is not detected in 5 seconds.

Also see

None

channel.write()

This function writes a value to a channel.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
channel.write(channelList, value)
channel.write(channelList, value, width)
```

<i>channelList</i>	String that specifies a list of channels, using channel list notation
<i>value</i>	The value to be written to the channel (must be decimal value)
<i>width</i>	Value that specifies the channel width of the write

Details

For widths greater than 1, the specified channel occupies the least significant byte. For example, writing the value of 4278255360 (hexadecimal FF00FF00) to channel 1 with a width of 4 sets channel 1 to 0, channel 2 to 255 (hexadecimal FF), channel 3 to 0, and channel 4 to 255 (hexadecimal FF). Writing the value of 4278255360 to channel 1 with a width of 1 sets channel 1 to 0 and leaves other channels untouched.

NOTE

You must use decimal values when sending commands to the TSP.

For digital I/O channels, only widths of 1, 2, 3, or 4 are supported. All other widths are ignored. Values written to inputs are ignored. If no specified channel is set for output, then an error is generated. If a width crosses channels, then only the channels set to output are affected.

Totalizers, DACs, and switch channels do not support a width other than 1. Specifying a width greater than 1 results in an error.

For a channel with a power state of `OFF`, an error is generated. No action is taken on any channel in the specified channel list.

For DAC channels, the value is expected to be the desired floating point voltage or current. Also, an error is generated if the value is out of range. No action is taken on any channel in the specified channel list.

For digital I/O channels, the value becomes the settings of the digital output.

For totalizer channels, the value becomes the new current totalizer count.

The time it takes to execute the write command is affected by the channel delay setting.

Example

```
channel.write("1001", 33)
channel.write("1006", 0)
```

Output a value of 33 to digital I/O channel 1.
Set totalizer channel 6 on slot 1 (assuming a Model 3750 card) to 0.

Also see

None

comm.gpib.enable

This attribute describes whether or not communication using the GPIB connection is enabled.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Not applicable	Nonvolatile memory	true (enabled)

Usage

```
state = comm.gpib.enable
comm.gpib.enable = state
```

<i>state</i>	true: Enabled false: Disabled
--------------	----------------------------------

Details

This performs the same function as the **MENU > GPIB > ENABLE** option that is available through the front panel of the instrument.

Also see

[Set the GPIB address](#) (on page 2-60)

comm.lan.enable

This attribute controls whether or not any communication using the LAN connection is enabled.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Not applicable	Nonvolatile memory	true (enabled)

Usage

```
state = comm.lan.enable
comm.lan.enable = state
```

<i>state</i>	true: Enabled false: Disabled
--------------	----------------------------------

Details

This is the master control setting. When this is true (enabled), you may individually control web, Telnet, VXI-11 and raw socket access to the instrument. However, when this is false (disabled), all LAN communication is disabled and this overrides the individual LAN enabled settings.

To disable only certain LAN communication with the instrument, enable this attribute and set the specific LAN communication attribute to false for raw sockets, Telnet, VXI-11 or web.

Example

```
comm.lan.enable = false
```

Disable all LAN communication with instrument.

Also see

[comm.lan.rawsockets.enable](#) (on page 8-111)

[comm.lan.telnet.enable](#) (on page 8-112)

[comm.lan.vxi11.enable](#) (on page 8-113)

[comm.lan.web.enable](#) (on page 8-114)

comm.lan.rawsockets.enable

This attribute describes whether or not communication using raw socket is enabled.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Not applicable	Nonvolatile memory	true (enabled)

Usage

```
state = comm.lan.rawsockets.enable
comm.lan.rawsockets.enable = state
```

<i>state</i>	true: Enabled false: Disabled
--------------	----------------------------------

Details

This performs the same function as the **MENU > LAN > ENABLE > RAW** option available through the front panel of the instrument.

Example

```
comm.lan.enable = true
comm.lan.rawsockets.enable = false
```

Enable all LAN communication with instrument, then disable only raw sockets over the LAN.

Also see

[comm.lan.enable](#) (on page 8-110)
[comm.lan.telnet.enable](#) (on page 8-112)
[comm.lan.vxi11.enable](#) (on page 8-113)
[comm.lan.web.enable](#) (on page 8-114)
[lan.status.port.rawsocket](#) (on page 8-281)
 Raw socket connection

comm.lan.telnet.enable

This attribute describes whether or not communication using Telnet is enabled.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Not applicable	Nonvolatile memory	true (enabled)

Usage

```
state = comm.lan.telnet.enable
comm.lan.telnet.enable = state
```

<i>state</i>	true: Enabled false: Disabled
--------------	----------------------------------

Details

This performs the same function as the **MENU > LAN > ENABLE > TELNET** option that is available through the front panel of the instrument.

Example

```
comm.lan.enable = true
comm.lan.telnet.enable = false
```

Enable all LAN communication with instrument, then disable only Telnet over the LAN.

Also see

[comm.lan.enable](#) (on page 8-110)
[comm.lan.rawsockets.enable](#) (on page 8-111)
[comm.lan.vxi11.enable](#) (on page 8-113)
[comm.lan.web.enable](#) (on page 8-114)
[lan.status.port.telnet](#) (on page 8-281)
 Telnet connection

comm.lan.vxi11.enable

This attribute describes whether or not communication using a VXI-11 connection is enabled.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Not applicable	Nonvolatile memory	true (enabled)

Usage

```
state = comm.lan.vxi11.enable
comm.lan.vxi11.enable = state
```

<i>state</i>	true: Enabled false: Disabled
--------------	----------------------------------

Details

This performs the same function as the **MENU > LAN > ENABLE > VXI11** option that is available through the front panel of the instrument.

Example

```
comm.lan.enable = true
comm.lan.vxi11.enable = false
```

Enable all LAN communication with instrument, then disable only VXI-11 over the LAN.

Also see

[comm.lan.enable](#) (on page 8-110)
[comm.lan.rawsockets.enable](#) (on page 8-111)
[comm.lan.telnet.enable](#) (on page 8-112)
[comm.lan.web.enable](#) (on page 8-114)
[lan.status.port.vxi11](#) (on page 8-282)
 VXI-11 connection

comm.lan.web.enable

This attribute describes whether or not communication using the web interface is enabled.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Not applicable	Nonvolatile memory	true (enabled)

Usage

```
state = comm.lan.web.enable
comm.lan.web.enable = state
```

<i>state</i>	true: Enabled false: Disabled
--------------	----------------------------------

Details

This performs the same function as the **MENU > LAN > ENABLE > WEB** option that is available through the front panel of the instrument.

Example

```
comm.lan.enable = true
comm.lan.web.enable = false
```

Enable all LAN communication with instrument, then disable only web communication over the LAN.

Also see

[comm.lan.enable](#) (on page 8-110)
[comm.lan.rawsockets.enable](#) (on page 8-111)
[comm.lan.telnet.enable](#) (on page 8-112)
[comm.lan.vxi11.enable](#) (on page 8-113)
 Web connection

createconfigscript()

This function captures the present settings of the instrument.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
createconfigscript (scriptVar)
```

<i>scriptVar</i>	The name of the script that will be created
------------------	---

Details

If *scriptVar* is set to `autoexec`, the `autoexec` script in the instrument will be replaced by the new configuration script.

If *scriptVar* is set to the name of an existing script, the existing script will be overwritten.

Once created, the configuration script can be run and edited like any other script.

Example

<code>createconfigscript("August2010")</code>	Captures the present settings of the instrument into a script named <code>August2010</code> .
---	---

Also see

[Create a configuration script](#) (on page 2-102)
[Save the present configuration](#) (on page 2-100)

dataqueue.add()

This function adds an entry to the data queue.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
result = dataqueue.add(value)
result = dataqueue.add(value, timeout)
```

<i>result</i>	The resulting value of <code>true</code> or <code>false</code> based on the success of the function
<i>value</i>	The data item to add; <i>value</i> can be of any type
<i>timeout</i>	The maximum number of seconds to wait for space in the data queue

Details

You cannot use the *timeout* value when accessing the data queue from a remote node (you can only use the *timeout* value while adding data to the local data queue).

The *timeout* value is ignored if the data queue is not full.

The `dataqueue.add()` function returns `false`:

- If the timeout expires before space is available in the data queue
- If the data queue is full and a *timeout* value is not specified

If the value is a table, a duplicate of the table and any subtables is made. The duplicate table does not contain any references to the original table or to any subtables.

Example

```

dataqueue.clear()
dataqueue.add(10)
dataqueue.add(11, 2)
result = dataqueue.add(12, 3)
if result == false then
    print("Failed to add 12 to the dataqueue")
end
print("The dataqueue contains:")
while dataqueue.count > 0 do
    print(dataqueue.next())
end

```

Clear the data queue.

Each line adds one item to the data queue.

Output:

```

The dataqueue contains:
1.00000e+01
1.10000e+01
1.20000e+01

```

Also see

[dataqueue.CAPACITY](#) (on page 8-116)

[dataqueue.clear\(\)](#) (on page 8-117)

[dataqueue.count](#) (on page 8-117)

[dataqueue.next\(\)](#) (on page 8-118)

dataqueue.CAPACITY

This constant is the maximum number of entries that you can store in the data queue.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Constant	Yes			

Usage

```
count = dataqueue.CAPACITY
```

<i>count</i>	The variable assigned the value of dataqueue.CAPACITY
--------------	---

Details

This constant always returns the maximum number of entries that can be stored in the data queue.

Example

```

MaxCount = dataqueue.CAPACITY
while dataqueue.count < MaxCount do
    dataqueue.add(1)
end
print("There are " .. dataqueue.count
    .. " items in the data queue")

```

Add items to the data queue until it is at capacity.

Output:

```

There are 128 items in the data
queue

```

Also see

[dataqueue.add\(\)](#) (on page 8-115)

[dataqueue.clear\(\)](#) (on page 8-117)

[dataqueue.count](#) (on page 8-117)

[dataqueue.next\(\)](#) (on page 8-118)

dataqueue.clear()

This function clears the data queue.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
dataqueue.clear()
```

Details

This function forces all `dataqueue.add()` commands that are in progress to time out. The function deletes all data from the data queue.

Example

```
MaxCount = dataqueue.CAPACITY
while dataqueue.count < MaxCount do
  dataqueue.add(1)
end
print("There are " .. dataqueue.count
  .. " items in the data queue")
dataqueue.clear()
print("There are " .. dataqueue.count
  .. " items in the data queue")
```

This example fills the data queue and prints the number of items in the queue. It then clears the queue and prints the number of items again.

Output:

```
There are 128 items in the data
queue
There are 0 items in the data queue
```

Also see

[dataqueue.add\(\)](#) (on page 8-115)
[dataqueue.CAPACITY](#) (on page 8-116)
[dataqueue.count](#) (on page 8-117)
[dataqueue.next\(\)](#) (on page 8-118)

dataqueue.count

This attribute contains the number of items in the data queue.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Power cycle	Not saved	Not applicable

Usage

```
count = dataqueue.count
```

<code>count</code>	The number of items in the data queue
--------------------	---------------------------------------

Details

The count gets updated as entries are added with `dataqueue.add()` and read from the data queue with `dataqueue.next()`. It is also updated when the `dataqueue` is cleared with `dataqueue.clear()`.

A maximum of `dataqueue.CAPACITY` items can be stored at any one time in the data queue.

Example

```

MaxCount = dataqueue.CAPACITY
while dataqueue.count < MaxCount do
  dataqueue.add(1)
end
print("There are " .. dataqueue.count
  .. " items in the data queue")
dataqueue.clear()
print("There are " .. dataqueue.count
  .. " items in the data queue")

```

Add items to the data queue until it is at capacity.

Output:

```

There are 128 items in the data queue
There are 0 items in the data queue

```

Also see

[dataqueue.add\(\)](#) (on page 8-115)
[dataqueue.CAPACITY](#) (on page 8-116)
[dataqueue.clear\(\)](#) (on page 8-117)
[dataqueue.next\(\)](#) (on page 8-118)

dataqueue.next()

This function removes the next entry from the data queue.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```

value = dataqueue.next()
value = dataqueue.next(timeout)

```

<i>value</i>	The next entry in the data queue
<i>timeout</i>	The number of seconds to wait for data in the queue

Details

If the data queue is empty, the function waits up to the *timeout* value.

If data is not available in the data queue before the *timeout* expires, the return value is `nil`.

The entries in the data queue are removed in first-in, first-out (FIFO) order.

If the value is a table, a duplicate of the original table and any subtables is made. The duplicate table does not contain any references to the original table or to any subtables.

Example

```

dataqueue.clear()
for i = 1, 10 do
    dataqueue.add(i)
end
print("There are " .. dataqueue.count
    .. " items in the data queue")

while dataqueue.count > 0 do
    x = dataqueue.next()
    print(x)
end
print("There are " .. dataqueue.count
    .. " items in the data queue")

```

Clears the data queue, adds ten entries, then reads the entries from the data queue.

Output:

```

There are 10 items in the data
queue
1.000000000e+00
2.000000000e+00
3.000000000e+00
4.000000000e+00
5.000000000e+00
6.000000000e+00
7.000000000e+00
8.000000000e+00
9.000000000e+00
1.000000000e+01
There are 0 items in the data queue

```

Also see

[dataqueue.add\(\)](#) (on page 8-115)
[dataqueue.CAPACITY](#) (on page 8-116)
[dataqueue.clear\(\)](#) (on page 8-117)
[dataqueue.count](#) (on page 8-117)

delay()

This function delays the execution of the commands that follow it.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

`delay(seconds)`

<i>seconds</i>	The number of seconds to delay, maximum 100,000
----------------	---

Details

You cannot set a delay for zero seconds.

The system delays execution of the commands for at least the specified number of seconds and fractional seconds. However, the processing time may cause the system to delay 5 μ s to 10 μ s (typical) more than the requested delay.

Example 1

```

beeper.beep(0.5, 2400)
delay(0.250)
beeper.beep(0.5, 2400)

```

Emit a double-beep at 2400 Hz. The sequence is 0.5 s on, 0.25 s off, 0.5 s on.

Example 2

```
dataqueue.clear()
dataqueue.add(35)
timer.reset()
delay(0.5)
dt = timer.measure.t()
print("Delay time was " .. dt)
print(dataqueue.next())
```

Clear the data queue, add 35 to it, then delay 0.5 seconds before reading it.

Output:

```
Delay time was 0.500099
3.500000000e+01
```

Also see

None

digio.readbit()

This function reads one digital I/O line.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
data = digio.readbit(N)
```

<i>data</i>	A custom variable that stores the state of the I/O line
<i>N</i>	Digital I/O line number to be read (1 to 14)

Details

A returned value of zero (0) indicates that the line is low. A returned value of one (1) indicates that the line is high.

Example

```
print(digio.readbit(4))
```

Assume line 4 is set high, and it is then read.

Output:

```
1.00000e+00
```

Also see

[Digital I/O port](#) (on page 2-29, on page 3-42)
[digio.readport\(\)](#) (on page 8-120)
[digio.writebit\(\)](#) (on page 8-130)
[digio.writeport\(\)](#) (on page 8-130)

digio.readport()

This function reads the digital I/O port.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
data = digio.readport()
```

<code>data</code>	The present value of the input lines on the digital I/O port
-------------------	--

Details

The binary equivalent of the returned value indicates the value of the input lines on the I/O port. The least significant bit (bit B1) of the binary number corresponds to line 1; bit B14 corresponds to line 14.

For example, a returned value of 170 has a binary equivalent of 000000010101010, which indicates that lines 2, 4, 6, and 8 are high (1), and the other 10 lines are low (0).

Example

```
data = digio.readport()
print(data)
```

Assume lines 2, 4, 6, and 8 are set high when the I/O port is read.

Output:

```
1.70000e+02
```

This is binary 10101010

Also see

[Digital I/O port](#) (on page 2-29, on page 3-42)

[digio.readbit\(\)](#) (on page 8-120)

[digio.writebit\(\)](#) (on page 8-130)

[digio.writeport\(\)](#) (on page 8-130)

digio.trigger[N].assert()

This function asserts a trigger on one of the digital I/O lines.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
digio.trigger[N].assert()
```

<code>N</code>	Digital I/O trigger line (1 to 14)
----------------	------------------------------------

Details

The set pulsewidth determines how long the trigger is asserted.

Example

```
digio.trigger[2].assert()
```

Asserts a trigger on digital I/O line 2.

Also see

[digio.trigger\[N\].pulsewidth](#) (on page 8-125)

digio.trigger[N].clear()

This function clears the trigger event on a digital I/O line.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
digio.trigger[N].clear()
```

<i>N</i>	Digital I/O trigger line (1 to 14)
----------	------------------------------------

Details

The event detector of a trigger recalls if a trigger event has been detected since the last `digio.trigger[N].wait()` command. This function clears the event detector of the specified trigger line, discards the previous history of the trigger line, and clears the `digio.trigger[N].overrun` attribute.

Example

<code>digio.trigger[2].clear()</code>	Clears the trigger event detector on I/O line 2.
---------------------------------------	--

Also see

[digio.trigger\[N\].overrun](#) (on page 8-124)

[digio.trigger\[N\].wait\(\)](#) (on page 8-129)

digio.trigger[N].EVENT_ID

This constant identifies the trigger event generated by the digital I/O line *N*.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Constant	Yes			

Usage

```
eventID = digio.trigger[N].EVENT_ID
```

<i>eventID</i>	The trigger event number
----------------	--------------------------

<i>N</i>	Digital I/O trigger line (1 to 14)
----------	------------------------------------

Details

To have another trigger object respond to trigger events generated by the trigger line, set the other object's stimulus attribute to the value of this constant.

Example 1

<code>digio.trigger[5].stimulus = digio.trigger[3].EVENT_ID</code>	Uses a trigger event on digital I/O trigger line 3 to be the stimulus for digital I/O trigger line 5.
--	---

Example 2

```
scan.trigger.arm.stimulus =
    digio.trigger[3].EVENT_ID
```

Uses a trigger event on digital I/O trigger line 3 to be the stimulus for starting a scan.

Also see

None

digio.trigger[N].mode

This attribute sets the mode in which the trigger event detector and the output trigger generator operate on the given trigger line.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Instrument reset Digital I/O trigger <i>N</i> reset Recall setup	Create configuration script Save setup	0 (digio.TRIG_BYPASS)

Usage

```
triggerMode = digio.trigger[N].mode
digio.trigger[N].mode = triggerMode
```

<i>triggerMode</i>	The trigger mode; see Details for values
<i>N</i>	Digital I/O trigger line (1 to 14)

Details

Set *triggerMode* to one of the following values:

Trigger mode values	
<i>triggerMode</i>	Description
digio.TRIG_BYPASS or 0	Allows direct control of the line.
digio.TRIG_FALLING or 1	Detects falling-edge triggers as input; asserts a TTL-low pulse for output.
digio.TRIG_RISING or 2	If the programmed state of the line is high, the digio.TRIG_RISING mode behavior is similar to digio.TRIG_RISINGA. If the programmed state of the line is low, the digio.TRIG_RISING mode behavior is similar to digio.TRIG_RISINGM. This setting should only be used if necessary for compatibility with other Keithley Instruments products.
digio.TRIG_EITHER or 3	Detects rising- or falling-edge triggers as input. Asserts a TTL-low pulse for output.
digio.TRIG_SYNCHRONOUS or 4	Detects the falling-edge input triggers and automatically latches and drives the trigger line low. Asserting the output trigger releases the latched line.
digio.TRIG_SYNCHRONOUSM or 5	Detects the falling-edge input triggers and automatically latches and drives the trigger line low. Asserts a TTL-low pulse as an output trigger.
digio.TRIG_SYNCHRONOUSA or 6	Detects rising-edge triggers as input. Asserts a TTL-low pulse for output.
digio.TRIG_RISINGA or 7	Detects rising-edge triggers as input. Asserts a TTL-low pulse for output.
digio.TRIG_RISINGM or 8	Asserts a TTL-high pulse for output. Input edge detection is not possible in this mode.

When programmed to any mode except `digio.TRIG_BYPASS`, the output state of the I/O line is controlled by the trigger logic, and the user-specified output state of the line is ignored.

Use of either `digio.TRIG_SYNCHRONOUS` or `digio.TRIG_SYNCHRONOUSM` is preferred over `digio.TRIG_SYNCHRONOUS`, because `digio.TRIG_SYNCHRONOUS` is provided for compatibility with the digital I/O and TSP-Link triggering on other Keithley Instruments products.

To control the line state, set the mode to `digio.TRIG_BYPASS` and use the `digio.writebit()` and `digio.writeport()` commands.

Example

```
digio.trigger[4].mode = 2
```

Sets the trigger mode for I/O line 4 to `digio.TRIG_RISING`.

Also see

[digio.trigger\[N\].clear](#) (see "[digio.trigger\[N\].clear\(\)](#)" on page 8-122)

[digio.trigger\[N\].reset\(\)](#) (on page 8-126)

[digio.writebit\(\)](#) (on page 8-130)

[digio.writeport\(\)](#) (on page 8-130)

[Scanning and triggering](#) (on page 3-1)

digio.trigger[N].overrun

Use this attribute to read the event detector overrun status.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Instrument reset Digital I/O trigger <i>N</i> clear Digital I/O trigger <i>N</i> reset Recall setup	Not saved	Not applicable

Usage

```
overrun = digio.trigger[N].overrun
```

<code>overrun</code>	Trigger overrun state (<code>true</code> or <code>false</code>)
----------------------	---

<code>N</code>	Digital I/O trigger line (1 to 14)
----------------	------------------------------------

Details

If this is `true`, an event was ignored because the event detector was already in the detected state when the event occurred.

This is an indication of the state of the event detector built into the line itself. It does not indicate if an overrun occurred in any other part of the trigger model or in any other detector that is monitoring the event.

Example

```
overrun = digio.trigger[1].overrun
print(overrun)
```

If there is no trigger overrun, the following text is output:
`false`

Also see

[digio.trigger\[N\].clear\(\)](#) (on page 8-122)

[digio.trigger\[N\].reset\(\)](#) (on page 8-126)

digio.trigger[N].pulsewidth

This attribute describes the length of time that the trigger line is asserted for output triggers.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Instrument reset Digital I/O trigger <i>N</i> reset Recall setup	Create configuration script Save setup	10e-6 (10 μ s) digital I/O lines 1 through 9 20 μ s digital I/O Lines 10 through 14

Usage

```
width = digio.trigger[N].pulsewidth
digio.trigger[N].pulsewidth = width
```

<i>width</i>	The pulse width (seconds)
<i>N</i>	Digital I/O trigger line (1 to 14)

Details

Setting *width* to zero (0) seconds asserts the trigger indefinitely. To release the trigger line, use `digio.trigger[N].release()`.

Example

```
digio.trigger[4].pulsewidth = 20e-6
```

Sets the pulse width for trigger line 4 to 20 μ s.

Also see

[digio.trigger\[N\].assert\(\)](#) (on page 8-121)
[digio.trigger\[N\].reset\(\)](#) (on page 8-126)
[digio.trigger\[N\].release\(\)](#) (on page 8-125)

digio.trigger[N].release()

This function releases an indefinite length or latched trigger.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
digio.trigger[N].release()
```

<i>N</i>	Digital I/O trigger line (1 to 14)
----------	------------------------------------

Details

Releases a trigger that was asserted with an indefinite pulse width time, as well as a trigger that was latched in response to receiving a synchronous mode trigger. Only the specified trigger line (*N*) is affected.

Example

```
digio.trigger[4].release()
```

Releases digital I/O trigger line 4.

Also see

[digio.trigger\[N\].pulsewidth](#) (on page 8-125)

digio.trigger[N].reset()

This function resets trigger values to their factory defaults.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
digio.trigger[N].reset()
```

<i>N</i>	Digital I/O trigger line (1 to 14)
----------	------------------------------------

Details

This function resets the following attributes to factory default settings:

- `digio.trigger[N].mode`
- `digio.trigger[N].pulsewidth`
- `digio.trigger[N].stimulus`

It also clears `digio.trigger[N].overrun`.

Example

```
digio.trigger[3].mode = 2
digio.trigger[3].pulsewidth = 50e-6
digio.trigger[3].stimulus = digio.trigger[5].EVENT_ID
print(digio.trigger[3].mode,
      digio.trigger[3].pulsewidth,digio.trigger[3].stimulus)
digio.trigger[3].reset()
print(digio.trigger[3].mode,
      digio.trigger[3].pulsewidth,digio.trigger[3].stimulus)
```

Set the digital I/O trigger line 3 for a falling edge with a pulse with of 50 microseconds.

Use digital I/O line 5 to trigger the event on line 3.

Reset the line back to factory default values.

Output before reset:

```
2.00000e+00      5.00000e-05      5.00000e+00
```

Output after reset:

```
0.00000e+00      1.00000e-05      0.00000e+00
```

Also see

[digio.trigger\[N\].mode](#) (on page 8-123)

[digio.trigger\[N\].overrun](#) (on page 8-124)

[digio.trigger\[N\].pulsewidth](#) (on page 8-125)

[digio.trigger\[N\].stimulus](#) (on page 8-127)

digio.trigger[N].stimulus

This attribute selects the event that causes a trigger to be asserted on the digital output line.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Instrument reset Digital I/O trigger <i>N</i> reset Save setup	Create configuration script Save setup	0

Usage

```
triggerStimulus = digio.trigger[N].stimulus
digio.trigger[N].stimulus = triggerStimulus
```

<i>triggerStimulus</i>	The event identifier for the triggering event
<i>N</i>	Digital I/O trigger line (1 to 14)

Details

Set this attribute to zero (0) to disable the automatic trigger output.

Do not use the stimulus attribute for generating output triggers under script control. Use `digio.trigger[N].assert()` instead.

The trigger stimulus for a digital I/O line may be set to one of the existing trigger event IDs, described in the following table.

Trigger event IDs	
Trigger event ID	Description
<code>channel.trigger[N].EVENT_ID</code>	A channel trigger event starts the scan.
<code>digio.trigger[N].EVENT_ID</code>	An edge (either rising, falling, or either based on the configuration of the line) on the digital input line.
<code>display.trigger.EVENT_ID</code>	The trigger key on the front panel is pressed.
<code>dmm.trigger.EVENT_LIMIT1_HIGH</code>	A DMM trigger event that indicates a measurement has exceed the high limit value on limit 1.
<code>dmm.trigger.EVENT_LIMIT1_LOW</code>	A DMM trigger event that indicates a measurement has exceed the low limit value on limit 1.
<code>dmm.trigger.EVENT_LIMIT2_HIGH</code>	A DMM trigger event that indicates a measurement has exceed the high limit value on limit 2.
<code>dmm.trigger.EVENT_LIMIT2_LOW</code>	A DMM trigger event that indicates a measurement has exceed the low limit value on limit 2.
<code>trigger.EVENT_ID</code>	A *trg message on the active command interface. If GPIB is the active command interface, a GET message also generates this event.
<code>trigger.blender[N].EVENT_ID</code>	A combination of events has occurred.
<code>trigger.timer[N].EVENT_ID</code>	A delay expired.
<code>tsplink.trigger[N].EVENT_ID</code>	An edge (either rising, falling, or either based on the configuration of the line) on the TSP-Link trigger line.
<code>lan.trigger[N].EVENT_ID</code>	A LAN trigger event has occurred.
<code>scan.trigger.EVENT_SCAN_READY</code>	Scan ready event.
<code>scan.trigger.EVENT_SCAN_START</code>	Scan start event.
<code>scan.trigger.EVENT_CHANNEL_READY</code>	Channel ready event.
<code>scan.trigger.EVENT_MEASURE_COMP</code>	Measure complete event.
<code>scan.trigger.EVENT_SEQUENCE_COMP</code>	Sequence complete event.
<code>scan.trigger.EVENT_SCAN_COMP</code>	Scan complete event.
<code>scan.trigger.EVENT_IDLE</code>	Idle event.
<code>schedule.alarm[N].EVENT_ID</code>	A scan starts when alarm <i>N</i> fires.

Example 1

```
digio.trigger[3].stimulus = 0
```

Clear the trigger stimulus of digital I/O line 3.

Example 2

```
digio.trigger[3].stimulus =
  scan.trigger.EVENT_CHANNEL_READY
```

Set the trigger stimulus of digital I/O line 3 to be the channel ready event during a scan.

Also see

[digio.trigger\[N\].assert\(\)](#) (on page 8-121)
[digio.trigger\[N\].clear\(\)](#) (on page 8-122)
[digio.trigger\[N\].reset\(\)](#) (on page 8-126)

digio.trigger[N].wait()

This function waits for a trigger.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
triggered = digio.trigger[N].wait(timeout)
```

<i>triggered</i>	The value <code>true</code> if a trigger is detected, or <code>false</code> if no triggers are detected during the timeout period
<i>N</i>	Digital I/O trigger line (1 to 14)
<i>timeout</i>	Timeout in seconds

Details

This function pauses for up to *timeout* seconds for an input trigger. If one or more trigger events are detected since the last time `digio.trigger[N].wait()` or `digio.trigger[N].clear()` was called, this function returns a value immediately. After waiting for a trigger with this function, the event detector is automatically reset and ready to detect the next trigger. This is true regardless of the number of events detected.

Example

```
triggered = digio.trigger[4].wait(3)
print(triggered)
```

Waits up to three seconds for a trigger to be detected on trigger line 4, then outputs the results.

Output if no trigger is detected:
false

Output if a trigger is detected:
true

Also see

[digio.trigger\[N\].clear\(\)](#) (on page 8-122)

digio.writebit()

This function sets a digital I/O line high or low.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
digio.writebit(N, data)
```

<i>N</i>	Digital I/O trigger line (1 to 14)
<i>data</i>	The value to write to the bit: <ul style="list-style-type: none"> • 0 (low) • Non-zero (high)

Details

If the output line is write-protected using the `digio.writeprotect` attribute, the command is ignored.

The `reset()` function does not affect the present state of the digital I/O lines.

Use the `digio.writebit()` and `digio.writeport()` commands to control the output state of the synchronization line when trigger operation is set to `digio.TRIG_BYPASS`.

The data must be zero (0) to clear the bit. Any value other than zero (0) sets the bit.

Example

```
digio.writebit(4, 0) Sets digital I/O line 4 low (0).
```

Also see

[digio.readbit\(\)](#) (on page 8-120)
[digio.readport\(\)](#) (on page 8-120)
[digio.trigger\[N\].mode](#) (on page 8-123)
[digio.writeport\(\)](#) (on page 8-130)
[digio.writeprotect](#) (on page 8-131)

digio.writeport()

This function writes to all digital I/O lines.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
digio.writeport(data)
```

<i>data</i>	Value to write to the port (0 to 16383)
-------------	---

Details

The binary representation of *data* indicates the output pattern to be written to the I/O port. For example, a *data* value of 170 has a binary equivalent of 00000010101010. Lines 2, 4, 6, and 8 are set high (1), and the other 10 lines are set low (0).

Write-protected lines are not changed.

The `reset()` function does not affect the present states of the digital I/O lines.

Use the `digio.writebit()` and `digio.writeport()` commands to control the output state of the synchronization line when trigger operation is set to `digio.TRIG_BYPASS`.

Example

```
digio.writeport(255)
```

Sets digital I/O Lines 1 through 8 high (binary 00000011111111).

Also see

[digio.readbit\(\)](#) (on page 8-120)

[digio.readport\(\)](#) (on page 8-120)

[digio.writebit\(\)](#) (on page 8-130)

[digio.writeprotect](#) (on page 8-131)

digio.writeprotect

This attribute contains the write-protect mask that protects bits from changes from the `digio.writebit()` and `digio.writeport()` functions.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Instrument reset Recall setup	Create configuration script Save setup	0

Usage

```
mask = digio.writeprotect
digio.writeprotect = mask
```

```
mask
```

Sets the value that specifies the bit pattern for write-protect

Details

Bits that are set to one cause the corresponding line to be write-protected.

The binary equivalent of *mask* indicates the mask to be set for the I/O port. For example, a mask value of 7 has a binary equivalent of 00000000000111. This mask write-protects Lines 1, 2, and 3.

Example

```
digio.writeprotect = 15
```

Write-protects lines 1, 2, 3, and 4.

Also see

[digio.writebit\(\)](#) (on page 8-130)

[digio.writeport\(\)](#) (on page 8-130)

display.clear()

This function clears all lines of the display.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
display.clear()
```

Details

This function switches to the user screen and then clears the display.

The `display.clear()`, `display.setcursor()`, and `display.settext()` functions are overlapped, nonblocking commands. That is, the script does not wait for one of these commands to complete. These nonblocking functions do not immediately update the display. For performance considerations, they update the physical display as soon as processing time becomes available.

Also see

[display.setcursor\(\)](#) (on page 8-147)

[display.settext\(\)](#) (on page 8-148)

display.getannunciators()

This function reads the annunciators (indicators) that are presently turned on.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
annunciators = display.getannunciators()
```

<code>annunciators</code>	The bitmasked value that shows which indicators are turned on
---------------------------	---

Details

This function returns a bitmasked value showing which indicators are turned on. The 16-bit binary equivalent of the returned value is the bitmask. The return value is a sum of set annunciators, based on the weighted value, as shown in the following table.

Annunciator (indicator) bitmasked values and equivalent constants			
Indicator	Bit	Weighted value	Equivalent constant
FILT	1	1	display.ANNUNCIATOR_FILTER
MATH	2	2	display.ANNUNCIATOR_MATH
4W	3	4	display.ANNUNCIATOR_4_WIRE
AUTO	4	8	display.ANNUNCIATOR_AUTO
ARM	5	16	display.ANNUNCIATOR_ARM
TRIG	6	32	display.ANNUNCIATOR_TRIGGER
*(star)	7	64	display.ANNUNCIATOR_STAR
SMPL	8	128	display.ANNUNCIATOR_SAMPLE
EDIT	9	256	display.ANNUNCIATOR_EDIT
ERR	10	512	display.ANNUNCIATOR_ERROR
REM	11	1024	display.ANNUNCIATOR_REMOTE
TALK	12	2048	display.ANNUNCIATOR_TALK
LSTN	13	4096	display.ANNUNCIATOR_LISTEN
SRQ	14	8192	display.ANNUNCIATOR_SRQ
REAR	15	16384	display.ANNUNCIATOR_REAR
REL	16	32768	display.ANNUNCIATOR_REL

Example 1

```
testAnnunciators = display.getannunciators()
print(testAnnunciators)

rem = bit.bitand(testAnnunciators, 1024)
if rem > 0 then
    print("REM is on")
else
    print("REM is off")
end
```

REM indicator is turned on.

Output:

```
1.28000e+03
REM is on
```

Example 2

```
print(display.ANNUNCIATOR_EDIT)

print(display.ANNUNCIATOR_TRIGGER)

print(display.ANNUNCIATOR_AUTO)
```

Output:

```
2.56000e+02
3.20000e+01
8.00000e+00
```

Also see

[bit.bitand\(\)](#) (on page 8-11)

display.getcursor()

This function reads the present position of the cursor on the front panel display.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
row, column, style = display.getcursor()
```

<i>row</i>	The row where the cursor is: 1 (top row); 2 (bottom row)
<i>column</i>	The column where the cursor is: <ul style="list-style-type: none"> If the cursor is in the top row: 1 to 20 If the cursor is in the bottom row: 1 to 32
<i>style</i>	Visibility of the cursor: 0 (invisible cursor); 1 (blinking cursor)

Details

This function switches the display to the user screen (the text set by `display.settext()`), and then returns values to indicate the cursor's row and column position and cursor style.

Columns are numbered from left to right on the display.

Example 1

```
testRow, testColumn = display.getcursor()
print(testRow, testColumn)
```

This example reads the cursor position into local variables and prints them.

Example output:

```
1.00000e+00 1.00000e+00
```

Example 2

```
print(display.getcursor())
```

This example prints the cursor position directly. In this example, the cursor is in row 1 at column 3, with an invisible cursor:

```
1.00000e+00 3.00000e+00
0.00000e+00
```

Also see

[display.gettext\(\)](#) (on page 8-136)

[display.screen](#) (on page 8-144)

[display.setcursor\(\)](#) (on page 8-147)

[display.settext\(\)](#) (on page 8-148)

display.getlastkey()

This function retrieves the key code for the last pressed key.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
keyCode = display.getlastkey()
```

<i>keyCode</i>	A returned value that represents the last front-panel key pressed. see Details for more information
----------------	--

Details

A history of the key code for the last pressed front-panel key is maintained by the instrument. When the instrument is turned on, or when it is transitioning from local to remote operation, the key code is set to 0 (`display.KEY_NONE`).

Pressing the EXIT (LOCAL) key normally aborts a script. To use this function with the EXIT (LOCAL) key, `display.locallockout` must be used.

The table below lists the *keyCode* value for each front-panel action.

Key codes			
Value	Key list	Value	Key list
0	<code>display.KEY_NONE</code>	82	<code>display.KEY_ENTER</code>
65	<code>display.KEY_RANGEUP</code>	83	<code>display.KEY_REC</code>
66	<code>display.KEY_FUNC</code>	84	<code>display.KEY_DMM</code>
67	<code>display.KEY_REL</code>	85	<code>display.KEY_DELETE</code>
68	<code>display.KEY_MENU</code>	86	<code>display.KEY_STEP</code>
69	<code>display.KEY_CLOSE</code>	87	<code>display.KEY_CHAN</code>
70	<code>display.KEY_SLOT</code>	90	<code>display.KEY_RATE</code>
71	<code>display.KEY_RUN</code>	91	<code>display.KEY_LIMIT</code>
72	<code>display.KEY_DISPLAY</code>	92	<code>display.KEY_TRIG</code>
73	<code>display.KEY_AUTO</code>	93	<code>display.KEY_OPEN</code>
74	<code>display.KEY_FILTER</code>	94	<code>display.KEY_PATT</code>
75	<code>display.KEY_EXIT</code>	95	<code>display.KEY_LOAD</code>
76	<code>display.KEY_STORE</code>	97	<code>display.WHEEL_ENTER</code>
77	<code>display.KEY_SCAN</code>	103	<code>display.KEY_RIGHT</code>
78	<code>display.KEY_INSERT</code>	104	<code>display.KEY_LEFT</code>
79	<code>display.KEY_OPENALL</code>	107	<code>display.WHEEL_LEFT</code>
80	<code>display.KEY_CONFIG</code>	114	<code>display.WHEEL_RIGHT</code>
81	<code>display.KEY_RANGEDOWN</code>		

Example

```
key = display.getlastkey()
print(key)
```

On the front panel, press the **MENU** key and then send the code to the left. This retrieves the key code for the last pressed key.

Output:
6.80000e+01

Also see

[display.locallockout](#) (on page 8-142)
[display.sendkey\(\)](#) (on page 8-145)

display.gettext()

This function reads the text displayed on the instrument front panel.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
text = display.gettext()
text = display.gettext(embellished)
text = display.gettext(embellished, row)
text = display.gettext(embellished, row, columnStart)
text = display.gettext(embellished, row, columnStart, columnEnd)
```

<i>text</i>	The returned value, which contains the text that is presently displayed
<i>embellished</i>	Indicates type of returned text: <i>false</i> (simple text); <i>true</i> (text with embedded character codes)
<i>row</i>	Selects the row from which to read the text: 1 (row 1); 2 (row 2). If <i>row</i> is not included, both rows of text are read
<i>columnStart</i>	Selects the first column from which to read text; for row 1, the valid column numbers are 1 to 20; for row 2, the valid column numbers are 1 to 32; if nothing is selected, 1 is used
<i>columnEnd</i>	Selects the last column from which to read text; for row 1, the valid column numbers are 1 to 20; for row 2, the valid column numbers are 1 to 32; the default is 20 for row 1, and 32 for row 2

Details

Using the command without any parameters returns both lines of the display.

The $\$N$ character code is included in the returned value to show where the top line ends and the bottom line begins. This is not affected by the value of *embellished*.

When *embellished* is set to *true*, all other character codes are returned along with the message. When *embellished* is set to *false*, only the message and the $\$N$ character code is returned. For information on the embedded character codes, see [display.settext\(\)](#) (on page 8-148).

The display is not switched to the user screen (the screen set using `display.settext()`). Text will be read from the active screen.

Example 1

```
display.clear()
display.setCursor(1, 1)
display.setText("ABCDEFGH IJ$DKLMNOPQRST")
display.setCursor(2, 1)
display.setText("abcdefghijklmnopqrstuvwxy z$F123456")
print(display.getText())
print(display.getText(true))
print(display.getText(false, 2))
print(display.getText(true, 2, 9))
print(display.getText(false, 2, 9, 10))
```

This example shows how to retrieve the display text in multiple ways. The output is:

```
ABCDEFGHIJKLMNOPQRST$Nabcdefghijklmnopqrstuvwxy z123456
$RABCDEFGHIJK$DKLMNOPQRST$N$Rabcdefghijklmnopqrstuvwxy z$F123456
abcdefghijklmnopqrstuvwxy z123456
$Rijklm$Bnopqrstuvwxy z$F123456
ij
```

Example 2

```
display.clear()
display.setText("User Screen")
text = display.getText()
print(text)
```

This outputs all text in both lines of the display:

```
User Screen      $N
```

This indicates that the message "User Screen" is on the top line. The bottom line is blank.

Also see

[display.clear\(\)](#) (on page 8-132)
[display.setCursor\(\)](#) (on page 8-134)
[display.setCursor\(\)](#) (on page 8-147)
[display.setText\(\)](#) (on page 8-148)

display.inputvalue()

This function displays a formatted input field on the instrument display that the operator can edit.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
display.inputvalue(format)
display.inputvalue(format, default)
display.inputvalue(format, default, minimum)
display.inputvalue(format, default, minimum, maximum)
```

<i>format</i>	A string that defines how the input field is formatted; see Details for more information
<i>default</i>	The default value for the input value
<i>minimum</i>	The minimum input value
<i>maximum</i>	The maximum input value

Details

The *format* parameter uses zeros (0), the decimal point, polarity sign, and exponents to define how the input field is formatted. The *format* parameter can include the options shown in the following table.

Option	Description	Examples
E	Include the E to display the value exponentially	0.00000e+0
+	Allows operators to enter positive or negative values; if the "+" sign is not included, the operator cannot enter a negative value	+0.00
0	Defines the digit positions for the value; you can use up to six zeros (0)	+00.0000e+00
.	Include to have a decimal point appear in the value	+0.00

The *default* parameter is the value shown when the value is first displayed.

The *minimum* and *maximum* parameters can be used to limit the values that can be entered. When + is not selected for *format*, the minimum limit must be more than or equal to zero (0). When limits are used, you cannot enter values above or below these limits.

The input value is limited to $\pm 1e37$.

Before calling `display.inputvalue()`, you should send a message prompt to the operator using `display.prompt()`. Make sure to position the cursor where the edit field should appear.

After this command is sent, script execution pauses until you enter a value and press the **ENTER** key.

For positive and negative entry (plus sign (+) used for the value field and/or the exponent field), polarity of a nonzero value or exponent can be toggled by positioning the cursor on the polarity sign and turning the navigation wheel . Polarity will also toggle when using the navigation wheel  to decrease or increase the value or exponent past zero. A zero (0) value or exponent (for example, +00) is always positive and cannot be toggled to negative polarity.

After executing this command and pressing the **EXIT (LOCAL)** key, the function returns `nil`.

Example

```
display.clear()
display.settext("Enter value between$N -0.10 and 2.00: ")
value = display.inputvalue("+0.00", 0.5, -0.1, 2.0)
print("Value entered = ", value)
```

Displays an editable field (+0.50) for operator input. The valid input range is –0.10 to +2.00, with a default of 0.50.

Output:

```
Value entered = 1.35000e+00
```

Also see

[display.prompt\(\)](#) (on page 8-143)
[display.setcursor\(\)](#) (on page 8-147)
[display.settext\(\)](#) (on page 8-148)

display.loadmenu.add()

This function adds an entry to the User menu, which can be accessed by pressing the **LOAD** key on the instrument front panel.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
display.loadmenu.add(displayName, code)
display.loadmenu.add(displayName, code, memory)
```

<i>displayName</i>	The name that is added to the User menu
<i>code</i>	The code that is run from the User menu
<i>memory</i>	Determines if code is saved to nonvolatile memory: 0 or <code>display.DONT_SAVE</code> : Does not save the code to nonvolatile memory 1 or <code>display.SAVE</code> : Saves the code to nonvolatile memory (default)

Details

After adding code to the load menu, you can run it from the front panel by pressing the **LOAD** key, then selecting **USER** to select from the available code to load. Pressing the **RUN** key will then run the script.

You can add items in any order. They are always displayed in alphabetical order when the menu is selected.

Any Lua code can be included in the *code* parameter. If *memory* is set to `display.SAVE`, the entry (name and code) is saved in nonvolatile memory. Scripts, functions, and variables used in the code are not saved by `display.SAVE`. Functions and variables need to be saved with the code. If the code is not saved in nonvolatile memory, it will be lost when the Series 3700A is turned off. See **Example 2** below.

If you do not make a selection for *memory*, the code is automatically saved to nonvolatile memory.



Quick Tip

You can create a script that defines several functions, and then use the `display.loadmenu.add()` command to add items that call those individual functions. This allows the operator to run tests from the front panel.

Example 1

```
display.loadmenu.add("Test9", "Test9()")
```

Assume a user script named "Test9" has been loaded into the runtime environment. Adds the menu entry to the User menu to run the script after loading.

Example 2

```
display.loadmenu.add(  
    "Test", "DUT1() beeper.beep(2, 500)",  
    display.SAVE)
```

Assume a script with a function named "DUT1" has already been loaded into the instrument, and the script has NOT been saved in nonvolatile memory. Now assume you want to add a test named "Test" to the USER TESTS menu. You want the test to run the function named "DUT1" and sound the beeper. This example adds "Test" to the menu, defines the code, and then saves the `displayName` and code in nonvolatile memory. When "Test" is run from the front panel USER TESTS menu, the function named "DUT1" executes and the beeper beeps for two seconds. Now assume you turn off instrument power. Because the script was not saved in nonvolatile memory, the function named "DUT1" is lost when you turn the instrument on. When "Test" is again run from the front panel, an error is generated because DUT1 no longer exists in the instrument as a function.

Example 3

```
display.loadmenu.add("Part1",  
    "testpart([[Part1]], 5.0)", display.SAVE)
```

Adds an entry called "Part1" to the front panel "USER TESTS" load menu for the code `testpart([[Part1]], 5.0)`, and saves it in nonvolatile memory.

Also see

[display.loadmenu.delete\(\)](#) (on page 8-141)

display.loadmenu.catalog()

This function creates an iterator for the user menu items accessed using the LOAD key on the instrument front panel.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
for displayName in display.loadmenu.catalog() do body end
for displayName, code in display.loadmenu.catalog() do body end
```

<i>displayName</i>	The name displayed in the menu
<i>code</i>	The code associated with the <i>displayName</i>
<i>body</i>	The body of the code to process the entries in the loop

Details

Each time through the loop, *displayName* and *code* will take on the values in the User menu. The instrument goes through the list in random order.

Example

```
for displayName, code in
  display.loadmenu.catalog() do
  print(displayName, code)
end
```

Output:

```
Test DUT1() beeper.beep(2, 500)
Part1 testpart([[Part1]], 5.0)
Test9 Test9()
```

Also see

[display.loadmenu.add\(\)](#) (on page 8-139)
[display.loadmenu.delete\(\)](#) (on page 8-141)

display.loadmenu.delete()

This function removes an entry from the User menu, which can be accessed using the **LOAD** key on the instrument front panel.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
display.loadmenu.delete(displayName)
```

<i>displayName</i>	The name to be deleted from the User menu
--------------------	---

Details

If you delete an entry from the User menu, you can no longer run it by pressing the **LOAD** key.

Example

<pre>display.loadmenu.delete("Test9") for displayName, code in display.loadmenu.catalog() do print(displayName, code) end</pre>	Deletes the entry named "Test9" Output: Test DUT1() beeper.beep(2, 500) Part1 testpart([[Part1]], 5.0)
---	---

Also see

[display.loadmenu.add\(\)](#) (on page 8-139)
[display.loadmenu.catalog\(\)](#) (on page 8-141)

display.locallockout

This attribute describes whether or not the EXIT (LOCAL) key on the instrument front panel is enabled.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Power cycle	Not saved	display.UNLOCK

Usage

```
lockout = display.locallockout
display.locallockout = lockout
```

<i>lockout</i>	0 or display.UNLOCK: Unlocks EXIT (LOCAL) key 1 or display.LOCK: Locks out EXIT (LOCAL) key
----------------	--

Details

Set `display.locallockout` to `display.LOCK` to prevent the user from interrupting remote operation by pressing the EXIT (LOCAL) key.

Set this attribute to `display.UNLOCK` to allow the EXIT (LOCAL) key to interrupt script/remote operation.

Example

<code>display.locallockout = display.LOCK</code>	Disables the front-panel EXIT (LOCAL) key.
--	--

Also see

None

display.menu()

This function presents a menu on the front panel display.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
selection = display.menu(name, items)
```

<i>selection</i>	Name of the variable that holds the menu item selected
<i>name</i>	Menu name to display on the top line
<i>items</i>	Menu items to display on the bottom line

Details

The menu consists of the menu name string on the top line, and a selectable list of items on the bottom line. The menu items must be a single string with each item separated by whitespace. The name for the top line is limited to 20 characters.

After sending this command, script execution pauses for the operator to select a menu item. An item is selected by rotating the navigation wheel  to place the blinking cursor on the item, and then pressing the navigation wheel  (or the ENTER key). When an item is selected, the text of that selection is returned.

Pressing the EXIT (LOCAL) key will not abort the script while the menu is displayed, but it will return `nil`. The script can be aborted by calling the `exit` function when `nil` is returned.

Example

```
selection = display.menu("Menu", "Test1 Test2 Test3")
print(selection)
```

Displays a menu with three menu items. If the second menu item is selected, `selection` is given the value `Test2`.

Output:
Test2

Also see

None

display.prompt()

This function prompts the user to enter a parameter from the front panel of the instrument.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
display.prompt(format, units, help)
display.prompt(format, units, help, default)
display.prompt(format, units, help, default, minimum)
display.prompt(format, units, help, default, minimum, maximum)
```

<i>format</i>	A string that defines how the input field is formatted; see Details for more information
<i>units</i>	Set the units text string for the top line (eight characters maximum); this indicates the units (for example, "V" or "A") for the value
<i>help</i>	Text string to display on the bottom line (32 characters maximum)
<i>default</i>	The value that is shown when the value is first displayed
<i>minimum</i>	The minimum input value that can be entered
<i>maximum</i>	The maximum input value that can be entered (must be more than minimum)

Details

This function creates an editable input field at the present cursor position, and an input prompt message on the bottom line. Example of a displayed input field and prompt:

```
0.00V
```

```
Input 0 to +2V
```

The *format* parameter uses zeros (0), the decimal point, polarity sign, and exponents to define how the input field is formatted.

The *format* parameter can include the options shown in the following table.

Option	Description	Examples
E	Include the E to display the value exponentially. Include a plus sign (+) for positive/negative exponent entry. Do not include the plus sign (+) to prevent negative value entry. 0 defines the digit positions for the exponent.	0.00000E+0
+	Allows operators to enter positive or negative values. If the plus sign (+) is not included, the operator cannot enter a negative value.	+0.00
0	Defines the digit positions for the value. You can use up to six zeros (0).	+00.00000E+00
.	The decimal point where needed for the value.	+0.00

The *minimum* and *maximum* parameters can be used to limit the values that can be entered. When a plus sign (+) is not selected for *format*, the minimum limit must be greater than or equal to zero (0). When limits are used, the operator cannot enter values above or below these limits.

The input value is limited to $\pm 1e37$.

After sending this command, script execution pauses for the operator to enter a value and press **ENTER**.

For positive and negative entry (plus sign (+) used for the value field and the exponent field), polarity of a nonzero value or exponent can be toggled by positioning the cursor on the polarity sign and turning the navigation wheel \odot . Polarity will also toggle when using the navigation wheel \odot to decrease or increase the value or exponent past zero. A zero value or exponent (for example, +00) is always positive and cannot be toggled to negative polarity.

After executing this command and pressing the **EXIT (LOCAL)** key, the value returns *nil*.

Example

```
value = display.prompt("0.00", "V", "Input 0 to +2V", 0.5, 0, 2)
print(value)
```

The above command prompts the operator to enter a voltage value. The valid input range is 0 to +2.00, with a default of 0.50:

```
0.50V
Input 0 to +2V
```

If the operator enters 0.70, the output is:

```
7.00000e-01
```

Also see

[display.inputvalue\(\)](#) (on page 8-138)

display.screen

This attribute contains the selected display screen.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Instrument reset Recall setup	Create configuration script Save setup	display.MAIN

Usage

```
displayID = display.screen
display.screen = displayID
```

displayID

One of the following values:

- 1 or `display.MAIN`: Displays the main screen
- 2 or `display.USER`: Displays the user screen

Details

Setting this attribute selects the display screen for the front panel. This performs the same action as pressing the DISPLAY key on the front panel. The text for the display screen is set by `display.setText()`.

Read this attribute to determine which of the available display screens was last selected.

NOTE

This does not support the CLOSED CHANNELS option that is available from the **DISPLAY** key.

Example

```
display.screen = display.USER
```

Selects the user display.

Also see

[display.setText\(\)](#) (on page 8-148)

display.sendkey()

This function sends a code that simulates the action of a front panel control.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
display.sendkey(keyCode)
```

keyCode

A parameter that specifies the key to virtually press; see **Details** for more information

Details

This command simulates the pressing of a front panel key or navigation wheel, or the turning the navigation wheel one click to the left or right.

Key codes

Value	Key list	Value	Key list
0	display.KEY_NONE	82	display.KEY_ENTER
65	display.KEY_RANGEUP	83	display.KEY_REC
66	display.KEY_FUNC	84	display.KEY_DMM
67	display.KEY_REL	85	display.KEY_DELETE
68	display.KEY_MENU	86	display.KEY_STEP
69	display.KEY_CLOSE	87	display.KEY_CHAN
70	display.KEY_SLOT	90	display.KEY_RATE
71	display.KEY_RUN	91	display.KEY_LIMIT
72	display.KEY_DISPLAY	92	display.KEY_TRIG
73	display.KEY_AUTO	93	display.KEY_OPEN
74	display.KEY_FILTER	94	display.KEY_PATT
75	display.KEY_EXIT	95	display.KEY_LOAD
76	display.KEY_STORE	97	display.WHEEL_ENTER
77	display.KEY_SCAN	103	display.KEY_RIGHT
78	display.KEY_INSERT	104	display.KEY_LEFT
79	display.KEY_OPENALL	107	display.WHEEL_LEFT
80	display.KEY_CONFIG	114	display.WHEEL_RIGHT
81	display.KEY_RANGEDOWN		

NOTE

When using this function, send built-in constants such as `display.KEY_RIGHT` (rather than the numeric value of 103). This will allow for better forward compatibility with firmware revisions.

Example

```
display.sendkey(display.KEY_RUN)
```

Simulates pressing the RUN key.

Also see

Front panel

display.setcursor()

This function sets the position of the cursor.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
display.setcursor(row, column)
display.setcursor(row, column, style)
```

<i>row</i>	The row number for the cursor (1 or 2)
<i>column</i>	The active column position to set; row 1 has columns 1 to 20, row 2 has columns 1 to 32
<i>style</i>	Set the cursor to invisible (0, default) or blinking (1)

Details

Sending this command selects the user screen and then moves the cursor to the given location.

The `display.clear()`, `display.setcursor()`, and `display.settext()` functions are overlapped, nonblocking commands. That is, the script does not wait for one of these commands to complete. These nonblocking functions do not immediately update the display. For performance considerations, they update the physical display as soon as processing time becomes available.

An out-of-range parameter for *row* sets the cursor to row 2. An out-of-range parameter for *column* sets the cursor to column 20 for row 1, or 32 for row 2.

An out-of-range parameter for *style* sets it to 0 (invisible).

A blinking cursor is only visible when it is positioned over displayed text. It cannot be seen when positioned over a space character.

Example

```
display.clear()
display.setcursor(1, 8)
display.settext("Hello")
display.setcursor(2, 14)
display.settext("World")
```

This example displays a message on the instrument front panel, approximately center. Note that the top line of text is larger than the bottom line of text. The front panel of the instrument displays "Hello" on the top line and "World" on the second line.

Also see

[display.clear\(\)](#) (on page 8-132)
[display.getcursor\(\)](#) (on page 8-134)
[display.gettext\(\)](#) (on page 8-136)
[display.screen](#) (on page 8-144)
[display.settext\(\)](#) (on page 8-148)

display.settext()

This function displays text on the user screen.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
display.settext(text)
```

<i>text</i>	Text message to be displayed, with optional character codes
-------------	---

Details

This function selects the user display screen and displays the given text.

After the instrument is turned on, the first time you use a display command to write to the display, the message "User Screen" is cleared. After the first write, you need to use `display.clear()` to clear the message.

The `display.clear()`, `display.setcursor()`, and `display.settext()` functions are overlapped, nonblocking commands. That is, the script does not wait for one of these commands to complete. These nonblocking functions do not immediately update the display. For performance considerations, they update the physical display as soon as processing time becomes available.

The text starts at the present cursor position. After the text is displayed, the cursor is after the last character in the display message.

Top line text does not wrap to the bottom line of the display automatically. Any text that does not fit on the current line is truncated. If the text is truncated, the cursor remains at the end of the line.

The text remains on the display until replaced or cleared.

The following character codes can be also be included in the text string:

Display character codes

Character Code	Description
<code>\$N</code>	Newline, starts text on the next line; if the cursor is already on line 2, text will be ignored after the <code>\$N</code> is received
<code>\$R</code>	Sets text to normal intensity, nonblinking
<code>\$B</code>	Sets text to blink
<code>\$D</code>	Sets text to dim intensity
<code>\$F</code>	Sets the text to background blink
<code>\$\$</code>	Escape sequence to display a single dollar symbol (<code>\$</code>)

Example

```
display.clear()
display.settext("Normal $BBlinking$N")
display.settext("$DDim $FBackgroundBlink$R $$$$ 2 dollars")
```

This example sets the display to:

```
Normal Blinking
Dim BackgroundBlink $$ 2 dollars
with the named effect on each word.
```

Also see

[display.clear\(\)](#) (on page 8-132)
[display.getcursor\(\)](#) (on page 8-134)
[display.gettext\(\)](#) (on page 8-136)
[display.screen](#) (on page 8-144)
[display.setcursor\(\)](#) (on page 8-147)

display.trigger.EVENT_ID

This constant is the event ID of the event generated when the front-panel TRIG key is pressed.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Constant	Yes			

Usage

```
eventID = display.trigger.EVENT_ID
```

<i>eventID</i>	The trigger event number
----------------	--------------------------

Details

Set the stimulus of any trigger event detector to the value of this constant to have it respond to front panel trigger key events.

Example

```
scan.trigger.channel.stimulus = display.trigger.EVENT_ID
```

Have the channel action of the trigger model be paced by a user pressing the front panel TRIG key.

Also see

display.waitkey()

This function captures the key code value for the next front-panel action.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
keyCode = display.waitkey()
```

<i>keyCode</i>	See Details for more information
----------------	---

Details

After you send this function, script execution pauses until a front-panel action (for example, pressing a key or the navigation wheel , or turning the navigation wheel ). After the action, the value of the key (or action) is returned.

If the **EXIT (LOCAL)** key is pressed while this function is waiting for a front-panel action, the script is not aborted. A typical use for this function is to prompt the user to press the **EXIT (LOCAL)** key to abort the script or press any other key to continue. For example, if the `keyCode` value 75 is returned (the **EXIT (LOCAL)** key was pressed), the `exit()` function can be called to abort the script.

The table below lists the *keyCode* value for each front panel action.
Set *keyCode* to one of the values shown in the following table.

Key codes			
Value	Key list	Value	Key list
0	display.KEY_NONE	82	display.KEY_ENTER
65	display.KEY_RANGEUP	83	display.KEY_REC
66	display.KEY_FUNC	84	display.KEY_DMM
67	display.KEY_REL	85	display.KEY_DELETE
68	display.KEY_MENU	86	display.KEY_STEP
69	display.KEY_CLOSE	87	display.KEY_CHAN
70	display.KEY_SLOT	90	display.KEY_RATE
71	display.KEY_RUN	91	display.KEY_LIMIT
72	display.KEY_DISPLAY	92	display.KEY_TRIG
73	display.KEY_AUTO	93	display.KEY_OPEN
74	display.KEY_FILTER	94	display.KEY_PATT
75	display.KEY_EXIT	95	display.KEY_LOAD
76	display.KEY_STORE	97	display.WHEEL_ENTER
77	display.KEY_SCAN	103	display.KEY_RIGHT
78	display.KEY_INSERT	104	display.KEY_LEFT
79	display.KEY_OPENALL	107	display.WHEEL_LEFT
80	display.KEY_CONFIG	114	display.WHEEL_RIGHT
81	display.KEY_RANGEDOWN		

NOTE

When using this function, send built-in constants such as `display.KEY_RIGHT` (rather than the numeric value of 103). This will allow for better forward compatibility with firmware revisions. For example, use `display.KEY_ENTER` instead of 82.

Example

```
key = display.waitkey()
print(key)
```

Pause script execution until the operator presses a key or the navigation wheel, or rotates the navigation wheel.

If the output is:

```
8.600000e+01
```

The STEP key was pressed.

Also see

[display.getlastkey\(\)](#) (on page 3-41, on page 8-135)

[display.sendkey\(\)](#) (on page 8-145)

[display.setText\(\)](#) (on page 8-148)

dmm.adjustment.count

This attribute indicates the number of times the instrument has been adjusted (calibrated).

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Nonvolatile memory	Not applicable

Usage

```
calibrationCount = dmm.adjustment.count
```

<code>calibrationCount</code>	The number of times the instrument has been adjusted or calibrated
-------------------------------	--

Details

Calibration (adjustment) may or may not be unlocked for this attribute to read and return a value.

Example

<code>adjustmentCount = dmm.adjustment.count</code>	Queries for the adjustment count.
---	-----------------------------------

Also see

[dmm.adjustment.date](#) (on page 8-152)
[dmm.calibration.unlock\(\)](#) (on page 8-168)

dmm.adjustment.date

This attribute sets or queries the calibration adjustment date in Coordinated Universal Time (UTC) format (number of seconds since January 1, 1970).

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Not applicable	DMM nonvolatile memory	Not applicable

Usage

```
calibrationDate = dmm.adjustment.date
dmm.adjustment.date = os.time({year=yyyy, month=m, day=d})
```

<i>calibrationDate</i>	The number of seconds since January 1, 1970
<code>os.time{year=yyyy, month=m, day=d}</code>	Specifies the date; if a value is not specified, sets the adjustment date to the present date of the instrument

Details

This attribute can only be set when calibration is unlocked.

For more information about formatting options with `os.time` or `os.date`, see the [Lua documentation](http://www.lua.org) (see Lua website - <http://www.lua.org>).

Example 1

```
dmm.adjustment.date = os.time{year=2007, month=7, day = 4}
```

Sets the adjustment date to July 4, 2007.

Example 2

```
print(os.date("%m/%d/%Y", dmm.adjustment.date))
```

Queries the date and formats the response as mm/dd/yyyy:

```
07/04/2007
```

Example 3

```
print(os.date("%x", dmm.adjustment.date))
```

Queries the date and formats the response as mm/dd/yy:

```
02/24/09
```

Also see

[dmm.adjustment.count](#) (on page 8-151)
[dmm.calibration.unlock\(\)](#) (on page 8-168)

dmm.aperture

The aperture setting for the active DMM function in seconds.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Function change DMM close Recall DMM configuration Instrument reset DMM reset Recall setup	Save DMM configuration Create configuration script Save setup	60 Hz: 1.666666667e-002 50 Hz: 2.000000000e-002

Usage

```
value = dmm.aperture
dmm.aperture = value
```

value

Represents the desired aperture:

- For 50 Hz line frequency, the range is 10e-6 s to 0.250 s
- For 60 Hz line frequency, the range is 8.33e-6 s to 0.250 s
- For frequency and period, the range is 0.01 s to 0.273 s

Details

The `dmm.aperture` attribute is available for the following functions.

Function	Default value
"accurrent"	1.666667e-02
"acvolts"	1.666667e-02
"commonsideohms"	1.666667e-02
"dccurrent"	1.666667e-02
"dcvolts"	1.666667e-02
"fourwireohms"	1.666667e-02
"frequency"	1.000000e-02
"period"	1.000000e-02
"temperature"	1.666667e-02
"twowireohms"	1.666667e-02

The aperture setting is not available for the functions "continuity" and "nofunction". If you query the aperture when either of these functions is selected, nil is returned. If you write the command when either of these functions is selected, an error is generated.

The aperture value is saved with the `dmm.func` function setting, so if you use another function, then return to the previous setting, such as "dcvolts" or "frequency", the aperture value you set previously is retained.

The setting for aperture may be automatically adjusted based on what the DMM supports. Therefore, after setting the aperture, query the value to see if it was adjusted.

If the detector bandwidth (`dmm.detectorbandwidth`) setting is 30 or less for "acvolts" or "accurrent", an error message is generated if you try to set the aperture for these functions.

Example

```
dmm.func = "dcvolts"  
dmm.aperture = 16.67e-3
```

Set the aperture to 16.67 milliseconds for DC volts.

Also see

[dmm.configure.recall\(\)](#) (on page 8-176)
[dmm.configure.set\(\)](#) (on page 8-178)
[dmm.detectorbandwidth](#) (on page 8-182)
[dmm.func](#) (on page 8-190)
[dmm.nplc](#) (on page 8-220)

dmm.appendbuffer()

Appends data from the reading buffer to a file on the USB flash drive. If no file exists, this function creates a file.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
dmm.appendbuffer(bufferVar, fileName)
dmm.appendbuffer(bufferVar, fileName, timeFormat)
```

<i>bufferVar</i>	A string with the name of a DMM reading buffer from which you want to append data to the specified file
<i>fileName</i>	A string with the file name of the file on the USB flash drive to which reading buffer data will be appended
<i>timeFormat</i>	How the date and time information should be saved. The values for <i>timeFormat</i> are: <ul style="list-style-type: none"> <code>dmm.buffer.SAVE_RELATIVE_TIME</code>: Saves relative time stamps only <code>dmm.buffer.SAVE_FORMAT_TIME</code>: Saves dates, times and fractional seconds. This is the default if no time format is specified <code>dmm.buffer.SAVE_RAW_TIME</code>: Saves seconds and fractional seconds only <code>dmm.buffer.SAVE_TIMESTAMP_TIME</code>: Saves only time stamps

Details

For options that save more than one item of time information, each item is comma delimited. For example, the default format will be <date>, <time>, and <fractional seconds> for each reading, separated by commas. The file extension .csv is appended to the filename if necessary. Any file extension other than .csv generates errors.

Because `dmm.appendbuffer()` appends data, it does not include header information. The `dmm.savebuffer()` function does include header information.

The index column entry starts at 1 for each append operation, which is also what the `dmm.savebuffer()` command does.

NOTE

The reading buffer files saved to the USB flash drive will always have an extension of .csv.

Errors are generated:

- If the reading buffer does not exist.
- If the reading buffer is not a DMM buffer.
- If the destination filename is not specified correctly.
- If the file extension is not set to .csv. (You can leave the file extension blank.)

Examples of valid destination file names:

```
dmm.appendbuffer("bufferVar", "/usb1/myData")
dmm.appendbuffer("bufferVar", "/usb1/myData.csv")
```

Invalid destination filename examples:

```
dmm.appendbuffer("bufferVar", "/usb1/myData.")
```

— The period is not followed by the csv extension.

```
dmm.appendbuffer("bufferVar", "/usb1/myData.txt")
```

— The only allowed extension is .csv. If .csv is not assigned, it is automatically added.

```
dmm.appendbuffer("bufferVar", "/usb1/myData.txt.csv")
```

— Two periods in the file name (`myData_txt.csv` would be correct).

Example

<pre>dmm.appendbuffer("bufferVar", "/usb1/myData.csv")</pre>	Appends readings from a valid DMM buffer named <code>bufferVar</code> with default time information to a file named <code>myData.csv</code> on the USB flash drive.
<pre>dmm.appendbuffer("bufferVar", "/usb1/myDataRel.csv", dmm.buffer.SAVE_RELATIVE_TIME)</pre>	Appends readings from <code>bufferVar</code> with relative time stamps to a file named <code>myDataRel.csv</code> on the USB flash drive.

Also see

[dmm.makebuffer\(\)](#) (on page 8-207)

[dmm.savebuffer\(\)](#) (on page 8-238)

dmm.autodelay

The autodelay setting for the selected DMM function.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Function change DMM close Recall DMM configuration Reset DMM reset Recall setup	Create configuration script Save setup Save DMM configuration	2 (dmm.AUTODELAY_ONCE)

Usage

```
value = dmm.autodelay
dmm.autodelay = value
```

<i>state</i>	Enable autodelay (dmm.ON or 1) Disable autodelay (dmm.OFF or 0) Enable autodelay for the first measurement only (dmm.AUTODELAY_ONCE or 2)
--------------	---

Details

The autodelay setting applies to the function selected by `dmm.func`. It is available for all functions except "nofunction".

To have the DMM include a delay before each measurement, set auto delay to `dmm.ON` or 1.

To have the DMM take a measurement without an automatic delay, set auto delay to `dmm.OFF` or 0.

To take a measurement for the first measurement in a set or group of measurements, you can use `dmm.AUTODELAY_ONCE` or 2. The delay occurs only on the first measurement of each set of measurements. If `dmm.measurecount` is set to 1, `dmm.AUTODELAY_ONCE` acts similarly to On, applying a delay at the start of every measurement.

An error is generated if you try to set autodelay for "nofunction". Error 1114, "Setting conflicts with function selected" is generated. If you query autodelay for "nofunction", nil is returned, along with error 1114.

Example

<pre>dmm.func = "twowireohms" dmm.autodelay = dmm.ON dmm.measurecount = 10 ReadingBufferOne = dmm.makebuffer(1000) dmm.measure(ReadingBufferOne)</pre>	An automatic delay is applied to each measurement when the DMM is measuring two-wire ohms. Take 10 measurements and store them in a reading buffer named <code>ReadingBufferOne</code> that can store up to 1000 readings.
<pre>dmm.func = "dcvolts" dmm.autodelay = dmm.OFF</pre>	No delay is applied is applied to the DC volt measurements.
<pre>dmm.func = "fourwireohms" dmm.autodelay = dmm.AUTODELAY_ONCE dmm.measurecount = 10 ReadingBufferTwo = dmm.makebuffer(1000) dmm.measure(ReadingBufferTwo)</pre>	Sets an auto delay for the first of the ten four-wire ohm readings. Readings two through ten will occur as quickly as possible, with readings stored in a reading buffer called <code>ReadingBufferTwo</code> that can store up to 1000 readings.

Also see

[Autodelay](#) (on page 4-5)
[dmm.configure.recall\(\)](#) (on page 8-176)
[dmm.configure.set\(\)](#) (on page 8-178)
[dmm.func](#) (on page 8-190)

[dmm.measurecount](#) (on page 8-217)

dmm.autorange

The auto range setting for the active DMM function.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	1 (dmm.ON)

Usage

```
value = dmm.autorange
dmm.autorange = value
```

<i>value</i>	Auto range: <ul style="list-style-type: none"> • Enable: dmm.ON or 1 • Disable: dmm.OFF or 0
--------------	--

Details

Auto range selects the best range in which to measure the applied signal. The instrument will auto range at 100% of range. When auto range is enabled, upranging occurs at 120% of range and downranging occurs when the reading is <10% of nominal range. For example, if you are on the 10 volt range and auto range is enabled, the instrument will auto range up to the 100 volts range when the measurement exceeds 12 volts and will auto range down to the 1 volt range when the measurement falls below 1 volt.

The auto range setting applies to the function selected by `dmm.func`. Auto range is available for the following functions:

- "accurrent" or `dmm.AC_CURRENT`
- "acvolts" or `dmm.AC_VOLTS`
- "commonsideohms" or `dmm.COMMON_SIDE_OHMS`
- "dccurrent" or `dmm.DC_CURRENT`
- "dcvolts" or `dmm.DC_VOLTS`
- "fourwireohms" or `dmm.FOUR_WIRE_OHMS`
- "twowireohms" or `dmm.TWO_WIRE_OHMS`

Auto range is not available for any other functions. If you try to set auto range for any other function, an error is returned. If you query the auto range for any other function, nil is returned and an error is generated.

The auto range value is saved with the `dmm.func` function setting, so if you use another function, then return to the previous setting, such as "dcvolts" or "fourwireohms", the autorange setting you set previously is retained. With auto range enabled, you can use the `dmm.range` command to view the range that is presently being used. Using `dmm.range` to select a fixed range disables auto range.

Example 1

<code>dmm.func = "twowireohms"</code> <code>dmm.autorange = dmm.ON</code>	Enable auto ranging for 2-wire ohms.
--	--------------------------------------

Example 2

```
dmm.func = "dcvolts"  
dmm.reset("active")  
print(dmm.autorange, dmm.range)  
dmm.range = 50e-3  
print(dmm.autorange, dmm.range)
```

Set DMM function to be DC volts.
Reset only the active DMM function (DC volts).
View the default auto range and range selection.
Select a range suitable for a 50 mV reading.
View the default auto range and range selection.

Output:

```
1.000000000e+00      1.000000000e+01  
0.000000000e+00      1.000000000e-01
```

Also see

[dmm.configure.recall\(\)](#) (on page 8-176)
[dmm.configure.set\(\)](#) (on page 8-178)
[dmm.func](#) (on page 8-190)
[dmm.range](#) (on page 8-225)

dmm.autozero

The autozero setting for the active DMM function.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	1 (dmm.ON)

Usage

```
value = dmm.autozero
dmm.autozero = value
```

<code>value</code>	Enable autozero (dmm.ON or 1) Disable autozero (dmm.OFF or 0) Refresh the reference points once then disable (dmm.AUTOZERO_ONCE or 2)
--------------------	---

Details

The autozero setting applies to the function selected by `dmm.func`. It is available for all functions except "continuity" and "nofunction".

You can send `dmm.AUTOZERO_ONCE` or 2 to refresh the reference points once. When this command is sent, the reference points are refreshed, and then autozero is set to disabled (`dmm.OFF` or 0). Querying `dmm.autozero` after sending `dmm.AUTOZERO_ONCE` generates a response of 0.

For `dmm.nplc` settings that are less than 0.2 plc, sending `dmm.AUTOZERO_ONCE` or 2 results in significant delays. For example, the delay time at a NPLC of 0.0005 is 2.75 s. The delay time at 0.199 is 5.45 s.

An error is generated if:

- You try to set `dmm.autozero` for "continuity" or "nofunction". The error 1114, "Setting conflicts with function selected" is generated.
- You query `dmm.autozero` for "continuity" or "nofunction". `nil` is returned, along with error 1114.

Example

<pre>dmm.func = "dcvolts" dmm.autozero = dmm.ON</pre>	Enables autozero for DC volts.
<pre>dmm.autozero = dmm.AUTOZERO_ONCE print(dmm.autozero)</pre>	Refreshes the reference points once and sets autozero to <code>dmm.OFF</code> or 0. Output: 0.000000000e+00
<pre>timer.reset() dmm.autozero=2 time=timer.measure.t() print(time)</pre>	Determines the time delay when autozero is selected.

Also see

[Autozero](#) (on page 4-3)
[dmm.configure.recall\(\)](#) (on page 8-176)
[dmm.configure.set\(\)](#) (on page 8-178)
[dmm.func](#) (on page 8-190)
[dmm.nplc](#) (on page 8-220)
[dmm.reset\(\)](#) (on page 8-230)
[reset\(\)](#) (on page 8-316)

dmm.buffer.catalog()

Creates an iterator for the user-created reading buffers.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
for name in dmm.buffer.catalog() do...end
```

<i>name</i>	A string representing the name of a user created DMM reading buffer
-------------	---

Details

You can access the catalog for the user-created local reading buffers so that you can print the names of all reading buffers in the system. The entries are enumerated in no particular order. From this list, you may selectively delete reading buffers from the system.

NOTE

Do not delete the reading buffers by sending:

```
for name in dmm.buffer.catalog() do name = nil end
```

This locks the system and forces you to stop the command (through the EXIT key on the front panel). It does not delete the reading buffers from the instrument. This occurs because *name* is a string type variable and not a reading buffer type.

Example

<pre>for name in dmm.buffer.catalog() do print(name) end</pre>	Print all user-created local reading buffers in the system. Assume the return is: buf3 buf5 buf1
<pre>buf1 = nil collectgarbage()</pre>	Deletes buf1.

Also see

[dmm.buffer.info\(\)](#) (on page 8-162)

dmm.buffer.info()

Returns the size and capacity of the reading buffer parameter.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
size, capacity = dmm.buffer.info(bufferVar)
```

<i>size</i>	Number representing the <i>N</i> (presently stored) attribute of the reading buffer parameter
<i>capacity</i>	Number representing the overall capacity attribute of the reading buffer parameter
<i>bufferVar</i>	String representing the reading buffer name that you want to query for size and capacity

Details

This function uses the specified reading buffer input parameter name to find the corresponding size and capacity to return. Use this function with the `dmm.buffer.catalog()` function to output the size and capacity for all reading buffers in the system.

Example

```
for n in dmm.buffer.catalog() do
  print(dmm.buffer.info(n))
end
```

Assume the system has the following reading buffers created: `buffer1`, `buffer2`, `buffer3`, `buffer4`, and `buffer5`.

Query the system for the size and capacity of each reading buffer without formatting the results.

The output is:

```
0.000000000e+00 2.000000000e+03
0.000000000e+00 4.000000000e+03
0.000000000e+00 5.000000000e+03
0.000000000e+00 3.000000000e+03
0.000000000e+00 1.000000000e+03
```

```
for n in dmm.buffer.catalog() do
  size, cap = dmm.buffer.info(n)
  print(n, 'size = ' .. size, 'capacity = '
    .. cap)
end
```

Query the system for the name, size, and capacity of each reading buffer while formatting the results.

The output is:

```
buffer2 size = 0 capacity = 2000
buffer4 size = 0 capacity = 4000
buffer5 size = 0 capacity = 5000
buffer3 size = 0 capacity = 3000
buffer1 size = 0 capacity = 1000
```

Also see

[dmm.buffer.catalog\(\)](#) (on page 8-161)

dmm.buffer.maxcapacity

The overall maximum capacity for reading buffers in the instrument.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Never	Not applicable	Not applicable

Usage

```
maximumCapacity = dmm.buffer.maxcapacity
```

<i>maximumCapacity</i>	A number that represents the overall maximum capacity for the reading buffers
------------------------	---

Details

Determines the maximum capacity of the instrument for reading buffer storage. This value represents the total system reading buffer storage size. A single reading buffer may be created with this as its size, or several reading buffers may be created in the instrument that are smaller in size. However, the sum total of all reading buffer sizes in the instrument cannot exceed this maximum.

Example

```
MaxBuffCap = dmm.buffer.maxcapacity
print(MaxBuffCap)
```

Reads the maximum reading buffer capacity for the instrument, which is 650,000 readings.
Output:
6.500000000e+05

Also see

[dmm.buffer.info\(\)](#) (on page 8-162)
[dmm.buffer.usedcapacity](#) (on page 8-163)
[dmm.makebuffer\(\)](#) (on page 8-207)

dmm.buffer.usedcapacity

Indicates how much of the maximum capacity for reading buffers in the instrument is used.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Instrument reset Recall setup	Not applicable	Not applicable

Usage

```
usedCapacity = dmm.buffer.usedcapacity
```

<i>usedCapacity</i>	The presently used capacity for reading buffers in the instrument
---------------------	---

Details

This value represents the sum total capacity of all reading buffers in the instrument.

Example

<pre>buf1 = dmm.makebuffer(300000) buf2 = dmm.makebuffer(300000) print(dmm.buffer.usedcapacity) print(dmm.buffer.maxcapacity - dmm.buffer.usedcapacity)</pre>	<p>Create buffers.</p> <p>Reads the used reading buffer capacity for the system.</p> <p>6.000000000e+05</p> <p>5.000000000e+04</p> <p>This shows that there is 50,000 available for creating additional reading buffers.</p>
---	--

Also see

[dmm.buffer.info\(\)](#) (on page 8-162)
[dmm.buffer.maxcapacity](#) (on page 8-163)

dmm.calibration.ac()

Begins the desired AC adjustment step on the DMM.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
dmm.calibration.ac(step)
dmm.calibration.ac(step, value)
```

<i>step</i>	The AC adjustment step to perform
<i>value</i>	The value for this adjustment step (if the adjustment step has a value)

Details

This command generates an error if the:

- Calibration is locked
- Step is out of sequence
- Step does not exist
- Step does not complete successfully
- Value passed is invalid for the step, out of range, or not needed

Example

For detail on how to use `dmm.calibration.ac()`, see [AC volts calibration](#) (on page C-29), [AC current calibration](#) (on page C-31), and [Frequency calibration](#) (on page C-33).

Also see

[dmm.calibration.dc\(\)](#) (on page 8-165)
[dmm.calibration.lock\(\)](#) (on page 8-166)
[dmm.calibration.unlock\(\)](#) (on page 8-168)

dmm.calibration.dc()

Begins the desired DC adjustment step on the DMM.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
dmm.calibration.dc(step)
dmm.calibration.dc(step, value)
```

<i>step</i>	The DC adjustment step to perform
<i>value</i>	The value for this adjustment step (if the adjustment step has a value)

Details

This command generates an error if the:

- Calibration is locked
- Step is out of sequence
- Step does not exist
- Step does not complete successfully
- Value passed is invalid for the step, out of range, or not needed

Example

For example of use, see [DC volts calibration](#) (on page C-25), [Resistance calibration](#) (on page C-27), and [DC current calibration](#) (on page C-28).

Also see

[dmm.calibration.ac\(\)](#) (on page 8-164)
[dmm.calibration.lock\(\)](#) (on page 8-166)
[dmm.calibration.unlock\(\)](#) (on page 8-168)

dmm.calibration.lock()

Locks calibration to prevent unintended changes.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
dmm.calibration.lock()
```

Details

Use this command to lock an unlocked calibration. An error is generated if this command is issued when calibration is already locked.

Once locked, you must unlock calibration before you can perform calibration again.

NOTE

Save calibration data before locking. Calibration data will be lost if it is not saved before locking.

Example

```
dmm.calibration.save ()
dmm.calibration.lock ()
```

Save calibration, then lock it.

Also see

[dmm.calibration.unlock\(\)](#) (on page 8-168)

[dmm.calibration.save\(\)](#) (on page 8-168)

dmm.calibration.password

This attribute sets the password that must be entered before you can unlock calibration.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (W)	Yes	Not applicable	DMM nonvolatile memory	KI003706

Usage

```
dmm.calibration.password = password
```

<i>password</i>	A string that represents the valid password to unlock calibration
-----------------	---

Details

This attribute can only be set when calibration is unlocked.

This attribute generates an error if calibration is locked or if the password string length is greater than ten characters.

NOTE

Be sure to record the password; there is no command to query for the password once it is set.

Example

```
dmm.calibration.unlock("KI003706")
dmm.calibration.password = "myUnlock"
dmm.calibration.lock()
```

To change the default calibration password, unlock the calibration with the default password.
Saves the password as "myUnlock".
Lock calibration. Subsequent unlocks will use the password "myUnlock".

Also see

[dmm.calibration.unlock\(\)](#) (on page 8-168)

dmm.calibration.save()

Saves calibration data.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
dmm.calibration.save()
```

Details

This command saves the calibration constants and adjustment date and increases the adjustment count by 1. The adjustment count is the number of times calibration has been saved.

This command does not check for errors in calibration data. Calibration data is saved regardless of calibration data errors.

The calibration date can be specified with `dmm.adjustment.date`. If it is not specified, the date is based on the system date.

To prevent data loss, you need to send the save command before locking calibration.

An error is generated if this command is issued when calibration is already locked.

Example

```
dmm.calibration.save()
```

Saves calibration data.

Also see

[dmm.adjustment.date](#) (on page 8-152)

[dmm.calibration.lock\(\)](#) (on page 8-166)

[dmm.calibration.unlock\(\)](#) (on page 8-168)

dmm.calibration.unlock()

Unlocks calibration if calibration was locked.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
dmm.calibration.unlock(password)
```

```
password
```

A string representing the password to unlock calibration

Details

If the password does not match the saved password, an error is generated. The default password from the factory is "KI003706". You can change the default with `dmm.calibration.password`.

Example

```
dmm.calibration.unlock("KI003706")
```

Unlocks calibration using the default password.

Also see

[dmm.calibration.lock\(\)](#) (on page 8-166)

[dmm.calibration.password](#) (on page 8-167)

dmm.calibration.verifydate

This attribute sets or queries the calibration verification date in UTC format (number of seconds since January 1, 1970).

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Not applicable	DMM nonvolatile memory	Not applicable

Usage

```
calibrationVerificationDate = dmm.calibration.verifydate
dmm.calibration.verifydate = os.time()
```

<code>calibrationVerificationDate</code>	The number of seconds since January 1, 1970 when the last calibration verify date was set
<code>os.time({year=yyyy, month=m, day=d})</code>	Specifies the date; if a value is not specified, sets the verification date to the present date of the instrument

Details

When using the `os.time()` function:

- If no parameters are specified, the current date and time of the instrument is used. See example 4 below.
- Use a table with entries for year as *yyyy*, month as *mm* and day as *dd* to specify a date. See example 3 below.

See [Lua documentation](http://www.lua.org) (see Lua website - <http://www.lua.org>) for the formatting options that are available for `os.date`.

This command can only be set when calibration is unlocked.

Example 1

<pre>print(os.date("%m/%d/%Y", dmm.calibration.verifydate))</pre>	Assume the system date is July 4, 2007 for this example; queries the calibration verification date and formats the response as mm/dd/yyyy: 07/04/2007
---	--

Example 2

<pre>print(os.date("%x", dmm.calibration.verifydate))</pre>	Assume the system date is July 4, 2007 for this example; queries the date and formats the response as mm/dd/yy: 07/04/07
---	---

Example 3

<pre>dmm.calibration.verifydate = os.time{year=2007, month=7, day = 4}</pre>	Set the calibration verification date to July 4, 2007.
--	--

Example 4

<pre>dmm.calibration.verifydate = os.time()</pre>	Set the calibration verification to the present date of the instrument.
---	---

Also see

[dmm.adjustment.date](#) (on page 8-152)
[dmm.calibration.unlock\(\)](#) (on page 8-168)
[Lua documentation](http://www.lua.org) (see Lua website - <http://www.lua.org>)

dmm.close()

Closes the specified channel or channel pattern to prepare for a measurement.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
dmm.close(channelList)
```

<i>channelList</i>	A string listing the channel or channel pattern to close
--------------------	--

Details

When you close a channel or channel pattern:

- Channels on all slots are opened if they interfere with measurement, including analog backplane relays 1 and 2 and commonside ohm backplane relays. The opening and closing of channels mimics that of `channel.exclusiveslotclose()`. Therefore, when using a for-loop with `dmm.close()` command, the last channel on each slot is closed at the end of the for loop execution.
- To have additional analog backplane relays 3 through 6 close, use them on an alternate slot. If they need to be on same slot, create a channel pattern.
- To have additional channels close, use patterns. When you use patterns, you must specify all items to close, including analog backplane relays. With patterns, there is no auto manipulation of analog backplane relays 1 and 2 as there is with channels.
- Any amp channels will open. If you need to have multiple amp channels closed, create a channel pattern.
- Associated channels and analog backplane relays will close, which include analog backplane relay 1 and 2, as needed based on configuration associated with channel (see `dmm.getconfig()`) Analog backplane relays specified by `channel.setbackplane()` are not used.

The DMM configuration is determined by the configuration associated with the channel or channel pattern being closed. If the configuration is a default name, the function of that configuration will be reset to factory default settings. You must create a unique DMM configuration to avoid using factory default settings when assigning to a channel. For more information on setting DMM configuration, see [dmm.configure.set\(\)](#) (on page 8-178), [dmm.setconfig\(\)](#) (on page 8-239), and [dmm.getconfig\(\)](#) (on page 8-192).

This command allows you to separate the closing of channels from measuring. Therefore, you may execute any number of commands between the close and measure commands to satisfy your application needs.

An error is generated if:

- The specified channel or channel pattern is invalid.
 - The channel number does not exist for the slot specified.
 - The channel pattern does not exist.
 - The specified channel does not support being closed (like a digital I/O channel).
 - More than one channel or channel pattern is specified.
 - The channel is paired with another bank for a multi-wire application.
 - The channel is an analog backplane relay.
 - The channel configuration is set to nofunction.
- Once an error is detected, the command stops processing. Channels and DMM settings remain unchanged.

Example

<pre>dmm.setconfig("3003", "tempMeasure") dmm.close('3003')</pre>	Close channel 3 on slot 3 and prepare the DMM for measuring temperature with <code>tempMeasure</code> settings.
<pre>dmm.setconfig("channelDCV", "dcvolts") dmm.close("channelDCV")</pre>	Close a channel pattern called <code>channelDCV</code> and prepare DMM for measuring DC volts at factory default settings.

Also see

[channel.exclusiveslotclose\(\)](#) (on page 8-57)
[channel.getclose\(\)](#) (on page 8-61)
[channel.getstate\(\)](#) (on page 8-76)
[channel.setbackplane\(\)](#) (on page 8-90)
[dmm.getconfig\(\)](#) (on page 8-192)
[dmm.open\(\)](#) (on page 8-222)

dmm.configure.catalog()

Creates an iterator for user-created DMM configurations.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
for name in dmm.configure.catalog() do ... end
```

<i>name</i>	A string representing the name of a user-created DMM configuration.
-------------	---

Details

You can access the catalog for user DMM configurations to print or delete all configurations in the runtime environment.

The entries are enumerated in no particular order. This only lists user-created DMM configurations; it does not list the factory default configurations.

Example

<pre>for name in dmm.configure.catalog() do print(name) end</pre>	<p>Prints the names of all user-created DMM configurations in the instrument. The output will look similar to:</p> <pre>TestDcv TestTemperature TestTwoWire</pre> <p>This indicates there are three user-created DMM configurations in the instrument with the names TestDCV, TestTemperature, and TestTwoWire.</p>
<pre>for name in dmm.configure.catalog() do dmm.configure.delete(name) end</pre>	<p>Deletes all user-created DMM configurations from the instrument.</p>

Also see

[dmm.configure.delete\(\)](#) (on page 8-173)

[dmm.configure.query\(\)](#) (on page 8-174)

[dmm.configure.recall\(\)](#) (on page 8-176)

[dmm.configure.set\(\)](#) (on page 8-178)

dmm.configure.delete()

Deletes a user-created DMM configuration from memory.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
dmm.configure.delete(name)
```

<i>name</i>	String that contains the name of the DMM configuration to delete
-------------	--

Details

If you delete a DMM configuration that is assigned to channels or channel patterns, those channels and patterns revert back to the factory default DMM configuration of "nofunction" (`dmm.setconfig()`).

If you delete a DMM configuration that is used in a scan list, the scan list is modified and the channel is set to "nofunction" for that configuration.

You cannot delete a DMM configuration on a closed channel. If you attempt to delete it, the error message is "1114, Settings conflict with deleting DMM configuration assigned to closed channel" is generated.

An error is generated if the name specified does not exist as a user configuration.

Example

<code>dmm.configure.delete("DCVDDMMConfig")</code>	Deletes a user configuration called DCVDDMMConfig.
--	--

Also see

[dmm.configure.catalog\(\)](#) (on page 8-172)

[dmm.configure.set\(\)](#) (on page 8-178)

[dmm.configure.query\(\)](#) (on page 8-174)

[dmm.configure.recall\(\)](#) (on page 8-176)

dmm.configure.query()

Lists DMM settings associated with a configuration.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
config = dmm.configure.query(userConfiguration)
config = dmm.configure.query(userConfiguration, userSeparator)
```

<i>config</i>	An output string that represents the DMM attribute settings of <i>userConfiguration</i>
<i>userConfiguration</i>	A string that contains the name for the DMM configuration to be listed. To query the settings for the active function, set this parameter to "active"
<i>userSeparator</i>	A string that represents the two-character separator that is inserted between items. The default value is a comma followed by a space (,)

Details

For the specified configuration, this function lists the settings and the corresponding DMM attributes.

If the specified configuration does not exist, a nil response is generated, along with an error message stating that the referenced name does not exist.

If *userSeparator* is specified, the attributes are delimited by this two-character separator. If more than two characters are specified, an error message is generated.

To query the factory default settings for a function, use the function, such as "dvolts" or "temperature", for the *userConfiguration* parameter. See `dmm.func` for valid functions.

Example

```
dmm.configure.set("DCvConfig")
DCvConfigItems = dmm.configure.query("DCvConfig")
print(DCvConfigItems)
```

Creates the configuration DCvConfig. Lists the DMM attributes in DCvConfig, separated by commas.

Output:

```
function = dcvolts,nplc = 5.000000E-001,aperture = 8.333333E-003,range =
  1.000000E+001,auto zero = 0,auto delay = 2,filter enable = 0,filter type =
  1,filter count = 10,filter window = 1.000000E-001,rel enable = 0,rel level =
  0.000000E+000,display digits = 6,dB reference = 1.000000E+000,input divider =
  0,units = 0,line sync = 0,limit 1 enable = 1,limit 1 autoclear = 1,limit 1 low
  value = -3.000000E+000,limit 1 high value = 5.000000E+000,limit 2 enable =
  0,limit 2 autoclear = 1,limit 2 low value = -2.000000E+000,limit 2 high value =
  2.000000E+000,math enable = 0,math format = 2,math mxb mfactor =
  1.000000E+000,math mxb bfactor = 0.000000E+000,math mxb units = X,math percent
  = 1.000000E+000
```

```
DCvConfigItems = dmm.configure.query("DCvConfig", "\n")
print(DCvConfigItems)
```

Lists the DMM attributes in DCvConfig separated by new lines.

Output:

```
function = dcvolts
nplc = 5.000000E-001
aperture = 8.333333E-003
range = 1.000000E+001
auto zero = 0
auto delay = 2
filter enable = 0
filter type = 1
filter count = 10
filter window = 1.000000E-001
rel enable = 0
rel level = 0.000000E+000
display digits = 6
dB reference = 1.000000E+000
input divider = 0
units = 0
line sync = 0
limit 1 enable = 1
limit 1 autoclear = 1
limit 1 low value = -3.000000E+000
limit 1 high value = 5.000000E+000
limit 2 enable = 0
limit 2 autoclear = 1
limit 2 low value = -2.000000E+000
limit 2 high value = 2.000000E+000
math enable = 0
math format = 2
math mxb mfactor = 1.000000E+000
math mxb bfactor = 0.000000E+000
math mxb units = X
math percent = 1.000000E+000

FactoryDCV = dmm.configure.query("dcvolts", "\n")
print(FactoryDCV)
```

Lists the factory default settings for DC volts separated by new lines.

```
ActiveFunc = dmm.configure.query("active", "\n")
print(ActiveFunc)
```

Lists the DMM attributes for the active function separated by new lines.

Also see

[dmm.configure.catalog\(\)](#) (on page 8-172)
[dmm.configure.delete\(\)](#) (on page 8-173)
[dmm.configure.recall\(\)](#) (on page 8-176)
[dmm.configure.set\(\)](#) (on page 8-178)
[dmm.func](#) (on page 8-190)

dmm.configure.recall()

Recalls a user or factory DMM configuration and replaces attributes in the present configuration with attributes from the recalled version.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
dmm.configure.recall(configuration)
```

<i>configuration</i>	A string that represents the name of the DMM configuration to recall
----------------------	--

Details

This command recalls the DMM configuration for one function.

When a configuration is recalled, the function associated with the configuration becomes active.

When you recall a DMM configuration, the existing DMM configuration settings for the function are replaced by the settings in the recalled configuration. Settings for other functions are not affected. For example, if the function associated with the configuration was temperature, only temperature settings are recalled. If a factory configuration is recalled, the function's attributes are set to their factory default values.

The DMM configuration can be user-defined or factory-defined.

User-defined DMM configurations are set with `dmm.configure.set()`. The factory-defined DMM configurations are:

- "accurrent"
- "acvolts"
- "commonsideohms"
- "continuity"
- "dcurrent"
- "dcvolts"
- "fourwireohms"
- "frequency"
- "nofunction"
- "period"
- "temperature"
- "twowireohms"

Example

```
dmm.func = "dcvolts"  
dmm.reset("active")  
dmm.nplc = 0.5  
dmm.range = 10  
dmm.configure.set("TestDcv")  
dmm.configure.recall("dcvolts")  
print(dmm.func, dmm.autorange, dmm.range, dmm.nplc)  
dmm.configure.recall("TestDcv")  
print(dmm.func, dmm.autorange, dmm.range, dmm.nplc)  
dmm.setconfig("slot1", "TestDcv")  
dmm.setconfig("2001:2015", "TestDcv")  
dmm.setconfig("3005", "TestDcv")
```

Set the DMM to the DC volts function.

Reset DC volts back to factory defaults.

Set the NPLC for DC volts to 0.5.

Select the 10 volt range for DC volts and disable autorange.

Save a user DMM configuration for DC volts called "TestDcv".

Recall and configure the DMM for factory DC volts.

Output the settings for factory-defined DC volts.

Recall the user DMM configuration called "TestDcv".

Output the settings for TestDcv.

Set the DMM configuration for slot 1, channels 2001 to 2005, and channel 3005 to TestDcv.

Output:

dcvolts	1.000000000e+00	1.000000000e+01	1.000000000e+00
dcvolts	0.000000000e+00	1.000000000e+01	5.000000000e-01

Also see

[dmm.configure.delete\(\)](#) (on page 8-173)

[dmm.configure.query\(\)](#) (on page 8-174)

[dmm.configure.set\(\)](#) (on page 8-178)

[dmm.func](#) (on page 8-190)

dmm.configure.set()

Creates a named DMM configuration for the selected function. The configuration includes pertinent attributes for that function.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Reset Recall setup	Create configuration script Save setup	See Details

Usage

```
dmm.configure.set (name)
```

<i>name</i>	A string that contains the name of the DMM configuration that you are creating
-------------	--

Details

This command saves the selected function and its pertinent settings. You can recall this configuration using `dmm.configure.recall()`. You can also apply the configuration using `dmm.setconfig()` to channels or channel patterns.

`dmm.configure.set()` stores only pertinent settings. For example, if `dmm.func` is set to "dcvolts", temperature settings are not stored.

DMM configurations are not saved through a power cycle. To save the configuration through a power cycle, use `setup.save()` or `createconfigscript()`. These options save all DMM user configurations.

If the name of the configuration:

- Already exists, the existing configuration is overwritten with the new configuration.
- Is the same as that of a factory-default configuration, an error is generated.
- Is longer than 30 characters, an error is generated.
- Any channels that were configured to use that configuration will be evaluated to determine if the new settings are valid for the channels. If they are, the channels will start using the new configuration settings. If not, the configuration associated with that channel will revert to the factory default setting of "nofunction".

Some DMM configurations are preset. The factory default configuration names are:

- "accurrent"
- "acvolts"
- "commonsideohms"
- "continuity"
- "dcurrent"
- "dcvolts"
- "fourwireohms"
- "frequency"
- "nofunction"
- "period"
- "temperature"
- "twowireohms"

If you change the settings for an existing DMM configuration, the existing scan list will be updated to use the new settings for the existing DMM configuration. However, if the function or a setting is not valid for a channel in the scan list, the scan list will be reset to the default configuration of "nofunction".

Example

```
dmm.func = "dcvolts"  
dmm.reset("active")  
dmm.nplc = 0.5  
dmm.range = 10  
dmm.configure.set("TestDcv")  
dmm.configure.recall("dcvolts")  
print(dmm.func, dmm.autorange, dmm.range, dmm.nplc)  
dmm.configure.recall("TestDcv")  
print(dmm.func, dmm.autorange, dmm.range, dmm.nplc)
```

Set the DMM to the DC volts function.

Reset DC volts back to factory defaults.

Set the NPLC for DC volts to 0.5.

Select the 10 volt range for DC volts and disable autorange.

Save a user DMM configuration for DC volts called "TestDcv".

Recall and configure the DMM for factory DC volts.

Output the settings for factory DC volts.

Recall the user DMM configuration called "TestDcv".

Output the settings for the TestDcv configuration.

Output:

dcvolts	1.000000000e+00	1.000000000e+01	1.000000000e+00
dcvolts	0.000000000e+00	1.000000000e+01	5.000000000e-01

Also see

[createconfigscript\(\)](#) (on page 8-115)
[dmm.configure.catalog\(\)](#) (on page 8-172)
[dmm.configure.delete\(\)](#) (on page 8-173)
[dmm.configure.query\(\)](#) (on page 8-174)
[dmm.configure.recall\(\)](#) (on page 8-176)
[dmm.func](#) (on page 8-190)
[dmm.setconfig\(\)](#) (on page 8-239)
[setup.save\(\)](#) (on page 8-368)

dmm.connect

Indicates how the DMM relays should be connected to the analog backplane.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	7 (dmm.CONNECT_ALL)

Usage

```
value = dmm.connect
dmm.connect = value
```

<i>value</i>	The DMM relay connection setting. See Details for valid values
--------------	---

Details

NOTE

Use of this command is not recommended with the exception of special cases. The default setting should handle most applications.

This setting affects all DMM functions. Valid values are shown in the table below.

Valid values	
Value	Relays connected
dmm.CONNECT_NONE or 0	None
dmm.CONNECT_ALL or 7	All
dmm.CONNECT_TWO_WIRE or 1	2-wire
dmm.CONNECT_FOUR_WIRE or 3	2-wire and sense
dmm.CONNECT_TWO_WIRE_AMPS or 5	2-wire & amp
dmm.CONNECT_AMPS or 4	amp

The relays are bitmapped into the lower 3 bits of the value as shown in the following table.

Relay bitmap		
Bit	Value	Relays represented
0	1	2-wire
1	2	sense
2	4	amp

To close a relay, set the appropriate bit to 1.

To open a relay, set the appropriate bit to 0.

An error is generated if:

- The sense relay bit is set to a 1 and the sense relay with amps is selected. These two settings correspond to a value of 2 or 6, respectively.
- The value is less than 0 or greater than 7.

Example

dmm.connect = dmm.CONNECT_TWO_WIRE_AMPS	Connects the DMM 2-wire and amp relays to the analog backplane.
---	---

Also see

None

dmm.dbreference

The decibel (DB) reference setting for the DMM in volts.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	1.000000E+00

Usage

```
value = dmm.dbreference
dmm.dbreference = value
```

<i>value</i>	The desired DB reference in volts (1e-7 to 1000)
--------------	--

Details

The DB reference setting applies only when `dmm.func` is set to "dcvolts" or "acvolts". If you query this value for any other function, nil is returned.

An error is generated:

- If you send this command for any function other than "dcvolts" or "acvolts".
- If the value is out of range.

The DB reference setting is saved with the `dmm.func` function setting, so if you use another function, then return to "dcvolts" or "acvolts", the DB reference setting you set previously are retained.

Example

```
dmm.func = "dcvolts"
dmm.dbreference = 5
```

Sets the DB reference to 5 volts for DC volts.

Also see

[Express DC or AC voltage in decibels](#) (see "[dB commands](#)" on page 4-48)
[dmm.configure.recall\(\)](#) (on page 8-176)
[dmm.configure.set\(\)](#) (on page 8-178)
[dmm.func](#) (on page 8-190)

dmm.detectorbandwidth

The AC detector bandwidth setting for the DMM in Hertz.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	300

Usage

```
value = dmm.detectorbandwidth
dmm.detectorbandwidth = value
```

<i>value</i>	The detector bandwidth in Hertz
--------------	---------------------------------

Details

Only applies when `dmm.func` is set to "acvolts" or "accurrent".

If you query this value for any other function, nil is returned.

When you send this value, the input value is adjusted as follows:

Write value	Read value
< 30	3
Between 30 and 300	30
≥ 300	300

An error is generated:

- If you send this command for any function other than "accurrent" or "acvolts"
- If you set `dmm.aperture` and the detector bandwidth read value is 30 or less
- If the value is below 3

Example

```
reset()
dmm.func = "acvolts"
print(dmm.func, dmm.detectorbandwidth)
dmm.detectorbandwidth = 35
print(dmm.func, dmm.detectorbandwidth)
dmm.func = "accurrent"
print(dmm.func, dmm.detectorbandwidth)
dmm.func = "acvolts"
print(dmm.func, dmm.detectorbandwidth)
```

Sets the detector bandwidth to 35 Hz for AC volts. 35 is adjusted to 30. AC current is still at 300 Hz.

Output:

```
acvolts      3.000000000e+02
acvolts      3.000000000e+01
accurrent    3.000000000e+02
acvolts      3.000000000e+01
```

Also see

- [dmm.aperture](#) (on page 8-153)
- [dmm.configure.recall\(\)](#) (on page 8-176)
- [dmm.configure.set\(\)](#) (on page 8-178)
- [dmm.func](#) (on page 8-190)

dmm.displaydigits

The display digits setting for the selected DMM function.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	See table in Details

Usage

```
value = dmm.displaydigits
dmm.displaydigits = value
```

value	
	7½ display digits: <code>dmm.DIGITS_7_5</code> or 7
	6½ display digits: <code>dmm.DIGITS_6_5</code> or 6
	5½ display digits: <code>dmm.DIGITS_5_5</code> or 5
	4½ display digits: <code>dmm.DIGITS_4_5</code> or 4
	3½ display digits: <code>dmm.DIGITS_3_5</code> or 3

Details

This is not available for "nofunction".

This attribute affects how the reading for a function is displayed on the front panel of the instrument. It does not affect the number of digits returned in a remote command reading. It also does not affect the accuracy or speed of measurements.

The display digits setting is saved with the `dmm.func` function setting, so if you use another function, then return to the function for which you set display digits, the display digits setting you set previously is retained.

To change the number of digits returned in a remote command reading, use `format.asciiprecision`.

Defaults	
If <code>dmm.func</code> is...	The default is...
"acurrent", "acvolts", "temperature"	5
"commonsideohms", "dccurrent", "dcvolts", "twowireohms", "fourwireohms", "frequency", "period"	6
"continuity"	4

An error is generated:

- If the value is invalid
- If `dmm.func` is set to "nofunction", if the command is queried, `nil` is returned
- `dmm.func` is set to "nofunction" or "continuity", if the command is written, the error "1114, Settings conflict with function selected" is returned

Example

```
dmm.func = "dcvolts"
dmm.displaydigits = dmm.DIGITS_7_5
```

Enables display digits to 7½ for DC volts.

Also see

- [dmm.configure.recall\(\)](#) (on page 8-176)
- [dmm.configure.set\(\)](#) (on page 8-178)
- [dmm.func](#) (on page 8-190)
- [format.asciiprecision](#) (on page 8-257)

dmm.drycircuit

The dry circuit setting for the selected DMM function.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	reset DMM reset Recall setup	Create configuration script Save setup	0 (dmm.OFF)

Usage

```
state = dmm.drycircuit
dmm.drycircuit = state
```

<code>state</code>	Enable dry circuit (dmm.ON or 1) Disable dry circuit (dmm.OFF or 0)
--------------------	--

Details

The dry circuit setting only applies when `dmm.func` is set to "fourwireohms" or "commonsideohms".

For power and low-glitch resistance measurements requiring a low open-circuit voltage (20 mV), dry circuit ohms can be used on the 1 Ω , 10 Ω , 100 Ω , 1 k Ω , and 10 k Ω ranges (maximum of 2.4 k Ω) for the 4-wire ohm function. When dry circuit is enabled, offset compensation is automatically set to on.

This command automatically sets `dmm.offsetcompensation` to `dmm.ON` when `dmm.func` = "fourwireohms" or "commonsideohms".

An error is generated if:

- You try to set `dmm.drycircuit` for a function other than "fourwireohms" or "commonsideohms". Error 1114, "Setting conflicts with function selected" is generated.
- You query `dmm.drycircuit` for a function other than "fourwireohms" or "commonsideohms". `nil` is returned, along with error 1114.
- The state is invalid.

The dry circuit setting is saved with the `dmm.func` function setting, so if you use another function, then return to the previous function, the dry circuit setting you set previously is retained.

Example

```
dmm.func = "fourwireohms"
dmm.drycircuit = dmm.ON
```

Enable dry circuit for 4-wire ohms.

Also see

- [dmm.configure.recall\(\)](#) (on page 8-176)
- [dmm.configure.set\(\)](#) (on page 8-178)
- [dmm.func](#) (on page 8-190)
- [dmm.offsetcompensation](#) (on page 8-221)

dmm.filter.count

The filter count setting for the selected DMM function.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	10

Usage

```
value = dmm.filter.count
dmm.filter.count = value
```

<code>value</code>	The filter count setting from 1 to 100
--------------------	--

Details

The number of measured readings that will yield one filtered measurement when filtered measurements are enabled.

The filter count setting only applies when `dmm.func` is set to one of the following:

- "accurrent"
- "acvolts"
- "commonsideohms"
- "dcurrent"
- "dcvolts"
- "fourwireohms"
- "temperature"
- "twowireohms"

If you query the setting for any other function, `nil` is returned.

The filter count setting is saved with the `dmm.func` function setting, so if you use another function, then return to the previous function, the filter count setting you set previously is retained.

An error is generated if:

- You send the setting for any other function.
- The value is out of range.

Example

```
dmm.func = "twowireohms"
dmm.filter.count = 5
dmm.filter.enable = dmm.ON
```

Sets the filter count for 2-wire ohms to 5 and enables filtered measurements.

Also see

- [dmm.configure.set\(\)](#) (on page 8-178)
- [dmm.configure.recall\(\)](#) (on page 8-176)
- [dmm.filter.enable](#) (on page 8-186)
- [dmm.filter.type](#) (on page 8-187)

dmm.filter.enable

Indicates if filtered measurements are enabled or disabled for the selected DMM function.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	0 (dmm.OFF)

Usage

```
value = dmm.filter.enable
dmm.filter.enable = value
```

<i>value</i>	Filter measurements setting: <ul style="list-style-type: none"> dmm.ON or 1: Filter measurements enabled dmm.OFF or 0: Filter measurements disabled
--------------	---

Details

The filter enable setting only applies when `dmm.func` is set to one of the following:

- "accurrent"
- "acvolts"
- "commonsideohms"
- "dccurrent"
- "dcvolts"
- "fourwireohms"
- "temperature"
- "twowireohms"

Querying the setting for any other function will return `nil` and an error message.

The filter enable setting is saved with the `dmm.func` function setting, so if you use another function, then return to the previous function, the filter enable setting you set previously is retained.

Example

```
dmm.func = "twowireohms"
dmm.filter.type = dmm.FILTER_MOVING_AVG
dmm.filter.count = 3
dmm.filter.enable = dmm.ON
```

Enable filtered measurements for 2-wire ohms using a moving average filter type with a count of 3 for each measurement.

Also see

- [dmm.configure.recall\(\)](#) (on page 8-176)
- [dmm.configure.set\(\)](#) (on page 8-178)
- [dmm.filter.count](#) (on page 8-185)
- [dmm.filter.type](#) (on page 8-187)
- [dmm.filter.window](#) (on page 8-188)
- [dmm.func](#) (on page 8-190)
- [dmm.reset\(\)](#) (on page 8-230)

dmm.filter.type

The filter type for the DMM measurements for selected DMM functions.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	1 (dmm.FILTER_REPEAT_AVG)

Usage

```
value = dmm.filter.type
dmm.filter.type = value
```

<code>value</code>	The filter type setting: <ul style="list-style-type: none"> • <code>dmm.FILTER_MOVING_AVG</code> or 0 for moving average filter • <code>dmm.FILTER_REPEAT_AVG</code> or 1 for repeating filter
--------------------	--

Details

The filter type setting only applies when `dmm.func` is set to one of the following:

- "accurrent"
- "acvolts"
- "commonsideohms"
- "dcurrent"
- "dcvolts"
- "fourwireohms"
- "temperature"
- "twowireohms"

Querying the setting for any other function returns `nil`. An error is generated if this setting is written or read for any other function.

You can choose from two averaging filter types: Repeating and moving. When the repeating filter type is selected, the stack (filter count) is filled, and the conversions are averaged to yield a reading. The stack is then cleared, and the process starts over.

When the moving average filter type is selected, a first-in, first-out stack is used. When the stack (filter count) becomes full, the measurement conversions are averaged to yield a reading. For each subsequent conversion placed into the stack, the oldest conversion is discarded. The stack is then re-averaged to yield a new reading.

The filter type setting is saved with the `dmm.func` function setting, so if you use another function, then return to the previous function, the filter type setting you set previously is retained.

Example

```
dmm.func = "twowireohms"
dmm.filter.type = dmm.FILTER_MOVING_AVG
dmm.filter.enable = dmm.ON
```

Set the filter type for 2-wire ohms to moving average and enable filtered measurements.

Also see

- [dmm.configure.recall\(\)](#) (on page 8-176)
- [dmm.configure.set\(\)](#) (on page 8-178)
- [dmm.filter.count](#) (on page 8-185)
- [dmm.filter.enable](#) (on page 8-186)
- [dmm.filter.window](#) (on page 8-188)
- [dmm.func](#) (on page 8-190)

dmm.filter.window

The filter window for the DMM measurements.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	1.000000E-01 (0.1)

Usage

```
value = dmm.filter.window
dmm.filter.window = value
```

<code>value</code>	The filter window setting; the range is between 0 and 10 to indicate percent of range
--------------------	---

Details

The filter window setting only applies when `dmm.func` is set to one of the following:

- "accurrent"
- "acvolts"
- "commonsideohms"
- "dcurrent"
- "dcvolts"
- "fourwireohms"
- "temperature"
- "twowireohms"

Querying the setting for any other function returns `nil`. An error is generated if this setting is written or read for any other function.

An error is generated if the value is out of range.

The filter window setting is saved with the `dmm.func` function setting, so if you use another function, then return to the previous function, the filter window setting you set previously is retained.

Example

```
dmm.func = "twowireohms"
dmm.filter.window = 0.25
dmm.filter.enable = dmm.ON
```

Set the filter window for 2-wire ohms to 0.25 and enable filtered measurements.

Also see

- [dmm.configure.recall\(\)](#) (on page 8-176)
- [dmm.configure.set\(\)](#) (on page 8-178)
- [dmm.filter.enable](#) (on page 8-186)
- [dmm.filter.count](#) (on page 8-185)
- [dmm.filter.type](#) (on page 8-187)

dmm.fourrtd

The type of four-wire RTD being used.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	0 (dmm.RTD_PT100)

Usage

```
value = dmm.fourrtd
dmm.fourrtd = value
```

<i>value</i>	<p>The desired type for four-wire RTD:</p> <ul style="list-style-type: none"> • dmm.RTD_PT100 or 0 for type PT100 • dmm.RTD_D100 or 1 for type D100 • dmm.RTD_F100 or 2 for type F100 • dmm.RTD_PT385 or 3 for type PT385 • dmm.RTD_PT3916 or 4 for type PT3916 • dmm.RTD_USER or 5 for user-specified type
--------------	---

Details

This attribute is only valid when `dmm.func` is set to "temperature" and `dmm.transducer` is set to `dmm.TEMP_FOURRTD`. For all other transducer types, the attribute is set but is not used until the transducer type is set for four-wire RTD.

All other functions generate an error and return nil when queried. An illegal parameter value error message is generated if the value specified is not a supported RTD type value as listed in the usage table.

The four-wire RTD setting is saved with the `dmm.func` function setting, so if you use another function, then return to "temperature", the four-wire RTD settings you set previously are retained.

Example

```
dmm.func = "temperature"
dmm.transducer = dmm.TEMP_FOURRTD
dmm.fourrtd = dmm.RTD_PT3916
```

Sets the type of four-wire RTD for PT3916.

Also see

[dmm.configure.recall\(\)](#) (on page 8-176)
[dmm.configure.set\(\)](#) (on page 8-178)
[dmm.func](#) (on page 8-190)
[dmm.transducer](#) (on page 8-246)

dmm.func

The selected function for the DMM.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Instrument reset DMM reset Recall setup	Create configuration script Save setup	dmm.DC_VOLTS

Usage

```
function = dmm.func
dmm.func = function
```

function	One of the following DMM functions:
	<ul style="list-style-type: none"> "accurent" or dmm.AC_CURRENT "acvolts" or dmm.AC_VOLTS "commonsideohms" or dmm.COMMON_SIDE_OHMS "continuity" or dmm.CONTINUITY "dcurrent" or dmm.DC_CURRENT "dcvolts" or dmm.DC_VOLTS "fourwireohms" or dmm.FOUR_WIRE_OHMS "frequency" or dmm.FREQUENCY "nofunction" or dmm.NO_FUNCTION "period" or dmm.PERIOD "temperature" or dmm.TEMPERATURE "twowireohms" or dmm.TWO_WIRE_OHMS

Details

This attribute determines the selected DMM function and indicates how the other DMM attributes are to be processed.

When the DMM functionality changes, the attributes for the new DMM function become active. Unless you update these attributes, they will be the factory defaults or the values that were used the last time the function was used. If you want to see settings for a particular function, change to that function with `dmm.func`, then write or read the desired settings specifically. To see all attributes at once, use `dmm.configure.query` with a first parameter value of "active" as shown in the example below.

An error is generated:

- If the setting does not match one of the ones specified in usage.
- If a user DMM configuration name is used to set the function.

If an error is found, no change is made to the function.

Example

<code>dmm.func = "temperature"</code>	Makes "temperature" the active DMM function.
<code>dmm.func = "dcvolts"</code> <code>dcm_nplc = dmm.nplc</code>	Check the NPLC setting for DC volts.
<code>dmm.func = dmm.DC_VOLTS</code> <code>dmm.nplc = 0.5</code> <code>dmm.range = 10</code> <code>dmm.func = "twowireohms"</code> <code>dmm.nplc = 0.1</code> <code>dmm.range = 100000</code> <code>dmm.func = "dcvolts"</code> <code>print(dmm.nplc)</code> <code>print(dmm.range)</code> <code>dmm.func = dmm.TWO_WIRE_OHMS</code> <code>print(dmm.nplc)</code> <code>print(dmm.range)</code>	Example showing how the instrument retains values for each function. Output: 0.5 10 .1 100000

```
dmm.func = "dcvolts"  
print(dmm.configure.query("active",  
    "\n"))
```

Select DC volts for the DMM function, then query the active settings to see how the DC volts function is presently configured.

Example output:

```
function = dcvolts  
nplc = 5.000000E-001  
aperture = 8.333333E-003  
range = 1.000000E+001  
auto zero = 1  
auto delay = 2  
filter enable = 0  
filter type = 1  
filter count = 3  
filter window = 5.300000E+000  
rel enable = 0  
rel level = 0.000000E+000  
display digits = 6  
dB reference = 1.000000E+000  
input divider = 0  
units = 0  
line sync = 0  
limit1 enable = 0  
limit 1 autoclear = 1  
limit 1 low value = -1.000000E+000  
limit 1 high value = 1.000000E+000  
limit 2 enable = 0  
limit 2 autoclear = 1  
limit 2 low value = -2.000000E+000  
limit 2 high value = 2.000000E+000  
math enable = 0  
math format = 2  
math mxb mfactor = 1.000000E+000  
math mxb bfactor = 0.000000E+000  
math mxb units = X  
math percent = 1.000000E+000
```

Also see

[dmm.configure.query\(\)](#) (on page 8-174)

[dmm.configure.recall\(\)](#) (on page 8-176)

[dmm.configure.set\(\)](#) (on page 8-178)

dmm.getconfig()

Queries for the DMM configurations that are associated with the specified channels or channel patterns.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Instrument reset Channel reset Recall setup	Create configuration script Save setup	"nofunction"

Usage

```
DMMconfiguration = dmm.getconfig(channelList)
```

<i>DMMconfiguration</i>	A comma-delimited string that lists the DMM configurations associated with items in <i>channelList</i>
<i>channelList</i>	The channels or channel patterns to query

Details

The response is a comma-delimited string that lists the user-defined and factory-defined configurations. They are listed in the same order in which they are specified in *channelList*.

The configurations indicate how the DMM will be configured when the corresponding channel or channel pattern is closed with the `dmm.close()` function or used in a scan list without an overriding DMM configuration.

An error is generated if:

- A specified channel or channel pattern is invalid.
- A channel number does not exist for slot based on installed card.
- Channel pattern does not exist.
- Channel being specified does not support a configuration setting (for example, a digital I/O channel or analog backplane relay).

Example

<pre>slot1_2Configs = dmm.getconfig("slot1, slot2") print(slot1_2Configs)</pre>	Queries channels on slots 1 and 2.
<pre>chan3001_3010Configs = dmm.getconfig("3001:3010") print(chan3001_3010Configs)</pre>	<p>Queries channels 1 to 10 on slot 3. Sample output may be:</p> <pre>dcvolts,dcvolts,dcvolts,dcvolt s,dcvolts,temperature,tempe rature,temperature,temperat ure,temperature</pre> <p>This shows that channels 3001 to 3005 are configured for "dcvolts" and 3006 to 3010 are configured for "temperature".</p>

Also see

- [dmm.close\(\)](#) (on page 8-170)
- [dmm.configure.recall\(\)](#) (on page 8-176)
- [dmm.configure.set\(\)](#) (on page 8-178)
- [dmm.setconfig\(\)](#) (on page 8-239)
- [scan.add\(\)](#) (on page 8-317)
- [scan.create\(\)](#) (on page 8-324)

dmm.inputdivider

Enables or disables the 10 M ohm input divider.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Instrument reset DMM reset Recall setup	Create configuration script Save setup	0 (dmm.OFF)

Usage

```
state = dmm.inputdivider
dmm.inputdivider = state
```

state	Enable input divider (dmm.ON or 1) Disable input divider (dmm.OFF or 0)
-------	--

Details

This attribute is only valid when `dmm.func` is set to DC volts.

The input divider setting is saved with the `dmm.func` function setting, so if you use another function, then return to "dcvolts", the input divider setting you set previously is retained.

An error is generated if you try to set input divider for any DMM function other than "dcvolts". Error 1114, "Setting conflicts with function selected" is generated. If you query any DMM function other than "dcvolts" for input divider, `nil` is returned, along with error 1114.

Example

```
dmm.func = "dcvolts"
dmm.inputdivider = dmm.ON
```

Enables the input divider for DC volts.

Also see

[DC volts input divider](#) (on page 4-58)
[dmm.configure.recall\(\)](#) (on page 8-176)
[dmm.configure.set\(\)](#) (on page 8-178)
[dmm.func](#) (on page 8-190)

dmm.limit[Y].autoclear

Indicates if limit Y should be cleared automatically or not.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	1 (dmm.ON)

Usage

```
value = dmm.limit[Y].autoclear
dmm.limit[Y].autoclear = value
```

<i>value</i>	The auto clear setting: <ul style="list-style-type: none"> • Enable: dmm.ON or 1 • Disable: dmm.OFF or 0
<i>Y</i>	1 or 2 for limit number

Details

This attribute is valid for all functions except "continuity" and "nofunction". A nil response and an error is generated if the command is received when `dmm.func` is set to either of these functions.

When this attribute is enabled, a limit fail condition tracks how the measurements are taken. If a measurement fails limit, the fail indication is set. If the next measurement passes limit, the failed limit condition clears.

Therefore, if you are scanning or taking a series of measurements with auto clear enabled for a limit, the last measurement limit dictates the fail indication for the limit.

To know if any of a series of measurements failed the limit, set the auto clear setting to off. When set to `dmm.OFF`, a failed indication will not be cleared automatically and will remain set until it is cleared by `dmm.limit[Y].clear()`.

The auto clear setting affects both the high and low limits of Y .

Example

<pre>dmm.func = "twowireohms" dmm.limit[2].autoclear = dmm.ON</pre>	Enables auto clear on limit 2 for two-wire ohms.
---	--

Also see

[dmm.configure.recall\(\)](#) (on page 8-176)
[dmm.configure.set\(\)](#) (on page 8-178)
[dmm.func](#) (on page 8-190)
[dmm.limit\[Y\].clear\(\)](#) (on page 8-195)
[dmm.measure\(\)](#) (on page 8-216)

dmm.limit[Y].clear()

Clears the test results of limit Y .

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
dmm.limit[Y].clear()
```

Y	1 or 2 for limit number
-----	-------------------------

Details

Use this command to clear the test results of limit Y when the limit auto clear (`dmm.limit[Y].autoclear`) command is disabled. Both the high and low test results are cleared.

To avoid the need to manually clear the test results for a limit, enable the auto clear command.

Example

```
dmm.func = "twowireohms"
dmm.limit[2].clear()
```

Clears the test results for the high and low limit 2 for two-wire ohms.

Also see

[dmm.configure.recall\(\)](#) (on page 8-176)

[dmm.configure.set\(\)](#) (on page 8-178)

[dmm.limit\[Y\].autoclear](#) (on page 8-194)

[dmm.limit\[Y\].high.fail](#) (on page 8-198)

[dmm.limit\[Y\].low.fail](#) (on page 8-202)

dmm.limit[Y].enable

Enable or disable limit *Y* testing.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	0 (dmm.OFF)

Usage

```
value = dmm.limit[Y].enable
dmm.limit[Y].enable = value
```

<i>value</i>	Limit <i>Y</i> testing: <ul style="list-style-type: none"> • Enable: dmm.ON or 1 • Disabled: dmm.OFF or 0
<i>Y</i>	1 or 2 for limit number

Details

This attribute is valid for all functions except "continuity" and "nofunction". A nil response and an error is generated if the command is received when `dmm.func` is set to either of these functions.

When this attribute is enabled, the limit *Y* testing occurs on each measurement taken by the DMM. Limit *Y* testing compares the measurements to the high and low limit values. If a measurement falls outside these limits, the test fails. The low limit is specified by `dmm.limit[Y].low.value` and the high limit is specified by `dmm.limit[Y].high.value`.

When this is enabled, limit testing occurs whether it is requested by the `dmm.measure` function or as part of a scan sequence. However, if events are not assigned to a trigger stimulus for a digital I/O line, there is no hardware indication of limits. The events that can be assigned to a trigger stimulus include:

- `dmm.trigger.EVENT_LIMIT1_HIGH`
- `dmm.trigger.EVENT_LIMIT1_LOW`
- `dmm.trigger.EVENT_LIMIT2_HIGH`
- `dmm.trigger.EVENT_LIMIT2_LOW`

To see the test results, use the `dmm.limit[Y].low.fail` and `dmm.limit[Y].high.fail` attributes.

When limit testing is disabled, no measurements are tested and the status bits are not updated, the fail indication does not get updated, and hardware lines are not generated.

Example

This example enables limits 1 and 2 for DC volt, measurements. Limit 1 is checking for readings to be between 3 and 5 volts while limit 2 is checking for the readings to be between 1 and 7 volts. The auto clear feature is disabled, so if any reading is outside these limits, the corresponding fail will be 1 afterwards. Therefore, if any one of the fails is 1, analyze the reading buffer data to find out which reading failed the limits.

```

dmm.func = "dcvolts"           -- set the DMM for DC volts functionality
dmm.reset("active")           -- reset DC volts to default settings
dmm.range = 10                 -- set the range to 10 volts
dmm.nplc = 0.1                 -- set the nplc to 0.1
dmm.limit[1].autoclear = dmm.OFF -- disable auto clearing for limit 1
dmm.limit[1].high.value = 5    -- set high limit on 1 to fail if reading
                                -- exceeds 5 volts
dmm.limit[1].low.value = 3     -- set low limit on 1 to fail if reading
                                -- is less than 3 volts
dmm.limit[1].enable = dmm.ON   -- enable limit 1 checking for DC volt
                                -- measurements
dmm.limit[2].autoclear = dmm.OFF -- disable auto clearing for limit 2
dmm.limit[2].high.value = 7    -- set high limit on 2 to fail if reading
                                -- exceeds 7 volts
dmm.limit[2].low.value = 1     -- set low limit on 2 to fail if reading
                                -- is less than 1 volts
dmm.limit[2].enable = dmm.ON   -- enable limit 2 checking for DC volt
                                -- measurements
dmm.measurecount = 50         -- set the measure count to 50
LimitBuffer = dmm.makebuffer(100) -- create a reading buffer that can store
                                -- 100 readings
dmm.measure(LimitBuffer)      -- take 50 readings and store them in
                                -- LimitBuffer
                                -- then check if any of the 50 readings
                                -- were outside of the limits

print("limit 1 high fail = " .. dmm.limit[1].high.fail)
print("limit 1 low fail = " .. dmm.limit[1].low.fail)
print("limit 2 high fail = " .. dmm.limit[2].high.fail)
print("limit 2 low fail = " .. dmm.limit[2].low.fail)
dmm.limit[1].clear()           -- clear limit 1 conditions
dmm.limit[2].clear()           -- clear limit 2 conditions

```

Sample output that shows all readings are within limit values (all readings between 3 and 5 volts):

```

limit 1 high fail = 0
limit 1 low fail = 0
limit 2 high fail = 0
limit 2 low fail = 0

```

Sample output showing at least one reading failed limit 1 high values (a 6 volt reading would cause this condition or a reading greater than 5 but less than 7.):

```

limit 1 high fail = 1
limit 1 low fail = 0
limit 2 high fail = 0
limit 2 low fail = 0

```

Sample output showing at least one reading failed limit limit 1 and 2 low values (a 0.5 volts reading would cause this condition or a reading less than 1):

```

limit 1 high fail = 0
limit 1 low fail = 1
limit 2 high fail = 0
limit 2 low fail = 1

```

Also see

[Reading buffers](#) (on page 3-56)
[dmm.configure.recall\(\)](#) (on page 8-176)
[dmm.configure.set\(\)](#) (on page 8-178)
[dmm.func](#) (on page 8-190)
[dmm.limit\[Y\].high.fail](#) (on page 8-198)

[dmm.limit\[Y\].high.value](#) (on page 8-200)
[dmm.limit\[Y\].low.fail](#) (on page 8-202)
[dmm.limit\[Y\].low.value](#) (on page 8-204)
[dmm.measure\(\)](#) (on page 8-216)

dmm.limit[Y].high.fail

Query for the high test results of limit *Y*.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	0

Usage

```
value = dmm.limit[Y].high.fail
```

<i>value</i>	The high fail indication for limit <i>Y</i> : <ul style="list-style-type: none"> 0 indicates test passed – measurement within the high limit 1 indicates test failed – measurement has exceeded high limit
<i>Y</i>	1 or 2 for limit number

Details

This attribute is valid for all functions except "continuity" and "nofunction". A nil response and an error is generated if the command is received when `dmm.func` is set to either of these functions.

This attribute returns the results of high limit *Y* testing. If this is 1 (failed), the measurement was above the high limit (`dmm.limit[Y].high.value`).

Note that if you are scanning or taking a series of measurements with auto clear (`dmm.limit[Y].autoclear`) enabled for a limit, the last measurement limit dictates the fail indication for the limit. If autoclear is disabled, you can take a series of readings and read fails to see if any of one of the readings failed.

To use this attribute, you must set the limit to enable.

If autoclear and limit are not set, the high fail value indicates the results of the last limit test that occurred when limits were enabled.

In addition to this attribute, you can see the fail indication by reading the measurement event register of the status model. If the readings are stored in a reading buffer, the values are associated with `bufferVar.statuses` for the readings.

You can use the digital I/O line trigger stimulus commands to generate a pulse when a limit fails. The events that can be assigned to a trigger stimulus include:

- `dmm.trigger.EVENT_LIMIT1_HIGH`
- `dmm.trigger.EVENT_LIMIT1_LOW`
- `dmm.trigger.EVENT_LIMIT2_HIGH`
- `dmm.trigger.EVENT_LIMIT2_LOW`

Example

This example enables limits 1 and 2 for DC volt, measurements. Limit 1 is checking for readings to be between 3 and 5 volts while limit 2 is checking for the readings to be between 1 and 7 volts. The auto clear feature is disabled, so if any reading is outside these limits, the corresponding fail will be 1 afterwards. Therefore, if any one of the fails is 1, analyze the reading buffer data to find out which reading failed the limits.

```
dmm.func = "dcvolts"           -- set the DMM for DC volts functionality
dmm.reset("active")           -- reset DC volts to default settings
dmm.range = 10                -- set the range to 10 volts
dmm.nplc = 0.1                -- set the nplc to 0.1
dmm.limit[1].autoclear = dmm.OFF -- disable auto clearing for limit 1
dmm.limit[1].high.value = 5    -- set high limit on 1 to fail if reading
                                -- exceeds 5 volts
dmm.limit[1].low.value = 3     -- set low limit on 1 to fail if reading
                                -- is less than 3 volts
dmm.limit[1].enable = dmm.ON  -- enable limit 1 checking for DC volt
                                -- measurements
dmm.limit[2].autoclear = dmm.OFF -- disable auto clearing for limit 2
dmm.limit[2].high.value = 7    -- set high limit on 2 to fail if reading
                                -- exceeds 7 volts
dmm.limit[2].low.value = 1     -- set low limit on 2 to fail if reading
                                -- is less than 1 volts
dmm.limit[2].enable = dmm.ON  -- enable limit 2 checking for DC volt
                                -- measurements
dmm.measurecount = 50         -- set the measure count to 50
LimitBuffer = dmm.makebuffer(100) -- create a reading buffer that can store
                                -- 100 readings
dmm.measure(LimitBuffer)      -- take 50 readings and store them in
                                -- LimitBuffer
                                -- then check if any of the 50 readings
                                -- were outside of the limits
print("limit 1 high fail = " .. dmm.limit[1].high.fail)
print("limit 1 low fail = " .. dmm.limit[1].low.fail)
print("limit 2 high fail = " .. dmm.limit[2].high.fail)
print("limit 2 low fail = " .. dmm.limit[2].low.fail)
dmm.limit[1].clear()          -- clear limit 1 conditions
dmm.limit[2].clear()          -- clear limit 2 conditions
```

Sample output that shows all readings are within limit values (all readings between 3 and 5 volts):

```
limit 1 high fail = 0
limit 1 low fail = 0
limit 2 high fail = 0
limit 2 low fail = 0
```

Sample output showing at least one reading failed limit 1 high values (a 6 volt reading would cause this condition or a reading greater than 5 but less than 7.):

```
limit 1 high fail = 1
limit 1 low fail = 0
limit 2 high fail = 0
limit 2 low fail = 0
```

Sample output showing at least one reading failed limit limit 1 and 2 low values (a 0.5 volts reading would cause this condition or a reading less than 1):

```
limit 1 high fail = 0
limit 1 low fail = 1
limit 2 high fail = 0
limit 2 low fail = 1
```

Also see

[Reading buffers](#) (on page 3-56)
[dmm.configure.recall\(\)](#) (on page 8-176)
[dmm.configure.set\(\)](#) (on page 8-178)
[dmm.func](#) (on page 8-190)
[dmm.limit\[Y\].autoclear](#) (on page 8-194)

dmm.limit[Y].high.value

The high limit value for limit *Y* when `dmm.limit[Y].enable` is set to `dmm.ON`.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	limit 1: 1.000000E+00 limit 2: 2.000000E+00

Usage

```
value = dmm.limit[Y].high.value
dmm.limit[Y].high.value = value
```

<i>value</i>	The high value for limit <i>Y</i> ; range is -4294967295 to +4294967295
<i>Y</i>	1 or 2 for limit number

Details

This attribute is valid for all functions except "continuity" and "nofunction". A nil response and an error is generated if the command is received when `dmm.func` is set to either of these functions.

This attribute specifies or queries the high limit value of limit *Y*. When limit *Y* testing is enabled (`dmm.limit[Y].enable = 1`), a fail indication occurs when the measurement value is greater than this value.

You may set or get the value regardless if the limit is set to a digio trigger stimulus:

- `dmm.trigger.EVENT_LIMIT1_HIGH`
- `dmm.trigger.EVENT_LIMIT1_LOW`
- `dmm.trigger.EVENT_LIMIT2_HIGH`
- `dmm.trigger.EVENT_LIMIT2_LOW`

Example

This example enables limits 1 and 2 for DC volt, measurements. Limit 1 is checking for readings to be between 3 and 5 volts while limit 2 is checking for the readings to be between 1 and 7 volts. The auto clear feature is disabled, so if any reading is outside these limits, the corresponding fail will be 1 afterwards. Therefore, if any one of the fails is 1, analyze the reading buffer data to find out which reading failed the limits.

```
dmm.func = "dcvolts"           -- set the DMM for DC volts functionality
dmm.reset("active")           -- reset DC volts to default settings
dmm.range = 10                -- set the range to 10 volts
dmm.nplc = 0.1                -- set the nplc to 0.1
dmm.limit[1].autoclear = dmm.OFF -- disable auto clearing for limit 1
dmm.limit[1].high.value = 5    -- set high limit on 1 to fail if reading
                                -- exceeds 5 volts
dmm.limit[1].low.value = 3     -- set low limit on 1 to fail if reading
                                -- is less than 3 volts
dmm.limit[1].enable = dmm.ON   -- enable limit 1 checking for DC volt
                                -- measurements
dmm.limit[2].autoclear = dmm.OFF -- disable auto clearing for limit 2
dmm.limit[2].high.value = 7    -- set high limit on 2 to fail if reading
                                -- exceeds 7 volts
dmm.limit[2].low.value = 1     -- set low limit on 2 to fail if reading
                                -- is less than 1 volts
dmm.limit[2].enable = dmm.ON   -- enable limit 2 checking for DC volt
                                -- measurements
dmm.measurecount = 50         -- set the measure count to 50
LimitBuffer = dmm.makebuffer(100) -- create a reading buffer that can store
                                -- 100 readings
dmm.measure(LimitBuffer)      -- take 50 readings and store them in
                                -- LimitBuffer then check if any
                                -- of the 50 readings were
                                -- outside of the limits
print("limit 1 high fail = " .. dmm.limit[1].high.fail)
print("limit 1 low fail = " .. dmm.limit[1].low.fail)
print("limit 2 high fail = " .. dmm.limit[2].high.fail)
print("limit 2 low fail = " .. dmm.limit[2].low.fail)
dmm.limit[1].clear()          -- clear limit 1 conditions
dmm.limit[2].clear()          -- clear limit 2 conditions
```

Sample output that shows all readings are within limit values (all readings between 3 and 5 volts):

```
limit 1 high fail = 0
limit 1 low fail = 0
limit 2 high fail = 0
limit 2 low fail = 0
```

Sample output showing at least one reading failed limit 1 high values (a 6 volt reading would cause this condition or a reading greater than 5 but less than 7.):

```
limit 1 high fail = 1
limit 1 low fail = 0
limit 2 high fail = 0
limit 2 low fail = 0
```

Sample output showing at least one reading failed limit limit 1 and 2 low values (a 0.5 volts reading would cause this condition or a reading less than 1):

```
limit 1 high fail = 0
limit 1 low fail = 1
limit 2 high fail = 0
limit 2 low fail = 1
```

Also see

[Reading buffers](#) (on page 3-56)
[digio.trigger\[N\].stimulus](#) (on page 8-127)
[dmm.configure.recall\(\)](#) (on page 8-176)
[dmm.configure.set\(\)](#) (on page 8-178)
[dmm.func](#) (on page 8-190)
[dmm.limit\[Y\].enable](#) (on page 8-196)
[dmm.limit\[Y\].high.fail](#) (on page 8-198)
[dmm.limit\[Y\].low.value](#) (on page 8-204)

dmm.limit[Y].low.fail

Queries for the low test results of limit Y .

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	0

Usage

```
value = dmm.limit[Y].low.fail
```

<i>value</i>	The low fail indication of limit Y : <ul style="list-style-type: none"> • Test passed: 0 (measurement above the low limit) • Test failed: 1 (measurement below the low limit)
Y	1 or 2 for limit number

Details

This attribute is valid for all functions except "continuity" and "nofunction". A nil response and an error is generated if the command is received when `dmm.func` is set to either of these functions.

This attribute returns the results of low limit Y testing. If this is 1 (failed) is returned, the measurement was below the low limit.

Note that if you are scanning or taking a series of measurements with auto clear (`dmm.limit[Y].autoclear`) enabled for a limit, the last measurement limit dictates the fail indication for the limit. If autoclear is disabled, you can take a series of readings and read fails to see if any of one of the readings failed.

To use this attribute, you must set the limit to enable.

If autoclear and limit are not set, the low fail value indicates the results of the last limit test that occurred when limits were enabled.

In addition to this attribute, you can see the fail indication by reading the measurement event register of the status model. If the readings are stored in a reading buffer, the values are associated with `bufferVar.statuses` for the readings.

Example

This example enables limits 1 and 2 for DC volt, measurements. Limit 1 is checking for readings to be between 3 and 5 volts while limit 2 is checking for the readings to be between 1 and 7 volts. The auto clear feature is disabled, so if any reading is outside these limits, the corresponding fail will be 1 afterwards. Therefore, if any one of the fails is 1, analyze the reading buffer data to find out which reading failed the limits.

```
dmm.func = "dcvolts"           -- set the DMM for DC volts functionality
dmm.reset("active")           -- reset DC volts to default settings
dmm.range = 10                -- set the range to 10 volts
dmm.nplc = 0.1                -- set the nplc to 0.1
dmm.limit[1].autoclear = dmm.OFF -- disable auto clearing for limit 1
dmm.limit[1].high.value = 5   -- set high limit on 1 to fail if reading
                                -- exceeds 5 volts
dmm.limit[1].low.value = 3    -- set low limit on 1 to fail if reading
                                -- is less than 3 volts
dmm.limit[1].enable = dmm.ON  -- enable limit 1 checking for DC volt
                                -- measurements
dmm.limit[2].autoclear = dmm.OFF -- disable auto clearing for limit 2
dmm.limit[2].high.value = 7   -- set high limit on 2 to fail if reading
                                -- exceeds 7 volts
dmm.limit[2].low.value = 1    -- set low limit on 2 to fail if reading
                                -- is less than 1 volts
dmm.limit[2].enable = dmm.ON  -- enable limit 2 checking for DC volt
                                -- measurements
dmm.measurecount = 50        -- set the measure count to 50
LimitBuffer = dmm.makebuffer(100) -- create a reading buffer that can store
                                -- 100 readings
dmm.measure(LimitBuffer)     -- take 50 readings and store them in
                                -- LimitBuffer
                                -- then check if any of the 50 readings
                                -- were outside of the limits

print("limit 1 high fail = " .. dmm.limit[1].high.fail)
print("limit 1 low fail = " .. dmm.limit[1].low.fail)
print("limit 2 high fail = " .. dmm.limit[2].high.fail)
print("limit 2 low fail = " .. dmm.limit[2].low.fail)
dmm.limit[1].clear()         -- clear limit 1 conditions
dmm.limit[2].clear()         -- clear limit 2 conditions
```

Sample output that shows all readings are within limit values (all readings between 3 and 5 volts):

```
limit 1 high fail = 0
limit 1 low fail = 0
limit 2 high fail = 0
limit 2 low fail = 0
```

Sample output showing at least one reading failed limit 1 high values (a 6 volt reading would cause this condition or a reading greater than 5 but less than 7.):

```
limit 1 high fail = 1
limit 1 low fail = 0
limit 2 high fail = 0
limit 2 low fail = 0
```

Sample output showing at least one reading failed limit limit 1 and 2 low values (a 0.5 volts reading would cause this condition or a reading less than 1):

```
limit 1 high fail = 0
limit 1 low fail = 1
limit 2 high fail = 0
limit 2 low fail = 1
```

Also see

[Reading buffers](#) (on page 3-56)
[dmm.configure.recall\(\)](#) (on page 8-176)
[dmm.configure.set\(\)](#) (on page 8-178)
[dmm.func](#) (on page 8-190)
[dmm.limit\[Y\].autoclear](#) (on page 8-194)

dmm.limit[Y].low.value

The low limit value for limit *Y* when `dmm.limit[Y].enable` is set to `dmm.ON`.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	limit 1: -1.000000E+00 limit 2: -2.000000E+00

Usage

```
value = dmm.limit[Y].low.value
dmm.limit[Y].low.value = value
```

<i>value</i>	The low limit value of limit <i>Y</i> ; The valid range is -4294967295 to +4294967295
<i>Y</i>	Limit number 1 or 2

Details

This attribute is valid for all functions except "continuity" and "nofunction". A nil response and an error is generated if the command is received when `dmm.func` is set to either of these functions.

This attribute specifies or queries the low limit value of limit *Y*. When limit *Y* testing is enabled (`dmm.limit[Y].enable = 1`), a fail indication occurs when the measurement value is less than this value.

You may set or get the value regardless if the limit is set to a digital I/O trigger stimulus:

- `dmm.trigger.EVENT_LIMIT1_HIGH`
- `dmm.trigger.EVENT_LIMIT1_LOW`
- `dmm.trigger.EVENT_LIMIT2_HIGH`
- `dmm.trigger.EVENT_LIMIT2_LOW`

Example

This example enables limits 1 and 2 for DC volt, measurements. Limit 1 is checking for readings to be between 3 and 5 volts while limit 2 is checking for the readings to be between 1 and 7 volts. The auto clear feature is disabled, so if any reading is outside these limits, the corresponding fail will be 1 afterwards. Therefore, if any one of the fails is 1, analyze the reading buffer data to find out which reading failed the limits.

```
dmm.func = "dcvolts"           -- set the DMM for DC volts functionality
dmm.reset("active")           -- reset DC volts to default settings
dmm.range = 10                -- set the range to 10 volts
dmm.nplc = 0.1                -- set the nplc to 0.1
dmm.limit[1].autoclear = dmm.OFF -- disable auto clearing for limit 1
dmm.limit[1].high.value = 5    -- set high limit on 1 to fail if reading
                                -- exceeds 5 volts
dmm.limit[1].low.value = 3     -- set low limit on 1 to fail if reading
                                -- is less than 3 volts
dmm.limit[1].enable = dmm.ON   -- enable limit 1 checking for DC volt
                                -- measurements
dmm.limit[2].autoclear = dmm.OFF -- disable auto clearing for limit 2
dmm.limit[2].high.value = 7    -- set high limit on 2 to fail if reading
                                -- exceeds 7 volts
dmm.limit[2].low.value = 1     -- set low limit on 2 to fail if reading
                                -- is less than 1 volts
dmm.limit[2].enable = dmm.ON   -- enable limit 2 checking for DC volt
                                -- measurements
dmm.measurecount = 50         -- set the measure count to 50
LimitBuffer = dmm.makebuffer(100) -- create a reading buffer that can store
                                -- 100 readings
dmm.measure(LimitBuffer)      -- take 50 readings and store them in
                                -- LimitBuffer then check if any
                                -- of the 50 readings were
                                -- outside of the limits
print("limit 1 high fail = " .. dmm.limit[1].high.fail)
print("limit 1 low fail = " .. dmm.limit[1].low.fail)
print("limit 2 high fail = " .. dmm.limit[2].high.fail)
print("limit 2 low fail = " .. dmm.limit[2].low.fail)
dmm.limit[1].clear()          -- clear limit 1 conditions
dmm.limit[2].clear()          -- clear limit 2 conditions
```

Sample output that shows all readings are within limit values (all readings between 3 and 5 volts):

```
limit 1 high fail = 0
limit 1 low fail = 0
limit 2 high fail = 0
limit 2 low fail = 0
```

Sample output showing at least one reading failed limit 1 high values (a 6 volt reading would cause this condition or a reading greater than 5 but less than 7.):

```
limit 1 high fail = 1
limit 1 low fail = 0
limit 2 high fail = 0
limit 2 low fail = 0
```

Sample output showing at least one reading failed limit limit 1 and 2 low values (a 0.5 volts reading would cause this condition or a reading less than 1):

```
limit 1 high fail = 0
limit 1 low fail = 1
limit 2 high fail = 0
limit 2 low fail = 1
```

Also see

[Reading buffers](#) (on page 3-56)
[digio.trigger\[N\].stimulus](#) (on page 8-127)
[dmm.configure.recall\(\)](#) (on page 8-176)
[dmm.configure.set\(\)](#) (on page 8-178)
[dmm.func](#) (on page 8-190)
[dmm.limit\[Y\].enable](#) (on page 8-196)
[dmm.limit\[Y\].high.value](#) (on page 8-200)
[dmm.limit\[Y\].low.fail](#) (on page 8-202)

dmm.linesync

Selects if line sync is used during the measurement.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	0 (dmm.OFF)

Usage

```
state = dmm.linesync
dmm.linesync = state
```

<i>state</i>	Enable line sync (dmm.ON or 1). Disable line sync (dmm.OFF or 0).
--------------	--

Details

This attribute is only valid when `dmm.func` is set to "commonsideohms", "continuity", "dcurrent", "dcvolts", "fourwireohms", "temperature", or "twowireohms". All other functions generate an error when written and return `nil` when queried.

When `dmm.linesync` is enabled, measurements are initiated at the first positive-going zero crossing of the power line cycle after the trigger.

The line sync setting is saved with the `dmm.func` function setting, so if you use another function, then return to a previous function, the line sync you set previously is retained.

Example

<pre>dmm.func = "fourwireohms" dmm.linesync = dmm.ON</pre>	Enables line sync for the "fourwireohms" function.
--	--

Also see

[Line cycle synchronization](#) (on page 4-4)
[dmm.configure.recall\(\)](#) (on page 8-176)
[dmm.configure.set\(\)](#) (on page 8-178)
[dmm.func](#) (on page 8-190)

dmm.makebuffer()

Creates a user buffer for storing readings. Reading buffers are allocated dynamically.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Reset Recall setup	Create configuration script Save setup	None

Usage

```
bufferVar = dmm.makebuffer(bufferSize)
```

<i>bufferVar</i>	The variable name for the buffer being created
<i>bufferSize</i>	Maximum number of readings that the buffer can store

Details

To be able to store readings, a reading buffer needs to be created. Once created, the reading buffer can be used to store readings from `dmm.measure()` command and from scanning (`scan.execute()` or `scan.background()`)

To delete a buffer, set *bufferVar* to `nil`.

Once a buffer is created, the attributes that can be accessed are:

- *bufferVar.appendmode* = 1 (ON) or 0 (OFF); default is zero (0) over a bus interface, and 1 for buffers created on the front panel.
- *bufferVar.basetimeseconds* returns the seconds for reading buffer entry 1 (read-only attribute).
- *bufferVar.basetimefractional* returns the seconds and fractional seconds for reading buffer entry 1 (read-only attribute).
- *bufferVar.capacity* returns the overall buffer size.
- *bufferVar.collecttimestamps* = 1 (ON) or 0 (OFF); default is 1.
- *bufferVar.collectchannels* = 1 (ON) or 0 (OFF); default is 1.
- *bufferVar.n* returns the number of readings currently stored in the buffer.
- *bufferVar.timestampresolution* returns the resolution of the time stamping (read-only attribute).

The following buffer bits indicate buffer statuses:

- `dmm.buffer.LIMIT1_LOW_BIT` or 1
- `dmm.buffer.LIMIT1_HIGH_BIT` or 2
- `dmm.buffer.LIMIT2_LOW_BIT` or 4
- `dmm.buffer.LIMIT2_HIGH_BIT` or 8
- `dmm.buffer.MEAS_OVERFLOW_BIT` or 64
- `dmm.buffer.MEAS_CONNECT_QUESTION_BIT` or 128

To see readings in buffer:

```
printbuffer(x, y, bufferVar)
```

Where *x* and *y* represent the reading numbers desired.

To see readings, channels, and units:

```
printbuffer(x, y, bufferVar, bufferVar.channels, bufferVar.units)
```

Where *x* and *y* represent reading numbers desired.

To see time stamps in buffer:

```
bufferVar.collecttimestamps = 1
print(x, y, bufferVar, bufferVar.timestamps)
```

Where *x* and *y* represent readings and time stamps for elements *x* to *y*.

To see seconds, fractional seconds, and relative time stamps:

```
bufferVar.collecttimestamps = 1
printbuffer(x, y, bufferVar.seconds)
printbuffer(x, y, bufferVar.fractionalseconds)
printbuffer(x, y, bufferVar.relativetimestamps)
```



CAUTION

Once you create a reading buffer, using that buffer name for another buffer or variable will cause access to the original data to be lost.

Example 1

```
bufferVar = dmm.makebuffer(300)
```

Creates a user reading buffer named `bufferVar` with a capacity of 300.

Example 2

```
dmm.measurecount = 10
dmm.measure(bufferVar2)
printbuffer(1, bufferVar2.n, bufferVar2)
bufferVar2 = nil
```

Take ten measurements on the active function and store them in the reading buffer, `bufferVar2`. View those ten readings.

Delete `bufferVar2`.

Sample output (actual output depends on how the active function is configured and what you are measuring):

```
1.134154698e+01, 1.132708486e+01,
1.134213865e+01,
1.134037749e+01,
1.132735758e+01,
1.134099844e+01,
1.133705087e+01,
1.132571507e+01,
1.134000616e+01, 1.133721111e+01
```

Also see

[Reading buffers](#) (on page 3-56)
[dmm.measure\(\)](#) (on page 8-216)
[printbuffer\(\)](#) (on page 8-308)
[scan.background\(\)](#) (on page 8-322)
[scan.execute\(\)](#) (on page 8-326)

dmm.math.enable

Enable or disable math operation on measurements.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	0 (dmm.OFF)

Usage

```
value = dmm.math.enable
dmm.math.enable = value
```

<i>value</i>	The math enable setting: <ul style="list-style-type: none"> • Enable: dmm.ON or 1 • Disable: dmm.OFF or 0
--------------	---

Details

This attribute is not available for "nofunction". If you write this attribute for "nofunction", an error message is generated.

When this attribute is set to `dmm.ON`, the math operation specified by `math format` attribute (`dmm.math.format`) will be performed before completing a measurement.

Example

```

dmm.func = "dcvolts"
dmm.reset("active")
dmm.measurecount = 5
MathBuffer = dmm.makebuffer(100)

MathBuffer.appendmode = 1
dmm.measure(MathBuffer)
dmm.math.format = dmm.MATH_MXB
dmm.math.mxb.mfactor = 1e6
dmm.math.mxb.bfactor = 0
dmm.math.mxb.units = "["
dmm.math.enable = dmm.ON

dmm.measure(MathBuffer)

printbuffer(1, 5, MathBuffer)
printbuffer(6, MathBuffer.n, MathBuffer)

dmm.measurecount = 1
for x = 1, 3 do
    print(dmm.measure())
end

```

Configure the DMM for DC volts.
Reset DC volts to the default settings.
Set the measure count to 5.
Create a reading buffer named MathBuffer that can store 100 readings.

Set the buffer to append readings.
Take 5 readings and store them in MathBuffer with no math operation.
Enable math operations for mx+b operation, with m set to 1e6 and b set to 0, with units set to micro .

Store the 5 additional readings in MathBuffer with math operations enabled.

View the readings with and without math operation.

Take 3 additional math readings without using the buffer.

Sample output assuming no load was connected to DMM:

Readings with no math operation:

```

3.898423119e-07, 4.066727213e-07,
5.122452892e-07,
4.724643216e-07,
4.770544332e-07

```

Readings with math operation:

```

5.061251403e-01, 4.158529446e-01,
5.504962196e-01,
3.821921259e-01,
6.132277455e-01

```

```

5.367258847e-01
6.040475222e-01
6.132277455e-01

```

Also see

[Math calculations](#) (on page 4-43)
[dmm.configure.recall\(\)](#) (on page 8-176)
[dmm.configure.set\(\)](#) (on page 8-178)
[dmm.math.format](#) (on page 8-211)

dmm.math.format

Specifies the math operation to perform on measurements.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	2 (dmm.MATH_PERCENT)

Usage

```
state = dmm.math.format
dmm.math.format = state
```

<i>state</i>	Math operation to be performed on measurements: <ul style="list-style-type: none"> • dmm.MATH_NONE or 0 • dmm.MATH_MXB or 1 • dmm.MATH_PERCENT or 2 • dmm.MATH_RECIPROCAL or 3
--------------	--

Details

This is not available for "nofunction". If this command is queried when "nofunction" is selected, nil is returned. If it is written when "nofunction" is selected, an error is returned.

If you set this attribute to dmm.MATH_NONE, math operation is disabled, even if math operation (dmm.math.enable) is enabled.

Use a setting of dmm.MATH_MXB to have

$$Y = mX + b$$

where:

- **X** is the normal measurement
- **m** is user-entered constant for scale factor (dmm.math.mxb.mfactor)
- **b** is user-entered constant for offset (dmm.math.mxb.bfactor)
- **Y** is the result

If you are using relative offset measurement control (dmm.rel.enable), the relative offset reading is used for X.

Use a setting of dmm.MATH_PERCENT to have:

$$\text{Percent} = \frac{(\text{Input} - \text{Reference})}{\text{Reference}} \times 100\%$$

where:

- **Input** is the normal measurement (if using dmm.rel.enable, it will be the relative offset value)
- **Reference** is user entered constant (dmm.math.percent)
- **Percent** is the result

Use a setting of dmm.MATH_RECIPROCAL for 1/X operation, where X is normal or the measurement value with relative offset applied.

The desired math operation is performed before any of the enabled limit testing.

Example

<pre>dmm.math.format = dmm.MATH_RECIPROCAL dmm.math.enable = dmm.ON</pre>	Enables the reciprocal operation on measurements
---	--

Also see

[Math calculations](#) (on page 4-43)
[dmm.configure.recall\(\)](#) (on page 8-176)
[dmm.configure.set\(\)](#) (on page 8-178)

[dmm.math.enable](#) (on page 8-209)
[dmm.math.percent](#) (on page 8-215)
[dmm.math.mxb.bfactor](#) (on page 8-212)
[dmm.math.mxb.mfactor](#) (on page 8-213)
[dmm.rel.enable](#) (on page 8-228)

dmm.math.mxb.bfactor

Specifies the offset for the $y = mx + b$ operation.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	0.000000e+00

Usage

```
value = dmm.math.mxb.bfactor
dmm.math.mxb.bfactor = value
```

<i>value</i>	The offset for the $y = mx + b$ operation; the valid range is -4294967295 to +4294967295
--------------	--

Details

This is not available for "nofunction.". If command is queried when "nofunction" is selected, nil is returned. If it is written when "nofunction" is selected, an error is returned.

This attribute specifies the offset (b) for an $mx + b$ operation.

Example

```
dmm.math.mxb.bfactor = 50
```

Sets the offset for $mx + b$ operation to 50.

Also see

[Math calculations](#) (on page 4-43)
[dmm.configure.recall\(\)](#) (on page 8-176)
[dmm.configure.set\(\)](#) (on page 8-178)
[dmm.math.format](#) (on page 8-211)
[dmm.math.mxb.mfactor](#) (on page 8-213)

dmm.math.mxb.mfactor

Specifies the scale factor for the $y = mx + b$ operation.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	1.000000E+00

Usage

```
value = dmm.math.mxb.mfactor
dmm.math.mxb.mfactor = value
```

<i>value</i>	The scale factor; valid range is -4294967295 to +4294967295
--------------	---

Details

This is not available for "nofunction". If command is queried when "nofunction" is selected, nil is returned. If it is written when "nofunction" is selected, an error is returned.

This attribute represents the scale factor (m) for an $mx + b$ operation.

Example

```
dmm.math.mxb.mfactor = 0.80
```

Sets the scale factor for the $mx + b$ operation to 0.80.

Also see

[Math calculations](#) (on page 4-43)
[dmm.configure.recall\(\)](#) (on page 8-176)
[dmm.configure.set\(\)](#) (on page 8-178)
[dmm.math.format](#) (on page 8-211)
[dmm.math.mxb.bfactor](#) (on page 8-212)

dmm.math.mxb.units

Specifies the unit character for the $y = mX + b$ operation.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	X

Usage

```
value = dmm.math.mxb.units
dmm.math.mxb.units = value
```

<i>value</i>	The unit character for the $y = mx + b$ operation. Valid values are: <ul style="list-style-type: none"> • A to Z • [(left bracket) for the micro (μ) symbol •] (right bracke) for the ohm (Ω) symbol • \ (two backslashes) for the degree ($^{\circ}$) symbol
--------------	---

Details

This attribute is not available for the "nofunction" selection. If the command is queried when "nofunction" is selected, nil is returned. If it is written when "nofunction" is selected, an error is returned.

This attribute represents the unit character to use when the math format is set for $mx + b$ (`dmm.math.format = dmm.MATH_MXB`).

Example

<code>dmm.math.mxb.units = "Q"</code>	Sets the units for the $mX + b$ operation to "Q".
---------------------------------------	---

Also see

[Math calculations](#) (on page 4-43)
[dmm.configure.recall\(\)](#) (on page 8-176)
[dmm.configure.set\(\)](#) (on page 8-178)
[dmm.math.format](#) (on page 8-211)

dmm.math.percent

Specifies the constant to use for the percent operation.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	1.000000E+00

Usage

```
value = dmm.math.percent
dmm.math.percent = value
```

<i>value</i>	The constant for the percent operation. The range is -4294967295 to +4294967295
--------------	---

Details

This is not available for "nofunction". If command is queried when "nofunction" is selected, nil is returned. If it is written when "nofunction" is selected, an error is returned.

This attribute represents the constant to use for percent when `dmm.math.format = dmm.MATH_PERCENT`.

Example 1

<code>dmm.math.percent = 1250</code>	Set constant for percent operation to 1250.
<code>dmm.math.percent = dmm.measure()</code>	Acquire the percent constant.

Example 2

<pre>dmm.func = "dcvolts" dmm.reset("active") dmm.math.format = dmm.MATH_PERCENT dmm.measurecount = 1 dmm.math.percent = dmm.measure() dmm.math.enable = dmm.ON dmm.measurecount = 5 MathBuffer = dmm.makebuffer(100) dmm.measure(MathBuffer) printbuffer(1, MathBuffer.n, MathBuffer) dmm.measurecount = 1 for x = 1, 3 do print(dmm.measure()) end</pre>	<p>Configure the DMM for DC volts and reset the DC volts function to the default settings.</p> <p>Set math format to percent. Acquire 1 reading to use as the relative percent value. Take 5 readings with percent math enabled and store them in a buffer called MathBuffer that can store 100 readings.</p> <p>Take three additional readings without using the reading buffer.</p> <p>Sample output assuming no load was connected to DMM:</p> <pre>2.717115286e+01, 1.259150986e+01, 1.259150986e+01, 9.277954635e+00, 3.313555227e+01 1.292338066e+01 2.452080209e+01 1.557421984e+01</pre>
--	---

Also see

[Math calculations](#) (on page 4-43)
[dmm.configure.recall\(\)](#) (on page 8-176)
[dmm.configure.set\(\)](#) (on page 8-178)
[dmm.math.format](#) (on page 8-211)

dmm.measure()

Returns the last reading of the measurement process without using the trigger model.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
reading = dmm.measure()
reading = dmm.measure(bufferVar)
```

<i>reading</i>	The last reading of the measurement process
<i>bufferVar</i>	A previously created reading buffer where all readings are stored

Details

This is not available for "nofunction". If the command is queried when "nofunction" is selected, nil is returned. If it is written when "nofunction" is selected, an error is returned.

When a reading buffer is used with a command or action that involves taking multiple readings, such as `dmm.measure` or scanning, all readings are available in the reading buffer. However, only the last reading is returned as a reading with the command.

You can also use a reading buffer to store additional information that is acquired while making a measurement.

The `dmm.measurecount` attribute determines how many measurements are performed. When you use a buffer, it also determines if the reading buffer has enough room to store the requested readings. The amount of room is based on readings already stored in the buffer (`bufferVar.n`), the capacity of the buffer (`bufferVar.capacity`), and the append mode of the reading buffer (`bufferVar.appendmode`). If the append mode is set to 0, any stored readings in the buffer are cleared before new ones are stored. If append mode is set to 1, any stored readings remain in the buffer and new ones are added to the buffer after the stored ones.

Example

```
DCVBuffer = dmm.makebuffer(100)
dmm.func = "dcvolts"
dmm.measurecount = 100
dmm.measure(DCVBuffer)
```

Performs 100 DC voltage measurements and stores them in a buffer called DCVBuffer.

Also see

[Reading buffer](#) (see "[Reading buffers](#)" on page 3-50)
[bufferVar.appendmode](#) (on page 8-17)
[bufferVar.capacity](#) (on page 8-20)
[bufferVar.n](#) (on page 8-30)
[dmm.makebuffer\(\)](#) (on page 8-207)
[dmm.measurecount](#) (on page 8-217)
[dmm.measurewithtime\(\)](#) (on page 8-218)

dmm.measurecount

The number of measurements to take when a measurement is requested by a DMM measure command.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	1

Usage

```
count = dmm.measurecount
dmm.measurecount = count
```

<i>count</i>	The number of measurements to take when a DMM measure function is used (maximum 450,000)
--------------	--

Details

This attribute controls the number of measurements taken any time a measurement is requested (through `dmm.measure`, `dmm.measurewithtime`, or the front panel MEASURE menu option). When using a reading buffer with a measure command, the count also controls the number of readings to be stored.

It has no effect on the trigger model, and the trigger model does not affect this setting.

This setting is applied to all functions (the setting is not related to a specific function).

Example

```
DMMbuffer = dmm.makebuffer(500)
dmm.measure(bufferVar)
dmm.measurecount = 50
```

Create a reading buffer called DMMbuffer that can store 500 readings.
Store 50 readings in DMMbuffer.
Set the measure count of the DMM to 50.

Also see

[Reading buffer](#) (see "[Reading buffers](#)" on page 3-50)
[dmm.autodelay](#) (on page 8-157)
[dmm.makebuffer\(\)](#) (on page 8-207)
[dmm.measure\(\)](#) (on page 8-216)
[dmm.measurewithtime\(\)](#) (on page 8-218)

dmm.measurewithtime()

Returns the last actual measurement and time information in UTC format without using the trigger model. You can also use a reading buffer to store additional information that is acquired while making a measurement.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
reading, seconds, fractional = dmm.measurewithtime()
reading, seconds, fractional = dmm.measurewithtime(bufferVar)
```

<i>reading</i>	The last reading of the measurement process
<i>seconds</i>	Seconds in UTC format
<i>fractional</i>	Fractional seconds
<i>bufferVar</i>	A previously created reading buffer variable in which all readings are stored

Details

This is not available for "nofunction". If the command is queried when "nofunction" is selected, nil is returned. If it is written when "nofunction" is selected, an error is returned.

When a reading buffer is used with a command or action that involves taking multiple readings, such as `dmm.measure` or scanning, all readings are available in the reading buffer. However, only the last reading and time information (seconds and fractional seconds) is returned as a reading with the command.

You can also use a reading buffer to store additional information that is acquired while making a measurement.

The `dmm.measurecount` attribute determines how many measurements are performed. When you use a buffer, it also determines if the reading buffer has enough room to store the requested readings. The amount of room is based on readings already stored in the buffer (`bufferVar.n`), the capacity of the buffer (`bufferVar.capacity`), and the append mode of the reading buffer (`bufferVar.appendmode`). If the append mode is set to 0, any stored readings in the buffer are cleared before new ones are stored. If append mode is set to 1, any stored readings remain in the buffer and new ones are added to the buffer after the stored ones.

Example

```
DCVbuffer = dmm.makebuffer(100)
dmm.func = "dcvolts"
dmm.measurecount = 100
reading, seconds, fractional = dmm.measurewithtime(DCVbuffer)
print(reading, seconds, fractional)
```

Create a reading buffer.

Perform 100 DC voltage measurements.

Store the measurements in a buffer called `DCVbuffer`.

Print the last measurement and time information in UTC format, which will look similar to:

```
-1.064005867e-02  1.779155900e+07  1.245658350e-01
```

Also see

[Reading buffer](#) (see "[Reading buffers](#)" on page 3-50)

[dmm.makebuffer\(\)](#) (on page 8-207)

[dmm.measure\(\)](#) (on page 8-216)

[dmm.measurecount](#) (on page 8-217)

dmm.measurewithptp()

This function returns the last actual measurement and time information in PTP format without using the trigger model. You can also use a reading buffer to store additional information that is acquired while making a measurement.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
reading, seconds, fractional = dmm.measurewithptp()
reading, seconds, fractional = dmm.measurewithptp(bufferVar)
```

<i>reading</i>	The last reading of the measurement process
<i>seconds</i>	Seconds in PTP format
<i>fractional</i>	Fractional seconds
<i>bufferVar</i>	A previously created reading buffer variable in which all readings are stored

Details

This is not available for "nofunction". If the command is queried when "nofunction" is selected, nil is returned. If it is written when "nofunction" is selected, an error is returned.

When a reading buffer is used with a command or action that involves taking multiple readings, such as `dmm.measure` or scanning, all readings are available in the reading buffer. However, only the last reading and time information (seconds and fractional seconds) is returned as a reading with the command.

You can also use a reading buffer to store additional information that is acquired while making a measurement.

The `dmm.measurecount` attribute determines how many measurements are performed. When you use a buffer, it also determines if the reading buffer has enough room to store the requested readings. The amount of room is based on readings already stored in the buffer (`bufferVar.n`), the capacity of the buffer (`bufferVar.capacity`), and the append mode of the reading buffer (`bufferVar.appendmode`). If the append mode is set to 0, any stored readings in the buffer are cleared before new ones are stored. If append mode is set to 1, any stored readings remain in the buffer and new ones are added to the buffer after the stored ones.

Example

```
DCVbuffer = dmm.makebuffer(100)
dmm.func = "dcvolts"
dmm.measurecount = 100
reading, seconds, fractional = dmm.measurewithptp(DCVbuffer)
print(reading, seconds, fractional)
```

Create a reading buffer.

Perform 100 DC voltage measurements.

Store the measurements in a buffer called `DCVbuffer`.

Print the last measurement and time information in PTP format, which will look similar to:

```
-1.064005867e-02  1.779155900e+07  1.245658350e-01
```

Also see

[Reading buffer](#) (see "[Reading buffers](#)" on page 3-50)

[dmm.makebuffer\(\)](#) (on page 8-207)

[dmm.measure\(\)](#) (on page 8-216)

[dmm.measurecount](#) (on page 8-217)

dmm.nplc

The integration rate in line cycles for the DMM for the function selected by `dmm.func`.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	1.000000E+000

Usage

```
value = dmm.nplc
dmm.nplc = value
```

<code>value</code>	The integration rate in line cycles: <ul style="list-style-type: none"> 60 Hertz: 0.0005 to 15 50 Hertz: 0.0005 to 12
--------------------	---

Details

This attribute is not applicable for "frequency", "period", and "nofunction". If you query this attribute for one of these functions, `nil` is returned. Note that "continuity" is fixed at 6.000000E-003 and cannot be changed. The setting for NPLC may be adjusted based on what the DMM supports. Therefore, after setting the NPLC, query the value to see if it was adjusted.

NOTE

For `dmm.nplc` settings that are less than 0.2, sending `dmm.AUTOZERO_ONCE` results in significant delays. For example, the delay time at an NPLC of 0.0005 is 2.75 s. The delay time at 0.199 is 5.45 s.

An error is generated if the command is used when `dmm.func` is set to "frequency", "period", "continuity", or "nofunction".

The NPLC setting is saved with the `dmm.func` function setting, so if you use another function, then return to the previous function, the NPLC setting you set previously is retained.

Example

```
dmm.func = "twowireohms"
dmm.nplc = 0.5
dmm.func = "dcvolts"
dmm.nplc = 0.1
```

Set the NPLC for 2-wire ohms to 0.5, then set the NPLC for DC volts to 0.1.

Also see

[dmm.aperture](#) (on page 8-153)
[dmm.autozero](#) (on page 8-160)
[dmm.configure.recall\(\)](#) (on page 8-176)
[dmm.configure.set\(\)](#) (on page 8-178)
[dmm.func](#) (on page 8-190)

dmm.offsetcompensation

The offset compensation setting for the DMM for the function selected by `dmm.func`.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	0 (dmm.OFF) for "commonsideohms" and "fourwireohms" 1 (dmm.ON) for "temperature"

Usage

```
state = dmm.offsetcompensation
dmm.offsetcompensation = state
```

`state`

The offset compensation setting:

- Enable: dmm.ON or 1
- Disable: dmm.OFF or 0

Details

The command applies when `dmm.func` is set to "fourwireohms", "commonsideohms" or "temperature". When `dmm.func` = "temperature", this attribute applies only when the transducer type is 3- or 4-wire RTD. Set this command as you would for 4-wire ohm measurements.

This command is automatically set to `dmm.ON` when `dmm.drycircuit` is set to `dmm.ON` and `dmm.func` = "fourwireohms" or "commonsideohms".

The offset compensation setting is saved with the `dmm.func` function setting, so if you use another function, then return to "fourwireohms", "commonsideohms" or "temperature", the offset compensation setting you set previously is retained.

If you query this attribute and the function is not "fourwireohms", "commonsideohms", or "temperature", nil is returned.

Example 1

```
dmm.func = "fourwireohms"
dmm.offsetcompensation = dmm.ON
```

Enable offset compensation for 4-wire ohms.

Example 2

```
dmm.func = "temperature"
dmm.transducer = dmm.TEMP_THREERTD
dmm.offsetcompensation = dmm.OFF
```

Disable offset compensation for 3-wire RTD temperature measurements.

Also see

[dmm.configure.recall\(\)](#) (on page 8-176)

[dmm.configure.set\(\)](#) (on page 8-178)

[dmm.func](#) (on page 8-190)

dmm.open()

Opens the specified channel or channel pattern.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
dmm.open(channelList)
```

<i>channelList</i>	A string that lists the channel or channel pattern to open
--------------------	--

Details

This command allows you to separate the opening and closing of channels and analog backplane relays when measuring. You can execute any number of commands between the open and close commands to meet your application needs.

The configuration (`dmm.getConfig()`) associated with the specified channel dictates whether a paired channel is open or not. For channel patterns, the channels associated with it are opened. A channel pattern includes a paired channel for multi-wire measurement if a channel is configured that way when the pattern is created (see commands `channel.setpole()` and `channel.pattern.setimage()`)

The configuration (`dmm.getConfig()`) dictates whether analog backplane relays 1 and 2 are opened and if a paired channel is opened. The `dmm.open()` function does not use the analog backplane relays specified by the `channel.setbackplane()` function or pole settings set by the `channel.setpole()` function.

An error is generated and the channels do not open if:

- An empty parameter string is specified.
- The specified channel or channel pattern is invalid.
- A channel number does not exist for installed card in slot specified.
- A slot is empty.
- The channel pattern does not exist.
- The channel does not support being closed (for example, a digital I/O channel).
- The channel is paired with another bank for a multi-wire application.
- The channel configuration is "nofunction".
- More than one channel or channel pattern is specified in the parameter.

Example 1

```
reset()
channel.setpole("slot2" , 4)
channel.pattern.setimage("2005, 2911, 2922", "Chan5_4W")
dmm.setconfig("Chan5_4W", "fourwireohms")
dmm.open("Chan5_4W")
print(channel.pattern.getimage("Chan5_4W"))
```

Assume a Model 3721 is installed in slot 2.
Reset the instrument.
Configure the slot 2 channels for 4-pole operation.
Create a pattern called Chan5_4W.
Assign 4-wire ohms configuration to the Chan5_4W pattern.
Open the channels associated with Chan5_4W and display image of the Chan5_4W.
Output:
2005 (2025), 2911, 2922

Example 2

```
dmm.setconfig("slot3", "dcvolts")
dmm.close("3030")
print(channel.getclose("slot3"))
dmm.open("3030")
print(channel.getclose("slot3"))
dmm.close("3031")
print(channel.getclose("slot3"))
dmm.open("3031")
print(channel.getclose("slot3"))
```

Assume a 3720 installed in slot 3.
Set the configuration for DC volts.
Close and open the channels.

Output:
3030;3911
nil
3031;3921
nil

Also see

[channel.getclose\(\)](#) (on page 8-61)
[channel.pattern.getimage\(\)](#) (on page 8-82)
[channel.pattern.setimage\(\)](#) (on page 8-83)
[channel.setbackplane\(\)](#) (on page 8-90)
[channel.setpole\(\)](#) (on page 8-101)
[dmm.close\(\)](#) (on page 8-170)
[dmm.getconfig\(\)](#) (on page 8-192)

dmm.opendetector

Determines if the detection of open leads is enabled or disabled.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	0 (dmm.OFF) for "commonsideohms" 1 (dmm.ON) for "fourwireohms" and "temperature"

Usage

```
state = dmm.opendetector
dmm.opendetector = state
```

<i>state</i>	Enable open lead detector (dmm.ON or 1) Disable open lead detector (dmm.OFF or 0)
--------------	--

Details

The command applies when `dmm.func` is set to "fourwireohms", "commonsideohms", or "temperature".

When `dmm.func` is set to temperature, the open detector setting is only used when the transducer type is thermocouple. For all other transducer types, it is set, but not used until the transducer type is set to thermocouple.

The open detector setting is saved with the `dmm.func` function setting, so if you use another function, then return to "fourwireohms", "commonsideohms", or "temperature", the open detector setting you set previously is retained.

An error is generated if `dmm.func` is set to any function other than "fourwireohms", "commonsideohms", or "temperature". If you query the setting for any other function, `nil` is returned.

Example

```
dmm.func = "temperature"
dmm.transducer = dmm.TEMP_THERMOCOUPLE
dmm.opendetector = dmm.ON
```

Enable the thermocouple open detector.

Also see

[dmm.configure.recall\(\)](#) (on page 8-176)
[dmm.configure.set\(\)](#) (on page 8-178)
[dmm.func](#) (on page 8-190)

dmm.range

Indicates the range of DMM for the selected function.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	See Details

Usage

```
value = dmm.range
dmm.range = value
```

<i>value</i>	The range for the function selected by <code>dmm.func</code>
--------------	--

Details

Set this value to the expected measurement value and the instrument will select the range appropriate to measure that value. Setting the range with this attribute will automatically disable the autorange setting (`dmm.autorange` command).

The instrument selects the range to best match the expected measure value for the functions, as shown below.

Ranges and defaults		
If <code>dmm.func</code> is...	The range is...	The default is...
"dcvolts"	0 to 303	303
"acvolts"	0 to 303	10
"dcurrent"	0 to 3.1	3.1
"accurrent"	0 to 3.1	3.1
"twowireohms"	0 to 120e6	1000
"fourwireohms"	0 to 120e6	1000
"commonsideohms"	0 to 120e6	1000

The range setting is saved with the `dmm.func` function setting, so if you use another function, then return to the previous function, the range settings you set previously are retained.

If you query the range when the selected function does not have a range associated with it, `nil` is returned.

An error is generated if:

- The `dmm.range` is received when `dmm.func` is "temperature", "frequency", "period", "continuity", or "nofunction".
- If *value* does not make sense for selected function.

Example

```
dmm.func = "dcvolts"
dmm.range = 5
dmm.func = "twowireohms"
dmm.range = 35000
print(dmm.range)
```

Set the range for DC volts to 10. Select a range on 2-wire ohms suitable for measuring 35000. View the selected range.

Output:
1.000000000e+05

Also see

- [dmm.autorange](#) (on page 8-158)
- [dmm.configure.recall\(\)](#) (on page 8-176)
- [dmm.configure.set\(\)](#) (on page 8-178)
- [dmm.func](#) (on page 8-190)
- [dmm.reset\(\)](#) (on page 8-230)

dmm.refjunction

The type of the thermocouple reference junction.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	1 (dmm.REF_JUNCTION_INTERNAL) for "temperature"

Usage

```
state = dmm.refjunction
dmm.refjunction = state
```

<i>state</i>	The reference junction type: <ul style="list-style-type: none"> • dmm.REF_JUNCTION_SIMULATED or 0 • dmm.REF_JUNCTION_INTERNAL or 1 • dmm.REF_JUNCTION_EXTERNAL or 2
--------------	--

Details

This attribute is only valid when `dmm.func` is set to "temperature". All other functions generate an error and return `nil` when queried.

This attribute only applies when the transducer type is set to thermocouple. For all other transducer types, the reference junction may be set, but it is not used until the transducer type is set to thermocouple.

The reference junction setting is saved with the `dmm.func` function setting, so if you use another function, then return to "temperature", the reference junction settings you set previously are retained.

Example

```
dmm.func = "temperature"
dmm.transducer = dmm.TEMP_THERMOCOUPLE
dmm.refjunction = dmm.REF_JUNCTION_SIMULATED
```

Enables the simulated thermocouple reference junction.

Also see

[dmm.configure.recall\(\)](#) (on page 8-176)
[dmm.configure.set\(\)](#) (on page 8-178)
[dmm.func](#) (on page 8-190)
[dmm.transducer](#) (on page 8-246)

dmm.rel.acquire()

Acquires an internal measurement to store as the relative level value.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
relativeValue = dmm.rel.acquire()
```

<code>relativeValue</code>	The internal measurement acquired for the relative offset level value
----------------------------	---

Details

This attribute is not applicable for "continuity" and "nofunction".

This function triggers the DMM to take a new measurement for the selected function. This measurement is then stored as the new relative offset level setting.

After executing this command, use the `dmm.rel.level` attribute to see the last relative level value that was acquired or set by the user. Setting the relative level value with the acquire function does not use the math, limit, and filter settings. It is a calibrated reading as if these settings are disabled.

If error occurs during the reading, nil is returned.

An error is generated if:

- `dmm.func` is set to "continuity" or "nofunction".
- The DMM is unable to take the measurement.

When an error occurs, the relative offset level setting maintains the last valid setting.

Example

<pre>dmm.func = "temperature" rel_value = dmm.rel.acquire()</pre>	Acquires a relative offset level value for temperature.
---	---

Also see

[dmm.func](#) (on page 8-190)

[dmm.rel.level](#) (on page 8-229)

dmm.rel.enable

Enables or disables relative measurement control for the function selected by `dmm.func`.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	0 (dmm.OFF)

Usage

```
value = dmm.rel.enable
dmm.rel.enable = value
```

<code>value</code>	The setting: <ul style="list-style-type: none"> • Enable: dmm.ON or 1 • Disable: dmm.OFF or 0
--------------------	---

Details

This attribute is not available if `dmm.func` is set to "continuity" or "nofunction". If you query this attribute when either of these functions are selected, nil is returned.

When relative measurements are enabled, all subsequent measured readings are offset by the relative offset specified by `dmm.rel.level`. Each returned measured relative reading will be the result of the following calculation:

Relative reading = Actual measured reading – Relative offset value

If you change functions with `dmm.func`, the relative enable setting changes to the enable setting for that function.

The relative enable setting is saved with the `dmm.func` function setting, so if you use another function, then return to the previous function, the relative enable settings you set previously are retained.

An error is generated if:

- `dmm.func` is set to "continuity" or "nofunction".
- If the value is out of range for the selected function.

Example

```
dmm.func = "accurrent"
dmm.rel.acquire()
dmm.rel.enable = dmm.ON
```

Enables the relative measurements for AC current and uses the acquire command to set the relative level attribute.

Also see

- [dmm.configure.recall\(\)](#) (on page 8-176)
- [dmm.configure.set\(\)](#) (on page 8-178)
- [dmm.func](#) (on page 8-190)
- [dmm.rel.acquire\(\)](#) (on page 8-227)
- [dmm.rel.level](#) (on page 8-229)

dmm.rel.level

The offset value for relative measurements for the function selected by `dmm.func`.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	0.000000E+000

Usage

```
value = dmm.rel.level
dmm.rel.level = value
```

<code>value</code>	The relative offset level setting
--------------------	-----------------------------------

Details

This attribute is not available if `dmm.func` is set to "continuity" or "nofunction". If you query this attribute when either of these functions are selected, nil is returned.

When relative measurements are enabled (as set by `dmm.rel.enable`), all subsequent measured readings are offset by the specified relative offset value. Specifically, each returned measured relative reading is the result of the following calculation:

Relative reading = Actual measured reading – Relative offset value

Changing functions with `dmm.func` reflects the relative level offset setting for that function.

The relative offset level setting is saved with the `dmm.func` function setting, so if you use another function, then return to the previous function, the relative offset level settings you set previously are retained.

NOTE

To set the relative offset level to include math, limits, and filter operations (if enabled) set `dmm.rel.level` to `dmm.measure()`. However, these operations are not used if you use the `dmm.rel.acquire()` function to set the relative offset level, even if the operations are enabled.

An error is generated:

- If `dmm.func` is set to "continuity" or "nofunction".
- If the value is out of range for the selected function.

Example

```
dmm.func = "accurrent"
dmm.rel.level = dmm.measure()
rel_value = dmm.measure()
dmm.rel.level = rel_value
dmm.func = "temperature"
rel_value = dmm.rel.acquire()
```

Perform an AC current measurement and use it as the relative offset value.
Take a measurement and store it in the variable `rel_value`.
Use the `rel_value` to set the relative level attribute.
Acquire a relative offset level value for temperature.

Also see

- [dmm.configure.recall\(\)](#) (on page 8-176)
- [dmm.configure.set\(\)](#) (on page 8-178)
- [dmm.func](#) (on page 8-190)
- [dmm.measure\(\)](#) (on page 8-216)
- [dmm.rel.acquire\(\)](#) (on page 8-227)
- [dmm.rel.enable](#) (on page 8-228)

dmm.reset()

Resets the DMM functions and attributes in the instrument, as indicated by the parameter.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
dmm.reset(scope)
```

<i>scope</i>	A string equaling "active" to set the active function only to factory default settings or "all" to set all functions back to factory default settings
--------------	---

Details

When the scope is set to active, this command resets the DMM attributes for the active function to factory default values. The settings for other functions are unchanged.

When the scope is set to all, this command resets the DMM functions and attributes to factory default settings.

This function does not affect the DMM configurations (`dmm.setconfig()` and `dmm.getconfig()`).

The factory default settings are:

- The selected DMM function is set to "dcvolts".
- The DMM settings are set to the defaults for "dcvolts".
- All attribute settings for other functions are set to factory default settings.

NOTE

To reset the entire instrument to factory default settings, use the `reset` command.

Example

<pre>dmm.func = "temperature" dmm.reset("active") print(dmm.func) dmm.reset("all") print(dmm.func)</pre>	<p>Set the DMM function to temperature. Perform a reset on temperature only. Check the function after resetting only temperature.</p> <p>Perform a reset on all DMM functions. Check the function after resetting all DMM functions.</p> <p>Output: temperature dcvolts</p>
--	---

Also see

- [dmm.func](#) (on page 8-190)
- [dmm.getconfig\(\)](#) (on page 8-192)
- [dmm.setconfig\(\)](#) (on page 8-239)
- [reset\(\)](#) (on page 8-316)

dmm.rtdalpha

The user type RTD alpha value.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	3.850550E-03

Usage

```
value = dmm.rtdalpha
dmm.rtdalpha = value
```

<i>value</i>	The RTD alpha value; the range is 0 to 0.01
--------------	---

Details

This attribute is only valid when `dmm.func` is set to "temperature". All other functions generate an error and return `nil` when queried.

This setting only applies when the transducer type is set to 3 or 4-wire RTD. For other transducer types, the setting is set but not used until the transducer type is set to an RTD type.

Changing functions with `dmm.func` reflects the setting for that function.

The RTD alpha setting is saved with the `dmm.func` function setting, so if you use another function, then return to "temperature", the RTD alpha setting you set previously is retained.

NOTE

The following attributes share common settings and apply to both 3 and 4-wire RTDs: `dmm.rtdalpha`, `dmm.rtdbeta`, `dmm.rtddelta`, and `dmm.rtdzero`. Therefore, when both 3 and 4-wire RTDs are set to USER type for RTD, switching transducers between 3 and 4 will cause both to use the same settings (for example, `dmm.rtdalpha`, `dmm.rtdbeta`). If unique settings are desired, they must be changed, or use two different DMM configurations.

An error is generated if the value is out of range.

Example 1

```
dmm.func = "temperature"
dmm.transducer = dmm.TEMP_THREERTD
dmm.rtdalpha = 0.005
dmm.transducer = dmm.TEMP_FOURRTD
dmm.rtdalpha = 0.007
dmm.transducer = dmm.TEMP_THREERTD
print(dmm.rtdalpha)
```

Set an alpha constant for RTD to 0.005 for 3-wire RTD.

Change to 4-wire RTD and change the alpha constant to 0.007.

Switch back to 3-wire RTD. The value has been updated to 0.007.

Output:

```
7.000000000e-03
```

Example 2

```
dmm.func = "temperature"  
dmm.transducer = dmm.TEMP_THREERTD  
dmm.rtdalpha = 0.005  
dmm.configure.set("RTD_3wire")  
dmm.transducer = dmm.TEMP_FOURRTD  
dmm.rtdalpha = 0.007  
dmm.configure.set("RTD_4wire")  
dmm.configure.recall("RTD_3wire")  
print(dmm.transducer, dmm.rtdalpha)  
dmm.configure.recall("RTD_4wire")  
print(dmm.transducer, dmm.rtdalpha)
```

This example sets unique alpha constants for 3-wire and 4-wire RTDs by creating two DMM configurations with the desired settings.

Output:

```
3.000000000e+00    5.000000000e-03  
4.000000000e+00    7.000000000e-03
```

Also see

- [dmm.configure.recall\(\)](#) (on page 8-176)
- [dmm.configure.set\(\)](#) (on page 8-178)
- [dmm.rtdbeta](#) (on page 8-233)
- [dmm.rtddelta](#) (on page 8-235)
- [dmm.rtdzero](#) (on page 8-236)
- [dmm.transducer](#) (on page 8-246)

dmm.rtdbeta

Indicates the user beta value for user type RTD.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	1.086300E-01

Usage

```
value = dmm.rtdbeta
dmm.rtdbeta = value
```

<i>value</i>	The user type RTD beta value; valid range is 0 to 1.0
--------------	---

Details

This attribute is only valid when `dmm.func` is set to "temperature". All other functions generate an error and return nil when queried.

This setting only applies when the transducer type is set to 3 or 4-wire RTD. For other transducer types, the setting is set but not used until the transducer type is set to an RTD type.

The RTD beta setting is saved with the `dmm.func` function setting, so if you use another function, then return to "temperature", the RTD beta setting you set previously is retained.

NOTE

The following attributes share common settings and apply to both 3 and 4-wire RTDs: `dmm.rtdalpha`, `dmm.rtdbeta`, `dmm.rtddelta`, and `dmm.rtdzero`. Therefore, when both 3 and 4-wire RTDs are set to USER type for RTD, switching transducers between 3 and 4 will cause both to use the same settings (for example, `dmm.rtdalpha`, `dmm.rtdbeta`). If unique settings are desired, they must be changed, or use two different DMM configurations.

An error is generated if the value is out of range.

Example 1

```
dmm.func = "temperature"
dmm.transducer = dmm.TEMP_THREERTD
dmm.rtdbeta = 0.3
dmm.transducer = dmm.TEMP_FOURRTD
dmm.rtdbeta = 0.5
dmm.transducer = dmm.TEMP_THREERTD
print(dmm.rtdbeta)
```

Set a beta constant for RTD to 0.3 for 3-wire RTD.
Change to 4-wire RTD.
Change the beta constant to 0.5.
Switch back to 3-wire RTD. The value is 0.5.
Output:
5.000000000e-01

Example 2

```
dmm.func = "temperature"
dmm.transducer = dmm.TEMP_THREERTD
dmm.rtdbeta = 0.3
dmm.configure.set("RTD_3wire")
dmm.transducer = dmm.TEMP_FOURRTD
dmm.rtdbeta = 0.5
dmm.configure.set("RTD_4wire")
dmm.configure.recall("RTD_3wire")
print(dmm.transducer, dmm.rtdbeta)
dmm.configure.recall("RTD_4wire")
print(dmm.transducer, dmm.rtdbeta)
```

This example sets unique beta constants for 3-wire and 4-wire RTDs by creating two DMM configurations with the desired settings.
Output:
3.000000000e+00 3.000000000e-01
4.000000000e+00 5.000000000e-01

Also see

[dmm.configure.recall\(\)](#) (on page 8-176)

[dmm.configure.set\(\)](#) (on page 8-178)

[dmm.func](#) (on page 8-190)

[dmm.rtdalpha](#) (on page 8-231)

[dmm.rtddelta](#) (on page 8-235)

[dmm.rtdzero](#) (on page 8-236)

dmm.rtddelta

The user type RTD delta value.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	1.499900E+00

Usage

```
value = dmm.rtddelta
dmm.rtddelta = value
```

<i>value</i>	The user type RTD delta value; valid range is 0 to 5
--------------	--

Details

This attribute is only valid when `dmm.func` is set to "temperature". All other functions generate an error and return nil when queried.

This setting only applies when the transducer type is set to 3 or 4-wire RTD. For other transducer types, the setting is set but not used until the transducer type is set to an RTD type.

The RTD delta setting is saved with the `dmm.func` function setting, so if you use another function, then return to "temperature", the RTD delta setting you set previously is retained.

NOTE

The following attributes share common settings and apply to both 3 and 4-wire RTDs: `dmm.rtdalpha`, `dmm.rtdbeta`, `dmm.rtddelta`, and `dmm.rtdzero`. Therefore, when both 3 and 4-wire RTDs are set to USER type for RTD, switching transducers between 3 and 4 will cause both to use the same settings (for example, `dmm.rtdalpha`, `dmm.rtdbeta`). If unique settings are desired, they must be changed, or use two different DMM configurations.

An error is generated if the value is out of range.

Example 1

```
dmm.func = "temperature"
dmm.transducer = dmm.TEMP_THREERTD
dmm.rtddelta = 3
dmm.transducer = dmm.TEMP_FOURRTD
dmm.rtddelta = 5
dmm.transducer = dmm.TEMP_THREERTD
print(dmm.rtddelta)
```

Set a delta constant for RTD to 3 for 3-wire RTD.
Change to 4-wire RTD.
Change the delta constant to 5.
Switch back to 3-wire RTD. The value is 5.
Output:
5.000000000e+00

Example 2

```
dmm.func = "temperature"
dmm.transducer = dmm.TEMP_THREERTD
dmm.rtddelta = 3
dmm.configure.set("RTD_3wire")
dmm.transducer = dmm.TEMP_FOURRTD
dmm.rtddelta = 5
dmm.configure.set("RTD_4wire")
dmm.configure.recall("RTD_3wire")
print(dmm.transducer, dmm.rtddelta)
dmm.configure.recall("RTD_4wire")
print(dmm.transducer, dmm.rtddelta)
```

This example sets unique delta constants for 3-wire and 4-wire RTDs by creating two DMM configurations with the desired settings.
Output:
3.000000000e+00 3.000000000e+00
4.000000000e+00 5.000000000e+00

Also see

[dmm.configure.recall\(\)](#) (on page 8-176)
[dmm.configure.set\(\)](#) (on page 8-178)
[dmm.func](#) (on page 8-190)
[dmm.rtdalpha](#) (on page 8-231)
[dmm.rtdbeta](#) (on page 8-233)
[dmm.rtdzero](#) (on page 8-236)

dmm.rtdzero

Indicates the user type RTD zero value.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	1.000000E+02

Usage

```
value = dmm.rtdzero
dmm.rtdzero = value
```

<i>value</i>	The user type RTD zero value; the range is 0 to 10000
--------------	---

Details

This attribute is only valid when `dmm.func` is set to "temperature". All other configurations generate an error and return nil when queried.

This setting only applies when the transducer type is set to 3 or 4-wire RTD. For other transducer types, the setting is set but not used until the transducer type is set to an RTD type.

The RTD zero setting is saved with the `dmm.func` function setting, so if you use another function, then return to "temperature", the RTD zero settings you set previously are retained.

NOTE

The following attributes share common settings and apply to both 3 and 4-wire RTDs: `dmm.rtdalpha`, `dmm.rtdbeta`, `dmm.rtddelta`, and `dmm.rtdzero`. Therefore, when both 3 and 4-wire RTDs are set to USER type for RTD, switching transducers between 3 and 4 will cause both to use the same settings (for example, `dmm.rtdalpha`, `dmm.rtdbeta`). If unique settings are desired, they must be changed, or use two different DMM configurations.

An error is generated if the value is out of range.

Example 1

```
dmm.func = "temperature"
dmm.transducer = dmm.TEMP_THREERTD
dmm.rtdzero = 300
dmm.transducer = dmm.TEMP_FOURRTD
dmm.rtdzero = 500
dmm.transducer = dmm.TEMP_THREERTD
print(dmm.rtdzero)
```

Set a zero constant for RTD to 300 for 3-wire RTD.
Change to 4-wire RTD.
Change the zero constant to 500.
Switch back to 3-wire RTD. The value is 500.
Output:
5.000000000e+02

Example 2

```
dmm.func = "temperature"
dmm.transducer = dmm.TEMP_THREERTD
dmm.rtdzero = 300
dmm.configure.set("RTD_3wire")
dmm.transducer = dmm.TEMP_FOURRTD
dmm.rtdzero = 500
dmm.configure.set("RTD_4wire")
dmm.configure.recall("RTD_3wire")
print(dmm.transducer, dmm.rtdzero)
dmm.configure.recall("RTD_4wire")
print(dmm.transducer, dmm.rtdzero)
```

This example sets unique zero constants for 3-wire and 4-wire RTDs by creating two DMM configurations with the desired settings.

Output:
3.000000000e+00 3.000000000e+02
4.000000000e+00 5.000000000e+02

Also see

[dmm.configure.recall\(\)](#) (on page 8-176)

[dmm.configure.set\(\)](#) (on page 8-178)

[dmm.func](#) (on page 8-190)

[dmm.rtdalpha](#) (on page 8-231)

[dmm.rtdbeta](#) (on page 8-233)

[dmm.rtddelta](#) (on page 8-235)

dmm.savebuffer()

Saves data from the specified reading buffer to a USB flash drive using the specified filename.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
dmm.savebuffer(bufferVar, fileName)
dmm.savebuffer(bufferVar, fileName, timeFormat)
```

<i>bufferVar</i>	A string that specifies the name of the DMM reading buffer that was created by <code>dmm.makebuffer()</code>
<i>fileName</i>	A string with the name of the file on the USB flash drive to which to save the DMM reading buffer
<i>timeFormat</i>	How date and time information from the buffer is saved in the file on the USB flash drive; the values are: <ul style="list-style-type: none"> <code>dmm.buffer.SAVE_FORMAT_TIME</code>: The default. When this is selected, dates, times, and fractional seconds are saved <code>dmm.buffer.SAVE_RELATIVE_TIME</code>: Relative time stamps are saved <code>dmm.buffer.SAVE_RAW_TIME</code>: Seconds and fractional seconds are saved <code>dmm.buffer.SAVE_TIMESTAMP_TIME</code>: Time stamps are saved

Details

The filename must specify the full path (including `/usb1/`). If included, the file extension must be set to `.csv` (if no file extension is specified, `.csv` is added).

For options that save more than one item of time information, each item is comma delimited. For example, the default format will be `<date>`, `<time>`, and `<fractional seconds>` for each reading, separated by commas.

You use `dmm.makebuffer()` to create a buffer.

Examples of valid destination file names:

```
dmm.savebuffer("bufferVar", "/usb1/myData")
dmm.savebuffer("bufferVar", "/usb1/myData.csv")
```

Invalid destination filename examples:

```
dmm.savebuffer("bufferVar", "/usb1/myData.")
```

— The period is not followed by the csv extension.

```
dmm.savebuffer("bufferVar", "/usb1/myData.txt")
```

— The only allowed extension is `.csv`. If `.csv` is not assigned, it is automatically added.

```
dmm.savebuffer("bufferVar", "/usb1/myData.txt.csv")
```

— Two periods in the file name (`myData_txt.csv` would be correct).

An error is generated if:

- The reading buffer does not exist or is not a DMM buffer.
- The destination filename is not specified correctly.
- The file extension is not `.csv` (or blank).

Example

```
dmm.savebuffer("bufferVar",
"/usb1/myData.csv")
```

Saves readings from a DMM buffer named `bufferVar` with default time information to a file named `myData.csv` on the USB flash drive.

```
dmm.savebuffer("bufferVar",
"/usb1/myDataRel.csv",
dmm.buffer.SAVE_RELATIVE_TIME)
```

Saves readings from `bufferVar` with relative time stamps to a file named `myDataRel.csv` on the USB flash drive.

Also see

[dmm.appendbuffer\(\)](#) (on page 8-155)

[dmm.makebuffer\(\)](#) (on page 8-207)

dmm.setconfig()

Associates a DMM configuration with items specified in parameter channel list.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Reset Channel reset Recall setup	Created configuration script Save setup	"nofunction"

Usage

```
dmm.setconfig(channelList, dmmConfiguration)
```

<i>channelList</i>	A string that lists the channels and channel patterns to change
<i>dmmConfiguration</i>	A string with the name of the DMM configuration that will be assigned to items in <i>channelList</i>

Details

dmmConfiguration can be the name of a configuration that was saved with `dmm.configure.set()`. If you use a saved configuration, the function of the configuration and the supporting DMM attributes for that function are associated with the *channelList* parameter items. These supporting DMM attributes may have user-defined or default values associated with them.

dmmConfiguration can also be a DMM configuration name that matches the DMM function name. If you use a default DMM configuration name, be aware that the supporting function attribute settings are the default values and not user-specified (as they may be in a user-defined saved configuration). The DMM function names are:

- "accurrent"
- "acvolts"
- "commonsideohms"
- "continuity"
- "dcurrent"
- "dcvolts"
- "fourwireohms"
- "frequency"
- "nofunction"
- "period"
- "temperature"
- "twowireohms"

To use a channel with the `dmm.close()` function, `dmm.setconfig()` cannot be set to "nofunction". The configuration being assigned determines whether analog backplane relay 1 or 2 get used, based on the function associated with the configuration when being assigned to a channel. For channel patterns, the pattern image must include the desired analog backplane relays along with the desired channels. This command has no effect on the poles setting for a channel (`channel.setpole()`) or analog backplane relays specified by `channel.setbackplane()` function.

.An error is generated if:

- There is more than one DMM configuration specified.
- A DMM configuration is specified that does not exist.
- The desired DMM functionality is not supported on a specified channel.
- An analog backplane relay is specified.
- A specified channel does not exist for the card installed on the slot specified.
- A specified channel is forbidden to close.
- A matrix channel is in channel list parameter (for example, the Model 3730 is 6 x 16 high density matrix card, so an error is generated if a Model 3730 channel is included in the channel list parameter).

Once an error is detected, the command stops processing and no channels or channel patterns are modified.

Example

<code>dmm.setconfig("1001:3100", "myDcv")</code>	Assigns <code>myDcv</code> to all the channels on slots 1 and 2 and channels 1 to 100 on slot 3.
<code>dmm.setconfig("slot5", "dcvolts")</code>	Assigns the factory default settings for <code>dcvolts</code> to channels on slot 5.

Also see

[channel.setbackplane\(\)](#) (on page 8-90)
[channel.setpole\(\)](#) (on page 8-101)
[dmm.close\(\)](#) (on page 8-170)
[dmm.configure.recall\(\)](#) (on page 8-176)
[dmm.configure.set\(\)](#) (on page 8-178)
[dmm.getconfig\(\)](#) (on page 8-192)

dmm.simreftemperature

The simulated reference temperature for thermocouples.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	2.300000E+01 (23°C)

Usage

```
value = dmm.simreftemperature
dmm.simreftemperature = value
```

<i>value</i>	The simulated reference temperature in Celsius (0 °C to 65 °C), Fahrenheit (32 °F to 149 °F), or Kelvin (273 °K to 338 °K)
--------------	--

Details

This attribute is only valid when `dmm.func` is set to "temperature". All other functions generate an error and return `nil` when queried.

The simulated reference temperature is only used when the transducer type is thermocouple, as set by `dmm.transducer`. For all other transducer types, the value is set but not used until the transducer type is set for thermocouple.

The simulated reference temperature setting is saved with the `dmm.func` function setting, so if you use another function, then return to "temperature" with the transducer type set to thermocouple, the simulated reference temperature setting you set previously is retained.

Example

```
dmm.func = "temperature"
dmm.transducer = dmm.TEMP_THERMOCOUPLE
dmm.units = dmm.UNITS_CELSIUS
dmm.simreftemperature = 30
```

Sets 30 degrees Celsius as the simulated reference temperature for thermocouples.

Also see

[dmm.configure.recall\(\)](#) (on page 8-176)

[dmm.configure.set\(\)](#) (on page 8-178)

[dmm.func](#) (on page 8-190)

[dmm.transducer](#) (on page 8-246)

[dmm.units](#) (on page 8-247)

dmm.thermistor

The type of thermistor.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	5000

Usage

```
value = dmm.thermistor
dmm.thermistor = value
```

<i>value</i>	The thermistor type in ohms, 2252, 5000 or 10000; if you enter any other value, it is converted as shown in the following table:								
	<table border="1"> <thead> <tr> <th>Parameter</th> <th>Converted value</th> </tr> </thead> <tbody> <tr> <td>>= 1950 and < 3500</td> <td>2252</td> </tr> <tr> <td>>= 3500 and < 7500</td> <td>5000</td> </tr> <tr> <td>>= 7500 and <= 10050</td> <td>10000</td> </tr> </tbody> </table>	Parameter	Converted value	>= 1950 and < 3500	2252	>= 3500 and < 7500	5000	>= 7500 and <= 10050	10000
Parameter	Converted value								
>= 1950 and < 3500	2252								
>= 3500 and < 7500	5000								
>= 7500 and <= 10050	10000								

Details

This attribute is only valid when `dmm.func` is set to "temperature". All other functions generate an error and return `nil` when queried. If you use a parameter outside of the ranges listed in the usage table, a parameter out of range error message is generated.

The thermistor attribute is only used when the transducer type is set for thermistor. For all other transducer types, the setting is set but not used until thermistor is selected for the transducer type (see `dmm.transducer`).

The thermistor setting is saved with the `dmm.func` function setting, so if you use another function, then return to "temperature", the thermistor setting you set previously is retained.

Example

<code>dmm.func = "temperature"</code> <code>dmm.transducer = dmm.TEMP_THERMISTOR</code> <code>dmm.thermistor = 3000</code>	Sets thermistor type to 2252. Note that the original value is set to 3000, but is automatically converted to 2252.
<code>print(dmm.thermistor)</code>	2252

Also see

[dmm.configure.recall\(\)](#) (on page 8-176)

[dmm.configure.set\(\)](#) (on page 8-178)

[dmm.func](#) (on page 8-190)

[dmm.transducer](#) (on page 8-246)

dmm.thermocouple

Indicates the thermocouple type.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	1 (dmm.THERMOCOUPLE_K)

Usage

```
value = dmm.thermocouple
dmm.thermocouple = value
```

<i>value</i>	<p>The thermocouple type:</p> <ul style="list-style-type: none"> • dmm.THERMOCOUPLE_J or 0 • dmm.THERMOCOUPLE_K or 1 • dmm.THERMOCOUPLE_T or 2 • dmm.THERMOCOUPLE_E or 3 • dmm.THERMOCOUPLE_R or 4 • dmm.THERMOCOUPLE_S or 5 • dmm.THERMOCOUPLE_B or 6 • dmm.THERMOCOUPLE_N or 7
--------------	--

Details

This attribute is only valid when `dmm.func` is set to "temperature". All other functions generate an error and return nil when queried. An illegal parameter value error message is generated if the value specified is not a supported thermocouple type value listed in the usage table.

The thermocouple attribute is only used when the transducer type is thermocouple (see `dmm.transducer`). For all other transducer types, the value is set but not used until the transducer type is set for thermocouple.

The thermocouple setting is saved with the `dmm.func` function setting, so if you use another function, then return to "temperature", the thermocouple value you set previously is retained.

Example

<pre>dmm.func = "temperature" dmm.transducer = dmm.TEMP_THERMOCOUPLE dmm.thermocouple = dmm.THERMOCOUPLE_J</pre>	Sets the thermocouple type to J.
--	----------------------------------

Also see

[dmm.configure.recall\(\)](#) (on page 8-176)
[dmm.configure.set\(\)](#) (on page 8-178)
[dmm.func](#) (on page 8-190)
[dmm.transducer](#) (on page 8-246)

dmm.threertd

The type of three-wire RTD being used.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	0 (dmm.RTD_PT100)

Usage

```
value = dmm.threertd
dmm.threertd = value
```

<i>value</i>	<p>The desired type for 3-wire RTD:</p> <ul style="list-style-type: none"> • dmm.RTD_PT100 or 0 for type PT100 • dmm.RTD_D100 or 1 for type D100 • dmm.RTD_F100 or 2 for type F100 • dmm.RTD_PT385 or 3 for type PT385 • dmm.RTD_PT3916 or 4 for type PT3916 • dmm.RTD_USER or 5 for user-specified type
--------------	--

Details

This attribute is only valid when `dmm.func` is set to "temperature" and `dmm.transducer` is set to `dmm.TEMP_THREERTD`. For all other transducer types, the attribute is set but is not used until the transducer type is set for three-wire RTD. All other functions generate an error and return nil when queried.

An illegal parameter value error message is generated if the value specified is not a supported RTD type value as listed in the usage table.

The three-wire RTD setting is saved with the `dmm.func` function setting, so if you use another function, then return to "temperature", the three-wire RTD setting you set previously is retained.

Example

```
dmm.func = "temperature"
dmm.transducer = dmm.TEMP_THREERTD
dmm.threertd = dmm.RTD_PT3916
```

Sets the type of three-wire RTD to PT3916.

Also see

[dmm.configure.recall\(\)](#) (on page 8-176)

[dmm.configure.set\(\)](#) (on page 8-178)

[dmm.func](#) (on page 8-190)

[dmm.transducer](#) (on page 8-246)

dmm.threshold

Indicates the threshold range.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	1.000000E+01

Usage

```
value = dmm.threshold
dmm.threshold = value
```

<i>value</i>	The desired threshold setting. The range for: <ul style="list-style-type: none"> Continuity is from 1 to 1000 Ω Frequency and period is from 0 to 303 V
--------------	---

Details

This attribute is only valid when `dmm.func` is set to "frequency", "period", or "continuity". All other functions generate an error and return nil when queried.

For frequency and period, this refers to a threshold voltage range.

For continuity, it refers to a threshold resistance in ohms.

Errors are generated if the parameter value does not make sense for selected function.

The threshold value is saved with the `dmm.func` function setting, so if you use another function, then return to "frequency", "period", or "continuity", the threshold value you set previously is retained.

Example

```
dmm.func = "frequency"
dmm.threshold = 30
```

Sets the threshold range for frequency to 30.

Also see

[dmm.configure.recall\(\)](#) (on page 8-176)

[dmm.configure.set\(\)](#) (on page 8-178)

[dmm.func](#) (on page 8-190)

dmm.transducer

The transducer type.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	1 (dmm.TEMP_THERMOCOUPLE)

Usage

```
value = dmm.transducer
dmm.transducer = value
```

<i>value</i>	The transducer type: <ul style="list-style-type: none"> • dmm.TEMP_THERMOCOUPLE or 1 • dmm.TEMP_THERMISTOR or 2 • dmm.TEMP_THREERTD or 3 • dmm.TEMP_FOURRTD or 4
--------------	--

Details

This attribute is only valid when `dmm.func` is set to "temperature". All other functions generate an error and return nil when queried.

NOTE

The setting of this attribute affects which other temperature-supported attributes get used. There are various attributes that are only applicable when the transducer type is a certain type. Although the transducer type needs to match for the attribute setting to be used, the transducer type does not need to match to change the setting or read the setting. For example, the transducer type does not need to be set to `dmm.TEMP_FOURRTD` to change the `dmm.fourrtd` attribute setting.

The transducer value is saved with the `dmm.func` function setting, so if you use another function, then return to "temperature", the transducer value you set previously is retained.

Example

```
dmm.func = "temperature"
dmm.transducer = dmm.TEMP_THERMISTOR
```

Sets transducer to thermistor type.

Also see

[dmm.configure.recall\(\)](#) (on page 8-176)
[dmm.configure.set\(\)](#) (on page 8-178)
[dmm.fourrtd](#) (on page 8-189)
[dmm.func](#) (on page 8-190)

dmm.units

The units that are used for voltage and temperature measurements.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset DMM reset Recall setup	Create configuration script Save setup	0 (dmm.UNITS_VOLTS) for "acvolts" and "dcvolts" 2 (dmm.UNITS_CELSIUS) for "temperature"

Usage

```
state = dmm.units
dmm.units = state
```

<i>value</i>	<p>For <code>dcvolts</code> and <code>acvolts</code>, select from the following units:</p> <ul style="list-style-type: none"> • <code>dmm.UNITS_VOLTS</code> or 0 • <code>dmm.UNITS_DECIBELS</code> or 1 <p>For <code>temperature</code>, select from the following units:</p> <ul style="list-style-type: none"> • <code>dmm.UNITS_CELSIUS</code> or 2 • <code>dmm.UNITS_KELVIN</code> or 3 • <code>dmm.UNITS_FAHRENHEIT</code> or 4
--------------	--

Details

This attribute is only valid when `dmm.func` is set to "dcvolts", "acvolts", or "temperature".

All other functions generate an error and return nil when queried.

The units value is saved with the `dmm.func` function setting, so if you use another function, then return to "dcvolts", "acvolts", or "temperature", the units setting you set previously is retained.

Errors are generated if the parameter value does not make sense for the selected function.

Example

<pre>dmm.func = "temperature" dmm.units = dmm.UNITS_FAHRENHEIT</pre>	Sets units for temperature measurements to Fahrenheit (°F).
--	---

Also see

[dmm.configure.recall\(\)](#) (on page 8-176)

[dmm.configure.set\(\)](#) (on page 8-178)

[dmm.func](#) (on page 8-190)

errorqueue.clear()

This function clears all entries out of the error queue.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
errorqueue.clear()
```

Details

See the Reading errors and [Status model](#) (on page D-1) topics for additional information about the error queue.

Also see

[errorqueue.count](#) (on page 8-248)

[errorqueue.next\(\)](#) (on page 8-248)

Reading errors

[Status model](#) (on page D-1)

errorqueue.count

This attribute gets the number of entries in the error queue.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Power cycle Clearing error queue Reading error messages	Not applicable	Not applicable

Usage

```
count = errorqueue.count
```

<code>count</code>	The number of entries in the error queue
--------------------	--

Example

```
count = errorqueue.count
print(count)
```

Returns the number of entries in the error queue.

The output below indicates that there are four entries in the error queue:

```
4.00000e+00
```

Also see

[errorqueue.clear\(\)](#) (on page 8-248)

[errorqueue.next\(\)](#) (on page 8-248)

errorqueue.next()

This function reads the oldest entry from the error queue and removes it from the queue.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
errorCode, message, severity, errorNode = errorqueue.next()
```

<i>errorCode</i>	The error code number for the entry
<i>message</i>	The message that describes the error code
<i>severity</i>	The severity level (0, 10, 20, 30, or 40); see Details for more information
<i>errorNode</i>	The node number where the error originated

Details

Entries are stored in a first-in, first-out (FIFO) queue. This function reads the oldest entry and removes it from the queue.

Error codes and messages are listed in the [Error and status messages](#) (on page 2-61) topics.

If there are no entries in the queue, code 0, "Queue is Empty" is returned.

Returned severity levels are described in the following table.

Severity level descriptions		
Number	Level	Description
0	Informational	Indicates that there are no entries in the queue.
10	Informational	Indicates a status message or minor error.
20	Recoverable	Indicates possible invalid user input; operation continues but action should be taken to correct the error.
30	Serious	Indicates a serious error that may require technical assistance, such as corrupted data.
40	Fatal	Instrument is not operational.

In an expanded system, each TSP-Link enabled instrument is assigned a node number. The variable *errorNode* stores the node number where the error originated.

Example

```
errorcode, message = errorqueue.next()
print(errorcode, message)
```

Reads the oldest entry in the error queue. The output below indicates that the queue is empty.

Output:

```
0.00000e+00 Queue Is Empty
```

Also see

[errorqueue.clear\(\)](#) (on page 8-248)

[errorqueue.count](#) (on page 8-248)

[Error and status messages](#) (on page 2-61)

[Status model](#) (on page D-1)

eventlog.all()

This function returns all entries from the event log as a single string and removes them from the event log.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
logString = eventlog.all()
```

<i>logString</i>	A listing of all event log entries
------------------	------------------------------------

Details

This function returns all events in the event log. Logged items are shown from oldest to newest. The response is a string that has the messages delimited with a new line character.

This function also clears the event log.

If there are no entries in the event log, this function returns the value `nil`.

Example

```
print(eventlog.all())
```

Get and print all entries from the event log and remove the entries from the log.

Output:

```
17:26:35.690 10 Oct 2007, LAN0, 192.168.1.102, LXI, 0, 1192037132,
1192037155.733269000, 0, 0x0
17:26:39.009 10 Oct 2007, LAN5, 192.168.1.102, LXI, 0, 1192037133,
1192037159.052777000, 0, 0x0
```

Also see

- [eventlog.clear\(\)](#) (on page 8-250)
- [eventlog.count](#) (on page 8-251)
- [eventlog.enable](#) (on page 8-251)
- [eventlog.next\(\)](#) (on page 8-252)
- [eventlog.overwritemethod](#) (on page 8-253)

eventlog.clear()

This function clears the event log.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
eventlog.clear()
```

Details

This function erases any messages in the event log.

Also see

[eventlog.all\(\)](#) (on page 8-250)
[eventlog.count](#) (on page 8-251)
[eventlog.enable](#) (on page 8-251)
[eventlog.next\(\)](#) (on page 8-252)
[eventlog.overwritemethod](#) (on page 8-253)

eventlog.count

This attribute gets the number of events contained in the event log.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Instrument reset Clearing event log Reading event log	Not applicable	Not applicable

Usage

```
N = eventlog.count
```

<i>N</i>	The number of events in the event log
----------	---------------------------------------

Example

```
print(eventlog.count)
```

Displays the present number of events contained in the Series 3700A event log.

Output looks similar to:
3.00000e+00

Also see

[eventlog.all\(\)](#) (on page 8-250)
[eventlog.clear\(\)](#) (on page 8-250)
[eventlog.enable](#) (on page 8-251)
[eventlog.next\(\)](#) (on page 8-252)
[eventlog.overwritemethod](#) (on page 8-253)

eventlog.enable

This attribute enables or disables the event log.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Instrument reset Recall setup	Create configuration script Save setup	eventlog.ENABLE

Usage

```
status = eventlog.enable
eventlog.enable = status
```

<i>status</i>	The enable status of the event log: 1 or eventlog.ENABLE: Event log enable 0 or eventlog.DISABLE: Event log disable
---------------	---

Details

When the event log is disabled (`eventlog.DISABLE` or 0), no new events are added to the event log. You can, however, read and remove existing events.

When the event log is enabled, new events are logged.

Example

```
print(eventlog.enable)
eventlog.enable = eventlog.DISABLE
print(eventlog.enable)
```

Displays the present status of the Series 3700A event log.

Output:

```
1.00000e+00
0.00000e+00
```

Also see

[eventlog.all\(\)](#) (on page 8-250)
[eventlog.clear\(\)](#) (on page 8-250)
[eventlog.count](#) (on page 8-251)
[eventlog.next\(\)](#) (on page 8-252)
[eventlog.overwritemethod](#) (on page 8-253)

eventlog.next()

This function returns the oldest message from the event log and removes it from the log.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
logString = eventlog.next()
```

<code>logString</code>	The next log entry
------------------------	--------------------

Details

Returns the next entry from the event log and removes it from the log.

If there are no entries in the event log, returns the value `nil`.

Example 1

```
print(eventlog.next())
```

Get the oldest message in the event log and remove that entry from the log.

Output:

```
17:28:22.085 10 Oct 2009, LAN2, 192.168.1.102, LXI, 0, 1192037134, <no time>, 0,
0x0
```

Example 2

```
print(eventlog.next())
```

If you send this command when there is nothing in the event log, you will get the following output:

```
nil
```

Also see

[eventlog.all\(\)](#) (on page 8-250)
[eventlog.clear\(\)](#) (on page 8-250)
[eventlog.count](#) (on page 8-251)
[eventlog.enable](#) (on page 8-251)
[eventlog.overwritemethod](#) (on page 8-253)

eventlog.overwritemethod

This attribute controls how the event log processes events if the event log is full.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Instrument reset Recall setup	Create configuration script Save setup	eventlog.DISCARD_OLDEST

Usage

```
method = eventlog.overwritemethod
eventlog.overwritemethod = method
```

method

Set to one of the following values:

- 0 or eventlog.DISCARD_NEWEST: New entries are not logged
- 1 or eventlog.DISCARD_OLDEST: Old entries are deleted as new events are logged

Details

When this attribute is set to eventlog.DISCARD_NEWEST, new entries are not be logged.

When this attribute is set to eventlog.DISCARD_OLDEST, the oldest entry is discarded when a new entry is added.

Example

```
eventlog.overwritemethod = 0
```

When the log is full, the event log will ignore new entries.

Also see

[eventlog.all\(\)](#) (on page 8-250)
[eventlog.clear\(\)](#) (on page 8-250)
[eventlog.count](#) (on page 8-251)
[eventlog.enable](#) (on page 8-251)
[eventlog.next\(\)](#) (on page 8-252)

exit()

This function stops a script that is presently running.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
exit()
```

Details

Terminates script execution when called from a script that is being executed.

This command does not wait for overlapped commands to complete before terminating script execution. If overlapped commands are required to finish, use the `waitcomplete()` function before calling `exit()`.

Also see

[waitcomplete\(\)](#) (on page 8-461)

fileVar:close()

This function closes the file that is represented by the `fileVar` variable.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
fileVar:close()
```

<code>fileVar</code>	The file descriptor variable to close
----------------------	---------------------------------------

Details

This command is equivalent to `io.close(fileVar)`.

Note that files are automatically closed when the file descriptors are garbage collected.

Also see

[File I/O](#) (on page 3-24)
[fileVar:flush\(\)](#) (on page 8-255)
[fileVar:read\(\)](#) (on page 8-255)
[fileVar:seek\(\)](#) (on page 8-256)
[fileVar:write\(\)](#) (on page 8-257)
[io.close\(\)](#) (on page 8-264)
[io.open\(\)](#) (on page 8-266)

fileVar:flush()

This function writes buffered data to a file.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
fileVar:flush()
```

<i>fileVar</i>	The file descriptor variable to flush
----------------	---------------------------------------

Details

The `fileVar:write()` or `io.write()` functions buffer data, which may not be written immediately to the USB flash drive. Use this function to flush this data. Using this function removes the need to close a file after writing to it, allowing it to be left open to write more data. Data may be lost if the file is not closed or flushed before a script ends.

If there is going to be a time delay before more data is written to a file, and you want to keep the file open, flush the file after you write to it to prevent loss of data.

Also see

[File I/O](#) (on page 3-24)
[fileVar:write\(\)](#) (on page 8-257)
[io.open\(\)](#) (on page 8-266)
[io.write\(\)](#) (on page 8-268)

fileVar:read()

This function reads data from a file.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
data1 = fileVar:read()
data1 = fileVar:read(format1)
data1, data2 = fileVar:read(format1, format2)
data1, ..., datan = fileVar:read(format1, ..., formatn)
```

<i>data1</i>	First data read from the file
<i>data2</i>	Second data read from the file
<i>datan</i>	Last data read from the file
<i>fileVar</i>	The descriptor of the file to be read
<i>format1</i>	A string or number indicating the first type of data to be read
<i>format2</i>	A string or number indicating the second type of data to be read
<i>formatn</i>	A string or number indicating the last type of data to be read
...	One or more entries (or values) separated by commas

Details

The format parameters may be any of the following:

"*n": Returns a number.

"*a": Returns the whole file, starting at the current position (returns an empty string if the current file position is at the end of the file).

"*l": Returns the next line, skipping the end of line; returns `nil` if the current file position is at the end of file.

n: Returns a string with up to n characters; returns an empty string if n is zero; returns `nil` if the current file position is at the end of file.

If no format parameters are provided, the function will perform as if the function is passed the value "*l".

Any number of format parameters may be passed to this command, each corresponding to a returned data value.

Also see

[File I/O](#) (on page 3-24)

[fileVar:write\(\)](#) (on page 8-257)

[io.input\(\)](#) (on page 8-265)

[io.open\(\)](#) (on page 8-266)

fileVar:seek()

This function sets and gets a file's current position.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
position, errorMsg = fileVar:seek()
position, errorMsg = fileVar:seek(whence)
position, errorMsg = fileVar:seek(whence, offset)
```

<i>position</i>	The new file position, measured in bytes from the beginning of the file
<i>errorMsg</i>	A string containing the error message
<i>fileVar</i>	The file descriptor variable
<i>whence</i>	A string indicating the base against which <i>offset</i> is applied; the <i>whence</i> attribute is optional (default is "cur")
<i>offset</i>	The intended new position, measured in bytes from a base indicated by <i>whence</i> (optional, default is 0)

Details

The *whence* parameters may be any of the following:

"set": Beginning of file

"cur": Current position

"end": End of file

If an error is encountered, it is logged to the error queue, and the command returns `nil` and the error string.

Also see

[File I/O](#) (on page 3-24)

[io.open\(\)](#) (on page 8-266)

Reading errors

fileVar:write()

This function writes data to a file.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
fileVar:write(data)
fileVar:write(data1, data2)
fileVar:write(data1, ..., datan)
```

<i>fileVar</i>	The file descriptor variable
<i>data</i>	Write all data to the file
<i>data1</i>	The first data to write to the file
<i>data2</i>	The second data to write to the file
<i>datan</i>	The last data to write to the file
...	One or more entries (or values) separated by commas

Details

This function may buffer data until a flush (`fileVar:flush()` or `io.flush()`) or close (`fileVar:close()` or `io.close()`) operation is performed.

Also see

[File I/O](#) (on page 3-24)
[fileVar:close\(\)](#) (on page 8-254)
[fileVar:flush\(\)](#) (on page 8-255)
[io.close\(\)](#) (on page 8-264)
[io.open\(\)](#) (on page 8-266)

format.asciiprecision

This attribute sets the precision (number of digits) for all numbers printed with the ASCII format.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	No	Instrument reset Recall setup	Create configuration script Save setup	6

Usage

```
precision = format.asciiprecision
format.asciiprecision = precision
```

<i>precision</i>	A number representing the number of digits to be printed for numbers printed with the <code>print()</code> , <code>printbuffer()</code> , and <code>printnumber()</code> functions; must be a number between 1 and 16
------------------	---

Details

This attribute specifies the precision (number of digits) for numeric data printed with the `print()`, `printbuffer()`, and `printnumber()` functions. The `format.asciiprecision` attribute is only used with the ASCII format. The precision value must be a number between 1 and 16.

Note that the precision is the number of significant digits printed. There is always one digit to the left of the decimal point; be sure to include this digit when setting the precision.

Example

<pre>format.asciiprecision = 10 x = 2.54 printnumber(x) format.asciiprecision = 3 printnumber(x)</pre>	<p>Output:</p> <pre>2.540000000e+00 2.54e+00</pre>
--	--

Also see

[format.byteorder](#) (on page 8-258)
[format.data](#) (on page 8-259)
[print\(\)](#) (on page 8-307)
[printbuffer\(\)](#) (on page 8-308)
[printnumber\(\)](#) (on page 8-309)

format.byteorder

This attribute sets the binary byte order for data printed using the `printnumber()` and `printbuffer()` functions.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Instrument reset	Create configuration script	format.LITTLEENDIAN

Usage

```
order = format.byteorder
format.byteorder = order
```

<i>order</i>	Byte order value as follows: <ul style="list-style-type: none"> • Most significant byte first: 0, <code>format.NORMAL</code>, <code>format.NETWORK</code>, or <code>format.BIGENDIAN</code> • Least significant byte first: 1, <code>format.SWAPPED</code> or <code>format.LITTLEENDIAN</code>
--------------	--

Details

This attribute selects the byte order in which data is written when printing data values with the `printnumber()` and `printbuffer()` functions. The byte order attribute is only used with the `format.SREAL`, `format.REAL`, `format.REAL32`, and `format.REAL64` data formats.

`format.NORMAL`, `format.BIGENDIAN`, and `format.NETWORK` select the same byte order. `format.SWAPPED` and `format.LITTLEENDIAN` select the same byte order. Selecting which to use is a matter of preference.

Select the `format.SWAPPED` or `format.LITTLEENDIAN` byte order when sending data to a computer with a Microsoft Windows operating system.

Example

```
x = 1.23
format.data = format.REAL32
format.byteorder = format.LITTLEENDIAN
printnumber(x)
format.byteorder = format.BIGENDIAN
printnumber(x)
```

Output depends on the terminal program you use, but will look something like:

```
#0p??
#0??p
```

Also see

[format.asciiprecision](#) (on page 8-257)
[format.data](#) (on page 8-259)
[printbuffer\(\)](#) (on page 8-308)
[printnumber\(\)](#) (on page 8-309)

format.data

This attribute sets the data format for data printed using the `printnumber()` and `printbuffer()` functions.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	No	Instrument reset Save setup	Create configuration script Recall setup	format.ASCII

Usage

```
value = format.data
format.data = value
```

value

The format to use for data, set to one of the following values:

- ASCII format: 1 or `format.ASCII`
- Single-precision IEEE Std 754 binary format: 2, `format.SREAL`, or `format.REAL32`
- Double-precision IEEE Std 754 binary format: 3, `format.REAL`, `format.REAL64`, or `format.DREAL`

Details

The precision of numeric values can be controlled with the `format.asciiprecision` attribute. The byte order of `format.SREAL`, `format.REAL`, `format.REAL32`, and `format.REAL64` can be selected with the `format.byteorder` attribute.

`REAL32` and `SREAL` select the same single precision format. `REAL` and `REAL64` select the same double precision format. They are alternative identifiers. Selecting which to use is a matter of preference.

The IEEE Std 754 binary formats use four bytes each for single-precision values and eight bytes each for double-precision values.

When data is written with any of the binary formats, the response message starts with “#0” and ends with a new line. When data is written with the ASCII format, elements are separated with a comma and space.

NOTE

Binary formats are not intended to be interpreted by humans.

Example

```
format.asciiprecision = 10
x = 3.14159265
format.data = format.ASCII
printnumber(x)
format.data = format.REAL64
printnumber(x)
```

Output a number represented by *x* in ASCII using a precision of 10, then output the same number in binary using double precision format.

Output:
3.141592650e+00
#0ñÔÈSá! @

Also see

[format.asciiprecision](#) (on page 8-257)

[format.byteorder](#) (on page 8-258)

[printbuffer\(\)](#) (on page 8-308)

[printnumber\(\)](#) (on page 8-309)

fs.chdir()

This function sets the current working directory.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
workingDirectory = fs.chdir(path)
```

<i>workingDirectory</i>	Returned value containing the working path
<i>path</i>	A string indicating the new working directory path

Details

The new working directory path may be absolute or relative to the current working directory.

An error is logged to the error queue if the given path does not exist.

Example

```
testPath = fs.chdir("/usb1/")
```

Change the working directory to usb1.

Also see

Not applicable

fs.cwd()

This function returns the absolute path of the current working directory.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
path = fs.cwd()
```

<i>path</i>	The absolute path of the current working directory
-------------	--

Also see

[File I/O](#) (on page 3-24)

fs.is_dir()

This function tests whether or not the specified path refers to a directory.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
status = fs.is_dir(path)
```

<i>status</i>	Whether or not the given path is a directory (true or false)
<i>path</i>	The path of the file system entry to test

Details

The file system path may be absolute or relative to the current working system path.
An error is logged to the error queue if the given path does not exist.

Also see

[File I/O](#) (on page 3-24)
[fs.is_file\(\)](#) (on page 8-261)

fs.is_file()

Tests whether the specified path refers to a file (as opposed to a directory).

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
status = fs.is_file(path)
```

<i>status</i>	true if the given path is a file; otherwise, false
<i>path</i>	The path of the file system entry to test

Details

The file system path may be absolute or relative to the current working system path.
An error is logged to the error queue if the given path does not exist.

Also see

[File I/O](#) (on page 3-24)
[fs.is_dir\(\)](#) (on page 8-261)

fs.mkdir()

This function creates a directory at the specified path.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
path = fs.mkdir(newPath)
```

<i>path</i>	The returned path of the new directory
<i>newpath</i>	Location (path) of where to create the new directory

Details

The directory path may be absolute or relative to the current working directory.

An error is logged to the error queue if the parent folder of the new directory does not exist, or if a file system entry already exists at the given path.

Also see

[File I/O](#) (on page 3-24)

[fs.rmdir\(\)](#) (on page 8-262)

fs.readdir()

This function returns a list of the file system entries in the directory.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
files = fs.readdir(path)
```

<i>files</i>	A table containing the names of all the file system entries in the specified directory
<i>path</i>	The directory path

Details

The directory path may be absolute or relative to the current working directory.

This command is nonrecursive. For example, entries in subfolders are not returned.

An error is logged to the error queue if the given path does not exist or does not represent a directory.

Also see

[File I/O](#) (on page 3-24)

fs.rmdir()

This function removes a directory from the file system.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
fs.rmdir (path)
```

<code>path</code>	The path of the directory to remove
-------------------	-------------------------------------

Details

This path may be absolute or relative to the current working directory.

An error is logged to the error queue if the given path does not exist, or does not represent a directory, or if the directory is not empty.

Also see

[File I/O](#) (on page 3-24)

[fs.mkdir\(\)](#) (on page 8-262)

gettimezone()

This function retrieves the local time zone.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
timeZone = gettimezone()
```

<code>timeZone</code>	The local timezone of the instrument
-----------------------	--------------------------------------

Details

See `settimezone()` for additional details on the time zone format and a description of the fields. `timeZone` can be in either of the following formats:

- If one argument was used with `settimezone()`, the format used is:
GMThh:mm:ss
- If four arguments were used with `settimezone()`, the format used is:
GMThh:mm:ssGMThh:mm:ss,Mmm.w.dw/hh:mm:ss,Mmm.w.dw/hh:mm:ss

Example

<code>timezone = gettimezone()</code>	Reads the value of the local timezone.
---------------------------------------	--

Also see

[settimezone\(\)](#) (on page 8-365)

gpib.address

This attribute contains the GPIB address.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Not applicable	Nonvolatile memory	16

Usage

```
address = gpib.address
gpib.address = address
```

<i>address</i>	GPIB address (0 to 30)
----------------	------------------------

Details

A new GPIB address takes affect when the command to change it is processed. If there are response messages in the output queue when this command is processed, they must be read at the new address.

If command messages are being queued (sent before this command has executed), the new settings may take effect in the middle of a subsequent command message, so care should be exercised when setting this attribute from the GPIB interface.

You should allow ample time for the command to be processed before attempting to communicate with the instrument again. After sending this command, make sure to use the new address to communicate with the instrument.

The GPIB address is stored in nonvolatile memory. The reset function has no affect on the address.

Example

```
gpib.address = 26
address = gpib.address
print(address)
```

Sets the GPIB address and reads the address.
Output:
2.600000e+01

Also see

[GPIB operation](#) (on page 2-59)

io.close()

This function closes a file.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes (see Details)			

Usage

```
io.close()
io.close(file)
```

<i>file</i>	The descriptor of the file to close
-------------	-------------------------------------

Details

If a file is not specified, the default output file closes.

Only `io.close()`, used without specifying a parameter, can be accessed from a remote node.

Example

```
testFile, testError = io.open("testfile.txt", "w")
if nil == testError then
  testFile:write("This is my test file")
  io.close(testFile)
end
```

Opens file `testfile.txt` for writing. If no errors were found while opening, writes "This is my test file" and closes the file.

Also see

[fileVar:close](#) (see "[fileVar:close\(\)](#)" on page 8-254)
[Script examples](#) (on page 3-26)
[io.open\(\)](#) (on page 8-266)

io.flush()

This function saves buffered data to a file.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
io.flush()
```

Details

You must use the `io.flush()` or `io.close()` functions to write data to the file system.

NOTE

Data is not automatically written to a file when you use the `io.write()` function. The `io.write()` function buffers data; it may not be written to the USB drive immediately. Use the `io.flush()` function to immediately write buffered data to the drive.

This function only flushes the default output file.

Using this command removes the need to close a file after writing to it and allows it to be left open to write more data. Data may be lost if the file is not closed or flushed before an application ends. To prevent the loss of data if there is going to be a time delay before more data is written (and when you want to keep file open and not close it), flush the file after writing to it.

Also see

[Script examples](#) (on page 3-26)
[fileVar:flush\(\)](#) (on page 8-255)
[fileVar:write\(\)](#) (on page 8-257)
[io.write\(\)](#) (on page 8-268)

io.input()

This function assigns a previously opened file, or opens a new file, as the default input file.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes (see Details)			

Usage

```
fileVar = io.input()
fileVar = io.input(newfile)
```

<i>fileVar</i>	The descriptor of the input file or an error message (if the function fails)
<i>newfile</i>	A string representing the path of a file to open as the default input file, or the file descriptor of an open file to use as the default input file

Details

The *newfile* path may be absolute or relative to the current working directory.

When using this function from a remote TSP-Link® node, this command does not accept a file descriptor and does not return a value.

If the function fails, an error message is returned.

Also see

[Script examples](#) (on page 3-26)

[io.open\(\)](#) (on page 8-266)

[io.output\(\)](#) (on page 8-267)

io.open()

This function opens a file for later reference.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
fileVar, errorMsg = io.open(path)
fileVar, errorMsg = io.open(path, mode)
```

<i>fileVar</i>	The descriptor of the opened file
<i>errorMsg</i>	Indicates whether an error was encountered while processing the function
<i>path</i>	The path of the file to open
<i>mode</i>	A string representing the intended access mode ("r" = read, "w" = write, and "a" = append)

Details

The path to the file to open may be absolute or relative to the current working directory. If you successfully open the file, *errorMsg* is nil and *fileVar* has the descriptor that can be used to access the file.

If an error is encountered, the command returns nil for *fileVar* and an error string.

Example

```
testFile, testError = io.open("testfile.txt", "w")
if testError == nil then
  testFile:write("This is my test file")
  io.close(testFile)
end
```

Opens file testfile.txt for writing. If no errors were found while opening, writes "This is my test file" and closes the file.

Also see

[Script examples](#) (on page 3-26)

[fileVar:close](#) (see "[fileVar:close\(\)](#)" on page 8-254)

[io.close\(\)](#) (on page 8-264)

io.output()

This function assigns a previously opened file, or opens a new file, as the default output file.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes (see Details)			

Usage

```
fileVar = io.output()
fileVar = io.output(newfile)
```

<i>fileVar</i>	The descriptor of the output file or an error message (if the function fails)
<i>newfile</i>	A file descriptor to assign (or the path of a file to open) as the default output file

Details

The path of the file to open may be absolute or relative to the current working directory.

When accessed from a remote node using the TSP-Link network, this command does not accept a file descriptor parameter and does not return a value.

If the function fails, an error message is returned.

Also see

[Script examples](#) (on page 3-26)
[io.input\(\)](#) (on page 8-265)
[io.open\(\)](#) (on page 8-266)

io.read()

This function reads data from the default input file.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
data1 = io.read()
data1 = io.read(format1)
data1, data2 = io.read(format1, format2)
data1, ..., dataN = io.read(format1, ..., formatN)
```

<i>data1</i>	The data read from the file
<i>data2</i>	The data read from the file
<i>dataN</i>	The data read from the file; the number of return values matches the number of format values given
<i>format1</i>	A string or number indicating the type of data to be read
<i>format2</i>	A string or number indicating the type of data to be read
<i>formatN</i>	A string or number indicating the type of data to be read
...	One or more entries (or values) separated by commas

Details

The format parameters may be any of the following:

Format parameter	Description
"*N"	Returns a number
"*a"	Returns the whole file, starting at the current position; returns an empty string if it is at the end of file
"*l"	Returns the next line, skipping the end of line; returns <code>nil</code> if the current file position is at the end of file
N	Returns a string with up to N characters; returns an empty string if N is zero (0); returns <code>nil</code> if the current file position is at the end of file

Any number of format parameters may be passed to this command, each corresponding to a returned data value.

If no format parameters are provided, the function will perform as if the function was passed the value "*l".

Also see

[fileVar.read\(\)](#) (on page 8-255)

[Script examples](#) (on page 3-26)

io.type()

This function checks whether or not a given object is a file handle.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
type = io.type(obj)
```

<i>type</i>	Indicates whether the object is an open file handle
<i>obj</i>	Object to check

Details

Returns the string "file" if the object is an open file handle. If it is not an open file handle, `nil` is returned.

Also see

[Script examples](#) (on page 3-26)

[io.open\(\)](#) (on page 8-266)

io.write()

This function writes data to the default output file.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
io.write()
io.write(data1)
io.write(data1, data2)
io.write(data1, ..., dataN)
```

<i>data1</i>	The data to be written
<i>data2</i>	The data to be written
<i>dataN</i>	The data to be written
...	One or more values separated by commas

Details

All data parameters must be either strings or numbers.

NOTE

Data is not immediately written to a file when you use the `io.write()` function. The `io.write()` function buffers data; it may not be written to the USB drive immediately. Use the `io.flush()` function to immediately write buffered data to the drive.

Also see

[Script examples](#) (on page 3-26)
[io.flush\(\)](#) (on page 8-265)

lan.applysettings()

This function re-initializes the LAN interface with new settings.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
lan.applysettings()
```

Details

Disconnects all existing LAN connections to the instrument and re-initializes the LAN with the current configuration settings.

This function initiates a background operation. LAN configuration could be a lengthy operation. Although the function returns immediately, the LAN initialization will continue to run in the background.

Even though the LAN configuration settings may not have changed since the LAN was last connected, new settings may take effect due to the dynamic nature of DHCP or DLLA configuration.

Re-initialization takes effect even if the configuration has not changed since the last time the instrument connected to the LAN.

Example

```
lan.applysettings() Re-initialize the LAN interface with new settings.
```

Also see

None

lan.config.dns.address[N]

Configures DNS server IP addresses.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	LAN restore defaults	Nonvolatile memory	"0.0.0.0"

Usage

```
dnsAddress = lan.config.dns.address[N]
lan.config.dns.address[N] = dnsAddress
```

<i>dnsAddress</i>	DNS server IP address
<i>N</i>	Entry index (1 or 2)

Details

This attribute is an array of DNS (domain name system) server addresses. These addresses take priority for DNS lookups and are consulted before any server addresses that are obtained using DHCP. This allows local DNS servers to be specified that take priority over DHCP-configured global DNS servers.

You can specify up to two addresses. The address specified by 1 is consulted first for DNS lookups.

Unused entries will be returned as "0.0.0.0" when read. *dnsAddress* must be a string specifying the DNS server's IP address in dotted decimal notation. To disable an entry, set its value to "0.0.0.0" or the empty string "".

Although only two address may be manually specified here, the instrument will use up to three DNS server addresses. If two are specified here, only one that is given by a DHCP server is used. If no entries are specified here, up to three addresses that are given by a DHCP server are used. The IP address obtained from the DHCP server takes priority for all DNS lookups.

Example

```
dnsaddress = "164.109.48.173"
lan.config.dns.address[1] = dnsaddress
```

Configure DNS address 1 to "164.109.48.173"

Also see

[lan.config.dns.domain](#) (on page 8-270)
[lan.config.dns.dynamic](#) (on page 8-271)
[lan.config.dns.hostname](#) (on page 8-272)
[lan.config.dns.verify](#) (on page 8-272)
[lan.restoredefaults\(\)](#) (on page 8-276)

lan.config.dns.domain

Configures the dynamic DNS domain.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	LAN restore defaults	Nonvolatile memory	""

Usage

```
domain = lan.config.dns.domain
lan.config.dns.domain = domain
```

<i>domain</i>	Dynamic DNS registration domain; use a string of 255 characters or less
---------------	---

Details

This attribute holds the domain to request during dynamic DNS registration. Dynamic DNS registration works with DHCP to register the domain specified in this attribute with the DNS server.

The length of the fully qualified host name (combined length of the domain and host name with separator characters) must be less than or equal to 255 characters. Although up to 255 characters are allowed, you must make sure the combined length is also no more than 255 characters.

Example

```
print(lan.config.dns.domain)
```

Outputs the present dynamic DNS domain. For example, if the domain is "Matrix", the response would be:
Matrix

Also see

[lan.config.dns.dynamic](#) (on page 8-271)

[lan.config.dns.hostname](#) (on page 8-272)

[lan.config.dns.verify](#) (on page 8-272)

[lan.restoredefaults\(\)](#) (on page 8-276)

lan.config.dns.dynamic

Enables or disables the dynamic DNS registration.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	LAN restore defaults	Nonvolatile memory	lan.ENABLE

Usage

```
state = lan.config.dns.dynamic
lan.config.dns.dynamic = state
```

state

The dynamic DNS registration state. It may be one of the following values:
1 or lan.ENABLE: Enabled
0 or lan.DISABLE: Disabled

Details

Dynamic DNS registration works with DHCP to register the host name with the DNS server. The host name is specified in the `lan.config.dns.hostname` attribute.

Example

```
print(lan.config.dns.dynamic)
```

Outputs the dynamic registration state.

If dynamic DNS registration is enabled, the response is:
1.00000e+00

Also see

[lan.config.dns.hostname](#) (on page 8-272)

[lan.restoredefaults\(\)](#) (on page 8-276)

lan.config.dns.hostname

This attribute defines the dynamic DNS host name.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	LAN restore defaults	Nonvolatile memory	Instrument-specific (see Details)

Usage

```
hostName = lan.config.dns.hostname
lan.config.dns.hostname = hostName
```

hostName

The host name to use for dynamic DNS registration; the host name must:

- be a string of 255 characters or less
- start with a letter
- end with a letter or digit
- contain only letters, digits, and hyphens

Details

This attribute holds the host name to request during dynamic DNS registration. Dynamic DNS registration works with DHCP to register the host name specified in this attribute with the DNS server.

The format for *hostName* is "K-<model number>-<serial number>", where <model number> and <serial number> are replaced with the actual model number and serial number of the instrument (for example, "K-3706A-1234567"). Note that hyphens separate the characters of *hostName*.

The length of the fully qualified host name (combined length of the domain and host name with separator characters) must be less than or equal to 255 characters. Although up to 255 characters can be entered here, care must be taken to be sure the combined length is also no more than 255 characters.

Example

```
print(lan.config.dns.hostname)
```

Outputs the present dynamic DNS host name.

Also see

[lan.config.dns.dynamic](#) (on page 8-271)

[lan.restoredefaults\(\)](#) (on page 8-276)

lan.config.dns.verify

This attribute defines the DNS host name verification state.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	LAN restore defaults	Nonvolatile memory	lan.ENABLE

Usage

```
state = lan.config.dns.verify
lan.config.dns.verify = state
```

state

DNS hostname verification state:

- 1 or lan.ENABLE: DNS host name verification enabled
- 0 or lan.DISABLE: DNS host name verification disabled

Details

When this is enabled, the instrument performs DNS lookups to verify that the DNS host name matches the value specified by `lan.config.dns.hostname`.

Example

```
print(lan.config.dns.verify)
```

Outputs the present DNS host name verification state.

If it is enabled, the output is:

```
1.00000e+00
```

Also see

[lan.config.dns.hostname](#) (on page 8-272)

[lan.restoredefaults\(\)](#) (on page 8-276)

lan.config.gateway

This attribute contains the LAN default gateway address.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	LAN restore defaults	Nonvolatile memory	"0.0.0.0"

Usage

```
gatewayAddress = lan.config.gateway
lan.config.gateway = gatewayAddress
```

<i>gatewayAddress</i>	LAN default gateway address; must be a string specifying the default gateway's IP address in dotted decimal notation
-----------------------	--

Details

This attribute specifies the default gateway IP address to use when manual or DLLA configuration methods are used to configure the LAN. If DHCP is enabled, this setting is ignored.

This attribute does not indicate the actual setting currently in effect. Use the `lan.status.gateway` attribute to determine the current operating state of the LAN.

The IP address must be formatted in four groups of numbers each separated by a decimal.

Example

```
print(lan.config.gateway)
```

Outputs the default gateway address. For example, you might see the output:

```
10.60.8.1
```

Also see

[lan.status.gateway](#) (on page 8-279)

[lan.restoredefaults\(\)](#) (on page 8-276)

lan.config.ipaddress

This attribute specifies the LAN IP address.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	LAN restore defaults	Nonvolatile memory	"192.168.0.2"

Usage

```
ipAddress = lan.config.ipaddress
lan.config.ipaddress = ipAddress
```

<i>ipAddress</i>	LAN IP address; must be a string specifying the IP address in dotted decimal notation
------------------	---

Details

This attribute specifies the LAN IP address to use when the LAN is configured using the manual configuration method. This setting is ignored when DLLA or DHCP is used.

This attribute does not indicate the actual setting currently in effect. Use the `lan.status.ipaddress` attribute to determine the current operating state of the LAN.

Example

```
ipaddress = lan.config.ipaddress
```

Retrieves the presently set LAN IP address.

Also see

[lan.restoredefaults\(\)](#) (on page 8-276)

[lan.status.ipaddress](#) (on page 8-279)

lan.config.method

This attribute contains the LAN settings configuration method.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	LAN restore defaults	Nonvolatile memory	lan.AUTO

Usage

```
method = lan.config.method
lan.config.method = method
```

<i>method</i>	The method for configuring LAN settings; it can be one of the following values: 0 or <code>lan.AUTO</code> : Selects automatic sequencing of configuration methods 1 or <code>lan.MANUAL</code> : Use only manually specified configuration settings
---------------	--

Details

This attribute controls how the LAN IP address, subnet mask, default gateway address, and DNS server addresses are determined.

When `method` is `lan.AUTO`, the instrument first attempts to configure the LAN settings using dynamic host configuration protocol (DHCP). If DHCP fails, it tries dynamic link local addressing (DLLA). If DLLA fails, it uses the manually specified settings.

When `method` is `lan.MANUAL`, only the manually specified settings are used. Neither DHCP nor DLLA are attempted.

Example

```
print(lan.config.method)
```

Outputs the current method.

For example:
1.00000e+00

Also see

[lan.restoredefaults\(\)](#) (on page 8-276)

lan.config.subnetmask

This attribute contains the LAN subnet mask.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	LAN restore defaults	Nonvolatile memory	"255.255.255.0"

Usage

```
mask = lan.config.subnetmask
lan.config.subnetmask = mask
```

<i>mask</i>	LAN subnet mask value string that specifies the subnet mask in dotted decimal notation
-------------	--

Details

This attribute specifies the LAN subnet mask to use when the manual configuration method is used to configure the LAN. This setting is ignored when DLLA or DHCP is used.

This attribute does not indicate the actual setting currently in effect. Use the `lan.status.subnetmask` attribute to determine the current operating state of the LAN.

Example

```
print(lan.config.subnetmask)
```

Outputs the LAN subnet mask, such as:
255.255.255.0

Also see

[lan.restoredefaults\(\)](#) (on page 8-276)
[lan.status.subnetmask](#) (on page 8-283)

lan.lxidomain

This attribute contains the LXI domain.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	LAN restore defaults	Nonvolatile memory	0

Usage

```
domain = lan.lxidomain
lan.lxidomain = domain
```

<i>domain</i>	The LXI domain number (0 to 255)
---------------	----------------------------------

Details

This attribute sets the LXI domain number.

All outgoing LXI packets will be generated with this domain number. All inbound LXI packets will be ignored unless they have this domain number.

Example

```
print(lan.lxidomain)
```

Displays the LXI domain.

Also see

[lan.restoredefaults\(\)](#) (on page 8-276)

lan.nagle

This attribute controls the state of the LAN Nagle algorithm.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Power cycle	Not saved	lan.ENABLE

Usage

```
state = lan.nagle
lan.nagle = state
```

<code>state</code>	1 or <code>lan.ENABLE</code> : Enable the LAN Nagle algorithm for TCP connections 0 or <code>lan.DISABLE</code> : Disable the Nagle algorithm for TCP connections
--------------------	--

Details

This attribute enables or disables the use of the LAN Nagle algorithm on transmission control protocol (TCP) connections.

Also see

[lan.restoredefaults\(\)](#) (on page 8-276)

lan.reset()

This function resets the LAN interface.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
lan.reset()
```

Details

This function resets the LAN interface. It performs the commands `lan.restoredefaults()` and `lan.applysettings()`.

Also see

[lan.applysettings\(\)](#) (on page 8-269)
[lan.restoredefaults\(\)](#) (on page 8-276)

lan.restoredefaults()

This function resets LAN settings to default values.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
lan.restoredefaults()
```

Details

The settings that are restored are shown in the following table.

Settings that are restored to default	
Attribute	Default setting
lan.config.dns.address[N]	"0.0.0.0"
lan.config.dns.domain	""
lan.config.dns.dynamic	lan.ENABLE
lan.config.dns.hostname	"K-<model number>-<serial number>"
lan.config.dns.verify	lan.ENABLE
lan.config.gateway	"0.0.0.0"
lan.config.ipaddress	"0.0.0.0"
lan.config.method	lan.AUTO
lan.config.subnetmask	"255.255.255.0"
lan.lxidomain	0
localnode.password	"admin"

The `lan.restoredefaults()` function does not reset the LAN password. The `localnode.password` attribute controls the web password, which can be reset separately.

This command is run when `lan.reset()` is sent.

Example

```
lan.restoredefaults() Restores the LAN defaults.
```

Also see

[lan.reset\(\)](#) (on page 8-276)
[localnode.password](#) (on page 8-296)

lan.status.dns.address[N]

This attribute contains the DNS server IP addresses.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
dnsAddress = lan.status.dns.address[N]
```

<i>dnsAddress</i>	DNS server IP address
<i>N</i>	Entry index (1, 2, or 3)

Details

This attribute is an array of DNS server addresses. The system can use up to three addresses.

Unused or disabled entries are returned as "0.0.0.0" when read. The *dnsAddress* returned is a string specifying the IP address of the DNS server in dotted decimal notation.

You can only specify two addresses manually. However, the instrument uses up to three DNS server addresses. If two are specified, only the one given by a DHCP server is used. If no entries are specified here, up to three address given by a DHCP server are used.

The value of `lan.status.dns.address[1]` is referenced first for all DNS lookups. The values of `lan.status.dns.address[2]` and `lan.status.dns.address[3]` are referenced second and third, respectively.

Example

```
print(lan.status.dns.address[1])
```

Outputs DNS server address 1, for example:
164.109.48.173

Also see

[lan.status.dns.name](#) (on page 8-278)

lan.status.dns.name

This attribute contains the present DNS fully qualified host name.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
hostName = lan.status.dns.name
```

```
hostName
```

Fully qualified DNS host name that can be used to connect to the instrument

Details

A fully qualified domain name (FQDN), sometimes referred to as an absolute domain name, is a domain name that specifies its exact location in the tree hierarchy of the Domain Name System (DNS).

A FQDN is the complete domain name for a specific computer or host on the LAN. The FQDN consists of two parts: the host name and the domain name.

If the DNS host name for an instrument is not found, this attribute stores the IP address in dotted decimal notation.

Example

```
print(lan.status.dns.name)
```

Outputs the dynamic DNS host name.

Also see

[lan.config.dns.address\[N\]](#) (on page 8-270)

[lan.config.dns.hostname](#) (on page 8-272)

lan.status.duplex

This attribute contains the duplex mode presently in use by the LAN interface.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
duplex = lan.status.duplex
```

```
duplex
```

LAN duplex setting can be one of the following values:
0 or `lan.HALF`: half-duplex operation
1 or `lan.FULL`: full-duplex operation

Example

```
print(lan.status.duplex)
```

Outputs the present LAN duplex mode, such as:
1.00000e+00

Also see

None

lan.status.gateway

This attribute contains the gateway address presently in use by the LAN interface.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
gatewayAddress = lan.status.gateway
```

<code>gatewayAddress</code>	LAN gateway address presently being used
-----------------------------	--

Details

The value of `gatewayAddress` is a string that indicates the IP address of the gateway in dotted decimal notation.

Example

<pre>print(lan.status.gateway)</pre>	Outputs the gateway address, such as: 10.60.8.1
--------------------------------------	--

Also see

[lan.config.gateway](#) (on page 8-273)

lan.status.ipaddress

This attribute contains the LAN IP address presently in use by the LAN interface.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
ipAddress = lan.status.ipaddress
```

<code>ipAddress</code>	LAN IP address specified in dotted decimal notation
------------------------	---

Details

The IP address is a character string that represents the IP address assigned to the instrument.

Example

<pre>print(lan.status.ipaddress)</pre>	Outputs the LAN IP address currently in use, such as: 10.60.8.83
--	---

Also see

[lan.config.ipaddress](#) (on page 8-273)

lan.status.macaddress

This attribute contains the LAN MAC address.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
macAddress = lan.status.macaddress
```

<code>macAddress</code>	The instrument MAC address
-------------------------	----------------------------

Details

The MAC address is a character string representing the instrument's MAC address in hexadecimal notation. The string includes colons that separate the address octets (see Example).

Example

<pre>print(lan.status.macaddress)</pre>	Outputs the MAC address of the instrument, for example: 00:60:1A:00:00:57
---	--

Also see

None

lan.status.port.dst

This attribute contains the LAN dead socket termination port number.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
port = lan.status.port.dst
```

<code>port</code>	Dead socket termination socket port number
-------------------	--

Details

This attribute holds the TCP port number used to reset all other LAN socket connections. To reset all LAN connections, open a connection to the DST port number.

Example

<pre>print(lan.status.port.dst)</pre>	Outputs the LAN dead socket termination port number, such as: 5.03000e+03
---------------------------------------	--

Also see

None

lan.status.port.rawsocket

This attribute contains the LAN raw socket connection port number.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
port = lan.status.port.rawsocket
```

<code>port</code>	Raw socket port number
-------------------	------------------------

Details

Stores the TCP port number used to connect the instrument and to control the instrument over a raw socket communication interface.

Example

```
print(lan.status.port.rawsocket)
```

Outputs the LAN raw socket port number, such as:
5.02500e+03

Also see

None

lan.status.port.telnet

This attribute contains the LAN Telnet connection port number.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
port = lan.status.port.telnet
```

<code>port</code>	Telnet port number
-------------------	--------------------

Details

This attribute holds the TCP port number used to connect to the instrument to control it over a Telnet interface.

Example

```
print(lan.status.port.telnet)
```

Get the LAN Telnet connection port number.
Output:
2.30000e+01

Also see

None

lan.status.port.vxi11

This attribute contains the LAN VXI-11 connection port number.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
port = lan.status.port.vxi11
```

<code>port</code>	LAN VXI-11 port number
-------------------	------------------------

Details

This attribute stores the TCP port number used to connect to the instrument over a VXI-11 interface.

Example

```
print(lan.status.port.vxi11)
```

Outputs the VXI-11 number, such as:
1.02400e+03

Also see

None

lan.status.speed

This attribute contains the LAN speed.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
speed = lan.status.speed
```

<code>speed</code>	LAN speed in Mbps, either 10 or 100
--------------------	-------------------------------------

Details

This attribute indicates the transmission speed currently in use by the LAN interface.

Example

```
print(lan.status.speed)
```

Outputs the instrument's transmission speed presently in use, such as:
1.00000e+02

Also see

None

lan.status.subnetmask

This attribute contains the LAN subnet mask that is presently in use by the LAN interface.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
mask = lan.status.subnetmask
```

<code>mask</code>	A string specifying the subnet mask in dotted decimal notation
-------------------	--

Details

Use this attribute to determine the present operating state of the LAN. This attribute will return the present LAN subnet mask value if the LAN is manually configured, or when DLLA or DHCP is used.

Example

<pre>print(lan.status.subnetmask)</pre>	Outputs the subnet mask of the instrument that is presently in use, such as: 255.255.255.0
---	---

Also see

[lan.config.subnetmask](#) (on page 8-275)

lan.trigger[N].assert()

This function simulates the occurrence of the trigger and generates the corresponding event ID.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
lan.trigger[N].assert()
```

<code>N</code>	The LAN event number (1 to 8)
----------------	-------------------------------

Details

Generates and sends a LAN trigger packet for the LAN event number specified.

Sets the pseudostate to the appropriate state.

The following indexes provide the listed events:

- 1:LAN0
- 2:LAN1
- 3:LAN2
- ...
- 8:LAN7

Example

<pre>lan.trigger[5].assert()</pre>	Creates a trigger with LAN packet 5.
------------------------------------	--------------------------------------

Also see

[lan.trigger\[N\].clear\(\)](#) (on page 8-284)
[lan.trigger\[N\].mode](#) (on page 8-287)
[lan.trigger\[N\].overrun](#) (on page 8-288)
[lan.trigger\[N\].stimulus](#) (on page 8-290)
[lan.trigger\[N\].wait\(\)](#) (on page 8-292)

lan.trigger[N].clear()

This function clears the event detector for a trigger.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
lan.trigger[N].clear()
```

<i>N</i>	The LAN event number to clear (1 to 8)
----------	--

Details

A trigger's event detector remembers if an event has been detected since the last call. This function clears a trigger's event detector and discards the previous history of the trigger packet.

This function clears all overruns associated with this LAN trigger.

Example

<code>lan.trigger[5].clear()</code>	Clears the event detector with LAN packet 5.
-------------------------------------	--

Also see

[lan.trigger\[N\].assert\(\)](#) (on page 8-283)
[lan.trigger\[N\].overrun](#) (on page 8-288)
[lan.trigger\[N\].stimulus](#) (on page 8-290)
[lan.trigger\[N\].wait\(\)](#) (on page 8-292)

lan.trigger[N].connect()

This function prepares the event generator for outgoing trigger events.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
lan.trigger[N].connect()
```

<i>N</i>	The LAN event number (1 to 8)
----------	-------------------------------

Details

Prepares the event generator to send event messages. For TCP connections, this opens the TCP connection. The event generator automatically disconnects when either the `lan.trigger[N].protocol` or `lan.trigger[N].ipaddress` attributes for this event are changed.

Example

```
lan.trigger[1].protocol = lan.MULTICAST
lan.trigger[1].connect()
lan.trigger[1].assert()
```

Set the protocol for LAN trigger 1 to be multicast when sending LAN triggers. Then, after connecting the LAN trigger, send a message on LAN trigger 1 by asserting it.

Also see

[lan.trigger\[N\].assert\(\)](#) (on page 8-283)
[lan.trigger\[N\].ipaddress](#) (on page 8-287)
[lan.trigger\[N\].overrun](#) (on page 8-288)
[lan.trigger\[N\].protocol](#) (on page 8-289)
[lan.trigger\[N\].stimulus](#) (on page 8-290)
[lan.trigger\[N\].wait\(\)](#) (on page 8-292)

lan.trigger[N].connected

This attribute stores the LAN event connection state.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
connected = lan.trigger[N].connected
```

<i>connected</i>	The LAN event connection state: <ul style="list-style-type: none"> • <code>true</code>: Connected • <code>false</code>: Not connected
<i>N</i>	The LAN event number (1 to 8)

Details

This read-only attribute is set to `true` when the LAN trigger is connected and ready to send trigger events following a successful `lan.trigger[N].connect()` command; if the LAN trigger is not ready to send trigger events, this value is `false`.

This attribute is also `false` when either `lan.trigger[N].protocol` or `lan.trigger[N].ipaddress` attributes are changed or the remote connection closes the connection.

Example

```
lan.trigger[1].protocol = lan.MULTICAST
print(lan.trigger[1].connected)
```

Outputs `true` if connected, or `false` if not connected.
Example output:
`false`

Also see

[lan.trigger\[N\].connect\(\)](#) (on page 8-285)

[lan.trigger\[N\].ipaddress](#) (on page 8-287)

[lan.trigger\[N\].protocol](#) (on page 8-289)

lan.trigger[N].disconnect()

This function disconnects the LAN trigger.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
lan.trigger[N].disconnect()
```

`N` The LAN event number (1 to 8)

Details

For TCP connections, this closes the TCP connection.

The LAN trigger automatically disconnects when either the `lan.trigger[N].protocol` or `lan.trigger[N].ipaddress` attributes for this event are changed.

Also see

[lan.trigger\[N\].ipaddress](#) (on page 8-287)

[lan.trigger\[N\].protocol](#) (on page 8-289)

lan.trigger[N].EVENT_ID

This constant is the event identifier used to route the LAN trigger to other subsystems (using stimulus properties).

Type	TSP-Link accessible	Affected by	Where saved	Default value
Constant	Yes			

Usage

```
lan.trigger[N].EVENT_ID
```

`N` The LAN event number (1 to 8)

Details

Set the stimulus of any trigger event detector to the value of this constant to have it respond to incoming LAN trigger packets.

Example

```
digio.trigger[14].stimulus =
lan.trigger[1].EVENT_ID
```

Route occurrences of triggers on LAN trigger 1 to digital I/O trigger 14.

Also see

None

lan.trigger[N].ipaddress

This attribute specifies the address (in dotted-decimal format) of UDP or TCP listeners.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Instrument reset LAN trigger N reset Recall setup	Create configuration script Save setup	"0.0.0.0"

Usage

```
ipAddress = lan.trigger[N].ipaddress
lan.trigger[N].ipaddress = ipAddress
```

<i>ipAddress</i>	The LAN address for this attribute as a string in dotted decimal notation
<i>N</i>	A number specifying the LAN event number (1 to 8)

Details

Sets the IP address for outgoing trigger events.

Set to "0.0.0.0" for multicast.

After changing this setting, the `lan.trigger[N].connect()` command must be called before outgoing messages can be sent.

Example

```
lan.trigger[3].protocol = lan.TCP
lan.trigger[3].ipaddress = "192.168.1.100"
lan.trigger[3].connect()
```

Set the protocol for LAN trigger 3 to be `lan.TCP` when sending LAN triggers. Use IP address "192.168.1.100" to connect the LAN trigger.

Also see

[lan.trigger\[N\].connect\(\)](#) (on page 8-285)

lan.trigger[N].mode

This attribute sets the trigger operation and detection mode.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Instrument reset LAN trigger N reset Recall setup	Create configuration script Save setup	0 (lan.TRIG_EITHER)

Usage

```
mode = lan.trigger[N].mode
lan.trigger[N].mode = mode
```

<i>mode</i>	A number representing the trigger mode (0 to 7); see the Details section for more information
<i>N</i>	A number representing the LAN event number (1 to 8)

Details

This attribute controls the mode in which the trigger event detector and the output trigger generator operate on the given trigger. These settings are intended to provide behavior similar to the digital I/O triggers.

Lan trigger mode values			
mode	Number	Trigger packets detected as input	LAN trigger packet generated for output with a...
lan.TRIG_EITHER	0	Rising or falling edge (positive or negative state)	negative state
lan.TRIG_FALLING	1	Falling edge (negative state)	negative state
lan.TRIG_RISING	2	Rising edge (positive state)	positive state
lan.TRIG_RISINGA	3	Rising edge (positive state)	positive state
lan.TRIG_RISINGM	4	Rising edge (positive state)	positive state
lan.TRIG_SYNCHRONOUS	5	Falling edge (negative state)	positive state
lan.TRIG_SYNCHRONOUSA	6	Falling edge (negative state)	positive state
lan.TRIG_SYNCHRONOUSM	7	Rising edge (positive state)	negative state

lan.TRIG_RISING and lan.TRIG_RISINGA are the same.

lan.TRIG_RISING and lan.TRIG_RISINGM are the same.

Use of either lan.TRIG_SYNCHRONOUSA or lan.TRIG_SYNCHRONOUSM over lan.TRIG_SYNCHRONOUS is preferred, as lan.TRIG_SYNCHRONOUS is provided for compatibility with other Keithley Instruments products.

Example

```
print(lan.trigger[1].mode)
```

Outputs the present LAN trigger mode of LAN event 1.

Also see

[Digital I/O](#) (on page 6-7)

[TSP-Link](#) (on page 6-21)

lan.trigger[N].overrun

This attribute contains the event detector's overrun status.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	LAN trigger N clear LAN trigger N reset	Not applicable	Not applicable

Usage

```
overrun = lan.trigger[N].overrun
```

<i>overrun</i>	The trigger overrun state for the specified LAN packet (<i>true</i> or <i>false</i>)
<i>N</i>	A number representing the LAN event number (1 to 8)

Details

This attribute indicates whether an event has been ignored because the event detector was already in the detected state when the event occurred.

This is an indication of the state of the event detector built into the synchronization line itself. It does not indicate if an overrun occurred in any other part of the trigger model, or in any other construct that is monitoring the event. It also is not an indication of an output trigger overrun.

Example

```
overrun = lan.trigger[5].overrun
print(overrun)
```

Checks the overrun status of a trigger on LAN5 and outputs the value, such as:
false

Also see

[lan.trigger\[N\].assert\(\)](#) (on page 8-283)

[lan.trigger\[N\].clear\(\)](#) (on page 8-284)

[lan.trigger\[N\].stimulus](#) (on page 8-290)

[lan.trigger\[N\].wait\(\)](#) (on page 8-292)

lan.trigger[N].protocol

This attribute sets the LAN protocol to use for sending trigger messages.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Instrument reset LAN trigger N reset Recall setup	Create configuration script Save setup	lan.TCP

Usage

```
protocol = lan.trigger[N].protocol
lan.trigger[N].protocol = protocol
```

<i>protocol</i>	The protocol to use for the trigger's messages: <ul style="list-style-type: none"> 0 or lan.TCP 1 or lan.UDP 2 or lan.MULTICAST
<i>N</i>	A number representing the LAN event number (1 to 8)

Details

The LAN trigger listens for trigger messages from all supported protocols, protocol but uses the designated protocol for sending outgoing messages. After changing this setting, `lan.trigger[N].connect()` must be called before outgoing event messages can be sent.

When the `lan.MULTICAST` protocol is selected, the `lan.trigger[N].ipaddress` attribute is ignored and event messages are sent to the multicast address 224.0.23.159.

Example

```
print(lan.trigger[1].protocol)
```

Get LAN protocol to use for sending trigger messages for LAN event 1.

Also see

[lan.trigger\[N\].ipaddress](#) (on page 8-287)

[lan.trigger\[N\].connect\(\)](#) (on page 8-285)

lan.trigger[N].pseudostate

This attribute sets the simulated line state for the LAN trigger.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Instrument reset LAN trigger N reset Recall setup	Create configuration script Save setup	1

Usage

```
pseudostate = lan.trigger[N].pseudostate
lan.trigger[N].pseudostate = pseudostate
```

<i>pseudostate</i>	The simulated line state (0 or 1)
<i>N</i>	A number representing the LAN event number (1 to 8)

Details

This attribute can be set to initialize the pseudo state to a known value. Setting this attribute will not cause the LAN trigger to generate any events or output packets.

Example

```
print(lan.trigger[1].pseudostate)
```

Get the present simulated line state for the LAN event 1.

Also see

None

lan.trigger[N].stimulus

This attribute specifies events that cause this trigger to assert.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Instrument reset LAN trigger N reset Recall setup	Create configuration script Recall setup	0

Usage

```
triggerStimulus = lan.trigger[N].stimulus
lan.trigger[N].stimulus = triggerStimulus
```

<i>triggerStimulus</i>	The LAN event identifier used to trigger the event
<i>N</i>	A number specifying the trigger packet over the LAN for which to set or query the trigger source (1 to 8)

Details

This attribute specifies which event causes a LAN trigger packet to be sent for this trigger. Set *triggerStimulus* to one of the existing trigger event IDs shown in the following table.

Trigger event IDs	
Trigger event ID	Description
<code>channel.trigger[N].EVENT_ID</code> or 41 to 48	The trigger event generated by the channel trigger <i>N</i> .
<code>digio.trigger[N].EVENT_ID</code> or 1 to 14	An edge (either rising, falling, or either based on the configuration of the line) on the digital input line.
<code>display.trigger.EVENT_ID</code> or 39	The trigger key (TRIG) on the front panel is pressed.
<code>dmm.trigger.EVENT_LIMIT1_HIGH</code> or 53	A DMM trigger event that indicates a measurement has exceed the high limit value on limit 1.
<code>dmm.trigger.EVENT_LIMIT1_LOW</code> or 52	A DMM trigger event that indicates a measurement has exceed the low limit value on limit 1.
<code>dmm.trigger.EVENT_LIMIT2_HIGH</code> or 55	A DMM trigger event that indicates a measurement has exceed the high limit value on limit 2.
<code>dmm.trigger.EVENT_LIMIT2_LOW</code> or 54	A DMM trigger event that indicates a measurement has exceed the low limit value on limit 2.
<code>trigger.EVENT_ID</code> or 40	A *trg message on the active command interface. If GPIB is the active command interface, a GET message also generates this event.
<code>trigger.blender[N].EVENT_ID</code> or 58 to 59	A combination of events has occurred.
<code>trigger.timer[N].EVENT_ID</code> or 20 to 23	A delay expired.
<code>tsplink.trigger[N].EVENT_ID</code> or 17 to 19	An edge (either rising, falling, or either based on the configuration of the line) on the TSP-Link trigger line.
<code>lan.trigger[N].EVENT_ID</code> or 29 to 36	A LAN trigger event has occurred.
<code>scan.trigger.EVENT_SCAN_READY</code> or 24	Scan ready event.
<code>scan.trigger.EVENT_SCAN_START</code> or 25	Scan start event.
<code>scan.trigger.EVENT_CHANNEL_READY</code> or 28	Channel ready event.
<code>scan.trigger.EVENT_MEASURE_COMP</code> or 56	Measure complete event.
<code>scan.trigger.EVENT_SEQUENCE_COMP</code> or 50	Sequence complete event.
<code>scan.trigger.EVENT_SCAN_COMP</code> or 26	Scan complete event.
<code>scan.trigger.EVENT_IDLE</code> or 27	Idle event.
<code>schedule.alarm[N].EVENT_ID</code> or 37 to 38	Trigger event generated by the alarm <i>N</i> .

NOTE

Use one of the text trigger event IDs (for example, `digio.trigger[N].EVENT_ID`) to set the stimulus value rather than the numeric value. Doing this will make the code compatible for future upgrades.

Setting this attribute to zero disables automatic trigger generation.

If any events are detected prior to calling `lan.trigger[N].connect()`, the event is ignored and the action overrun is set.

Example

```
lan.trigger[5].stimulus = trigger.timer[1].EVENT_ID
```

Use timer 1 trigger event as the source for LAN packet 5 trigger stimulus.

Also see

[lan.trigger\[N\].assert\(\)](#) (on page 8-283)
[lan.trigger\[N\].clear\(\)](#) (on page 8-284)
[lan.trigger\[N\].connect\(\)](#) (on page 8-285)
[lan.trigger\[N\].overrun](#) (on page 8-288)
[lan.trigger\[N\].wait\(\)](#) (on page 8-292)

lan.trigger[N].wait()

This function waits for an input trigger.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
triggered = lan.trigger[N].wait(timeout)
```

<i>triggered</i>	Trigger detection indication
<i>N</i>	The trigger packet over LAN to wait for (1 to 8)
<i>timeout</i>	Maximum amount of time in seconds to wait for the trigger event

Details

If one or more trigger events have been detected since the last time `lan.trigger[N].wait()` or `lan.trigger[N].clear()` was called, this function returns immediately.

After waiting for a LAN trigger event with this function, the event detector is automatically reset and rearmed regardless of the number of events detected.

Example

```
triggered = lan.trigger[5].wait(3)
```

Wait for a trigger with LAN packet 5 with a timeout of 3 seconds.

Also see

[lan.trigger\[N\].assert\(\)](#) (on page 8-283)
[lan.trigger\[N\].clear\(\)](#) (on page 8-284)
[lan.trigger\[N\].overrun](#) (on page 8-288)
[lan.trigger\[N\].stimulus](#) (on page 8-290)

localnode.define.*

These constants indicate the number of available features (of each feature type) for each local node instrument.

Type	TSP-Link accessible	Affected by	Where saved	Default value
CONSTANT (R)	--			
.MAX_TIMERS	Yes			
.MAX_DIO_LINES	Yes			
.MAX_TSPLINK_TRIGS	Yes			
.MAX_BLENDERS	Yes			
.MAX_BLENDER_INPUTS	Yes			
.MAX_LAN_TRIGS	Yes			

Usage

```

maxNumber = localnode.define.MAX_TIMERS
maxNumber = localnode.define.MAX_DIO_LINES
maxNumber = localnode.define.MAX_TSPLINK_TRIGS
maxNumber = localnode.define.MAX_BLENDERS
maxNumber = localnode.define.MAX_BLENDER_INPUTS
maxNumber = localnode.define.MAX_LAN_TRIGS
maxNumber = localnode.define.MAX_CHANNEL_TRIGS

```

<i>maxNumber</i>	A variable assigned the value of the constant.; the constant equals the local node instrument's maximum number available for the specified feature
------------------	--

Details

These read-only constants indicate the following types of features: timers, digital input/output lines, triggers, and blenders. They provide the number of features available (which is the maximum) for the specified local node feature.

When using this command from a remote node, `localnode` should be replaced with the node reference, for example `node[5].define.MAX_TIMERS`.

Example 1

```
maxNumber = localnode.define.MAX_TIMERS
```

Reads the maximum number of timers that are available for the presently active instrument.
--

Also see

None

localnode.description

This attribute stores a user-defined description of the instrument.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Not applicable	Nonvolatile memory	Instrument specific (see Details)

Usage

```
localnode.description = description
description = localnode.description
```

<i>description</i>	User-defined description of the instrument
--------------------	--

Details

This attribute stores a string that contains a description of the instrument. This value appears on instrument's LXI home page.

This attribute's default value contains *Keithley ModelNumber #SSSSSSSS*, where: *ModelNumber* is the instrument's model number, and *#SSSSSSSS* is the instrument's eight-digit serial number. You can change it to a value that makes sense for your system.

When using this command from a remote node, *localnode* should be replaced with the node reference, for example *node[5].description*.

Example

<pre>description = "System in Lab 05" localnode.description = description</pre>	<p>Set <i>description</i> equal to "System in Lab 05". Set the LXI home page of this instrument to display "System in Lab 05".</p>
---	--

Also see

[Using the web interface](#) (on page 2-36)

localnode.emulation

This attribute sets the instrument to report the model number as 3706 instead of 3706A.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	No	Not applicable	Nonvolatile memory	localnode.OFF

Usage

```
value = localnode.emulation
localnode.emulation = value
```

<i>value</i>	0 or <i>localnode.OFF</i> : No emulation (model number is reported as 3706A) 1 or <i>localnode.EMULATION_3706</i> : Reports the model number as 3706
--------------	---

Details

This command needs to be set if you replace a Model 3706 with a Model 3706A in a system where computer drivers may be querying the model. This can occur if you replace a Model 3706 with a Model 3706A in an existing system, or if you duplicate a system but use a Model 3706A instead of a Model 3706.

When this command is set to *localnode.EMULATION_3706*, the model number is reported as a 3706 when you send a request with a command such as *localnode.model* or **idn?*. This allows drivers that query the model number to continue to operate normally.

NOTE

All other Model 3706A behavior is the same. Emulation mode does not affect the changes to the IEEE-1588 features or the response times that occurred with the update from the Model 3706 to the Model 3706A.

This setting is preserved through a power cycle and instrument reset.

Example

```
localnode.emulation = localnode.EMULATION_3706
```

Sets the Model 3706A for Model 3706 emulation.

Also see

[localnode.model](#) (on page 8-296)

localnode.linefreq

This attribute contains the line frequency setting used for NPLC calculations.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	60

Usage

```
frequency = localnode.linefreq
```

<i>frequency</i>	An integer representing the instrument's detected line frequency
------------------	--

Details

When using this command from a remote node, `localnode` should be replaced with the node reference, for example `node[5].linefreq`.

Example

```
frequency = localnode.linefreq
```

Reads line frequency setting.

Also see

None

localnode.model

This attribute stores the model number.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
model = localnode.model
```

<code>model</code>	The model number of the instrument
--------------------	------------------------------------

Details

When using this command from a remote node, `localnode` should be replaced with the node reference, for example `node[5].model`.

Example

<code>print(localnode.model)</code>	Outputs the model number.
-------------------------------------	---------------------------

Also see

[localnode.description](#) (on page 8-293)

[localnode.revision](#) (on page 8-300)

[localnode.serialno](#) (on page 8-300)

localnode.password

This attribute stores the remote access password.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (W)	Yes	LAN reset	Nonvolatile memory	"admin"

Usage

```
localnode.password = password
```

<code>password</code>	String containing the remote interface password
-----------------------	---

Details

This write-only attribute stores the password that is set for any remote interface. When password usage is enabled (`localnode.passwordmode`), you must supply this password to change the configuration or to control an instrument from a web page or other remote command interface.

The instrument continues to use the old password for all interactions until the command to change it executes. When changing the password, give the instrument time to execute the command before attempting to use the new password.

You can retrieve the password from the front panel through **MENU > LAN > STATUS > PASSWORD**.

The password can be reset by resetting the LAN from the front panel or by using the `lan.reset()` command.

When using this command from a remote node, `localnode` should be replaced with the node reference, for example `node[5].password`.

Example

```
localnode.password = "N3wpa55w0rd"
```

Changes the remote interface password to N3wpa55w0rd.

Also see

[lan.reset\(\)](#) (on page 8-276)
[localnode.passwordmode](#) (on page 8-297)

localnode.passwordmode

This attribute stores the remote access password enable mode.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Not applicable	Nonvolatile memory	1 (localnode.PASSWORD_WEB)

Usage

```
mode = localnode.passwordmode
localnode.passwordmode = mode
```

<i>mode</i>	The remote password enable mode.
-------------	----------------------------------

Details

This attribute controls if and where remote access passwords are required. Set this attribute to one of the values below to enable password checking:

`localnode.PASSWORD_NONE` or 0: Disable passwords everywhere

`localnode.PASSWORD_WEB` or 1: Use passwords on the web interface only

`localnode.PASSWORD_LAN` or 2: Use passwords on the web interface and all LAN interfaces

`localnode.PASSWORD_ALL` or 3: Use passwords on the web interface and all remote command interfaces

When using this command from a remote node, `localnode` should be replaced with the node reference, for example `node[5].passwordmode`.

Example

```
mode = localnode.PASSWORD_WEB
localnode.passwordmode = mode
```

Sets value of `mode` to `PASSWORD_WEB`.
Allows use of passwords on the web interface only.

Also see

[localnode.password](#) (on page 8-296)

localnode.prompts

This attribute sets and reads the local node prompting state (enabled or disabled).

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Power cycle	Not saved	0 (disabled)

Usage

```
prompting = localnode.prompts
localnode.prompts = prompting
```

<i>prompting</i>	Prompting state (0 to disable or 1 to enable)
------------------	---

Details

The command messages do not generate prompts. The instrument generates prompts in response to command messages.

When the prompting mode is enabled (set to 1), the instrument generates prompts in response to command messages. There are three prompts that might be generated:

- **TSP>** is the standard prompt. This prompt indicates that everything is normal and the command is done processing.
- **TSP?** is issued if there are entries in the error queue when the prompt is issued. Like the TSP> prompt, it indicates the command is done processing. It does not mean the previous command generated an error, only that there are still errors in the queue when the command was done processing.
- **>>>>** is the continuation prompt. This prompt is used when downloading scripts. When downloading scripts, many command messages must be sent as a group. The continuation prompt indicates that the instrument is expecting more messages as part of the current command.

When using this command from a remote node, `localnode` should be replaced with the node reference, for example, `node[5].prompts`.

NOTE

Do not disable prompting when using Test Script Builder. Test Script Builder requires prompts and sets the prompting mode behind the scenes. If you disable prompting, using Test Script Builder causes the instrument to stop responding because it is waiting for the prompt that lets it know that the command is done executing.

Example

```
localnode.prompts = 1
```

Enable prompting.

Also see

[localnode.showerrors](#) (on page 8-301)

[localnode.prompts4882](#) (on page 8-298)

localnode.prompts4882

This attribute enables and disables the generation of prompts for IEEE Std 488.2 common commands.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Power cycle	Not saved	1 (enabled)

Usage

```
prompting = localnode.prompts4882
localnode.prompts4882 = prompting
```

```
prompting | IEEE Std 488.2 prompting mode
```

Details

When set to 1, the IEEE Std 488.2 common commands generate prompts if prompting is enabled with the `localnode.prompts` attribute. If set to 1, limit the number of `*trg` commands sent to a running script to 50 regardless of the setting of the `localnode.prompts` attribute.

When set to 0, IEEE Std 488.2 common commands will not generate prompts. When using the `*trg` command with a script that executes `trigger.wait()` repeatedly, set `localnode.prompts4882` to 0 to avoid problems associated with the command interface input queue filling.

This attribute resets to the default value each time the instrument power is cycled.

When using this command from a remote node, `localnode` should be replaced with the node reference, for example `node[5].prompts4882`.

Example

```
localnode.prompts4882 = 0
```

Disables IEEE Std 488.2 common command prompting.

Also see

[localnode.prompts](#) (on page 8-297)

localnode.reset()

This function resets the local node instrument.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
localnode.reset()
```

Details

If you want to reset a specific instrument or a subordinate node, use the `node[x].reset()` command.

A local node reset includes a `channel.reset("allslots")`, `dmm.reset("all")` and a `scan.reset()`. In addition:

- Other settings are restored back to factory default settings
- Existing channel patterns and DMM configurations are deleted
- All channels and backplane relays are opened
- The dmm function is "dcvolts"
- User-created reading buffers are deleted

A `localnode.reset()` is different than a `reset()` because `reset()` resets the entire system.

When using this command from a remote node, `localnode` should be replaced with the node reference, for example `node[5].reset()`.

Example

```
localnode.reset()
```

Resets the local node.

Also see

[channel.reset\(\)](#) (on page 8-88)

[dmm.reset\(\)](#) (on page 8-230)

[reset\(\)](#) (on page 8-316)

[scan.reset\(\)](#) (on page 8-333)

localnode.revision

This attribute stores the firmware revision level.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
revision = localnode.revision
```

<code>revision</code>	Firmware revision level
-----------------------	-------------------------

Details

This attribute indicates the firmware revision number currently running in the instrument.

When using this command from a remote node, `localnode` should be replaced with the node reference, for example `node[5].revision`.

Example

<pre>print(localnode.revision)</pre>	Outputs the present revision level. Sample output: 01.50b
--------------------------------------	--

Also see

[localnode.description](#) (on page 8-293)

[localnode.model](#) (on page 8-296)

[localnode.serialno](#) (on page 8-300)

localnode.serialno

This attribute stores the instrument's serial number.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
serialno = localnode.serialno
```

<code>serialno</code>	The serial number of the instrument
-----------------------	-------------------------------------

Details

This read-only attribute indicates the instrument serial number.

When using this command from a remote node, `localnode` should be replaced with the node reference, for example `node[5].serialno`.

Example

<pre>display.clear()</pre>	Clears the unit's display.
<pre>display.settext(localnode.serialno)</pre>	Places the unit's serial number on the top line of its display.

Also see

[localnode.description](#) (on page 8-293)

[localnode.model](#) (on page 8-296)

[localnode.revision](#) (on page 8-300)

localnode.showerrors

This attribute sets whether or not the instrument automatically sends generated errors.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Power cycle	Not saved	0 (disabled)

Usage

```
errorMode = localnode.showerrors
localnode.showerrors = errorMode
```

<i>errorMode</i>	Enables (1) or disables (0) the show errors state
------------------	---

Details

If this attribute is set to 1, the instrument automatically sends any generated errors stored in the error queue, and then clears the queue. Errors are processed after executing a command message (just before issuing a prompt, if prompts are enabled).

If this attribute is set to 0, errors are left in the error queue and must be explicitly read or cleared.

When using this command from a remote node, `localnode` should be replaced with the node reference, for example, `node[5].showerrors`.

Example

<code>localnode.showerrors = 1</code>	Enables sending of generated errors.
---------------------------------------	--------------------------------------

Also see

[localnode.prompts](#) (on page 8-297)

makegetter()

This function creates a function to get the value of an attribute.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
getter = makegetter(table, attributeName)
```

<i>getter</i>	The return value
<i>table</i>	Read-only table where the attribute is located
<i>attributeName</i>	A string representing the name of the attribute

Details

This function is useful for aliasing attributes to improve execution speed. Calling the function created with `makegetter()` executes faster than accessing the attribute directly.

Creating a getter function is only useful if it is going to be called several times. Otherwise, the overhead of creating the getter function outweighs the overhead of accessing the attribute directly.

Example

```
getrange = makegetter(dmm, "range")
-- (intervening code)
r = getrange()
```

Create a getter function called `getrange`.
When `getrange()` is called, it returns the value of `dmm.range` and assigns it to the variable `r`.

Also see

[makesetter\(\)](#) (on page 8-302)

makesetter()

This function creates a function that, when called, sets the value of an attribute.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
setter = makesetter(table, attributeName)
```

<code>setter</code>	Function that sets the value of the attribute
<code>table</code>	Read-only table where the attribute is located
<code>attributeName</code>	The string name of the attribute

Details

This function is useful for aliasing attributes to improve execution speed. Calling the `setter` function will execute faster than accessing the attribute directly.

Creating a `setter` function is only useful if it is going to be called several times. If you are not calling the `setter` function several times, it is more efficient to access the attribute directly.

Example

```
setrange = makesetter(dmm, "range")
setrange(5)
```

Use `setrange` with a value of 5 to set `dmm.range` for the currently selected function.

Also see

[makegetter\(\)](#) (on page 8-301)

memory.available()

This function reads and returns the amount of memory that is available in the instrument overall for storing user scripts and channel patterns and for user-defined DMM configurations.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
memoryAvailable = memory.available()
```

<i>memoryAvailable</i>	<p>Comma-delimited string with percentages for available memory; the format is <code>systemMemory, scriptMemory, patternMemory, configurationMemory</code>, where:</p> <ul style="list-style-type: none"> <code>systemMemory</code>: The percentage of memory available in the instrument <code>scriptMemory</code>: The percentage of memory available in the instrument to store user scripts <code>patternMemory</code>: The percentage of memory available in the instrument to store channel patterns <code>configurationMemory</code>: The percentage of memory available to store DMM configurations
------------------------	---

Details

Use this function to view the available memory in the overall instrument as well as the memory available for storing user scripts, channel patterns, and user DMM configurations.

The response to this function is a single string that returns the overall instrument memory available, script memory available, channel pattern memory available, and DMM configuration memory available as comma-delimited percentages.

Example: Available memory

<pre>memoryAvailable = memory.available() print(memoryAvailable)</pre>	<p>Reads and returns the amount of memory available in the instrument.</p> <p>Output: 51.56, 92.84, 100.00, 100.00</p> <p>You can also use: <code>print(memory.available())</code></p>
--	--

Example: After recalling a setup

<pre>setup.recall(1) print(memory.available())</pre>	<p>Reads and returns the amount of memory available in the instrument after a setup is recalled.</p> <p>Output: 11.13, 92.84, 0.16, 97.03</p>
--	---

Example: Used and available memory

```
print("Memory used:", memory.used())
print("Memory available: ",
      memory.available())
```

Reads and returns the amount memory used and memory available percentages.

Output:

```
Memory used: 69.14, 0.16, 12.74, 1.04
Memory available: 30.86, 99.84, 87.26, 98.96
```

Also see

[memory.used\(\)](#) (on page 8-304)

memory.used()

This function reports the amount of memory used in the instrument overall and for user scripts, storing channel patterns, and storing user DMM configurations.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
memoryUsed = memory.used()
```

<i>memoryUsed</i>	<p>A comma-delimited string with percentages for used memory; the format is <code>systemMemory, scriptMemory, patternMemory, configurationMemory</code>, where:</p> <ul style="list-style-type: none"> <code>systemMemory</code>: The percentage of memory used in the instrument <code>scriptMemory</code>: The percentage of memory used in the instrument to store user scripts <code>patternMemory</code>: The percentage of memory used in the instrument to store channel patterns <code>configurationMemory</code>: The percentage of memory used to store DMM configurations
-------------------	--

Details

Use this function to view the used memory in the overall instrument, as well as the memory used for storing user scripts, channel patterns, and user DMM configurations.

The response to this function is a single string that shows the overall instrument memory used, as well as the script memory used, channel pattern memory used, and DMM configuration memory used as comma-delimited percentages.

Example

```
MemUsed = memory.used()
print(MemUsed)
```

Reads the memory used in the instrument and returns out the percentages.

Output:

```
69.14, 0.16, 12.74, 1.04
```

Also see

[memory.available\(\)](#) (on page 8-303)

node[N].execute()

This function starts test scripts from a remote node.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes (see Details)			

Usage

```
node[N].execute(scriptCode)
```

<i>N</i>	The node number of this instrument
<i>scriptCode</i>	A string containing the source code

Details

Only the remote master node can use the execute command to run a script on this node. This function does not run test scripts on the master node, only on this node when initiated by the master node.

This function may only be called when the group number of the node is different than the node of the master.

This function will not wait for the script to finish execution.

This function cannot be used from the local node. This command should only be used from a remote master when controlling this instrument over a TSP-link®.

Example 1

```
node[2].execute(sourcecode)
```

Runs script code on node 2. The code is in a string variable called `sourcecode`.

Example 2

```
node[3].execute("x = 5")
```

Runs script code in string constant ("x = 5") to set `x` equal to 5 on node 3.

Example 3

```
node[32].execute(TestDut.source)
```

Runs the test script stored in the variable `TestDut` (previously stored on the master node) on node 32.

Also see

[tsplink.group](#) (on page 8-433)
Introduction to TSP advanced features

node[N].getglobal()

This function returns the value of a global variable.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes (see Details)			

Usage

```
value = node[N].getglobal(name)
```

<i>value</i>	The value of the variable
<i>N</i>	The node number of this instrument
<i>name</i>	The global variable name

Details

Use this function to have the remote master node retrieve the value of a global variable from this node's runtime environment.

Do not use this command to retrieve the value of a global variable from the local node (access the global variable directly). This command should only be used from a remote master when controlling this instrument over a TSP-link®.

Example

```
print(node[5].getglobal("test_val"))
```

Retrieves and outputs the value of the global variable named `test_val` from node 5.

Also see

Introduction to TSP advanced features
[node\[N\].setglobal\(\)](#) (on page 8-306)

node[N].setglobal()

This function sets the value of a global variable.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes (see Details)			

Usage

```
node[N].setglobal(name, value)
```

<i>N</i>	The node number of this instrument
<i>name</i>	The global variable name to set
<i>value</i>	The value to assign to the variable

Details

From a remote node, use this function to assign the given value to a global variable.

Do not use this command to create or set the value of a global variable from the local node (set the global variable directly instead). This command should only be used from a remote master when controlling this instrument over a TSP-link®.

Example

```
node[3].setglobal("x", 5)
```

Sets the global variable `x` on node 3 to the value of 5.

Also see

Introduction to TSP advanced features
[node\[N\].getglobal\(\)](#) (on page 8-305)

opc()

This function sets the operation complete status bit when all overlapped commands are completed.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
opc()
```

Details

This function causes the operation complete bit in the Standard Event Status Register to be set when all previously started local overlapped commands are complete.

Note that each node independently sets its operation complete bits in its own status model. Any nodes not actively performing overlapped commands will set their bits immediately. All remaining nodes will set their own bits as they complete their own overlapped commands.

Also see

[waitcomplete\(\)](#) (on page 8-461)

[Status Model](#) (on page D-1)

print()

This function generates a response message.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
print(value1)
print(value1, value2)
print(value1, ..., valueN)
```

<i>value1</i>	The first argument to output
<i>value2</i>	The second argument to output
<i>valueN</i>	The last argument to output
...	One or more values separated with commas

Details

TSP-enabled instruments do not have inherent query commands. Like any other scripting environment, the `print()` command and other related `print()` commands generate output. The `print()` command creates one response message.

The output from multiple arguments are separated with a tab character.

Numbers are printed using the `format.asciiprecision` attribute. If you want use Lua formatting, print the return value from the `tostring()` function.

Example 1

```
x = 10
print(x)
```

Example of an output response message:

```
1.00000e+01
```

Note that your output might be different if you set your ASCII precision setting to a different value.

Example 2

```
x = 10
print(tostring(x))
```

Example of an output response message:
10

Also see

[format.asciiprecision](#) (on page 8-257)

printbuffer()

This function prints data from tables or reading buffer subtables.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
printbuffer(startIndex, endIndex, buffer1)
printbuffer(startIndex, endIndex, buffer1, buffer2)
printbuffer(startIndex, endIndex, buffer1, ..., bufferN)
```

<i>startIndex</i>	Beginning index of the buffer to print
<i>endIndex</i>	Ending index of the buffer to print
<i>buffer1</i>	First table or reading buffer subtable to print
<i>buffer2</i>	Second table or reading buffer subtable to print
<i>bufferN</i>	The last table or reading buffer subtable to print
...	One or more tables or reading buffer subtables separated with commas

Details

The correct usage of this function for a buffer containing n elements is:

$$1 \leq \text{startIndex} \leq \text{endIndex} \leq n$$

Where n refers to the index of the last entry in the tables to be printed.

If $\text{endIndex} < \text{startIndex}$ or $n < \text{startIndex}$, no data is printed. If $\text{startIndex} \leq 1$, 1 is used as startIndex . If $n < \text{endIndex}$, n is used as endIndex .

When any given reading buffers are used in overlapped commands that have not yet completed (at least to the desired index), this function outputs data as it becomes available.

When there are outstanding overlapped commands to acquire data, n refers to the index that the last entry in the table will have after all the measurements have completed.

If you pass a reading buffer instead of a reading buffer subtable, the default subtable for that reading buffer will be used.

This command generates a single response message that contains all data. The response message is stored in the output queue.

The `format.data` attribute controls the format of the response message.

Example

```
format.data = format.ASCII
format.asciiprecision = 6
printbuffer(1, rb1.n, rb1)
```

This assumes that `rb1` is a valid reading buffer in the runtime environment. The use of `rb1.n` (*bufferVar.n*) indicates that the instrument should output all readings in the reading buffer. Based on the 10 responses in the output data, `rb1.n` equals 10 in this example.

Example of output data (`rb1.readings`):

```
4.07205e-05, 4.10966e-05, 4.06867e-05, 4.08865e-05, 4.08220e-05, 4.08988e-05,
4.08250e-05, 4.09741e-05, 4.07174e-05, 4.07881e-05
```

Also see

[bufferVar.n](#) (on page 8-30)
[format.asciiprecision](#) (on page 8-257)
[format.byteorder](#) (on page 8-258)
[format.data](#) (on page 8-259)
[print\(\)](#) (on page 8-307)
[printnumber\(\)](#) (on page 8-309)

printnumber()

This function prints numbers using the configured format.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
printnumber(value1)
printnumber(value1, value2)
printnumber(value1, ..., valueN)
```

<i>value1</i>	First value to print in the configured format
<i>value2</i>	Second value to print in the configured format
<i>valueN</i>	Last value to print in the configured format
...	One or more values separated with commas

Details

There are multiple ways to use this function, depending on how many numbers are to be printed. This function prints the given numbers using the data format specified by `format.data` and `format.asciiprecision`.

Example

```
format.asciiprecision = 10
x = 2.54
printnumber(x)
format.asciiprecision = 3
printnumber(x, 2.54321, 3.1)
```

Configure the ASCII precision to 10 and set *x* to 2.54.
Read the value of *x* based on these settings.
Change the ASCII precision to 3.
View how the change affects the output of *x* and some numbers.
Output:
2.540000000e+00
2.54e+00, 2.54e+00, 3.10e+00

Also see

[format.asciiprecision](#) (on page 8-257)
[format.byteorder](#) (on page 8-258)
[format.data](#) (on page 8-259)
[print\(\)](#) (on page 8-307)
[printbuffer\(\)](#) (on page 8-308)

ptp.domain

This attribute describes the IEEE Std 1588-2008 precision time protocol (PTP) domain.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Never	Nonvolatile memory	0

Usage

```
value = ptp.domain
ptp.domain = value
```

<i>value</i>	0 = default domain 1 = alternate domain 1 2 = alternate domain 2 3 = alternate domain 3 4 - 127 = user-defined domains 128 - 255 = Reserved
--------------	--

Details

Only instruments in the same domain will interact with each other in the IEEE-1588 PTP.

Example

```
ptp.domain=1
print(ptp.domain)
```

Sets the ptp domain to 1 (alternate domain 1) and prints the result.
Output:
1

Also see

Not applicable

ptp.ds.info()

This function is a read-only string that returns the settings of the different data sets (DS) associated with the IEEE-1588 2008 specification.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
ptp.ds.info()
```

Details

The following data sets are returned:

- Current
- Default
- Parent
- Time properties
- Port
- Foreign master

For more detailed information regarding field information, refer to the IEEE-1588 2008 specification.

Example

```

print(ptp.ds.info())
Output:
Current DS
    Steps removed: 0
    Offset from Master: 0.000000000
    Mean Path Delay: 0.000000000

Default DS
    Number of Ports: 1
    Two Step Clock: T
        Priority 1: 128
        Priority 2: 128
        Domain: 0
    Clock Identity: 12 34 56 FF FE 65 43 21
    Clock Qual - Class: 248
    Clock Qual - Accuracy: 254
    Clock Qual - Variance: 0
    Slave Only: F

Parent DS
    Parent Stats: F
    Parent Clock Identify: 12 34 56 FF FE 65 43 21
    Parent Port Identify: 0
    Parent Offset Var: 65535
    Parent Phase Chnge Rate: 2147483647
        GM Priority 1: 128
        GM Priority 2: 128
    GM Clck Qual - Class: 248
    GM Clck Qual - Accuracy: 254
    GM Clck Qual - Variance: 0
    GM Clock Identify: 12 34 56 FF FE 65 43 21

Time Properties DS
    Current UTC Offset: 0
        Leap 59: F
        Leap 61: F
    Current UTC Offset Vald: T
        PTP Timescale: T
        Time Traceable: F
    Frequency Traceable: F
    Time Source: Internal Oscillator

Port DS
    Clock Identify: 12 34 56 FF FE 65 43 21
    Port Identify: 1
    Port State: 6
    Log Mn Delay Req Intrvl: 4
    Peer mean Path Delay: 0
    Log Announce Interval: 1
    Announc Receipt Timeout: 3
    Log Sync Interval: 0
    Delay Mechanism: E2E
    Log Mn PDelay Rq Intrvl: 0
    Version Number: 2

Foreign Master DS 1
    Announce Messages: 2
    Frgn Mstr Clock Idntfy: 00 60 1A FF FE 01 54 29
    Frgn Mstr Port Idntfy: 1

```

Also see

Not applicable

ptp.enable

This attribute enables or disables the precision time protocol (PTP) described in IEEE-1588 on the TSP.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Not applicable	Nonvolatile memory	0 (ptp.OFF)

Usage

```
state = ptp.enable
ptp.enable = state
```

<i>state</i>	Disable the ptp protocol: <code>ptp.OFF</code> or 0 Enable the ptp protocol: <code>ptp.ON</code> or 1
--------------	--

Details

From the factory, this attribute is disabled (`ptp.OFF`). After setting this attribute, it is saved in nonvolatile memory, and that setting value is recalled the next time the instrument is powered on.

Example

<code>ptp.enable=1</code> <code>print(ptp.enable)</code>	Output: 1.000000000e+00
---	----------------------------

Also see

Not applicable

ptp.portstate

This attribute is a read-only value that indicates the state of the IEEE-1588 precision time protocol (PTP).

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Never	Not applicable	Not applicable

Usage

```
state = ptp.portstate
```

<i>state</i>	<pre>ptp.INITIALIZING (0) ptp.FAULTY (1) ptp.DISABLE (2) ptp.LISTENING (3) ptp.PRE_MASTER (4) ptp.MASTER (5) ptp.PASSIVE (6) ptp.UNCALIBRATED (7) ptp.SLAVE (8) ptp.UNKNOWN (9)</pre>
<pre>print (ptp.portstate)</pre>	<pre>Output (this output indicates that PTP is disabled): 2.000000000e+00</pre>

Also see

[ptp.enable](#) (on page 8-313)

ptp.slavepreferred

This attribute describes whether you prefer to have the instrument be a subordinate clock or not.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Never	Nonvolatile memory	false (disabled)

Usage

```
value = ptp.slavepreferred
ptp.slavepreferred = value
```

value	true: Disabled. false: Enabled.
-------	------------------------------------

Details

From the factory, this attribute is false. After you set this attribute, it is saved in nonvolatile memory. That setting is recalled the next time the instrument is powered up.

Example

```
ptp.slavepreferred = TRUE
print (ptp.slavepreferred)
```

Set the instrument to be a subordinate clock. Check to see if the instrument is a subordinate clock.
Output:
true

Also see

Not applicable

ptp.time()

This function is a read-only string that returns the PTP time in seconds and fractionseconds.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
ptp.time ()
```

Example

```
sec, fraction=ptp.time ()
print (sec+fraction)
```

Output:
1.306440045e+09

Also see

Not applicable

ptp.utcoffset

This attribute describes the offset, in seconds, between UTC and PTP.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	See Details	Nonvolatile memory	See Details

Usage

```
value = ptp.utcoffset
ptp.utcoffset = value
```

<code>value</code>	The offset in seconds
--------------------	-----------------------

Details

If the instrument is a subordinate, the `ptp.utcoffset` value is from the master. If the value is from the master, the setting is overwritten on the next synchronization. The Series 3700A does not keep track of this value through a power cycle (that is, it defaults to 0 if the 3700 is the master). The `ptp.utcoffset` is only non-zero if the Series 3700A communicates to a master clock that is aware of the difference between PTP and UTC time.

You can only write to this command if the Series 3700A is the master. If the Series 3700A is not the master, an error is generated when you try to write to the Series 3700A.

The Series 3700A is not time-zone aware, so UTC time is presented as the local time.

UTC Time = PTP Time – UTC Offset

Example

```
ptp.utcoffset=33
print(ptp.utcoffset)
```

Sets the UTC offset to 33 seconds.

Output:

```
3.300000000e+01
```

Also see

Not applicable

reset()

This function resets commands to their default settings.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
reset()
reset(system)
```

<code>system</code>	<p>true: If the node is the master, the entire system is reset</p> <p>false: Only the local group is reset</p>
---------------------	--

Details

The `reset()` command in its simplest form resets the entire TSP-enabled system, including the controlling node and all subordinate nodes.

If you want to reset a specific instrument, use either the `localnode.reset()` or `node[x].reset()` command. The `localnode.reset()` command is used for the local instrument. The `node[x].reset()` command is used to reset an instrument on a subordinate node.

When no value is specified for `system`, the default value is `true`.

Resetting the entire system using `reset(true)` is permitted only if the node is the master. If the node is not the master node, executing this command generates an error.

Example

```
reset(true)
```

If the node is the master node, the entire system is reset; if the node is not the master node, an error is generated.

Also see

[localnode.reset\(\)](#) (on page 8-299)

scan.abort()

This function aborts a running background scan.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
scan.abort()
```

Details

If no scan is running, the call to this function is ignored.

NOTE

When a scan is aborted, the channels remain in the opened or closed states that they were in when the scan was aborted.

Example

```
scan.background()  
scan.abort()
```

Starts background scan, and then aborts the scan.

Also see

[scan.background\(\)](#) (on page 8-322)
[Scanning and triggering](#) (on page 3-1)

scan.add()

This function adds a scan step to the scan list.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
scan.add(channelList)
scan.add(<channelList>, <dmmConfig>)
scan.add(<channelList>, <width>)
```

<i>channelList</i>	String specifying channels to add using normal channel list syntax
<i>dmmConfig</i>	String listing the DMM configuration to use with items in <i>channelList</i>
<i>width</i>	Value that specifies the width of the channel read to use with items in <i>channelList</i>

Details

Use this function to add channels and channel patterns to the present scan list. If the scan list does not exist, it also creates a scan list. See `scan.create()` for information about creating a scan list.

Channels and channel patterns added using the `scan.add()` function are added to the end of the present list (appended) in the same order as specified in *channelList*. In addition, the added channels are scanned in the order specified in *channelList*. Specifying multiple channels in *channelList* adds multiple steps to the scan.

Each channel's or channel pattern's configuration, associated with `dmm.setconfig()` and `dmm.getconfig()`, is used unless the optional *dmmConfig* parameter is specified. Specifying the *dmmConfig* parameter temporarily overrides the channel's (or channel pattern's) associated configuration. Specifying *dmmConfig* does not modify the assigned configuration of a channel or channel pattern.

The scan list of channels (or channel patterns) is not updated if an error occurs during processing of the function. However, because each channel is added as a separate step when you add multiple channels to *channelList*, steps that were already added to the scan list update, even if an error is detected.

For digital I/O or totalizer channels, each created scan step instructs the scan to read the selected channel and then save the value into the specified reading buffer. If you do not specify a reading buffer, the channel is read but the value is not saved.

The *width* parameter is valid for digital I/O type channels. Widths of 1, 2, 3, or 4 are supported. If specified, the scan can read up to four consecutive channels simultaneously, and then saves the resulting value into the specified reading buffer.

DAC channels are not supported.

Measurement time stamps may vary from channel read time stamps because of the way different channel types generate reading buffer time stamps.

Example 1

```
scan.create("3001:3010", "DCV")
```

For this example, assume "DCV" is a previously defined user configuration for DC volts. Clears the old scan list and creates a new scan list with each channel (1 to 10 on slot 3) using DCV as the overriding DMM configuration.

Example 2

```
scan.add("3001:3010", "2wire")
```

For this example, assume "2wire" is a previously defined user configuration for 2-wire ohms. Uses `2wire` for all 10 channels and adds them to the end of the existing scan list.

Example 3

```
scan.create("")
```

Clears the old scan list and creates a new empty scan list.

Example 4

```
for chan = 3001, 3010 do
    scan.add("" .. chan, "DCV")
    scan.add("" .. chan, "2wire")
end
```

For this example, assume "DCV" is a previously defined user DC volts configuration, and "2wire" is a previously defined user 2-wire ohms configuration.

Adds channels 3001 through 3010 to the end of the existing scan list. This loops through the channels twice, adding channels to the scan list twice. The first time, it adds "DCV" for a channel. The second time, it adds "2wire" for that channel. The first parameter ("" .. chan) converts the chan number to a string.

Also see

[scan.create\(\)](#) (on page 8-324)
[dmm.getconfig\(\)](#) (on page 8-192)
[dmm.setconfig\(\)](#) (on page 8-239)
Reading buffers
[Scanning and triggering](#) (on page 3-1)

scan.addimagestep()

This function allows you to include multiple channels in a single scan step.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
scan.addimagestep(channelList)
scan.addimagestep(channelList, dmmConfig)
```

<i>channelList</i>	String specifying a list of channels
<i>dmmConfig</i>	String specifying a DMM configuration

Details

This function adds a list of channels to be closed simultaneously in a single step of a scan. An optional DMM configuration can be added to force the scan to take a measurement during the same step.

This function is an advanced command; the *channelList* parameter must specify appropriate relays to support the requested DMM configuration, or an invalid measurement will result.

Unlike `scan.add()`, the paired channels and backplanes necessary for measurement are not automatically added to the step. Use the `channel.setpole()` command to indicate if the paired channel should be added or not. Backplanes assigned to channels by the `channel.setbackplane()` command are not added to the image step automatically. For example, if a measurement is taken on a 4-wire ohms configuration without designating 4-pole with the `channel.setpole()` command, the corresponding paired channels and backplanes will not be added, and the specified *dmmConfig* will not cause additional relay closures as it normally would.

If you have changed the pole setting on any of the channels in the list (using `channel.setpole()`), an additional paired channel is added or removed, as appropriate. For example, to ensure that the proper channels close to enable a 4-wire measurement, set the pole setting in addition to using the 4-wire ohms DMM configuration.

When a DMM configuration (other than "nofunction") is specified, the instrument will take the appropriate measurement based on the function set in the configuration; if no DMM configuration is specified with the command, no measurement will be taken.

Example

<pre>scan.addimagestep("1001", "dcvolts")</pre>	Adds a single step that closes Channel 1001 and takes a DC voltage measurement. Note that the voltage measurement will be inaccurate if this is the only step in the scan (because the backplane channels are not closed).
<pre>scan.addimagestep("1001, 1911", "dcvolts")</pre>	Adds a single step that closes Channels 1001 and 1911, and then takes a DC voltage measurement.
<pre>channel.setpole("1001", 4) scan.addimagestep("1001, 1911", "dcvolts")</pre>	Set Channel 1001 to 4-pole operation. Adds a single step that closes Channels 1001, 1031, and 1911, and then takes a DC voltage measurement.

```
scan.addimagestep("1101, 2202, 1911", "dcvolts")
scan.addimagestep("1102, 2202, 1911", "dcvolts")
scan.addimagestep ("1103, 2202, 1911", "dcvolts")
```

Adds three steps with the following actions:

- Closes Channels 1101, 2202, and 1911, and then takes a DC voltage measurement.
- Opens Channel 1101, closes Channel 1102 and maintains Channel 1911 and 2202 closed, and then takes a DC voltage measurement.
- Opens Channel 1102, closes Channel 1103 and maintains Channel 1911 and 2202 closed, and then takes a DC voltage measurement.

Also see

[channel.setbackplane\(\)](#) (on page 8-90)

[channel.setpole\(\)](#) (on page 8-101)

[scan.add\(\)](#) (on page 8-317)

[Scanning and triggering](#) (on page 3-1)

scan.addwrite()

This function writes a specified value to a channel at the added step in the scan.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
scan.addwrite(channelList, writeValue)
scan.addwrite(channelList, writeValue, width)
```

<i>channelList</i>	String specifying channels to add using normal channel list syntax
<i>writeValue</i>	The value to write to the channel for this scan step
<i>width</i>	Specifies the width of the channel write to use with items in <i>channelList</i>

Details

This function is similar to issuing `channel.write()` at the scan step. Specifying multiple channels in *channelList* causes multiple steps to be added to the scan.

For digital I/O channels, only a width of 1, 2, 3, or 4 is supported. Any information (bits) greater than the specified width are ignored. Values written to inputs are ignored. If no specified channel is set for output, an error is generated. If a width crosses channels, only the channels set to output are affected.

For backplane and switch channels, there is no valid behavior. Calling on a specific channel generates an error.

For DAC channels, if the channel mode is changed after the scan is created, the scan is rebuilt. If the write value is no longer compatible with the new mode, an error is generated and the scan becomes invalid.

Example

```
scan.addwrite("6001, 6003, 6005", 21845, 2)
```

Assume a Model 3750 in slot 6.
Add to existing scan list channels 1, 3 and 5 on slot 6 to write a 16-bit hex value of hexadecimal 5555 (decimal 21845).

Also see

[Scanning and triggering](#) (on page 3-1)

scan.background()

This function starts a scan and runs the scan in the background.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
state, scanCount, stepCount, reading = scan.background()
state, scanCount, stepCount, reading = scan.background(bufferVar)
```

<i>state</i>	The result of scanning: scan.EMPTY or 0 scan.BUILDING or 1 scan.RUNNING or 2 scan.ABORTED or 3 scan.FAILED or 4 scan.FAILED_INIT or 5 scan.SUCCESS or 6
<i>scanCount</i>	This is current number scans completed
<i>stepCount</i>	This is current number steps completed
<i>reading</i>	If measurements are taken during the scan, this parameter contains the last scan reading completed
<i>bufferVar</i>	A reading buffer used during scanning to store the readings. If a buffer is not specified, no readings are stored during the scan

Details

You can also use this function to specify the scanning reading buffer. This reading buffer, if specified, stores the readings and accompanying attributes as specified for the scan. An error is generated if the reading buffer does not exist or the parameter is not a reading buffer.

Before using this command, use `scan.create()` and `scan.add()` or `scan.addimagestep()` to set up a scan list.

When the scan is run in the background, you must use the `scan.state()` function to check the status of the scan.

Example

```
scan.background(rbuff1)
```

Runs a scan in the background and stores readings in a buffer named `rbuff1`.

Also see

[scan.add\(\)](#) (on page 8-317)
[scan.create\(\)](#) (on page 8-324)
[scan.execute\(\)](#) (on page 8-326)
[scan.list\(\)](#) (on page 8-327)
[scan.state\(\)](#) (on page 8-335)
[Scanning and triggering](#) (on page 3-1)

scan.bypass

This attribute indicates whether the first channel of the scan waits for the channel stimulus event to be satisfied before closing.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset Scan reset Recall setup	Create configuration script Save setup	1 (scan.ON)

Usage

```
bypass = scan.bypass
scan.bypass = bypass
```

bypass

The state of the bypass. Set to one of the following values:
 scan.OFF or 0: Disabled
 scan.ON or 1: Enabled

Details

When *bypass* is ON and the `scan.trigger.arm.stimulus` is set to a non-zero value, the first channel of the scan closes (the `scan.trigger.channel.stimulus` setting is ignored).

For other channels (other than the first), the channel stimulus must be satisfied before the channel action takes place.

When *bypass* is OFF, every channel (including the first) must satisfy the `scan.trigger.channel.stimulus` setting before the channel action occurs for that step.

Example

```
scan.bypass = scan.OFF
print(scan.bypass)
```

Disables the bypass option for scanning and displays the present bypass state.

Output:

```
0.000000000e+000
```

Also see

[scan.trigger.arm.stimulus](#) (on page 8-337)
[scan.trigger.channel.stimulus](#) (on page 8-340)
[Scanning and triggering](#) (on page 3-1)

scan.create()

This function deletes the existing scan list and creates a new list of channels and channel patterns to scan.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
scan.create(channelList)
scan.create(channelList, dmmConfig)
```

<i>channelList</i>	String specifying channels to add
<i>dmmConfig</i>	The DMM configuration to use with items in the <i>channelList</i>

Details

The existing scan list is lost after calling this function.

The items in *channelList* are scanned in the order listed.

Each channel's (or channel pattern's) configuration is used unless the optional *dmmConfig* parameter is specified (see `dmm.setconfig()` and `dmm.getconfig()`). Specifying the *dmmConfig* parameter temporarily overrides the channel's or channel pattern's associated configuration. Specifying *dmmConfig* does not modify the assigned configuration of a channel or channel pattern.

If a forbidden channel is included in a range of channels or slot parameter (such as slot 1), the forbidden channel is ignored and no error is generated. If a forbidden channel is individually specified in the channel list, an error is generated.

You cannot specify an analog backplane relay as part of the channel list.

If an error occurs, the scan list of channels or channel patterns is cleared, even though no new scan list is created.

The function `scan.reset()` clears the list. To clear the scan list without performing a scan reset, send an empty string for the *channelList* parameter.

Example 1

<pre>scan.create("1001:1010")</pre>	Replaces the active scan list with an empty scan list. Adds channels 1 through 10 on slot 1. Uses the existing DMM configuration (<code>dmm.setconfig()</code>).
-------------------------------------	---

Example 2

<pre>scan.create() for chan = 1001, 1010 do scan.add("" .. chan) end</pre>	Replaces the active scan list with an empty scan list. Loops through channels 1001 to 1010, and then adds 10 channels to the scan list. The parameter (<code>"" .. chan</code>) converts the channel number to a string. The scan list now has, in order, channels 1 through 10 on slot 1. Uses the existing DMM configuration (<code>dmm.setconfig()</code>).
--	---

Example 3

```
scan.create("3001:3010", "testDCV")
```

For this example, assume `testDCV` is a previously defined user DC volts configuration.

Clears the old scan list and creates a new scan list with each channel (1 to 10 on slot 3).

Each channel uses the DMM configuration associated with `testDCV`.

Example 4

```
scan.create("")

for chan = 3001, 3010 do

    scan.add("" .. chan, "testDCV")

    scan.add("" .. chan, "test2wire")

end
```

For this example, assume `testDCV` is a previously defined user DC volts configuration, and `test2wire` is a previously defined user 2-wire ohm configuration.

This loops through the channels, adding channels to the scan list. The first time, it adds `testDCV` for a channel. The second time, it adds `test2wire` for that channel.

The first parameter (`"" .. chan`) converts the `chan` number to a string. Clears the old scan list and creates a new scan list.

Loops through channels 3001 to 3010. Adds channels 3001 through 3010 to the end of the existing scan list.

Also see

- [dmm.getconfig\(\)](#) (on page 8-192)
- [dmm.setconfig\(\)](#) (on page 8-239)
- [scan.add\(\)](#) (on page 8-317)
- [scan.reset\(\)](#) (on page 8-333)
- [Scanning and triggering](#) (on page 3-1)

scan.execute()

This function starts the scan immediately in the foreground with a configured scan list.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
state, scanCount, stepCount, reading = scan.execute()
state, scanCount, stepCount, reading = scan.execute(bufferVar)
```

<i>state</i>	The result of scanning: scan.EMPTY or 0 scan.BUILDING or 1 scan.RUNNING or 2 scan.ABORTED or 3 scan.FAILED or 4 scan.FAILED_INIT or 5 scan.SUCCESS or 6
<i>scanCount</i>	The present number of scans completed
<i>stepCount</i>	The present number of steps completed
<i>reading</i>	If measurements are taken during the scan, this parameter contains the last scan reading completed
<i>bufferVar</i>	A reading buffer used during scanning to store the readings. If a buffer is not specified, no readings are stored during the scan

Details

In addition to starting and running the scan in immediate mode (not in the background), you can use this function to specify the scanning reading buffer. This reading buffer stores the readings and accompanying attributes as specified for the scan. An error is generated if the reading buffer does not exist or if the parameter is not a reading buffer.

Before using this command, use `scan.create()` and `scan.add()` or `scan.addimagestep()` to set up a scan list.

Execution runs until the scan is complete or until the `abort` command is sent.

Because this function waits for the scan to complete, the `scan.state()` function cannot be used to see the current status of scanning.

Example

```
scan.execute(rbBuff1)
```

Runs a scan immediately and stores the readings in a reading buffer named `rbbuff1`.

Also see

[scan.add\(\)](#) (on page 8-317)
[scan.background\(\)](#) (on page 8-322)
[scan.create\(\)](#) (on page 8-324)
[scan.list\(\)](#) (on page 8-327)
[scan.state\(\)](#) (on page 8-335)
[Scanning and triggering](#) (on page 3-1)

scan.list()

This function queries the active scan list.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes	Instrument reset Channel reset Scan reset Recall setup Change of channel or scan setting	Create configuration script Save setup	Empty list

Usage

```
scanList = scan.list()
```

<i>scanList</i>	A string that lists the existing scan step information.
-----------------	---

Details

This function lists the existing scan list.

When you change a channel or scan attribute for an existing scan list item, the scan list is recreated based on this change. If the scan list cannot be rebuilt, an error is generated and the scan list is lost.

To avoid unintentional changes to an existing scan list, configure channel and scan settings before using the commands `scan.add()`, `scan.addimagestep()`, and `scan.create()` to build a scan list.

If the scan list is empty, the string "Empty Scan" is returned. Otherwise, the string lists each step in the scan along with its information for step, open, measure configuration, count, and close (see the example below).

Example

```

reset()
dmm.setconfig("2020, 2021", "dcvolts")
dmm.nplc = 0.5
dmm.range = 10
dmm.configure.set("DCVSlot2")
dmm.setconfig("2016,2017", "DCVSlot2")
scan.create("2007,2008,2020,2021,2016,2017")
print(scan.list())

```

Assume a Model 3721 in slot 2.

Configure channels 20 and 21 for DC volts on slot 2.

Change the DMM settings for NPLC and range and save those DC volt settings as "DCVSlot2".

Configure channels 16 and 17 for "DCVSlot2" on slot 2.

Populate the scan list with the function `scan.create("2007,2008,2020,2021,2016,2017")`, then initiate the scan list to be output.

Outputs the existing scan list. For example, an existing scan list may appear as follows:

```

Init) OPEN...
1) STEP: 2007
CLOSE: 2007
MEASURE: nofunction COUNT: 1
2) STEP: 2008
OPEN: 2007
CLOSE: 2008
MEASURE: nofunction COUNT: 1
3) STEP: 2020
OPEN: 2008
CLOSE: 2020 2911
MEASURE: dcvolts COUNT: 1
4) STEP: 2021
OPEN: 2020 2911
CLOSE: 2021 2921
MEASURE: dcvolts COUNT: 1
5) STEP: 2016
OPEN: 2021 2921
CLOSE: 2016 2911
MEASURE: DCVSlot2 COUNT: 1
6) STEP: 2017
OPEN: 2016
CLOSE: 2017
MEASURE: DCVSlot2 COUNT: 1

```

Also see

[scan.create\(\)](#) (on page 8-324)

[Scanning and triggering](#) (on page 3-1)

scan.measurecount

This attribute sets the number of iterations performed when a scanning measurement is requested.

Type	TSP-Link™ accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset Scan reset Recall setup	Create configuration script Save setup	1

Usage

```
count = scan.measurecount
scan.measurecount = count
```

<code>count</code>	The count value being used or read; valid range is 1 to 450000
--------------------	--

Details

Use this attribute to indicate how many measurements to take on a step when measurements are needed. This sets the measure count in the trigger model. During a scan, the Model 3706A iterates through the sequence event detector and measure action of the trigger model *count* times. After performing *count* iterations, the Model 3706A returns to check the scan count.

This must be set before the scan is started. Once set, it applies to all scan steps in the list, including scan steps that exist in the list and any that are added before the scan is started.

All steps take the same number of measurements. When taking multiple measurements, the measurements may be taken as quickly as possible based on the configuration (`scan.trigger.measure.stimulus = 0`) or they may be paced by a trigger (`scan.trigger.measure.stimulus` is nonzero).

Example

<code>scan.measurecount = 5</code>	Sets the measure count to 5.
------------------------------------	------------------------------

Also see

[scan.create\(\)](#) (on page 8-324)
[Scanning and triggering](#) (on page 3-1)

scan.mode

This attribute controls the scan mode setting.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset Scan reset Recall setup	Create configuration script Save setup	0 (scan.MODE_OPEN_ALL)

Usage

```
scanModeSetting = scan.mode
scan.mode = scanModeSetting
```

<i>scanModeSetting</i>	The present scan mode setting. Set to one of the following values: <ul style="list-style-type: none"> • scan.MODE_OPEN_ALL or 0 • scan.MODE_OPEN_SELECTIVE or 1: See Details • scan.MODE_FIXED_ABR or 2: See Details
------------------------	---

Details

When this attribute is set to `scan.MODE_OPEN_ALL`, all channels on all slots are opened before a scan starts. When this attribute is set to `scan.MODE_OPEN_SELECTIVE`, an intelligent open is performed. Assuming all steps being scanned have a function value of "nofunction" with their DMM configuration then:

- All channels and analog backplane relays involved in scanning are opened
 - Closed channels and backplane relays not involved in scanning remain closed during the scan
- If any step has a DMM configuration with a function set to any other value than "nofunction":
- Analog backplane relays 1 and 2 are opened on all slots
 - Any commonside ohms backplane relays are opened on all slots
 - Any amp channels are opened on all slots
 - All channels and backplane relays involved in scanning are opened
 - If a closed channel or backplane relay is not involved in scanning, it remains closed during the scan
 - All channels are opened on any bank that contains backplane relays that are involved in scanning

When this attribute is set to `scan.MODE_FIXED_ABR`, it is equivalent to setting `MODE_OPEN_SELECTIVE`, except:

- All required backplane relays are closed before the start of the scan
- These backplane relays are not opened or closed during the scan
- These backplane relays do not open at the end of scan

Example

<code>scan.mode = scan.MODE_OPEN_SELECTIVE</code>	Sets the scan mode setting to open selective.
---	---

Also see

- [scan.reset\(\)](#) (on page 8-333)
- [Scanning and triggering](#) (on page 3-1)

scan.nobufferbackground()

This function starts a scan in background mode and specifies that no reading buffer is used during scanning.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
state, scandcount, stepcount = scan.nobufferbackground()
```

<i>state</i>	The result of scanning: <ul style="list-style-type: none"> • scan.EMPTY or 0 • scan.BUILDING or 1 • scan.RUNNING or 2 • scan.ABORTED or 3 • scan.FAILED or 4 • scan.FAILED_INIT or 5 • scan.SUCCESS or 6
<i>scandcount</i>	The present number of scans completed
<i>stepcount</i>	The present number of steps completed

Details

Before using this command, use `scan.create()`, `scan.add()` and `scan.addimagestep()` to set up scan elements. If a reading buffer is specified, an error is generated.

To view the scan status, use `scan.state()`.

To run a scan in the background with a reading buffer, see [scan.background\(\)](#) (on page 8-322).

Example

```
scan.nobufferbackground()
```

Run the scan in the background with no reading buffer.

Also see

[scan.add\(\)](#) (on page 8-317)
[scan.background\(\)](#) (on page 8-322)
[scan.create\(\)](#) (on page 8-324)
[scan.execute\(\)](#) (on page 8-326)
[scan.list\(\)](#) (on page 8-327)
[scan.nobufferexecute\(\)](#) (on page 8-332)
[scan.state\(\)](#) (on page 8-335)
[Scanning and triggering](#) (on page 3-1)

scan.nobufferexecute()

This function starts a scan immediately and specifies that no reading buffer is used during scanning.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
state, scanCount, stepCount = scan.nobufferbackground()
```

<i>state</i>	<p>The result of scanning:</p> <ul style="list-style-type: none"> • scan.EMPTY or 0 • scan.BUILDING or 1 • scan.RUNNING or 2 • scan.ABORTED or 3 • scan.FAILED or 4 • scan.FAILED_INIT or 5 • scan.SUCCESS or 6
<i>scanCount</i>	The present number of scans that have completed
<i>stepCount</i>	The present number of steps have completed

Details

Before using this command, use `scan.create()`, `scan.add()`, and `scan.addimagestep()` to set up scan elements. If a reading buffer is specified, an error is generated.

The command continues execution until scanning completes or is aborted by the user.

To run a scan immediately with a reading buffer, see [scan.execute\(\)](#) (on page 8-326).

Example

<code>scan.nobufferexecute()</code>	Runs the scan immediately with no reading buffer.
-------------------------------------	---

Also see

- [scan.add\(\)](#) (on page 8-317)
- [scan.background\(\)](#) (on page 8-322)
- [scan.create\(\)](#) (on page 8-324)
- [scan.execute\(\)](#) (on page 8-326)
- [scan.list\(\)](#) (on page 8-327)
- [scan.nobufferbackground\(\)](#) (on page 8-331)
- [scan.state\(\)](#) (on page 8-335)
- [Scanning and triggering](#) (on page 3-1)

scan.reset()

This function resets the trigger model and scan list settings to their factory default settings.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
scan.reset()
```

Details

When `scan.reset()` is sent, the trigger model and scan settings that are reset to the factory defaults are:

- `scan.bypass`
- `scan.measurecount`
- `scan.mode`
- `scan.scancount`
- `scan.trigger.arm.stimulus`
- `scan.trigger.channel.stimulus`
- `scan.trigger.measure.stimulus`
- `scan.trigger.sequence.stimulus`

In addition, the scan list is cleared.

NOTE

Sending this function only affects the trigger model and scan list settings. To reset all instrument settings to factory default settings, use the `reset()` command.

Example

```
scan.reset()
```

Performs a reset on the trigger model and scan settings.

Also see

- [channel.reset\(\)](#) (on page 8-88)
- [dmm.reset\(\)](#) (on page 8-230)
- [reset\(\)](#) (on page 8-316)
- [scan.bypass](#) (on page 8-323)
- [scan.measurecount](#) (on page 8-329)
- [scan.mode](#) (on page 8-330)
- [scan.scancount](#) (on page 8-334)
- [scan.trigger.arm.stimulus](#) (on page 8-337)
- [scan.trigger.channel.stimulus](#) (on page 8-340)
- [scan.trigger.measure.stimulus](#) (on page 8-344)
- [scan.trigger.sequence.stimulus](#) (on page 8-347)
- [Scanning and triggering](#) (on page 3-1)

scan.scancount

This attribute sets the scan count in the trigger model.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset Scan reset Recall setup	Create configuration script Save setup	1

Usage

```
scanCount = scan.scancount
scan.scancount = scanCount
```

<i>scanCount</i>	The present scan count value (1 to 2,000,000,000)
------------------	---

Details

The scan count attribute setting indicates how many times the scan list is iterated through before the scan completes.

During a scan, the instrument iterates through the arm layer of the trigger model the specified number of times. After performing the specified number of iterations, the instrument returns to an idle state.

Example

<code>scan.scancount = 5</code>	Sets the scan count to 5.
---------------------------------	---------------------------

Also see

[Trigger model](#) (on page 3-1)
[Scanning and triggering](#) (on page 3-1)

scan.state()

This function provides the present state of a running background scan.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
scanState, scanCount, stepCount, reading = scan.state()
```

<i>scanState</i>	The present state of the scan running in the background. Possible states include: scan.EMPTY or 0 scan.BUILDING or 1 scan.RUNNING or 2 scan.ABORTED or 3 scan.FAILED or 4 scan.FAILED_INIT or 5 scan.SUCCESS or 6
<i>scanCount</i>	The current number of scans that have completed
<i>stepCount</i>	The current number of steps that have completed
<i>reading</i>	If measurements are taken during the scan, this parameter contains the last scan reading completed

Details

scanCount is the number of the current iteration through the scan portion of the trigger model. This number does not increment until the scan begins. Therefore, if the instrument is waiting for an input to trigger a scan start, the scan count represents the previous number of scan iterations. If no scan has begun, the scan count is zero (0).

stepCount is the number of times the scan has completed a pass through the channel action portion of the trigger model. This number does not increment until after the action completes. Therefore, if the instrument is waiting for an input to trigger a channel action, the step count represents the previous step. If no step has yet completed, the step count is zero. If the step count has yet to complete the first step in a subsequent pass through a scan, the scan count represents the last step in the previous scan pass.

Example

```
scan.background()
scanState, scanCount, stepCount = scan.state()
print(scanState)
```

Runs a scan in the background.
Check the present scan state.
View value of scanState.
Output shows that scan is running:
2.00000e+00

Also see

[scan.background\(\)](#) (on page 8-322)
[scan.mode](#) (on page 8-330)
[Scanning and triggering](#) (on page 3-1)

scan.stepcount

This attribute contains the number of steps in the present scan.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
scanStepCount = scan.stepcount
```

<code>scanStepCount</code>	The present step count value
----------------------------	------------------------------

Details

This is set by the number of steps in the active scan list. The value of this attribute is initially determined when the scan is created. Adding steps with the `scan.create()`, `scan.addimagestep()`, and `scan.add()` functions updates this attribute's value.

Example

<pre>print(scan.stepcount)</pre>	Responds with the present step count. Output assuming there are five steps in the scan list: 5.00000e+00
----------------------------------	--

Also see

[scan.add\(\)](#) (on page 8-317)
[scan.addimagestep\(\)](#) (on page 8-320)
[scan.create\(\)](#) (on page 8-324)
[Scanning and triggering](#) (on page 3-1)

scan.trigger.arm.clear()

This function clears the arm event detector.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
scan.trigger.arm.clear()
```

Details

This function sets the trigger model's arm event detector to the undetected state.

Example

<pre>scan.trigger.arm.clear()</pre>	Clears the arm event detector.
-------------------------------------	--------------------------------

Also see

[scan.trigger.arm.set\(\)](#) (on page 8-337)
[scan.trigger.arm.stimulus](#) (on page 8-337)
[Trigger model](#) (on page 3-1)
[Scanning and triggering](#) (on page 3-1)

scan.trigger.arm.set()

This function sets the arm event detector to the detected state.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
scan.trigger.arm.set()
```

Details

This function sets the arm event detector of the trigger model to the detected state.

Example

```
scan.trigger.arm.set()
```

Sets the arm event detector to the detected state.

Also see

[scan.trigger.arm.clear\(\)](#) (on page 8-336)
[scan.trigger.arm.stimulus](#) (on page 8-337)
[Trigger model](#) (on page 3-1)
[Scanning and triggering](#) (on page 3-1)

scan.trigger.arm.stimulus

This attribute determines which event starts the scan.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Instrument reset Recall setup Scan reset	Create configuration script Save setup	0

Usage

```
eventID = scan.trigger.arm.stimulus  
scan.trigger.arm.stimulus = eventID
```

```
eventID
```

Trigger stimulus used for the channel action (arm layer); see **Details**

Details

This attribute selects which events cause the arm event detector to enter the detected state.

Set this attribute to 0 to start the scan without waiting for an event.

eventID may be one of the following trigger event IDs.

Trigger event IDs	
Trigger event ID	Description
<code>channel.trigger[N].EVENT_ID</code> or 41 to 48	The trigger event generated by the channel trigger <i>N</i> .
<code>digio.trigger[N].EVENT_ID</code> or 1 to 14	An edge (either rising, falling, or either based on the configuration of the line) on the digital input line.
<code>display.trigger.EVENT_ID</code> or 39	The trigger key (TRIG) on the front panel is pressed.
<code>dmm.trigger.EVENT_LIMIT1_HIGH</code> or 53	A DMM trigger event that indicates a measurement has exceeded the high limit value on limit 1.
<code>dmm.trigger.EVENT_LIMIT1_LOW</code> or 52	A DMM trigger event that indicates a measurement has exceeded the low limit value on limit 1.
<code>dmm.trigger.EVENT_LIMIT2_HIGH</code> or 55	A DMM trigger event that indicates a measurement has exceeded the high limit value on limit 2.
<code>dmm.trigger.EVENT_LIMIT2_LOW</code> or 54	A DMM trigger event that indicates a measurement has exceeded the low limit value on limit 2.
<code>trigger.EVENT_ID</code> or 40	A *trg message on the active command interface. If GPIB is the active command interface, a GET message also generates this event.
<code>trigger.blender[N].EVENT_ID</code> or 58 to 59	A combination of events has occurred.
<code>trigger.timer[N].EVENT_ID</code> or 20 to 23	A delay expired.
<code>tsplink.trigger[N].EVENT_ID</code> or 17 to 19	An edge (either rising, falling, or either based on the configuration of the line) on the TSP-Link trigger line.
<code>lan.trigger[N].EVENT_ID</code> or 29 to 36	A LAN trigger event has occurred.
<code>scan.trigger.EVENT_SCAN_READY</code> or 24	Scan ready event.
<code>scan.trigger.EVENT_SCAN_START</code> or 25	Scan start event.
<code>scan.trigger.EVENT_CHANNEL_READY</code> or 28	Channel ready event.
<code>scan.trigger.EVENT_MEASURE_COMP</code> or 56	Measure complete event.
<code>scan.trigger.EVENT_SEQUENCE_COMP</code> or 50	Sequence complete event.
<code>scan.trigger.EVENT_SCAN_COMP</code> or 26	Scan complete event.
<code>scan.trigger.EVENT_IDLE</code> or 27	Idle event.
<code>schedule.alarm[N].EVENT_ID</code> or 37 to 38	Trigger event generated by the alarm <i>N</i> .

NOTE

Use one of the text trigger event IDs (for example, `digio.trigger[N].EVENT_ID`) to set the stimulus value rather than the numeric value. Doing this will make the code compatible for future upgrades.

Example 1

```
scan.trigger.arm.stimulus =
  scan.trigger.EVENT_SCAN_READY
```

Sets trigger stimulus of the arm event detector to scan ready event.

Example 2

```
scan.trigger.arm.stimulus = 0
```

The scan begins immediately.

Example 3

```
scan.trigger.arm.stimulus = digio.trigger[3].EVENT_ID
```

The scan begins when the instrument receives a signal from digital I/O line 3.

Also see

[scan.trigger.arm.clear\(\)](#) (on page 8-336)

[scan.trigger.arm.set\(\)](#) (on page 8-337)

[Trigger model](#) (on page 3-1)

[Scanning and triggering](#) (on page 3-1)

scan.trigger.channel.clear()

This function clears the channel event detector.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
scan.trigger.channel.clear()
```

Details

This function clears the channel event detector of the trigger model (sets it to the undetected state).

Example

```
scan.trigger.channel.clear()
```

Clears the channel event detector.

Also see

[scan.trigger.channel.set\(\)](#) (on page 8-340)

[scan.trigger.channel.stimulus](#) (on page 8-340)

[Trigger model](#) (on page 3-1)

[Scanning and triggering](#) (on page 3-1)

scan.trigger.channel.set()

This function sets the channel event detector to the detected state.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
scan.trigger.channel.set()
```

Details

This function sets the channel event detector of the trigger model to the detected state.

Example

```
scan.trigger.channel.set()
```

Sets the channel event detector of the trigger model to the detected state.

Also see

[scan.trigger.channel.clear\(\)](#) (on page 8-339)
[scan.trigger.channel.stimulus](#) (on page 8-340)
[Trigger model](#) (on page 3-1)
[Scanning and triggering](#) (on page 3-1)

scan.trigger.channel.stimulus

This attribute determines which trigger events cause the channel actions to occur.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Instrument reset Recall setup Scan reset	Create configuration script Save setup	50 (scan.trigger.EVENT_SEQUENCE_COMP)

Usage

```
eventID = scan.trigger.channel.stimulus  
scan.trigger.channel.stimulus = eventID
```

```
eventID
```

Trigger stimulus used for the channel action; see **Details** for possible trigger event IDs

Details

This attribute selects which events cause the channel event detector to enter the detected state. Set this attribute to 0 to start the channel action immediately at the default setting.

Set *eventID* to one of the existing trigger event IDs shown in the following table.

Trigger event IDs	
Trigger event ID	Description
<code>channel.trigger[N].EVENT_ID</code> or 41 to 48	The trigger event generated by the channel trigger <i>N</i> .
<code>digio.trigger[N].EVENT_ID</code> or 1 to 14	An edge (either rising, falling, or either based on the configuration of the line) on the digital input line.
<code>display.trigger.EVENT_ID</code> or 39	The trigger key (TRIG) on the front panel is pressed.
<code>dmm.trigger.EVENT_LIMIT1_HIGH</code> or 53	A DMM trigger event that indicates a measurement has exceed the high limit value on limit 1.
<code>dmm.trigger.EVENT_LIMIT1_LOW</code> or 52	A DMM trigger event that indicates a measurement has exceed the low limit value on limit 1.
<code>dmm.trigger.EVENT_LIMIT2_HIGH</code> or 55	A DMM trigger event that indicates a measurement has exceed the high limit value on limit 2.
<code>dmm.trigger.EVENT_LIMIT2_LOW</code> or 54	A DMM trigger event that indicates a measurement has exceed the low limit value on limit 2.
<code>trigger.EVENT_ID</code> or 40	A *trg message on the active command interface. If GPIB is the active command interface, a GET message also generates this event.
<code>trigger.blender[N].EVENT_ID</code> or 58 to 59	A combination of events has occurred.
<code>trigger.timer[N].EVENT_ID</code> or 20 to 23	A delay expired.
<code>tsplink.trigger[N].EVENT_ID</code> or 17 to 19	An edge (either rising, falling, or either based on the configuration of the line) on the TSP-Link trigger line.
<code>lan.trigger[N].EVENT_ID</code> or 29 to 36	A LAN trigger event has occurred.
<code>scan.trigger.EVENT_SCAN_READY</code> or 24	Scan ready event.
<code>scan.trigger.EVENT_SCAN_START</code> or 25	Scan start event.
<code>scan.trigger.EVENT_CHANNEL_READY</code> or 28	Channel ready event.
<code>scan.trigger.EVENT_MEASURE_COMP</code> or 56	Measure complete event.
<code>scan.trigger.EVENT_SEQUENCE_COMP</code> or 50	Sequence complete event.
<code>scan.trigger.EVENT_SCAN_COMP</code> or 26	Scan complete event.
<code>scan.trigger.EVENT_IDLE</code> or 27	Idle event.
<code>schedule.alarm[N].EVENT_ID</code> or 37 to 38	Trigger event generated by the alarm <i>N</i> .

NOTE

Use one of the text trigger event IDs (for example, `digio.trigger[N].EVENT_ID`) to set the stimulus value rather than the numeric value. Doing this will make the code compatible for future upgrades.

Example 1

```
scan.trigger.channel.stimulus =
scan.trigger.EVENT_SCAN_START
```

Sets the trigger stimulus of the channel event detector to scan start event.

Example 2

```
scan.trigger.channel.stimulus = 0
print(scan.trigger.channel.stimulus)
```

Starts the channel action immediately after the Scan Start Event. This also resets the stimulus to the default.
Output:
5.000000000e+01

Also see

[scan.trigger.channel.clear\(\)](#) (on page 8-339)
[scan.trigger.channel.set\(\)](#) (on page 8-340)
[Trigger model](#) (on page 3-1)
[Scanning and triggering](#) (on page 3-1)

scan.trigger.clear()

This function clears the trigger model.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
scan.trigger.clear()
```

Details

This function sets the arm, channel, measure, and sequence event detectors of the trigger model to the undetected state.

Example

```
scan.trigger.clear()
```

Clears the trigger model.

Also see

[scan.trigger.channel.set\(\)](#) (on page 8-340)
[scan.trigger.channel.stimulus](#) (on page 8-340)
[Trigger model](#) (on page 3-1)
[Scanning and triggering](#) (on page 3-1)

scan.trigger.measure.clear()

This function clears the measure event detector.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
scan.trigger.measure.clear()
```

Details

This function sets the measure event detector of the trigger model to the undetected state.

Example

```
scan.trigger.measure.clear()
```

Clears the measure event detector.

Also see

[Scanning and triggering](#) (on page 3-1)

scan.trigger.measure.set()

This function sets the measure event detector to the detected state.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
scan.trigger.measure.set()
```

Details

This function sets the measure event detector of the trigger model to the detected state.

Example

```
scan.trigger.measure.set()
```

Sets the measure event detector to the detected state.

Also see

[Scanning and triggering](#) (on page 3-1)

scan.trigger.measure.stimulus

This attribute selects the trigger stimulus of the event detector trigger.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Instrument reset Recall setup Scan reset	Create configuration script Save setup	0

Usage

```
eventID = scan.trigger.measure.stimulus
scan.trigger.measure.stimulus = eventID
```

<i>eventID</i>	The trigger stimulus that is used for the measure event
----------------	---

Details

This attribute selects the events that will cause the measure event detector to enter the detected state. You can use this to pace each one of the measure count readings with an event.

To pace all readings by a single event, use `scan.trigger.sequence.stimulus`.

To bypass waiting for an event, set this to 0.

eventID can be set to one of the existing trigger event IDs, shown in the following table.

Trigger event IDs	
Trigger event ID	Description
channel.trigger[N].EVENT_ID or 41 to 48	The trigger event generated by the channel trigger <i>N</i> .
digio.trigger[N].EVENT_ID or 1 to 14	An edge (either rising, falling, or either based on the configuration of the line) on the digital input line.
display.trigger.EVENT_ID or 39	The trigger key (TRIG) on the front panel is pressed.
dmm.trigger.EVENT_LIMIT1_HIGH or 53	A DMM trigger event that indicates a measurement has exceed the high limit value on limit 1.
dmm.trigger.EVENT_LIMIT1_LOW or 52	A DMM trigger event that indicates a measurement has exceed the low limit value on limit 1.
dmm.trigger.EVENT_LIMIT2_HIGH or 55	A DMM trigger event that indicates a measurement has exceed the high limit value on limit 2.
dmm.trigger.EVENT_LIMIT2_LOW or 54	A DMM trigger event that indicates a measurement has exceed the low limit value on limit 2.
trigger.EVENT_ID or 40	A *trg message on the active command interface. If GPIB is the active command interface, a GET message also generates this event.
trigger.blender[N].EVENT_ID or 58 to 59	A combination of events has occurred.
trigger.timer[N].EVENT_ID or 20 to 23	A delay expired.
tsplink.trigger[N].EVENT_ID or 17 to 19	An edge (either rising, falling, or either based on the configuration of the line) on the TSP-Link trigger line.
lan.trigger[N].EVENT_ID or 29 to 36	A LAN trigger event has occurred.
scan.trigger.EVENT_SCAN_READY or 24	Scan ready event.
scan.trigger.EVENT_SCAN_START or 25	Scan start event.

<code>scan.trigger.EVENT_CHANNEL_READY</code> or 28	Channel ready event.
<code>scan.trigger.EVENT_MEASURE_COMP</code> or 56	Measure complete event.
<code>scan.trigger.EVENT_SEQUENCE_COMP</code> or 50	Sequence complete event.
<code>scan.trigger.EVENT_SCAN_COMP</code> or 26	Scan complete event.
<code>scan.trigger.EVENT_IDLE</code> or 27	Idle event.
<code>schedule.alarm[N].EVENT_ID</code> or 37 to 38	Trigger event generated by the alarm <i>N</i> .

NOTE

Use one of the text trigger event IDs (for example, `digio.trigger[N].EVENT_ID`) to set the stimulus value rather than the numeric value. Doing this will make the code compatible for future upgrades.

Example

```
scan.trigger.measure.stimulus = scan.trigger.EVENT_CHANNEL_READY
```

Sets the trigger stimulus of the measure event detector to the channel ready event.

Also see

[scan.trigger.sequence.stimulus](#) (on page 8-347)
[Scanning and triggering](#) (on page 3-1)

scan.trigger.sequence.clear()

This function clears the sequence event detector.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
scan.trigger.sequence.clear()
```

Details

This function sets the sequence event detector to the undetected state.

Example

```
scan.trigger.sequence.clear()
```

Clears the sequence event detector.

Also see

[Scanning and triggering](#) (on page 3-1)

scan.trigger.sequence.set()

This function sets the sequence even detector to the detected state.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
scan.trigger.sequence.set()
```

Details

This function sets the sequence event detector to the detected state.

Example

```
scan.trigger.sequence.set()
```

Sets the sequence event detector to the detected state.

Also see

[scan.trigger.sequence.clear\(\)](#) (on page 8-345)

[Scanning and triggering](#) (on page 3-1)

scan.trigger.sequence.stimulus

This attribute selects the trigger stimulus for the sequence event detector.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Instrument reset Recall setup Scan reset	Create configuration script Save setup	28 (scan.trigger.EVENT_CHANNEL_READY)

Usage

```
eventID = scan.trigger.sequence.stimulus
scan.trigger.sequence.stimulus = eventID
```

<i>eventID</i>	The trigger stimulus that is used for the sequence event
----------------	--

Details

This attribute selects the events that cause the sequence event detector to enter the detected state.

Use this to start a set of measure count readings that are triggered by a single event.

To pace each reading by an event, use `scan.trigger.measure.stimulus`.

To bypass pacing the readings, set this to 0.

Set *eventID* to one of the existing trigger event IDs shown in the following table.

Trigger event IDs	
Trigger event ID	Description
channel.trigger[N].EVENT_ID or 41 to 48	The trigger event generated by the channel trigger <i>N</i> .
digio.trigger[N].EVENT_ID or 1 to 14	An edge (either rising, falling, or either based on the configuration of the line) on the digital input line.
display.trigger.EVENT_ID or 39	The trigger key (TRIG) on the front panel is pressed.
dmm.trigger.EVENT_LIMIT1_HIGH or 53	A DMM trigger event that indicates a measurement has exceed the high limit value on limit 1.
dmm.trigger.EVENT_LIMIT1_LOW or 52	A DMM trigger event that indicates a measurement has exceed the low limit value on limit 1.
dmm.trigger.EVENT_LIMIT2_HIGH or 55	A DMM trigger event that indicates a measurement has exceed the high limit value on limit 2.
dmm.trigger.EVENT_LIMIT2_LOW or 54	A DMM trigger event that indicates a measurement has exceed the low limit value on limit 2.
trigger.EVENT_ID or 40	A *trg message on the active command interface. If GPIB is the active command interface, a GET message also generates this event.
trigger.blender[N].EVENT_ID or 58 to 59	A combination of events has occurred.
trigger.timer[N].EVENT_ID or 20 to 23	A delay expired.
tsplink.trigger[N].EVENT_ID or 17 to 19	An edge (either rising, falling, or either based on the configuration of the line) on the TSP-Link trigger line.
lan.trigger[N].EVENT_ID or 29 to 36	A LAN trigger event has occurred.
scan.trigger.EVENT_SCAN_READY or 24	Scan ready event.
scan.trigger.EVENT_SCAN_START or 25	Scan start event.

<code>scan.trigger.EVENT_CHANNEL_READY</code> or 28	Channel ready event.
<code>scan.trigger.EVENT_MEASURE_COMP</code> or 56	Measure complete event.
<code>scan.trigger.EVENT_SEQUENCE_COMP</code> or 50	Sequence complete event.
<code>scan.trigger.EVENT_SCAN_COMP</code> or 26	Scan complete event.
<code>scan.trigger.EVENT_IDLE</code> or 27	Idle event.
<code>schedule.alarm[N].EVENT_ID</code> or 37 to 38	Trigger event generated by the alarm <i>N</i> .

NOTE

Use one of the text trigger event IDs (for example, `digio.trigger[N].EVENT_ID`) to set the stimulus value rather than the numeric value. Doing this will make the code compatible for future upgrades.

Example

```
scan.trigger.sequence.stimulus = scan.trigger.EVENT_CHANNEL_READY
```

Sets the trigger stimulus of the sequence event detector to the channel ready event.

Also see

[scan.trigger.measure.stimulus](#) (on page 8-344)
[Scanning and triggering](#) (on page 3-1)

schedule.alarm[N].enable

This attribute enables or disables an alarm.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset Recall setup	NOt saved	0 (schedule.OFF)

Usage

```
state = schedule.alarm[N].enable
schedule.alarm[N].enable = state
```

<i>state</i>	Disable the alarm (schedule.OFF or 0) Enable the alarm (schedule.ON or 1)
<i>N</i>	Alarm number (1 or 2)

Details

If you enable an alarm that has a start time that is in the past, the alarm executes immediately.

If an alarm time in the past is used to start a scan, the alarm time may be missed by the scan start. This can occur because the scan clears any pending triggers before it begins, so it will miss any trigger generated from the alarm enable. To prevent a missed alarm, start the scan in the background, then enable the alarm.

Example

```
schedule.alarm[1].enable = 1
```

Enables alarm 1.

Also see

[schedule.alarm\[N\].EVENT_ID](#) (on page 8-350)
[schedule.alarm\[N\].fractionalseconds](#) (on page 8-351)
[schedule.alarm\[N\].period](#) (on page 8-352)
[schedule.alarm\[N\].ptpseconds](#) (on page 8-352)
[schedule.alarm\[N\].repetition](#) (on page 8-353)
[schedule.alarm\[N\].seconds](#) (on page 8-354)
[schedule.disable\(\)](#) (on page 8-354)

schedule.alarm[N].EVENT_ID

This constant describes the trigger event generated by the alarm *N*.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Constant	Yes			

Usage

```
eventID = schedule.alarm[N].EVENT_ID
```

<i>eventID</i>	The trigger event number
<i>N</i>	Alarm number (1 or 2)

Details

To have another trigger object respond to trigger events generated by the schedule alarm, set the other object's stimulus attribute to the value of this constant.

Example

```
scan.trigger.arm.stimulus =
  schedule.alarm[1].EVENT_ID
```

Uses a trigger event on alarm 1 to be the stimulus for the trigger arm.

Also see

None

schedule.alarm[N].fractionalseconds

This attribute describes the fractional seconds portion of the alarm time.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset	Not saved	0

Usage

```
schedule.alarm[N].fractionalseconds = fraction
fraction = schedule.alarm[N].fractionalseconds
```

<i>N</i>	Alarm number (1 or 2)
<i>fraction</i>	The fractional seconds portion of the alarm time

Details

1588 has too much resolution to represent in a single floating point value so the alarm times are split into two values (seconds and fractional seconds).

Example

```
-- get current time and store in variable sec
sec = os.time()
-- set alarm 1 seconds to be 1 minute after current time
schedule.alarm[1].seconds = sec + 60
-- set alarm 1 fractional seconds to be 0.5
schedule.alarm[1].fractionalseconds = 0.5
print("value of sec is ", sec)
print("value of alarm 1 seconds is ", schedule.alarm[1].seconds)
print("value of alarm 1 fractional seconds is ",
      schedule.alarm[1].fractionalseconds)
```

Create an alarm to occur 60.5 seconds from current time in UTC seconds.

Output:

```
value of sec is      1.306405866e+009
value of alarm 1 seconds is      1.306405926e+009
value of alarm 1 fractional seconds is 5.000000000e-001
```

Also see

[schedule.alarm\[N\].seconds](#) (on page 8-354)

schedule.alarm[N].period

This attribute describes the time, in seconds, between adjacent firings of the alarm.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset Recall setup	Create configuration script Save setup	0

Usage

```
value = schedule.alarm[N].period
schedule.alarm[N].period = value
```

<i>N</i>	Alarm number (1 or 2)
<i>value</i>	The time in seconds

Example

```
schedule.alarm[1].period = 0.5
```

Set a period of 0.5 seconds between firings of alarms after the initial alarm.

Also see

None

schedule.alarm[N].ptpseconds

The seconds portion of the alarm time in PTP seconds.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset	Not saved	0

Usage

```
schedule.alarm[N].ptpseconds = seconds
seconds = schedule.alarm[N].ptpseconds
```

<i>N</i>	Alarm (1 or 2)
<i>seconds</i>	The seconds portion of the alarm time in PTP seconds

Details

1588 has too much resolution to represent in a single floating point value, so the alarm times are split into two values (seconds and fractional seconds).

Example

```
sec,ns = ptp.time()
schedule.alarm[1].ptpseconds = sec + 30
```

Create an alarm to occur 30 seconds from current time in PTP seconds.

Also see

[ptp.utcoffset](#) (on page 8-316)

schedule.alarm[N].repetition

This attribute describes the number of times an alarm repeats after the first alarm firing.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset Recall setup	Save setup	0

Usage

```
count = schedule.alarm[N].repetition
schedule.alarm[N].repetition = count
```

<i>count</i>	The number of repetitions
<i>N</i>	Alarm 1 or 2

Details

The alarm will fire a total of `count+1` times. If 0 and period is non-zero, the alarm fires forever. Once an alarm begins, the repetition counts down for each trigger generated. It ends at zero (0). You must set this repetition back to some value if you intend to reissue the alarm. Otherwise, the alarm will either not fire (if the period is zero) or fire forever (if period is non-zero).

Example

```
schedule.alarm[1].repetition = 10
```

Set the alarm to fire 10 times.

Also see

[schedule.alarm\[N\].enable](#) (on page 8-349)

schedule.alarm[N].seconds

The seconds portion of the alarm time in UTC seconds.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset	Not saved	0

Usage

```
value = schedule.alarm[N].seconds
schedule.alarm[N].seconds = value
```

<i>value</i>	Seconds portion of the alarm time in UTC seconds
<i>N</i>	Alarm number (1 or 2)

Details

1588 has too much resolution to represent in a single floating point value, so the alarm times are split into two values (seconds and fractional seconds).

Example

```
local l_myTime
l_myTime = os.time{year = 2008, month = 3, day = 15, hour = 10}
schedule.alarm[1].seconds = l_myTime
```

Create an alarm to occur on March 15, 2008 at 10 am in UTC seconds.

Also see

[ptp.utcoffset](#) (on page 8-316)

schedule.disable()

This function disables all alarms.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
schedule.disable()
```

Details

This command sets the `schedule.alarm[N].enable` attribute to 0 (`schedule.OFF`) for each schedule alarm *N*.

Also see

[schedule.alarm\[N\].enable](#) (on page 8-349)

script.anonymous

This is a reference to the anonymous script.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	No	See Details	See Details	Not applicable

Usage

```
scriptVar = script.anonymous
```

<code>scriptVar</code>	The name of the variable that references the script
------------------------	---

Details

You can use the `script.anonymous` script like any other script. Also, you can save the anonymous script as a user script by giving it a name.

This script is replaced by loading a script with the `loadscript` or `loadandruncscript` commands when they are used without a name.

Example 1

<pre>script.anonymous.list()</pre>	Displays the content of the anonymous script.
------------------------------------	---

Example 2

<pre>print(script.anonymous.source)</pre>	Retrieves the source of the anonymous script.
---	---

Also see

[Anonymous scripts](#) (on page 7-3)
[scriptVar.autorun](#) (on page 8-360)
[scriptVar.list\(\)](#) (on page 8-361)
[scriptVar.name](#) (on page 8-361)
[scriptVar.run\(\)](#) (on page 8-362)
[scriptVar.save\(\)](#) (on page 8-363)
[scriptVar.source](#) (on page 8-363)

script.delete()

This function deletes a script from nonvolatile memory.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
script.delete(scriptName)
```

<code>scriptName</code>	The string that represents the name of the script
-------------------------	---

Example

<pre>script.delete("test8")</pre>	Deletes a user script named "test8" from nonvolatile memory.
-----------------------------------	--

Also see

[Delete user scripts](#) (on page 7-10)
[Delete user scripts from the instrument](#) (on page 7-43)
[scriptVar.save\(\)](#) (on page 8-363)

script.load()

This function creates a script from a specified file.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
scriptVar = script.load(file)
scriptVar = script.load(file, name)
```

<i>scriptVar</i>	The created script. This is <code>nil</code> if an error is encountered
<i>file</i>	The path and file name of the script file to load
<i>name</i>	The name of the script to be created

Details

The file path may be absolute or relative to the current working directory. The root folder of the USB flash drive has the absolute path `"/usb1/"`. Both the forward slash (`/`) and backslash (`\`) are supported as directory separators.

The file to be loaded must start with the `loadscript` or `loadandrunscript` keywords, contain the body of the script, and end with the `endscript` keyword.

Script naming:

- If the *name* parameter is an empty string, or *name* is absent (or `nil`) and the script name cannot be extracted from the file, *scriptVar* is the only handle to the created script.
- If *name* is given (and not `nil`), any script name embedded in the file is ignored.
- If *name* conflicts with the name of an existing script in the `script.user.scripts` table, the existing script's name attribute is set to an empty string before it is replaced in the `script.user.scripts` table by the new script.
- If *name* is absent or `nil`, the command attempts to extract the name of the script from the file. Any conflict between the extracted name and that of an existing script in the `scripts` table generates an error. If the script name cannot be extracted, the created script's name attribute is initialized to the empty string, and must be set to a valid nonempty string before saving the script to nonvolatile memory.

Example

<pre>myTest8 = script.load("/usb1/filename.tsp", "myTest8")</pre>	Loads the script myTest8 from the USB flash drive.
---	--

Also see

[script.new\(\)](#) (on page 8-357)

script.new()

This function creates a script.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
scriptVar = script.new(code)
scriptVar = script.new(code, name)
```

<i>scriptVar</i>	The name of the variable that will reference the script
<i>code</i>	A string containing the body of the script
<i>name</i>	The name of the script

Details

The *name* parameter is the name that is added to the `script.user.scripts` table. If *name* is not given, an empty string will be used, and the script will be unnamed. If the name already exists in `script.user.scripts`, the existing script's *name* attribute is set to an empty string before it is replaced by the new script.

Note that *name* is the value that is used for the instrument front panel display. If this value is not defined, the script will not be available from the instrument front panel.

You must save the new script into nonvolatile memory to keep it when the instrument is turned off.

Example 1

```
myTest8 = script.new(
    "display.clear() display.settext('Hello from myTest8')", "myTest8")
myTest8()
```

Creates a new script referenced by the variable `myTest8` with the name "myTest8".
Runs the script. The instrument displays "Hello from myTest8".

Example 2

```
autoexec = script.new(
    "display.clear() display.settext('Hello from autoexec')", 'autoexec')
```

Creates a new autoexec script that clears the display when the instrument is turned on and displays "Hello from autoexec".

Also see

[Create a script using the script.new\(\) command](#) (on page 7-38)
[Global variables and the script.user.scripts table](#) (on page 7-37)
[Named scripts](#) (on page 7-4)
[scriptVar.save\(\)](#) (on page 8-363)
[script.newautorun\(\)](#) (on page 8-358)

script.newautorun()

This function is identical to the `script.new()` function, but it creates a script with the `autorun` attribute set to "yes".

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
scriptVar = script.newautorun(code)
scriptVar = script.newautorun(code, name)
```

<i>scriptVar</i>	The name of the variable that will reference the script
<i>code</i>	A string containing the body of the script
<i>name</i>	The name of the script

Details

The `script.newautorun()` function is identical to the `script.new()` function, except that the `autorun` attribute of the script is set to `yes`. This causes the script to automatically run immediately after it is created.

Example

```
NewAuto = script.newautorun("print('Hello from new auto run command')",
    'NewAuto')
print(NewAuto.autorun)
print(NewAuto.name)
```

Creates a new script called `NewAuto` that automatically has the `autorun` attribute set to `yes` after it is created. The `name` attribute's value is set to "NewAuto".

Output:

```
Hello from new auto run command
yes
NewAuto
```

Also see

[Create a script using the `script.new\(\)` command](#) (on page 7-38)
[Global variables and the `script.user.scripts` table](#) (on page 7-37)
[Named scripts](#) (on page 7-4)
[scriptVar.save\(\)](#) (on page 8-363)
[script.new\(\)](#) (on page 8-357)

script.restore()

This function restores a script that was removed from the runtime environment.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
script.restore(name)
```

<i>name</i>	The name of the script to be restored
-------------	---------------------------------------

Details

This command copies the script from nonvolatile memory back into the runtime environment, and it creates a global variable with the same name as the name of the script.

Example

```
script.restore("test9")
```

Restores a script named "test9" from nonvolatile memory.

Also see

[script.delete\(\)](#) (on page 8-355)

script.run()

This function runs the anonymous script.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
script.run()
run()
```

Details

Each time the `script.run()` command is given, the anonymous script is executed. This script can be run using this command many times without having to re-send it.

Example

```
run()
```

Runs the anonymous script.

Also see

[script.anonymous](#) (on page 8-354)

script.user.catalog()

This function returns an iterator that can be used in a `for` loop to iterate over all the scripts stored in nonvolatile memory.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
for name in script.user.catalog() do body end
```

<i>name</i>	String representing the name of the script
<i>body</i>	Code that implements the body of the <code>for</code> loop to process the names in the catalog

Details

Accessing the catalog of scripts stored in nonvolatile memory allows you to process all scripts in nonvolatile memory. The entries will be enumerated in no particular order.

Each time the body of the function executes, *name* takes on the name of one of the scripts stored in nonvolatile memory. The `for` loop repeats until all scripts have been iterated.

Example

```
for name in script.user.catalog() do
  print(name)
end
```

Retrieve the catalog listing for user scripts.

Also see

None

scriptVar.autorun

This attribute controls the autorun state of a script.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	No	Not applicable	See Details	See Details

Usage

```
scriptVar.autorun = state
state = scriptVar.autorun
```

<i>scriptVar</i>	The name of the variable that references the script
<i>state</i>	Whether or not the script runs automatically when powered on: <ul style="list-style-type: none"> "yes" (script runs automatically) "no" (script does not run automatically)

Details

Autorun scripts run automatically when the instrument is turned on. You can set any number of scripts to autorun.

The run order for autorun scripts is arbitrary, so make sure the run order is not important.

The default value for `scriptVar.autorun` depends on how the script was loaded. The default is "no" if the script was loaded with `loadscript` or `script.new()`. It is "yes" for scripts loaded with `loadandrunscript` or `script.newautorun()`.

NOTE

Make sure to save the script in nonvolatile memory after setting the `autorun` attribute so that the instrument will retain the setting.

Example

```
test5.autorun = "yes"
test5.save ()
```

Assume a script named "test5" is in the runtime environment. The next time the instrument is turned on, "test5" script automatically loads and runs.

Also see

None

scriptVar.list()

This function generates a script listing.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
scriptVar.list ()
```

<i>scriptVar</i>	The name of variable that references the script
------------------	---

Details

This function generates output in the form of a sequence of response messages (one message for each line of the script). It also generates output of the script control messages (`loadscript` or `loadandrunscript`, and `endscript`).

Example

```
test7 = script.new("display.clear() display.settext('Hello from my test')",
  "test7")
test7 ()
test7.save ()
test7.list ()
```

The above example code creates a script named "test7" that displays text on the front panel, lists the script with the following output:

```
loadscript test7
display.clear() display.settext('Hello from my test')
endscript
```

Also see

[Load a script by sending commands over the remote interface](#) (on page 7-4)

[Retrieve source code one line at a time](#) (on page 7-8)

scriptVar.name

This attribute contains the name of a script in the runtime environment.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	No	Not applicable	Not applicable	Not applicable

Usage

```
scriptVar.name = scriptName
scriptName = scriptVar.name
```

<i>scriptVar</i>	Name of the variable that references the script
<i>scriptName</i>	A string that represents the name of the script

Details

When setting the script name, this attribute renames the script that the variable *scriptVar* references.

This attribute must be either a valid Lua identifier or the empty string. Changing the name of a script changes the index used to access the script in the `script.user.scripts` table. Setting the attribute to an empty string removes the script from the table completely, and the script becomes an unnamed script.

As long as there are variables referencing an unnamed script, the script can be accessed through those variables. When all variables that reference an unnamed script are removed, the script will be removed from the run-time environment.

If the new name is the same as a name that is already used for another script, the name of the other script is set to an empty string, and that script becomes unnamed.

NOTE

Changing the name of a script does not change the name of any variables that reference that script. The variables will still reference the script, but the names of the script and variables may not match.

Example

```
test7 = script.new("display.clear() display.settext('Hello from my test')", "")
test7()
print(test7.name)

test7.name = "test7"
print(test7.name)

test7.save()
```

The above example calls the `script.new()` function to create a script with no name, runs the script, names the script "test7", and then saves the script in nonvolatile memory.

Also see

[script.new\(\)](#) (on page 8-357)

[scriptVar.save\(\)](#) (on page 8-363)

[Rename a script](#) (on page 7-41)

scriptVar.run()

This function runs a script.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
scriptVar.run()
scriptVar()
```

<i>scriptVar</i>	The name of variable that references the script
------------------	---

Details

The `scriptVar.run()` function runs the script; you can also run the script by using `scriptVar()`.

Example

```
test8.run()
```

Runs the script referenced by the variable `test8`.

Also see

None

scriptVar.save()

This function saves the script to nonvolatile memory or to a USB flash drive.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
scriptVar.save()
scriptVar.save(filename)
```

<code>scriptVar</code>	The name of variable that references the script
<code>filename</code>	The file name to use when saving the script to a USB flash drive

Details

The `scriptVar.save()` function only saves a script to nonvolatile memory or a USB flash drive.

If no `filename` is given, the script will be saved to internal nonvolatile memory. Only a named script (the script's name attribute is not an empty string) can be saved to internal nonvolatile memory. If a `filename` is given, the script will be saved to the USB flash drive.

You are not required to add the file extension, but if you would like to, the only allowed extension is `.tsp` (see Example 2).

Example 1

```
test8.save()
```

Saves the script referenced by the variable `test8` to nonvolatile memory.

Example 2

```
test8.save("/usb1/myScript.tsp")
```

Saves the script referenced by the variable `test8` to a file named `myScript.tsp` on your flash drive.

Also see

[Save a user script](#) (on page 7-10)

scriptVar.source

This attribute holds the source code of a script.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW) (see Details)	No	Not applicable	Not saved	Not applicable

Usage

```
code = scriptVar.source
scriptVar.source = nil
```

<i>scriptVar</i>	The name of the variable that references the script that contains the source code
<i>code</i>	The body of the script

Details

The `loadscript` or `loadandruncscript` and `endscript` keywords are not included in the source code.

The body of the script is a single string with lines separated by the new line character.

The instrument automatically keeps the source for all scripts loaded on the instrument. To free up memory or to obfuscate the code, assign `nil` to the source attribute of the script. Although this attribute is writable, it can only be set to the `nil` value.

Example

```
test7 = script.new("display.clear() display.settext('Hello from my test')", "")
print(test7.source)
```

The above example creates a script called "test7" that displays a message on the front panel.

Retrieve the source code.

Output:

```
display.clear() display.settext('Hello from my test')
```

Also see

[scriptVar.list\(\)](#) (on page 8-361)

settime()

This function sets the real-time clock (sets current time of the system).

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
settime(time)
```

<i>time</i>	The time in seconds since January 1, 1970 UTC
-------------	---

Details

This function sets the date and time of the instrument based on the *time* parameter (specified in UTC time). UTC time is specified as the number of seconds since Jan 1, 1970, UTC. You can use UTC time from a local time specification, or you can use UTC time from another source (for example, your computer).

To use the Lua `os.time()` function to generate a time value in UTC time, use the following format:

```
os.time({year = year, month = month, day = day, hour = hour, min = min, sec = sec})
```

Where:

year = A full year (2006 or later)
month = The desired month (1 to 12)
day = The desired day (1 to 31)
hour = The desired hour (00 to 23)
min = The desired minute (00 to 59)
sec = The desired second (00 to 59)

When you are using the `os.time()` function, make sure that you include the *year*, *month*, and *day* parameters, which are mandatory (the rest are optional). If the other parameters are not used, they default to noon for that day.

Set the time zone before calling the `os.time()` function.

Example

```
systemTime = os.time({year = 2010,
    month = 3,
    day = 31,
    hour = 14,
    min = 25})
settime(systemTime)
```

Sets the date and time to Mar 31, 2010 at 2:25 pm.

Also see

[gettimezone\(\)](#) (on page 8-263)

[settimezone\(\)](#) (on page 8-365)

settimezone()

This function sets the local time zone.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
settimezone(offset)
settimezone(offset, dstOffset, dstStart, dstEnd)
```

<i>offset</i>	String representing offset from UTC
<i>dstOffset</i>	String representing daylight savings offset from UTC
<i>dstStart</i>	String representing when daylight savings time starts
<i>dstEnd</i>	String representing when daylight savings time ends

Details

The time zone is only used when converting between local time and UTC time when using the `os.time()` and `os.date()` functions.

If only one parameter is given, the same time offset is used throughout the year. If four parameters are given, time is adjusted twice during the year for daylight savings time.

offset and *dstOffset* are strings of the form "[+|-]hh[:mm[:ss]]" that indicate how much time must be added to the local time to get UTC time: *hh* is a number between 0 and 23 that represents hours; *mm* is a number between 0 and 59 that represents minutes; *ss* is a number between 0 and 59 that represents seconds. The minutes and seconds fields are optional.

The UTC-5 time zone would be specified with the string "5" because UTC-5 is 5 hours behind UTC and one must add 5 hours to the local time to get UTC time. The time zone UTC4 would be specified as "-4" because UTC4 is 4 hours ahead of UTC and 4 hours must be subtracted from the local time to get UTC.

dstStart and *dstEnd* are strings of the form "MM.w.dw/hh[:mm[:ss]]" that indicate when daylight savings time begins and ends respectively: *MM* is a number between 1 and 12 that represents the month; *w* is a number between 1 and 5 that represents the week within the month; *dw* is a number between 0 and 6 that represents the day of the week (where 0 is Sunday). The rest of the fields represent the time of day that the change takes effect: *hh* represents hours; *mm* represents minutes; *ss* represents seconds. The minutes and seconds fields are optional. The week of the month and day of the week fields are not specific dates.

Example

<code>settimezone("8", "1", "3.3.0/02", "11.2.0/02")</code>	Sets <code>offset</code> to equal +8 hours, +1 hour for DST, starts on Mar 14 at 2:00 a.m, ends on Nov 7 at 2:00 a.m.
<code>settimezone(offset)</code>	Sets local time zone to <code>offset</code> .

Also see

[gettimezone\(\)](#) (on page 8-263)
[settime\(\)](#) (on page 8-364)

setup.cards()

This function returns the card model numbers that are defined for each slot in a saved setup.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
CardModels = setup.cards()
CardModels = setup.cards("/path/filename.set")
```

<i>CardModels</i>	A comma-delimited string listing the card model numbers for each slot
<i>path/filename</i>	The path and name of the file on the flash drive; the path may be absolute or relative to the current working directory; the <code>.set</code> extension must be on the filename

Details

This function returns a comma-delimited string that lists the card model for each slot in the instrument (from 1 to 6) for the desired saved setup. If no card was installed in the slot when the setup was saved, a 0 is returned as the card model number.

Use `CardModels = setup.cards()` to return cards associated with the internally saved setup.

Use `CardModels = setup.cards("/path/filename.set")` to return cards associated with the setup saved on the USB flash drive.

Example 1

<code>CardModels = setup.cards()</code> <code>print(CardModels)</code>	Query the cards associated with the internal saved setup. Output, assuming a Model 3722 card in slot 1: 3722,0,0,0,0,0
<code>print(setup.card("/usb1/mysetup.set")</code> <code>)</code>	Query the cards associated with <code>mysetup.set</code> on the root directory on the flash drive. Output, assuming a Model 3723 on slot 2, Model 3722 on slot 3, and Model 3720 on slot 4: 0,3723,3722,3720,0,0

Example 2

```
print (setup.card ("/usb1/mysetup.set"
))
```

Query the cards associated with setup saved as JulySetup.set on the thumb drive. The following example of output shows that slots 1, 5, and 6 are empty, slot 2 has a Model 3723 installed, slot 3 has a Model 3722 installed and slot 4 has a model 3720 installed:

```
0, 3723, 3722, 3720, 0, 0
```

Also see

[setup.recall\(\)](#) (on page 8-368)

[setup.save\(\)](#) (on page 8-368)

setup.poweron

This attribute specifies which saved setup to recall when the instrument is turned on.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Not applicable	Nonvolatile memory	0

Usage

```
N = setup.poweron
setup.poweron = N
```

<i>N</i>	An integer that specifies the setup to recall when the instrument power is turned on (0 or 1)
----------	---

Details

When $N = 0$, the instrument uses the factory default setup when it is turned on. When N is set to 1, it uses the setup saved with `setup.save()`.

Only setups stored in nonvolatile memory are available (you cannot recall a script from a USB flash drive with this command). To save a script to be used when the instrument is powered on, you can create a configuration script and name it `autoexec`.

Example

```
setup.poweron = 0
```

Set the instrument to use the factory default setup when power is turned on.

Also see

[Start-up \(power-on\) configuration](#) (on page 2-36)

[Save the present configuration](#) (on page 2-100)

[createconfigscript\(\)](#) (on page 8-115)

[setup.save\(\)](#) (on page 8-368)

setup.recall()

This function recalls settings from a saved setup.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
setup.recall(id)
```

id

An integer or string specifying the location of the setup to recall:

- Factory default setup (0)
- User-saved setup in nonvolatile memory (1)
- User-saved setup on a USB flash drive ("*path/filename*")

Details

If the *id* parameter is 1, the internal setup that was saved with `setup.save()` is recalled. If the *id* parameter is 0, the instrument recalls the factory default setup.

When the *id* parameter is a string, it is interpreted as the path and file name of the setup to restore from a file on a USB flash drive. The path may be absolute or relative to the current working directory.

Before a setup is recalled, an instrument reset is performed.

Example 1

```
setup.recall(1)
```

Recall the user-saved setup.

Example 2

```
setup.recall("/usb1/KEITHLEY_30730.set")
```

Recall a user-saved setup stored in a file named KEITHLEY_30730 on a USB flash drive.

Also see

[User setup](#) (on page 2-34)
[setup.save\(\)](#) (on page 8-368)

setup.save()

This function saves the present setup as a user-saved setup.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
setup.save()  
setup.save(id)
```

id

A string that specifies the path and file name to which to save the user setup on a USB flash drive ("*path/filename*")

Details

When the *id* parameter is a string, it is interpreted as the path and file name of the location to save the present setup on a USB flash drive. The path may be absolute or relative to the current working directory.

If you do not specify the *id* parameter, the setup is saved to the instrument's nonvolatile memory. If a previous setup exists, it is overwritten.

You can also create configuration scripts to save setups. See [Save the present configuration](#) (on page 2-100).

Example

```
setup.save()
```

Saves the present setup to the internal memory of the instrument.

Also see

[User setup](#) (on page 2-34)

[createconfigscript\(\)](#) (on page 8-115)

[setup.recall\(\)](#) (on page 8-368)

slot[X].banks.matrix

This attribute describes the number of banks in the matrix for a card.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Never	Not applicable	Not applicable

Usage

```
value = slot[X].banks.matrix
```

<i>value</i>	The number of banks in the matrix
<i>X</i>	The slot number

Details

Returns the number of banks in the matrix on the card in slot *x*. If no matrix or no card exists, it returns nil.

Example

```
print(slot[1].banks.matrix)
```

Returns the number of banks in the matrix on the card in slot 1 (4 banks).

Output:

```
4.000000000e+000
```

Also see

[slot\[X\].columns.matrix](#) (on page 8-370)

slot[X].columns.matrix

This attribute returns the number of columns in the matrix for the card in slot *x*.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
value = slot[X].columns.matrix
```

<i>value</i>	The number of columns in the matrix
<i>X</i>	The slot number

Details

This attribute is only available for a slot if a card is installed and if the installed card supports matrix channels. If matrix channels are not available, the return value is `nil`.

Example

```
print(slot[4].columns.matrix)
```

Returns the number of columns in the matrix on the card in slot 4 (28).
Example output:
2.800000000e+01

Also see

[slot\[X\].banks.matrix](#) (on page 8-369)

[slot\[X\].rows.matrix](#) (on page 8-384)

slot[X].commonsideohms

This attribute indicates whether a card in slot *x* supports commonside 4-wire ohm channels.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
commonsideohms = slot[X].commonsideohms
```

<i>commonsideohms</i>	Indication of whether or not commonside 4-wire ohm channels are supported
<i>X</i>	Slot number (1 to 6)

Details

This attribute is only available for a slot if a card is installed and if the installed card supports commonside 4-wire ohm channels. If the attribute is not available, the return value is `nil`.

If commonside 4-wire ohms channels are supported, the returned value is 1.

Example

```
print(slot[1].commonsideohms)
```

Query if slot 1 supports commonside 4-wire ohms channels.

Also see

None

slot[X].digio

Indicates whether or not a card in slot *x* supports digital I/O channels.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Not applicable	Nonvolatile memory	0

Usage

```
value = slot[X].digio
```

<i>value</i>	Indicator for whether or not the card in the slot supports digital I/O channels
<i>X</i>	Slot number (1 to 6)

Details

This attribute is only available for a slot if a card is installed and if the installed card supports digital I/O channels. If the attribute is not available, the return value is `nil`.

If digital I/O channels are supported, the returned value is 1.

Example

```
print(slot[1].digio)
```

Query if slot 1 supports digital I/O channels.

Also see

slot functions and attributes

slot[X].endchannel.*

These attributes indicates whether or not the channel in slot *x* supports a feature and if so, which channels support the feature.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
value = slot[X].endchannel.amps (channel supports amperage measurements)
```

```
value = slot[X].endchannel.analogoutput (channel supports a digital analog output (DAC))
```

```
value = slot[X].endchannel.digitalio (channel supports digital inputs and outputs)
```

```
value = slot[X].endchannel.isolated (channel supports isolated channels)
```

```
value = slot[X].endchannel.totalizer (channel supports totalizer channels)
```

```
value = slot[X].endchannel.voltage (channel supports voltage or two-wire measurements)
```

<i>value</i>	The channel number of the ending channel of the group of channels that supports the feature
<i>X</i>	Slot number (1 to 6).

Details

This attribute is only available for a slot if a card is installed and if the installed card supports the selected feature. If the attribute is not available, the return value is `nil`.

Channels are grouped by feature sets, so you can use the start and ending channel numbers to identify a group of channels that supports a particular feature. If the card supports the feature, the returned value is the number of the ending channel.

If only one channel in the card supports the feature, the ending channel will match the starting channel number.

Example

```
CardChannels = function(SlotNumber)
  if slot[SlotNumber].idn == "Empty Slot" then
    print("  Slot is Empty")
  else
    if (slot[SlotNumber].startchannel.voltage == nil) and
      (slot[SlotNumber].endchannel.voltage == nil) then
      print("  no voltage channels")
    else
      print("  Start voltage channel is " .. slot[SlotNumber].startchannel.voltage)
      print("  End voltage channel is " .. slot[SlotNumber].endchannel.voltage)
    end

    if (slot[SlotNumber].startchannel.amps == nil) and
      (slot[SlotNumber].endchannel.amps == nil) then
      print("  no amp channels")
    else
      print("  Start amp channel is " .. slot[SlotNumber].startchannel.amps)
      print("  End amp channel is " .. slot[SlotNumber].endchannel.amps)
    end

    if (slot[SlotNumber].digio == 1) then
      print("  Start digital i/o channel is " ..
        slot[SlotNumber].startchannel.digitalio)
      print("  End digital i/o channel is " .. slot[SlotNumber].endchannel.digitalio)
    else
      print("  no digio channels")
    end

    if (slot[SlotNumber].totalizer == 1) then
      print("  Start totalizer channel is " ..
        slot[SlotNumber].startchannel.totalizer)
      print("  End totalizer channel is " .. slot[SlotNumber].endchannel.totalizer)
    else
      print("  no totalizer channels")
    end

    if (slot[SlotNumber].startchannel.analogoutput == nil) and
      (slot[SlotNumber].endchannel.analogoutput == nil) then
      print("  no analog output channels")
    else
      print("  Start analog output channel is " ..
        slot[SlotNumber].startchannel.analogoutput)
      print("  End analog output channel is " ..
        slot[SlotNumber].endchannel.analogoutput)
    end

    if (slot[SlotNumber].matrix == 1) then
      print("  Channels on card are matrix type")
    end
  end
end

for x = 1,6 do
  print("Checking card channels in slot " .. x)
  CardChannels(x)
end
```

If the Series 3700A contains the following cards:

- Slot 1: 3732
- Slot 2: 3720
- Slot 3: 3750
- Slot 4: Empty
- Slot 5: 3721
- Slot 6: Empty

The output of this example is similar to:

```
Checking card channels in slot 1
  no voltage channels
  no amp channels
  no digio channels
  no totalizer channels
  no analog output channels
  Channels on card are matrix type
Checking card channels in slot 2
  Start voltage channel is 1
  End voltage channel is 60
  no amp channels
  no digio channels
  no totalizer channels
  no analog output channels
Checking card channels in slot 3
  no voltage channels
  no amp channels
  Start digital i/o channel is 1
  End digital i/o channel is 5
  Start totalizer channel is 6
  End totalizer channel is 9
  Start analog output channel is 10
  End analog output channel is 11
Checking card channels in slot 4
  Slot is Empty
Checking card channels in slot 5
  Start voltage channel is 1
  End voltage channel is 40
  Start amp channel is 41
  End amp channel is 42
  no digio channels
  no totalizer channels
  no analog output channels
Checking card channels in slot 6
  Slot is Empty
```

Also see

slot functions and attributes
[slot\[X\].startchannel.*](#) (on page 8-384)

slot[X].idn

This attribute returns a string that contains information about the card in slot *x*.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
idnString = slot[X].idn
```

<i>idnString</i>	The return string
<i>X</i>	Slot number (1 to 6)

Details

The information that is returned depends on whether the card in the slot is an actual card or pseudocard.

For actual cards, this returns a comma-separated string that contains the model number, description, firmware revision, and serial number of the card installed in slot *x*.

For pseudocards, the response is *Pseudo*, followed by the model number, description, firmware revision, and ??? for the serial number.

Example

```
print(slot[3].idn)
```

If a Model 3723 is installed in slot 3, the response is:

```
3723,Dual 1x30 Reed Multiplexer,01.40e,1243657
```

Also see

[slot\[X\] attributes](#) (see "[Slot](#)" on page 6-18)

slot[X].interlock.override

This attribute suppresses or permits interlock errors to be generated.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset Recall setup	Create configuration script Save setup	0

Usage

```
value = slot[X].interlock.override
slot[X].interlock.override = value
```

<i>value</i>	Indicates the desired state of the interlock override; valid values are <code>slot.ON</code> (1) or <code>slot.OFF</code> (0, the default)
<i>X</i>	The slot containing the card to which the interlock state is applied

Details

This command suppresses errors that would otherwise be generated when the interlock is not closed. If the interlock is not physically connected, channels will still not close.

This attribute exists only for installed cards that support detecting an interlock break. Otherwise, the return value is `nil`. If the card supports detecting an interlock break, set this attribute to the desired response.

To enable interlock override on the card, set to `slot.ON`. If an override performed on card is not desired, set to `slot.OFF`. This setting applies to all interlocks on the card.

Example

```
slot[3].interlock.override = slot.ON
```

Suppresses interlock errors.

Also see

[slot\[X\].interlock.state](#) (on page 8-377)

slot[X].interlock.state

This attribute indicates the interlock state of a card.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Nonvolatile memory	1

Usage

```
value = slot[X].interlock.state
```

<i>value</i>	Indicates whether the interlocks are engaged or not; see table below for possible return values
--------------	---

Details

This attribute will not exist for a slot if a card is not installed or the card installed does not support detecting an interlock break. In these cases, the return value will be `nil`.

Return values for slot[X].interlock.state	
Return value	Description
<code>nil</code>	No card is installed or the installed card does not support interlocks
0	Interlocks 1 and 2 are disengaged on the card
1	Interlock 1 is engaged, interlock 2 (if it exists) is disengaged
2	Interlock 2 in engaged, interlock 1 is disengaged
3	Both interlock 1 and 2 are engaged

Use this attribute to query the interlock state for cards that support detecting interlock break.

Also see

[slot\[X\].interlock.override](#) (on page 8-376)

slot[X].isolated

This attribute indicates if the card in slot *x* supports isolated channels.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
value = slot[X].isolated
```

<i>value</i>	1 if isolated channels are supported
<i>X</i>	Slot number (1 to 6)

Details

This attribute is only available for a slot if a card is installed and if the installed card supports the isolated channels. If isolated channels are not available, the return value is `nil`.

Example

```
IsolatedChan1 = slot[1].isolated
print(IsolatedChan1)
```

Query if slot 1 supports isolated channels. If it does support isolated channels, the output is:
1.000000000e+00

Also see

[slot\[X\].idn](#) (on page 8-375)

slot[X].matrix

This attribute indicates if the card in slot *x* supports matrix channels.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
value = slot[X].matrix
```

<i>value</i>	1 if matrix channels are supported
<i>X</i>	Slot number (1 to 6)

Details

This attribute is only available for a slot if a card is installed and if the installed card supports matrix channels. If matrix channels are not available, the return value is `nil`.

Example

```
Matrix1 = slot[1].matrix
print(Matrix1)
```

Query if slot 1 supports matrix channels. If it does support matrix channels, the output is:
1.000000000e+00

Also see

[slot\[X\].idn](#) (on page 8-375)

slot[X].maxvoltage

This attribute returns the maximum voltage of all channels on a card in slot *x*.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
maximumVolts = slot[X].maxvoltage
```

<i>maximumVolts</i>	The maximum voltage
<i>X</i>	Slot number (1 to 6)

Details

This attribute is only available for a slot if a card is installed and if the installed card supports voltage settings. If voltage settings are not available, the return value is `nil`.

Example

```
maxVolts2 = slot[2].maxvoltage
print(maxVolts2)
```

Query the maximum voltage on slot 2. The output will be similar to:
3.0000000000e+02

Also see

[slot\[X\].idn](#) (on page 8-375)

slot[X].multiplexer

This attribute indicates if the card in slot *x* supports multiplexer channels.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
value = slot[X].multiplexer
```

<i>value</i>	1 if multiplexer channels are supported
<i>X</i>	Slot number (1 to 6)

Details

This attribute is only available for a slot if a card is installed and if the installed card supports multiplexer channels. If multiplexer channels are not available, the return value is `nil`.

Example

```
MuxChan1 = slot[1].multiplexer
print(MuxChan1)
```

Query if slot 1 supports multiplexer channels. If it does support multiplexer channels, the output is:
1.0000000000e+00

Also see

[slot\[X\].idn](#) (on page 8-375)

slot[X].poles.four

This attribute indicates if a four-pole setting is supported for the channels on the card.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
fourPole = slot[X].poles.four
```

<i>fourPole</i>	The return value
<i>X</i>	Slot number (1 to 6)

Details

This attribute only exists if a card is installed and if the card supports four-pole settings for the channels on the card. If not, the value is nil. If supported, the value is 1.

Example

```
fourPole3 = slot[3].poles.four
print(fourPole3)
```

Queries if Slot 3 supports four-pole settings for the channels on the card.

Output if card supports four pole:

```
1.000000000e+00
```

Output if card does not support four pole:

```
nil
```

Also see

[slot\[X\].poles.one](#) (on page 8-381)

[slot\[X\].poles.two](#) (on page 8-382)

slot[X].poles.one

This attribute indicates if a one-pole setting is supported for the channels on the card.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
onePole = slot[X].poles.one
```

<i>onePole</i>	The return value
<i>X</i>	Slot number (1 to 6)

Details

This attribute only exists if a card is installed and if the card supports one-pole settings for the channels on the card. If not, the value is `nil`. If supported, the value is 1.

Example

<pre>print(slot[3].poles.one)</pre>	<p>Query to see if Slot 3 supports one-pole settings for the channels on the card.</p> <p>Output if card supports one pole: 1.000000000e+00</p> <p>Output if card does not support one pole: nil</p>
-------------------------------------	--

Also see

[slot\[X\].poles.four](#) (on page 8-380)
[slot\[X\].poles.two](#) (on page 8-382)

slot[X].poles.two

This attribute indicates if a two-pole setting is supported for the channels on the card.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
twoPole = slot[X].poles.two
```

<i>twoPole</i>	The return value
<i>X</i>	Slot number (1 to 6)

Details

This attribute only exists if a card is installed and if the card supports a two-pole setting for the channels on the card.

If not, the value is `nil`. If supported, the value is `1`.

Example

```
twoPole3 = slot[3].poles.two
print(twoPole3)
```

Query to see if Slot 3 supports two-pole settings for the channels on the card.

Output if card supports two pole:

```
1.000000000e+00
```

Output if card does not support two pole:

```
nil
```

Also see

[slot\[X\].poles.one](#) (on page 8-381)

[slot\[X\].poles.four](#) (on page 8-380)

slot[X].pseudocard

This attribute specifies the corresponding pseudocard to implement for the designated slot.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Not applicable	Not applicable	See Details

Usage

```
pseudoCard = slot[X].pseudocard
slot[X].pseudocard = pseudoCard
```

<i>pseudoCard</i>	<ul style="list-style-type: none"> • Set <i>pseudocard</i> to one of the following values: • <code>slot.PSEUDO_NONE</code> or 0 for no pseudocard selection • 3720 for Model 3720 Dual 1x30 Multiplexer card simulation • 3721 for Model 3721 Dual 1x20 Multiplex card simulation • 3722 for Model 3722 Dual 1x48 Multiplexer card simulation • 3723 for Model 3723 Dual 1x30 Reed Multiplexer card simulation • 3724 for Model 3724 Dual 1x30 FET Multiplexer card simulation • 3730 for Model 3730 6 x 16 High Density Matrix card simulation • 3731 for Model 3731 6x16 High Speed Reed Relay Matrix card simulation • 3732 or 37320 for Model 3732 Quad 4 x 28 Ultra-High Density Reed Relay Matrix card simulation • 37321 for Model 3732 Dual 4 x 56 Ultra-High Density Reed Relay Matrix card simulation • 37322 for Model 3732 Single 4 x 112 Ultra-High Density Reed Relay Matrix card simulation • 37323 for Model 3732 Dual 8 x 28 Ultra-High Density Reed Relay Matrix card simulation • 37324 for Model 3732 Single 16 x 28 Ultra-High Density Reed Relay Matrix card simulation • 3740 for Model 3740 32-Channel Isolated Switch card simulation • 3750 for Model 3750 Multifunction I/O card
X	Slot number (1 to 6)

Details

This attribute only exists for a slot if that slot has no card installed in it. If a card is installed, the response is `nil` when queried. If no card installed and the slot is empty, the response is 0.

After assigning a pseudocard, the valid commands and attributes based on that pseudocard exist for that slot. For example, the `slot[X].idn` attribute is valid.

Changing the pseudocard card assignment from a card to `slot.PSEUDO_NONE` invalidates existing scan lists that include that slot.

Example

```
slot[6].pseudocard = 3720
```

Sets the pseudocard of slot 6 for Model 3720 card simulation.

Also see

[slot\[X\] attributes](#) (see "[Slot](#)" on page 6-18)
[slot\[X\].idn](#) (on page 8-375)

slot[X].rows.matrix

This attribute returns the number of rows in the matrix on the card in slot X.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
value = slot[X].rows.matrix
```

value	Number of rows in the matrix card of the selected slot
X	Slot number (1 to 6)

Details

This attribute is only available for a slot if a card is installed and if the installed card supports matrix channels. If matrix channels are not available, the return value is nil.

Example

```
print(slot[4].rows.matrix)
```

Returns the number of rows in the matrix on the card in slot 4 (12 rows).
Example output:
1.2000000000e+01

Also see

[slot\[X\].columns.matrix](#) (on page 8-370)

[slot\[X\].idn](#) (on page 8-375)

[slot\[X\].matrix](#) (on page 8-378)

slot[X].startchannel.*

These attributes indicates whether or not the channel in slot *x* supports a feature and if so, which channels support the feature.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
value = slot[X].startchannel.amps (channel supports amperage measurements)
```

```
value = slot[X].startchannel.analogoutput (channel supports a digital analog output (DAC))
```

```
value = slot[X].startchannel.digitalio (channel supports digital inputs and outputs)
```

```
value = slot[X].startchannel.isolated (channel supports isolated channels)
```

```
value = slot[X].startchannel.totalizer (channel supports totalizer channels)
```

```
value = slot[X].startchannel.voltage (channel supports voltage or two-wire measurements)
```

value	The channel number of the starting channel of the group of channels that supports the feature
X	Slot number (1 to 6)

Details

This attribute is only available for a slot if a card is installed and if the installed card supports the selected feature. If the attribute is not available, the return value is `nil`.

Channels are grouped on the cards by feature sets, so you can use the start and ending channel numbers to identify a group of channels that supports a particular feature. If the card supports the feature, the returned value is the number of the starting channel.

If only one channel in the card supports the feature, the starting channel will match the ending channel number.

Example

```
CardChannels = function(SlotNumber)
  if slot[SlotNumber].idn == "Empty Slot" then
    print("  Slot is Empty")
  else
    if (slot[SlotNumber].startchannel.voltage == nil) and
      (slot[SlotNumber].endchannel.voltage == nil) then
      print("    no voltage channels")
    else
      print("    Start voltage channel is " .. slot[SlotNumber].startchannel.voltage)
      print("    End voltage channel is " .. slot[SlotNumber].endchannel.voltage)
    end

    if (slot[SlotNumber].startchannel.amps == nil) and
      (slot[SlotNumber].endchannel.amps == nil) then
      print("    no amp channels")
    else
      print("    Start amp channel is " .. slot[SlotNumber].startchannel.amps)
      print("    End amp channel is " .. slot[SlotNumber].endchannel.amps)
    end

    if (slot[SlotNumber].digio == 1) then
      print("    Start digital i/o channel is " ..
        slot[SlotNumber].startchannel.digitalio)
      print("    End digital i/o channel is " .. slot[SlotNumber].endchannel.digitalio)
    else
      print("    no digio channels")
    end

    if (slot[SlotNumber].totalizer == 1) then
      print("    Start totalizer channel is " ..
        slot[SlotNumber].startchannel.totalizer)
      print("    End totalizer channel is " .. slot[SlotNumber].endchannel.totalizer)
    else
      print("    no totalizer channels")
    end

    if (slot[SlotNumber].startchannel.analogoutput == nil) and
      (slot[SlotNumber].endchannel.analogoutput == nil) then
      print("    no analog output channels")
    else
      print("    Start analog output channel is " ..
        slot[SlotNumber].startchannel.analogoutput)
      print("    End analog output channel is " ..
        slot[SlotNumber].endchannel.analogoutput)
    end

    if (slot[SlotNumber].matrix == 1) then
      print("    Channels on card are matrix type")
    end
  end
end

for x = 1,6 do
  print("Checking card channels in slot " .. x)
  CardChannels(x)
end
```

If the Series 3700A contains the following cards:

- Slot 1: 3732
- Slot 2: 3720
- Slot 3: 3750
- Slot 4: Empty
- Slot 5: 3721
- Slot 6: Empty

The output of this example is similar to:

```
Checking card channels in slot 1
  no voltage channels
  no amp channels
  no digio channels
  no totalizer channels
  no analog output channels
  Channels on card are matrix type
Checking card channels in slot 2
  Start voltage channel is 1
  End voltage channel is 60
  no amp channels
  no digio channels
  no totalizer channels
  no analog output channels
Checking card channels in slot 3
  no voltage channels
  no amp channels
  Start digital i/o channel is 1
  End digital i/o channel is 5
  Start totalizer channel is 6
  End totalizer channel is 9
  Start analog output channel is 10
  End analog output channel is 11
Checking card channels in slot 4
  Slot is Empty
Checking card channels in slot 5
  Start voltage channel is 1
  End voltage channel is 40
  Start amp channel is 41
  End amp channel is 42
  no digio channels
  no totalizer channels
  no analog output channels
Checking card channels in slot 6
  Slot is Empty
```

Also see

slot functions and attributes
[slot\[X\].endchannel.*](#) (on page 8-371)

slot[X].tempsensor

This attribute indicates if the card in slot *x* supports temperature sensor channels.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
value = slot[X].tempsensor
```

<i>value</i>	1 if temperature sensor channels are supported
<i>X</i>	Slot number (1 to 6)

Details

This attribute is only available for a slot if a card is installed and if the installed card supports temperature sensor channels. If temperature sensor channels are not available, the return value is `nil`.

Example

```
TempSensor = slot[1].tempsensor
print(TempSensor)
```

Query to determine if slot 1 supports temperature sensor channels. If it does support temperature sensor channels, the output is:
1.000000000e+00

Also see

[slot\[X\].idn](#) (on page 8-375)

slot[X].thermal.state

This attribute indicates the thermal state of the card in the specified slot.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
value = slot[X].thermal.state
```

<i>value</i>	0 if thermal conditions will not affect specifications 1 if thermal conditions are getting warm enough to affect specifications
<i>X</i>	Slot number (1 to 6)

Details

This attribute is only available for a slot if a card is installed and if the installed card supports thermal state detection. If thermal state detection is not available, the return value is `nil`.

Example

```
print(slot[3].thermal.state)
```

Query the thermal state on slot 3. If spec might be affected by the thermal state, the output is:
1.000000000e+00

Also see

[slot\[X\].idn](#) (on page 8-375)

status.condition

This attribute stores the status byte condition register.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not saved	Not applicable

Usage

```
statusByte = status.condition
```

<i>statusByte</i>	The status byte; a zero (0) indicates no bits set; other values indicate various bit settings
-------------------	---

Details

This attribute is used to read the status byte, which is returned as a numeric value. The binary equivalent of the value of this attribute indicates which register bits are set. In the binary equivalent, the least significant bit is bit B0, and the most significant bit is bit B7. For example, if a value of $1.29000e+02$ (which is 129) is read as the value of this register, the binary equivalent is 1000 0001. This value indicates that bit B0 and bit B7 are set.

B7	B6	B5	B4	B3	B2	B1	B0
**	>	>	>	>	>	>	*
1	0	0	0	0	0	0	1

* Least significant bit

** Most significant bit

The returned value can indicate one or more status events occurred. When an enabled status event occurs, a summary bit is set in this register to indicate the event occurrence.

The individual bits of this register have the following meanings:

Bit	Value	Description
B0	<code>status.MEASUREMENT_SUMMARY_BIT</code> <code>status.MSB</code>	Set summary bit indicates that an enabled measurement event has occurred. Bit B0 decimal value: 1
B1	<code>status.SYSTEM_SUMMARY_BIT</code> <code>status.SSB</code>	Set summary bit indicates that an enabled system event has occurred. Bit B1 decimal value: 2
B2	<code>status.ERROR_AVAILABLE</code> <code>status.EAV</code>	Set summary bit indicates that an error or status message is present in the Error Queue. Bit B2 decimal value: 4
B3	<code>status.QUESTIONABLE_SUMMARY_BIT</code> <code>status.QSB</code>	Set summary bit indicates that an enabled questionable event has occurred. Bit B3 decimal value: 8
B4	<code>status.MESSAGE_AVAILABLE</code> <code>status.MAV</code>	Set summary bit indicates that a response message is present in the Output Queue. Bit B4 decimal value: 16
B5	<code>status.EVENT_SUMMARY_BIT</code> <code>status.ESB</code>	Set summary bit indicates that an enabled standard event has occurred. Bit B5 decimal value: 32
B6	<code>status.MASTER_SUMMARY_STATUS</code> <code>status.MSS</code>	Request Service (RQS)/Master Summary Status (MSS). Depending on how it is used, bit B6 of the status byte register is either the Request for Service (RQS) bit or the Master Summary Status (MSS) bit: <ul style="list-style-type: none"> When using the GPIB or VXI-11 serial poll sequence of the Model 3706A to obtain the status byte (serial poll byte), B6 is the RQS bit. The set bit indicates that the Request Service (RQS) bit of the status byte (serial poll byte) is set and a serial poll (SRQ) has occurred. When using the <code>status.condition</code> register command or the <code>*STB?</code> common command to read the status byte, B6 is the MSS bit. Set bit indicates that an enabled summary bit of the status byte register is set. Bit B6 decimal value: 64
B7	<code>status.OPERATION_SUMMARY_BIT</code> <code>status.OSB</code>	Set summary bit indicates that an enabled operation event has occurred. Bit B7 decimal value: 128

In addition to the above constants, when more than one bit of the register is set, `statusByte` equals the sum of their decimal weights. For example, if 129 is returned, bits B0 and B7 are set (1 + 128).

Bit	B7	B6	B5	B4	B3	B2	B1	B0
Binary value	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
Decimal	128	64	32	16	8	4	2	1
Weights	(2 ⁷)	(2 ⁶)	(2 ⁵)	(2 ⁴)	(2 ³)	(2 ²)	(2 ¹)	(2 ⁰)

Example

```
statusByte = status.condition
print(statusByte)
```

Returns `statusByte`.

Sample output:

```
1.29000e+02
```

Converting this output (129) to its binary equivalent yields 1000 0001

Therefore, this output indicates that the set bits of the status byte condition register are presently B0 (MSS) and B7 (OSB).

Also see

[Status byte and service request \(SRQ\)](#) (on page D-18)

status.measurement.*

This attribute contains the measurement event register set.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute	--	--	--	--
.condition (R)	Yes	Not applicable	Not saved	Not applicable
.enable (RW)	Yes	Status reset	Not saved	0
.event (R)	Yes	Status reset	Not saved	Not applicable
.ntr (RW)	Yes	Status reset	Not saved	0
.ptr (RW)	Yes	Status reset	Not saved	399 (All bits set)

Usage

```

measurementRegister = status.measurement.condition
measurementRegister = status.measurement.enable
measurementRegister = status.measurement.event
measurementRegister = status.measurement.ntr
measurementRegister = status.measurement.ptr
status.measurement.enable = measurementRegister
status.measurement.ntr = measurementRegister
status.measurement.ptr = measurementRegister

```

<i>measurementRegister</i>	The measurement event register's status. A zero (0) indicates no bits set (also send 0 to clear all bits);the only valid value other than 0 is 8
----------------------------	--

Details

These attributes read or write the measurement event registers.

Reading a status register returns a value. The binary equivalent of the returned value indicates which register bits are set. The least significant bit of the binary number is bit B0, and the most significant bit is bit B15.

For example, assume value 384 is returned for the enable register. The binary equivalent is 0000 0001 1000 0000. This value indicates that bit B7 (ROF) and bit B8 (BAV) are set.

B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0
**	>	>	>	>	>	>	>	>	>	>	>	>	>	>	*
0	0	0	0	0	0	0	1	1	0	0	0	0	0	0	0

* Least significant bit

** Most significant bit

For information about .condition, .enable, .event, .ntr, and .ptr registers, refer to [Status register sets](#) (on page D-2) and [Enable and transition registers](#) (on page D-22). The individual bits of this register are defined in the following table.

Bit	Value	Description
B0	status.measurement.LOWER_LIMIT1 status.measurement.LLMT1	Set bit indicates that a reading has exceeded the lower limit 1 value. Bit B0 decimal value: 1
B1	status.measurement.UPPER_LIMIT1 status.measurement.ULMT1	Set bit indicates that a reading has exceeded the upper limit 1 value. Bit B1 decimal value: 2
B2	status.measurement.LOWER_LIMIT2 status.measurement.LLMT2	Set bit indicates that a reading has exceeded the lower limit 2 value. Bit B2 decimal value: 4
B3	status.measurement.UPPER_LIMIT2 status.measurement.ULMT2	Set bit indicates that a reading has exceeded the upper limit 2 value. Bit B3 decimal value: 8
B4-B6	Not used	Not applicable
B7	status.measurement.READING_OVERFLOW status.measurement.ROF	Set bit indicates that a reading has resulted in an overflow measurement value. Bit B7 decimal value: 128
B8	status.measurement.BUFFER_AVAILABLE status.measurement.BAV	Set bit indicates that a reading buffer is storing measurement values. Bit B8 decimal value: 256 Binary value: 0001 0000 0000
B9-B15	Not used	Not applicable

In addition to the above constants, *measurementRegister* can be set to the decimal equivalent of the bit to set. To set more than one bit of the register, set *measurementRegister* to the sum of their decimal weights. For example, to set bits B1 and B8, set *measurementRegister* to 258 (which is the sum of 2 + 256).

Bit	B7	B6	B5	B4	B3	B2	B1	B0
Binary value	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
Decimal	128	64	32	16	8	4	2	1
Weights	(2 ⁷)	(2 ⁶)	(2 ⁵)	(2 ⁴)	(2 ³)	(2 ²)	(2 ¹)	(2 ⁰)

Bit	B15	B14	B13	B12	B11	B10	B9	B8
Binary value	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
Decimal	32,768	16,384	8,192	4,096	2,048	1024	512	256
Weights	(2 ¹⁵)	(2 ¹⁴)	(2 ¹³)	(2 ¹²)	(2 ¹¹)	(2 ¹⁰)	(2 ⁹)	(2 ⁸)

Example

```
status.measurement.enable = status.measurement.BAV
```

Sets the BAV bit of the measurement event enable register.

Also see

Measurement event registers

status.node_enable

This attribute stores the system node enable register.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Status reset	Not saved	0

Usage

```
nodeEnableRegister = status.node_enable
status.node_enable = nodeEnableRegister
```

<i>nodeEnableRegister</i>	The system node enable register's status; a zero (0) indicates no bits set (also send 0 to clear all bits); other values indicate various bit settings
---------------------------	--

Details

This attribute is used to read or write to the system node enable register. Reading the system node enable register returns a value. The binary equivalent of the value indicates which register bits are set. In the binary equivalent, the least significant bit is bit B0, and the most significant bit is bit B7. For example, assume the value of $1.29000e+02$ (which is 129) is returned for the system node enable register, the binary equivalent is 1000 0001. This value indicates that bit B0 and bit B7 are set.

B7	B6	B5	B4	B3	B2	B1	B0
**	>	>	>	>	>	>	**
1	0	0	0	0	0	0	1

* Least significant bit

** Most significant bit

Assigning a value to this attribute enables one or more status events. When an enabled status event occurs, a summary bit is set in the appropriate system summary register. The register and bit that is set depends on the TSP-Link node number assigned to this instrument.

For information about .condition, .enable, .event, .ntr, and .ptr registers, refer to [Status register sets](#) (on page D-2) and [Enable and transition registers](#) (on page D-22). The individual bits of this register are defined in the following table.

Bit	Value	Description
B0	status.MEASUREMENT_SUMMARY_BIT status.MSB	Set summary bit indicates that an enabled measurement event has occurred. Bit B0 decimal value: 1
B1	Not used	Not applicable.
B2	status.ERROR_AVAILABLE status.EAV	Set summary bit indicates that an error or status message is present in the Error Queue. Bit B2 decimal value: 4

Bit	Value	Description
B3	<code>status.QUESTIONABLE_SUMMARY_BIT</code> <code>status.QSB</code>	Set summary bit indicates that an enabled questionable event has occurred. Bit B3 decimal value: 8
B4	<code>status.MESSAGE_AVAILABLE</code> <code>status.MAV</code>	Set summary bit indicates that a response message is present in the Output Queue. Bit B4 decimal value: 16
B5	<code>status.EVENT_SUMMARY_BIT</code> <code>status.ESB</code>	Set summary bit indicates that an enabled standard event has occurred. Bit B5 decimal value: 32
B6	<code>status.MASTER_SUMMARY_STATUS</code> <code>status.MSS</code>	Set bit indicates that an enabled Master Summary Status (MSS) bit of the Status Byte Register is set. Bit B6 decimal value: 64
B7	<code>status.OPERATION_SUMMARY_BIT</code> <code>status.OSB</code>	Set summary bit indicates that an enabled operation event has occurred. Bit B7 decimal value: 128

As an example, to set the B0 bit of the system node enable register, set `status.node_enable = status.MSB`.

In addition to the above values, `nodeEnableRegister` can be set to the numeric equivalent of the bit to set. To set more than one bit of the register, set `nodeEnableRegister` to the sum of their decimal weights. For example, to set bits B0 and B7, set `nodeEnableRegister` to 129 (1 + 128).

Bit	B7	B6	B5	B4	B3	B2	B1	B0
Binary value	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
Decimal	128	64	32	16	8	4	2	1
Weights	(2 ⁷)	(2 ⁶)	(2 ⁵)	(2 ⁴)	(2 ³)	(2 ²)	(2 ¹)	(2 ⁰)

Example 1

```
nodeEnableRegister = status.MSB + status.OSB
status.node_enable = nodeEnableRegister
```

Sets the MSB and OSB bits of the system node enable register using constants.

Example 2

```
-- decimal 129 = binary 10000001
nodeEnableRegister = 129
status.node_enable = nodeEnableRegister
```

Sets the MSB and OSB bits of the system node enable register using a decimal value.

Also see

[status.condition](#) (on page 8-389)
[status.system.*](#) (on page 8-408)
[Status byte and service request \(SRQ\)](#) (on page D-18)

status.node_event

This attribute stores the status node event register.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not saved	0

Usage

```
nodeEventRegister = status.node_event
```

`nodeEventRegister` The node event register's status; a zero (0) indicates no bits set; other values indicate various bit settings

Details

This attribute is used to read the status node event register, which is returned as a numeric value (reading this register returns a value). The binary equivalent of the value of this attribute indicates which register bits are set. In the binary equivalent, the least significant bit is bit B0, and the most significant bit is bit B7. For example, if a value of $1.29000e+02$ (which is 129) is read as the value of this register, the binary equivalent is 1000 0001. This value indicates that bit B0 and bit B7 are set.

B7	B6	B5	B4	B3	B2	B1	B0
**	>	>	>	>	>	>	*
1	0	0	0	0	0	0	1

* Least significant bit

** Most significant bit

The returned value can indicate one or more status events occurred.

Bit	Value	Description
B0	<code>status.MEASUREMENT_SUMMARY_BIT</code> <code>status.MSB</code>	Set summary bit indicates that an enabled measurement event has occurred. Bit B0 decimal value: 1
B1	Not used	Not applicable
B2	<code>status.ERROR_AVAILABLE</code> <code>status.EAV</code>	Set summary bit indicates that an error or status message is present in the Error Queue. Bit B2 decimal value: 4
B3	<code>status.QUESTIONABLE_SUMMARY_BIT</code> <code>status.QSB</code>	Set summary bit indicates that an enabled questionable event has occurred. Bit B3 decimal value: 8
B4	<code>status.MESSAGE_AVAILABLE</code> <code>status.MAV</code>	Set summary bit indicates that a response message is present in the Output Queue. Bit B4 decimal value: 16
B5	<code>status.EVENT_SUMMARY_BIT</code> <code>status.ESB</code>	Set summary bit indicates that an enabled standard event has occurred. Bit B5 decimal value: 32
B6	<code>status.MASTER_SUMMARY_STATUS</code> <code>status.MSS</code>	Set bit indicates that an enabled Master Summary Status (MSS) bit of the Status Byte register is set. Bit B6 decimal value: 64
B7	<code>status.OPERATION_SUMMARY_BIT</code> <code>status.OSB</code>	Set summary bit indicates that an enabled operation event has occurred. Bit B7 decimal value: 128

In addition to the above constants, *nodeEventRegister* can be set to the decimal equivalent of the bit(s) set. When more than one bit of the register is set, *nodeEventRegister* contains the sum of their decimal weights. For example, if 129 is returned, bits B0 and B7 are set (1 + 128).

Bit	B7	B6	B5	B4	B3	B2	B1	B0
Binary value	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
Decimal	128	64	32	16	8	4	2	1
Weights	(2 ⁷)	(2 ⁶)	(2 ⁵)	(2 ⁴)	(2 ³)	(2 ²)	(2 ¹)	(2 ⁰)

Example

```
nodeEventRegister = status.node_event
print(nodeEventRegister)
```

Reads the status node event register.

Sample output:

```
1.29000e+02
```

Converting this output (129) to its binary equivalent yields 1000 0001

Therefore, this output indicates that the set bits of the status byte condition register are presently B0 (MSB) and B7 (OSB).

Also see

[status.condition](#) (on page 8-389)

[status.system.*](#) (on page 8-408)

[Status byte and service request \(SRQ\)](#) (on page D-18)

status.operation.*

These attributes manage the status model's operation status register set.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute	--	--	--	--
.condition (R)	Yes	Not applicable	Not saved	Not applicable
.enable (RW)	Yes	Status reset	Not saved	0
.event (R)	Yes	Status reset	Not saved	Not applicable
.ntr (RW)	Yes	Status reset	Not saved	0
.ptr (RW)	Yes	Status reset	Not saved	22545

Usage

```
operationRegister = status.operation.condition
operationRegister = status.operation.enable
operationRegister = status.operation.event
operationRegister = status.operation.ntr
operationRegister = status.operation.ptr
status.operation.enable = operationRegister
status.operation.ntr = operationRegister
status.operation.ptr = operationRegister
```

<i>operationRegister</i>	The operation status register's status. A zero (0) indicates no bits set (also send 0 to clear all bits); other values indicate various bit settings
--------------------------	--

Details

These attributes read or write the operation status registers.

Reading a status register returns a value. The binary equivalent of the returned value indicates which register bits are set. The least significant bit of the binary number is bit B0, and the most significant bit is bit B15. For example, if a value of 2.04800e+04 (which is 20,480) is read as the value of the condition register, the binary equivalent is 0101 0000 0000 0000. This value indicates that bit B14 (PROGRAM_RUNNING) and bit B12 (USER) are set.

B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0
**	>	>	>	>	>	>	>	>	>	>	>	>	>	>	*
0	1	0	1	0	0	0	0	0	0	0	0	0	0	0	0

* Least significant bit

** Most significant bit

For information about .condition, .enable, .event, .ntr, and .ptr registers, refer to [Status register sets](#) (on page D-2) and [Enable and transition registers](#) (on page D-22). The individual bits of this register are defined in the following table.

Bit	Value	Description
B0	<code>status.operation.CALIBRATING</code> <code>status.operation.CAL</code>	Set bit indicates that the DMM is calibrating. Bit B0 decimal value: 1
B1-B3	Not used	Not applicable
B4	<code>status.operation.MEASURING</code> <code>status.operation.MEAS</code>	Set bit indicates that DMM is measuring. Bit B4 decimal value: 16
B5-B9	Not used	Not applicable
B11	<code>status.operation.PROMPTS</code> <code>status.operation.PRMPPTS</code>	Set bit indicates that the command prompts are enabled. Bit B11 decimal value: 2048
B12	<code>status.operation.USER</code>	Set bit indicates that the summary bit from the <code>status.operation.user</code> register is set. Bit B12 decimal value: 4096
B14	<code>status.operation.PROGRAM_RUNNING</code> <code>status.operation.PROG</code>	Set bit indicates that a command or program is running. Bit B14 decimal value: 16,384
B15	Not used	Not applicable

As an example, to set bit B12 of the operation status enable register, set `status.operation.enable = status.operation.USER`.

In addition to the above constants, `operationRegister` can be set to the numeric equivalent of the bit to set. To set more than one bit of the register, set `operationRegister` to the sum of their decimal weights. For example, to set bits B12 and B14, set `operationRegister` to 20,480 (which is the sum of 4096 + 16,384).

Bit	B7	B6	B5	B4	B3	B2	B1	B0
Binary value	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
Decimal	128	64	32	16	8	4	2	1
Weights	(2 ⁷)	(2 ⁶)	(2 ⁵)	(2 ⁴)	(2 ³)	(2 ²)	(2 ¹)	(2 ⁰)

Bit	B15	B14	B13	B12	B11	B10	B9	B8
Binary value	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
Decimal	32,768	16,384	8,192	4,096	2,048	1024	512	256
Weights	(2 ¹⁵)	(2 ¹⁴)	(2 ¹³)	(2 ¹²)	(2 ¹¹)	(2 ¹⁰)	(2 ⁹)	(2 ⁸)

The used bits of the operation event registers are:

- Bit B0, CAL - Set bit indicates that the instrument is calibrating.
- Bit B4, MEAS - Bit is set when taking a measurement.
- Bit B11, PRMPTS - Set bit indicates that command prompts are enabled.
- Bit B12, USER - Set bit indicates that an enabled bit in the operation status user register is set.
- Bit B14, PROG - Set bit indicates that a program is running.

Example 1

```
operationRegister = status.operation.USER +
    status.operation.PROG
status.operation.enable = operationRegister
```

Sets the USER and PROG bits of the operation status enable register using constants.

Example 2

```
-- decimal 20480 = binary 0101 0000 0000 0000
operationRegister = 20480
status.operation.enable = operationRegister
```

Sets the USER and PROG bits of the operation status enable register using a decimal value.

Also see

Operation Status Registers

status.operation.user.*

These attributes manage the status model's operation status user register set.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute	--	--	--	--
.condition (RW)	Yes	Status reset	Not saved	0
.enable (RW)	Yes	Status reset	Not saved	0
.event (R)	Yes	Status reset	Not saved	0
.ntr (RW)	Yes	Status reset	Not saved	0
.ptr (RW)	Yes	Status reset	Not saved	32,767 (All bits set)

Usage

```
operationRegister = status.operation.user.condition
operationRegister = status.operation.user.enable
operationRegister = status.operation.user.event
operationRegister = status.operation.user.ntr
operationRegister = status.operation.user.ptr
status.operation.user.condition = operationRegister
status.operation.user.enable = operationRegister
status.operation.user.ntr = operationRegister
status.operation.user.ptr = operationRegister
```

<i>operationRegister</i>	The operation status user register's status; a zero (0) indicates no bits set (also send 0 to clear all bits); other values indicate various bit settings
--------------------------	---

Details

These attributes are used to read or write to the operation status user registers. Reading a status register returns a value. The binary equivalent of the value indicates which register bits are set. In the binary equivalent, the least significant bit is bit B0, and the most significant bit is bit B15. For example, if a value of $1.29000e+02$ (which is 129) is read as the value of the condition register, the binary equivalent is 0000 0000 1000 0001. This value indicates that bits B0 and B7 are set.

B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0
**	>	>	>	>	>	>	>	>	>	>	>	>	>	>	*
0	0	0	0	0	0	0	0	1	0	0	0	0	0	0	1

* Least significant bit

** Most significant bit

For information about .condition, .enable, .event, .ntr, and .ptr registers, refer to [Status register sets](#) (on page D-2) and [Enable and transition registers](#) (on page D-22). The individual bits of this register are defined in the following table.

Bit	Value	Description
B0	status.operation.user.BIT0	Bit B0 decimal value: 1
B1	status.operation.user.BIT1	Bit B1 decimal value: 2
B2	status.operation.user.BIT2	Bit B2 decimal value: 4
B3	status.operation.user.BIT3	Bit B3 decimal value: 8
B4	status.operation.user.BIT4	Bit B4 decimal value: 16
B5	status.operation.user.BIT5	Bit B5 decimal value: 32
B6	status.operation.user.BIT6	Bit B6 decimal value: 64
B7	status.operation.user.BIT7	Bit B7 decimal value: 128
B8	status.operation.user.BIT8	Bit B8 decimal value: 256
B9	status.operation.user.BIT9	Bit B9 decimal value: 512
B10	status.operation.user.BIT10	Bit B10 decimal value: 1024
B11	status.operation.user.BIT11	Bit B11 decimal value: 2048
B12	status.operation.user.BIT12	Bit B12 decimal value: 4096
B13	status.operation.user.BIT13	Bit B13 decimal value: 8192
B14	status.operation.user.BIT14	Bit B14 decimal value: 16,384
B15	Not used	Not applicable

As an example, to set bit B0 of the operation status user enable register, set `status.operation.user.enable = status.operation.user.BIT0`.

In addition to the above constants, `operationRegister` can be set to the numeric equivalent of the bit to set. To set more than one bit of the register, set `operationRegister` to the sum of their decimal weights. For example, to set bits B11 and B14, set `operationRegister` to 18,432 (which is the sum of 2048 + 16,384).

Bit	B7	B6	B5	B4	B3	B2	B1	B0
Binary value	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
Decimal	128	64	32	16	8	4	2	1
Weights	(2 ⁷)	(2 ⁶)	(2 ⁵)	(2 ⁴)	(2 ³)	(2 ²)	(2 ¹)	(2 ⁰)

Bit	B15	B14	B13	B12	B11	B10	B9	B8
Binary value	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
Decimal	32,768	16,384	8,192	4,096	2,048	1024	512	256
Weights	(2 ¹⁵)	(2 ¹⁴)	(2 ¹³)	(2 ¹²)	(2 ¹¹)	(2 ¹⁰)	(2 ⁹)	(2 ⁸)

Example 1

```
operationRegister = status.operation.user.BIT11 +
status.operation.user.BIT14
status.operation.user.enable = operationRegister
```

Sets bits B11 and B14 of the operation status user enable register using constants.

Example 2

```
-- 18432 = binary 0100 1000 0000 0000
operationRegister = 18432
status.operation.enable = operationRegister
```

Sets bits B11 and B14 of the operation status user enable register using a decimal value.

Also see

[status.operation.*](#) (on page 8-396)
Operation Status Register

status.questionable.*

These attributes manage the status model's questionable status register set.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute	--	--	--	--
.condition (R)	Yes	Not applicable	Not saved	Not applicable
.enable (RW)	Yes	Status reset	Not saved	0
.event (R)	Yes	Status reset	Not saved	0
.ntr (RW)	Yes	Status reset	Not saved	0
.ptr (RW)	Yes	Status reset	Not saved	32,256 (All bits set)

Usage

```
quesRegister = status.questionable.condition
quesRegister = status.questionable.enable
quesRegister = status.questionable.event
quesRegister = status.questionable.ntr
quesRegister = status.questionable.ptr
status.questionable.enable = quesRegister
status.questionable.ntr = quesRegister
status.questionable.ptr = quesRegister
```

<i>quesRegister</i>	The questionable status register's status; a zero (0) indicates no bits set (also send 0 to clear all bits); other values indicate various bit settings
---------------------	---

Details

These attributes are used to read or write to the questionable status registers. Reading a status register returns a value. In the binary equivalent, the least significant bit is bit B0, and the most significant bit is bit B15. For example, if a value of 1.02400e+04 (which is 10,240) is read as the value of the condition register, the binary equivalent is 0010 1000 0000 0000. This value indicates that bits B11 and B13 are set.

B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0
**	>	>	>	>	>	>	>	>	>	>	>	>	>	>	*
0	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0

* Least significant bit

** Most significant bit

For information about .condition, .enable, .event, .ntr, and .ptr registers, refer to [Status register sets](#) (on page D-2) and [Enable and transition registers](#) (on page D-22). The individual bits of this register are defined in the following table.

Bit	Value	Description
B0	Not used	Not available
B1	<code>status.questionable.SLOT1_INTERLOCK</code> <code>status.questionable.S1INL</code>	Sets the interlock connection of the card in slot 1. Bit B1 decimal value: 2
B2	<code>status.questionable.SLOT2_INTERLOCK</code> <code>status.questionable.S2INL</code>	Sets the interlock connection of the card in slot 2. Bit B2 decimal value: 4
B3	<code>status.questionable.SLOT3_INTERLOCK</code> <code>status.questionable.S3INL</code>	Sets the interlock connection of the card in slot 3. Bit B3 decimal value: 8
B4	<code>status.questionable.SLOT4_INTERLOCK</code> <code>status.questionable.S4INL</code>	Sets the interlock connection of the card in slot 4. Bit B4 decimal value: 16
B5	<code>status.questionable.SLOT5_INTERLOCK</code> <code>status.questionable.S5INL</code>	Sets the interlock connection of the card in slot 5. Bit B5 decimal value: 32
B6	<code>status.questionable.SLOT6_INTERLOCK</code> <code>status.questionable.S6INL</code>	Sets the interlock connection of the card in slot 6. Bit B6 decimal value: 64
B7	<code>status.questionable.DMM_CONNECTION</code> <code>status.questionable.DMMCONN</code>	Indicates that the DMM connection is in question for a measurement taken. Bit B7 decimal value: 128
B8	<code>status.questionable.CALIBRATION</code> <code>status.questionable.CAL</code>	Indicates that the calibration of the instrument is in question. Bit B8 decimal value: 256
B9	<code>status.questionable.S1THR</code> <code>status.questionable.SLOT1_THERMAL</code>	Indicates that the thermal functions of the card in slot 1 are questionable. Bit B9 decimal value: 512
B10	<code>status.questionable.S2THR</code> <code>status.questionable.SLOT2_THERMAL</code>	Indicates that the thermal functions of the card in slot 2 are questionable. Bit B10 decimal value: 1,024
B11	<code>status.questionable.S3THR</code> <code>status.questionable.SLOT3_THERMAL</code>	Indicates that the thermal functions of the card in slot 3 are questionable. Bit B11 decimal value: 2,048
B12	<code>status.questionable.S4THR</code> <code>status.questionable.SLOT4_THERMAL</code>	Indicates that the thermal functions of the card in slot 4 are questionable. Bit B12 decimal value: 4,096
B13	<code>status.questionable.S5THR</code> <code>status.questionable.SLOT5_THERMAL</code>	Indicates that the thermal functions of the card in slot 5 are questionable. Bit B13 decimal value: 8,192
B14	<code>status.questionable.S6THR</code> <code>status.questionable.SLOT6_THERMAL</code>	Indicates that the thermal functions of the card in slot 6 are questionable. Bit B14 decimal value: 16,384
B15	Not used	Not available

As an example, to set bit B9 of the questionable status enable register, set `status.questionable.enable = status.questionable.SLOT1_THERMAL`.

In addition to the above constants, `quesRegister` can be set to the numeric equivalent of the bit to set. To set more than one bit of the register, set `quesRegister` to the sum of their decimal weights. For example, to set bits B12 and B13, set `quesRegister` to 12,288 (which is the sum of 4096 + 8192).

Bit	B7	B6	B5	B4	B3	B2	B1	B0
Binary value	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
Decimal	128	64	32	16	8	4	2	1
Weights	(2 ⁷)	(2 ⁶)	(2 ⁵)	(2 ⁴)	(2 ³)	(2 ²)	(2 ¹)	(2 ⁰)

Bit	B15	B14	B13	B12	B11	B10	B9	B8
Binary value	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
Decimal	32,768	16,384	8,192	4,096	2,048	1024	512	256
Weights	(2 ¹⁵)	(2 ¹⁴)	(2 ¹³)	(2 ¹²)	(2 ¹¹)	(2 ¹⁰)	(2 ⁹)	(2 ⁸)

Example 1

```
quesRegister = status.questionable.S1INL +
  status.questionable.S6INL
status.questionable.enable = quesRegister
```

Sets bits B1 and B6 of the status questionable enable register using constants.

Example 2

```
-- decimal 66 = binary 0100 0010
quesRegister = 66
status.questionable.enable = quesRegister
```

Sets bits B1 and B6 of the status questionable enable register using a decimal value.

Also see

Questionable Status Registers

status.request_enable

This attribute stores the service request (SRQ) enable register.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Status reset	Not saved	0

Usage

```
requestSRQEnableRegister = status.request_enable
status.request_enable = requestSRQEnableRegister
```

<i>requestSRQEnableRegister</i>	The service request (SRQ) enable register's status. A zero (0) indicates no bits set (also send 0 to clear all bits); other values indicate various bit settings
---------------------------------	--

Details

This attribute is used to read or write to the service request enable register. Reading the service request enable register returns a value. The binary equivalent of the value of this attribute indicates which register bits are set. In the binary equivalent, the least significant bit is bit B0, and the most significant bit is bit B7. For example, if a value of 1.29000e+02 (which is 129) is read as the value of this register, the binary equivalent is 1000 0001. This value indicates that bit B0 and bit B7 are set.

B7	B6	B5	B4	B3	B2	B1	B0
**	>	>	>	>	>	>	*
1	0	0	0	0	0	0	1

* Least significant bit

** Most significant bit

For information about `.condition`, `.enable`, `.event`, `.ntr`, and `.ptr` registers, refer to [Status register sets](#) (on page D-2) and [Enable and transition registers](#) (on page D-22). The individual bits of this register are defined in the following table.

Bit	Value	Description
B0	<code>status.MEASUREMENT_SUMMARY_BIT</code> <code>status.MSB</code>	Set summary bit indicates that an enabled event in the Measurement Event Register has occurred. Bit B0 decimal value: 1
B1	<code>status.SYSTEM_SUMMARY_BIT</code> <code>status.SSB</code>	Set summary bit indicates that an enabled event in the System Summary Register has occurred. Bit B1 decimal value: 2
B2	<code>status.ERROR_AVAILABLE</code> <code>status.EAV</code>	Set summary bit indicates that an error or status message is present in the Error Queue. Bit B2 decimal value: 4
B3	<code>status.QUESTIONABLE_SUMMARY_BIT</code> <code>status.QSB</code>	Set summary bit indicates that an enabled event in the Questionable Status Register has occurred. Bit B3 decimal value: 8
B4	<code>status.MESSAGE_AVAILABLE</code> <code>status.MAV</code>	Set summary bit indicates that a response message is present in the Output Queue. Bit B4 decimal value: 16
B5	<code>status.EVENT_SUMMARY_BIT</code> <code>status.ESB</code>	Set summary bit indicates that an enabled event in the Standard Event Status Register has occurred. Bit B5 decimal value: 32
B6	Not used	Not applicable
B7	<code>status.OPERATION_SUMMARY_BIT</code> <code>status.OSB</code>	Set summary bit indicates that an enabled event in the Operation Status Register has occurred. Bit B7 decimal value: 128

As an example, to set bit B0 of the service request enable register, set `status.request_enable = status.MSB`.

In addition to the above values, `requestSRQEnableRegister` can be set to the numeric equivalent of the bit to set. To set more than one bit of the register, set `requestSRQEnableRegister` to the sum of their decimal weights. For example, to set bits B0 and B7, set `requestSRQEnableRegister` to 129 (1 + 128).

Bit	B7	B6	B5	B4	B3	B2	B1	B0
Binary value	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
Decimal	128	64	32	16	8	4	2	1
Weights	(2 ⁷)	(2 ⁶)	(2 ⁵)	(2 ⁴)	(2 ³)	(2 ²)	(2 ¹)	(2 ⁰)

Example 1

```
requestSRQEnableRegister = status.MSB +
    status.OSB
status.request_enable = requestSRQEnableRegister
```

Sets the MSB and OSB bits of the service request (SRQ) enable register using constants.

Example 2

```
-- decimal 129 = binary 10000001
requestSRQEnableRegister = 129
status.request_enable = requestSRQEnableRegister
```

Sets the MSB and OSB bits of the service request (SRQ) enable register using a decimal value.

Also see

[status.condition](#) (on page 8-389)
[status.system.*](#) (on page 8-408)
[Status byte and service request \(SRQ\)](#) (on page D-18)

status.request_event

This attribute stores the service request (SRQ) event register.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not saved	0

Usage

```
requestSRQEventRegister = status.request_event
```

<i>requestSRQEventRegister</i>	The request event register's status; a zero (0) indicates no bits set; other values indicate various bit settings
--------------------------------	---

Details

This attribute is used to read the service request event register, which is returned as a numeric value. Reading this register returns a value. The binary equivalent of the value of this attribute indicates which register bits are set. In the binary equivalent, the least significant bit is bit B0, and the most significant bit is bit B7. For example, if a value of $1.29000e+02$ (which is 129) is read as the value of this register, the binary equivalent is 1000 0001. This value indicates that bit B0 and bit B7 are set.

B7	B6	B5	B4	B3	B2	B1	B0
**	>	>	>	>	>	>	*
1	0	0	0	0	0	0	1

* Least significant bit

** Most significant bit

The returned value can indicate one or more status events occurred.

For information about `.condition`, `.enable`, `.event`, `.ntr`, and `.ptr` registers, refer to [Status register sets](#) (on page D-2) and [Enable and transition registers](#) (on page D-22). The individual bits of this register are defined in the following table.

Bit	Value	Description
B0	<code>status.MEASUREMENT_SUMMARY_BIT</code> <code>status.MSB</code>	Set summary bit indicates that an enabled event in the Measurement Event Register has occurred. Bit B0 decimal value: 1
B1	<code>status.SYSTEM_SUMMARY_BIT</code> <code>status.SSB</code>	Set summary bit indicates that an enabled event in the System Summary Register has occurred. Bit B1 decimal value: 2
B2	<code>status.ERROR_AVAILABLE</code> <code>status.EAV</code>	Set summary bit indicates that an error or status message is present in the Error Queue. Bit B2 decimal value: 4
B3	<code>status.QUESTIONABLE_SUMMARY_BIT</code> <code>status.QSB</code>	Set summary bit indicates that an enabled event in the Questionable Status Register has occurred. Bit B3 decimal value: 8
B4	<code>status.MESSAGE_AVAILABLE</code> <code>status.MAV</code>	Set summary bit indicates that a response message is present in the Output Queue. Bit B4 decimal value: 16
B5	<code>status.EVENT_SUMMARY_BIT</code> <code>status.ESB</code>	Set summary bit indicates that an enabled event in the Standard Event Status Register has occurred. Bit B5 decimal value: 32
B6	Not used	Not applicable
B7	<code>status.OPERATION_SUMMARY_BIT</code> <code>status.OSB</code>	Set summary bit indicates that an enabled event in the Operation Status Register has occurred. Bit B7 decimal value: 128

In addition to the above constants, `requestEventRegister` can be set to the decimal equivalent of the bit(s) set. When more than one bit of the register is set, `requestEventRegister` contains the sum of their decimal weights. For example, if 129 is returned, bits B0 and B7 are set (1 + 128).

Bit	B7	B6	B5	B4	B3	B2	B1	B0
Binary value	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
Decimal	128	64	32	16	8	4	2	1
Weights	(2 ⁷)	(2 ⁶)	(2 ⁵)	(2 ⁴)	(2 ³)	(2 ²)	(2 ¹)	(2 ⁰)

Example

```
requestEventRegister = status.request_event
print(requestEventRegister)
```

Reads the status request event register.
Sample output: 1.29000e+02
Converting this output (129) to its binary equivalent yields: 1000 0001
Therefore, this output indicates that the set bits of the status request event register are presently B0 (MSB) and B7 (OSB).

Also see

[status.condition](#) (on page 8-389)
[status.system.*](#) (on page 8-408)
[Status byte and service request \(SRQ\)](#) (on page D-18)

status.reset()

This function resets all bits in the system status model.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
status.reset()
```

Details

This function clears all status data structure registers (.enable, .event, NTR, and PTR) to their default values. For information about .condition, .enable, .event, .ntr, and .ptr registers, refer to [Status register sets](#) (on page D-2) and [Enable and transition registers](#) (on page D-22).

Example

<code>status.reset()</code>	Resets the instrument status model.
-----------------------------	-------------------------------------

Also see

[Status Model](#) (on page D-1)

status.standard.*

These attributes manage the status model's standard event status register set.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute	--	--	--	--
.condition (R)	Yes	Not applicable	Not saved	Not applicable
.enable (RW)	Yes	Status reset	Not saved	0
.event (R)	Yes	Status reset	Not saved	0
.ntr (RW)	Yes	Status reset	Not saved	0
.ptr (RW)	Yes	Status reset	Not saved	253 (All bits set)

Usage

```
standardRegister = status.standard.condition
standardRegister = status.standard.enable
standardRegister = status.standard.event
standardRegister = status.standard.ntr
standardRegister = status.standard.ptr
status.standard.enable = standardRegister
status.standard.ntr = standardRegister
status.standard.ptr = standardRegister
```

<code>standardRegister</code>	The standard event status register's status; a zero (0) indicates no bits set (also send 0 to clear all bits); other values indicate various bit settings
-------------------------------	---

Details

These attributes are used to read or write to the standard event status registers. Reading a status register returns a value. The binary equivalent of the returned value indicates which register bits are set. The least significant bit of the binary number is bit B0, and the most significant bit is bit B15. For example, if a value of $1.29000e+02$ (which is 129) is read as the value of the condition register, the binary equivalent is 0000 0000 1000 0001. This value indicates that bit B0 and bit B7 are set.

B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0
**	>	>	>	>	>	>	>	>	>	>	>	>	>	>	*
0	0	0	0	0	0	0	0	1	0	0	0	0	0	0	1

* Least significant bit

** Most significant bit

For information about .condition, .enable, .event, .ntr, and .ptr registers, refer to [Status register sets](#) (on page D-2) and [Enable and transition registers](#) (on page D-22). The individual bits of this register are defined in the following table.

Bit	Value	Description
B0	status.standard.OPERATION_COMPLETE status.standard.OPC	Set bit indicates that all pending selected instrument operations are completed and the instrument is ready to accept new commands. The bit is set in response to an *OPC command. The <code>opc()</code> function can be used in place of the *OPC command. Bit B0 decimal value: 1
B1	Not used	Not applicable
B2	status.standard.QUERY_ERROR status.standard.QYE	Set bit indicates that you attempted to read data from an empty Output Queue. Bit B2 decimal value: 4
B3	status.standard.DEVICE_DEPENDENT_ERROR status.standard.DDE	Set bit indicates that an instrument operation did not execute properly due to some internal condition. Bit B3 decimal value: 8
B4	status.standard.EXECUTION_ERROR status.standard.EXE	Set bit indicates that the instrument detected an error while trying to execute a command. Bit B4 decimal value: 16
B5	status.standard.COMMAND_ERROR status.standard.CME	Set bit indicates that a command error has occurred. Command errors include: IEEE Std 488.2 syntax error: Instrument received a message that does not follow the defined syntax of the IEEE Std 488.2 standard. Semantic error: Instrument received a command that was misspelled or received an optional IEEE Std 488.2 command that is not implemented. GET error: The instrument received a Group Execute Trigger (GET) inside a program message. Bit B5 decimal value: 32
B6	status.standard.USER_REQUEST status.standard.URQ	Set bit indicates that the LOCAL key on the instrument front panel was pressed. Bit B6 decimal value: 64
B7	status.standard.POWER_ON status.standard.PON	Set bit indicates that the instrument has been turned off and turned back on since the last time this register has been read. Bit B7 decimal value: 128
B8 to B15	Not used	Not applicable

As an example, to set bit B0 of the standard event status enable register, set `status.standard.enable = status.standard.OPC`.

In addition to the above constants, `standardRegister` can be set to the numeric equivalent of the bit to set. To set more than one bit of the register, set `standardRegister` to the sum of their decimal weights. For example, to set bits B0 and B4, set `standardRegister` to 17 (which is the sum of 1 + 16).

Bit	B7	B6	B5	B4	B3	B2	B1	B0
Binary value	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
Decimal	128	64	32	16	8	4	2	1
Weights	(2 ⁷)	(2 ⁶)	(2 ⁵)	(2 ⁴)	(2 ³)	(2 ²)	(2 ¹)	(2 ⁰)

Example 1

```
standardRegister = status.standard.OPC
+ status.standard.EXE
status.standard.enable = standardRegister
```

Sets the OPC and EXE bits of the standard event status enable register using constants.

Example 2

```
-- decimal 17 = binary 0001 0001
standardRegister = 17
status.standard.enable = standardRegister
```

Sets the OPC and EXE bits of the standard event status enable register using a decimal value.

Also see

[Event summary bit \(ESB register\)](#) (on page D-12)

status.system.*

These attributes manage the status model's TSP-Link[®] system summary register for nodes 1 through 14.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute	--	--	--	--
.condition (R)	Yes	Not applicable	Not saved	Not applicable
.enable (RW)	Yes	Status reset	Not saved	0
.event (R)	Yes	Status reset	Not saved	0
.ntr (RW)	Yes	Status reset	Not saved	0
.ptr (RW)	Yes	Status reset	Not saved	32,767 (All bits set)

Usage

```
enableRegister = status.system.condition
enableRegister = status.system.enable
enableRegister = status.system.event
enableRegister = status.system.ntr
enableRegister = status.system.ptr
status.system.enable = enableRegister
status.system.ntr = enableRegister
status.system.ptr = enableRegister
```

<code>enableRegister</code>	The system summary register's status; a zero (0) indicates no bits set; other values indicate various bit settings
-----------------------------	--

Details

In an expanded system (TSP-Link), these attributes are used to read or write to the system summary registers. They are set using a constant or a numeric value, but are returned as a numeric value. The binary equivalent of the value indicates which register bits are set. In the binary equivalent, the least significant bit is bit B0, and the most significant bit is bit B15. For example, if a value of $1.29000e+02$ (which is 129) is read as the value of the condition register, the binary equivalent is 0000 0000 1000 0001. This value indicates that bit B0 and bit B7 are set.

B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0
**	>	>	>	>	>	>	>	>	>	>	>	>	>	>	*
0	0	0	0	0	0	0	0	1	0	0	0	0	0	0	1

* Least significant bit

** Most significant bit

For information about `.condition`, `.enable`, `.event`, `.ntr`, and `.ptr` registers, refer to [Status register sets](#) (on page D-2) and [Enable and transition registers](#) (on page D-22). The individual bits of this register are defined in the following table.

Bit	Value	Description
B0	<code>status.system.EXTENSION_BIT</code> <code>status.system.EXT</code>	Bit B0 decimal value: 1
B1	<code>status.system.NODE1</code>	Bit B1 decimal value: 2
B2	<code>status.system.NODE2</code>	Bit B2 decimal value: 4
B3	<code>status.system.NODE3</code>	Bit B3 decimal value: 8
B4	<code>status.system.NODE4</code>	Bit B4 decimal value: 16
B5	<code>status.system.NODE5</code>	Bit B5 decimal value: 32
B6	<code>status.system.NODE6</code>	Bit B6 decimal value: 64
B7	<code>status.system.NODE7</code>	Bit B7 decimal value: 128
B8	<code>status.system.NODE8</code>	Bit B8 decimal value: 256
B9	<code>status.system.NODE9</code>	Bit B9 decimal value: 512
B10	<code>status.system.NODE10</code>	Bit B10 decimal value: 1024
B11	<code>status.system.NODE11</code>	Bit B11 decimal value: 2048
B12	<code>status.system.NODE12</code>	Bit B12 decimal value: 4096
B13	<code>status.system.NODE13</code>	Bit B13 decimal value: 8192
B14	<code>status.system.NODE14</code>	Bit B14 decimal value: 16384
B15	Not used	Not applicable

As an example, to set bit B0 of the system summary status enable register, set `status.system.enable = status.system.enable.EXT`.

In addition to the above constants, `enableRegister` can be set to the numeric equivalent of the bit to set. To set more than one bit of the register, set `enableRegister` to the sum of their decimal weights. For example, to set bits B11 and B14, set `enableRegister` to 18,432 (which is the sum of 2048 + 16,384).

Bit	B7	B6	B5	B4	B3	B2	B1	B0
Binary value	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
Decimal	128	64	32	16	8	4	2	1
Weights	(2 ⁷)	(2 ⁶)	(2 ⁵)	(2 ⁴)	(2 ³)	(2 ²)	(2 ¹)	(2 ⁰)

Bit	B15	B14	B13	B12	B11	B10	B9	B8
Binary value	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
Decimal	32,768	16,384	8,192	4,096	2,048	1024	512	256
Weights	(2 ¹⁵)	(2 ¹⁴)	(2 ¹³)	(2 ¹²)	(2 ¹¹)	(2 ¹⁰)	(2 ⁹)	(2 ⁸)

Example 1

```
enableRegister = status.system.NODE11 +
  status.system.NODE14
status.system.enable = enableRegister
```

Sets bits B11 and B14 of the system summary enable register using constants.

Example 2

```
-- decimal 18432 = binary 0100 1000 0000 0000
enableRegister = 18432
status.system.enable = enableRegister
```

Sets bits B11 and B14 of the system summary enable register using a decimal value.

Also see

[status.system2.*](#) (on page 8-410)

[System summary and standard event registers](#) (see "[System summary bit \(System register\)](#)" on page D-5)

status.system2.*

These attributes manage the status model's TSP-Link[®] system summary register for nodes 15 through 28.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute	--	--	--	--
.condition (R)	Yes	Not applicable	Not saved	Not applicable
.enable (RW)	Yes	Status reset	Not saved	0
.event (R)	Yes	Status reset	Not saved	0
.ntr (RW)	Yes	Status reset	Not saved	0
.ptr (RW)	Yes	Status reset	Not saved	32,767 (All bits set)

Usage

```
enableRegister = status.system2.condition
enableRegister = status.system2.enable
enableRegister = status.system2.event
enableRegister = status.system2.ntr
enableRegister = status.system2.ptr
status.system2.enable = enableRegister
status.system2.ntr = enableRegister
status.system2.ptr = enableRegister
```

<i>enableRegister</i>	The system summary 2 register's status; a zero (0) indicates no bits set; other values indicate various bit settings
-----------------------	--

Details

In an expanded system (TSP-Link), these attributes are used to read or write to the system summary registers. They are set using a constant or a numeric value, but are returned as a numeric value. The binary equivalent of the value indicates which register bits are set. In the binary equivalent, the least significant bit is bit B0, and the most significant bit is bit B15. For example, if a value of 1.29000e+02 (which is 129) is read as the value of the condition register, the binary equivalent is 0000 0000 1000 0001. This value indicates that bit B0 and bit B7 are set.

B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0
**	>	>	>	>	>	>	>	>	>	>	>	>	>	>	*
0	0	0	0	0	0	0	0	1	0	0	0	0	0	0	1

* Least significant bit

** Most significant bit

For information about .condition, .enable, .event, .ntr, and .ptr registers, refer to [Status register sets](#) (on page D-2) and [Enable and transition registers](#) (on page D-22). The individual bits of this register are defined in the following table.

Bit	Value	Description
B0	status.system2.EXTENSION_BIT status.system2.EXT	Bit B0 decimal value: 1
B1	status.system2.NODE15	Bit B1 decimal value: 2
B2	status.system2.NODE16	Bit B2 decimal value: 4
B3	status.system2.NODE17	Bit B3 decimal value: 8
B4	status.system2.NODE18	Bit B4 decimal value: 16
B5	status.system2.NODE19	Bit B5 decimal value: 32
B6	status.system2.NODE20	Bit B6 decimal value: 64
B7	status.system2.NODE21	Bit B7 decimal value: 128
B8	status.system2.NODE22	Bit B8 decimal value: 256
B9	status.system2.NODE23	Bit B9 decimal value: 512
B10	status.system2.NODE24	Bit B10 decimal value: 1024
B11	status.system2.NODE25	Bit B11 decimal value: 2048
B12	status.system2.NODE26	Bit B12 decimal value: 4096
B13	status.system2.NODE27	Bit B13 decimal value: 8192
B14	status.system2.NODE28	Bit B14 decimal value: 16,384
B15	Not used	Not applicable

As an example, to set bit B0 of the system summary 2 enable register, set `status.system2.enable = status.system2.EXT`.

In addition to the above constants, `enableRegister` can be set to the numeric equivalent of the bit to set. To set more than one bit of the register, set `enableRegister` to the sum of their decimal weights. For example, to set bits B11 and B14, set `enableRegister` to 18,432 (which is the sum of 2048 + 16,384).

Bit	B7	B6	B5	B4	B3	B2	B1	B0
Binary value	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
Decimal	128	64	32	16	8	4	2	1
Weights	(2 ⁷)	(2 ⁶)	(2 ⁵)	(2 ⁴)	(2 ³)	(2 ²)	(2 ¹)	(2 ⁰)

Bit	B15	B14	B13	B12	B11	B10	B9	B8
Binary value	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
Decimal	32,768	16,384	8,192	4,096	2,048	1024	512	256
Weights	(2 ¹⁵)	(2 ¹⁴)	(2 ¹³)	(2 ¹²)	(2 ¹¹)	(2 ¹⁰)	(2 ⁹)	(2 ⁸)

Example 1

```
enableRegister = status.system2.NODE25 +
status.system2.NODE28
status.system2.enable = enableRegister
```

Sets bits B11 and B14 of the system summary 2 enable register using constants.

Example 2

```
-- decimal 18432 = binary 0100 1000 0000 0000
enableRegister = 18432
status.system2.enable = enableRegister
```

Sets bits B11 and B14 of the system summary 2 enable register using a decimal value.

Also see

[status.system.*](#) (on page 8-408)

[status.system3.*](#) (on page 8-412)

[System summary and standard event registers](#) (see "[System summary bit \(System register\)](#)" on page D-5)

status.system3.*

These attributes manage the status model's TSP-Link[®] system summary register for nodes 29 through 42.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute	--	--	--	--
.condition (R)	Yes	Not applicable	Not saved	Not applicable
.enable (RW)	Yes	Status reset	Not saved	0
.event (R)	Yes	Status reset	Not saved	0
.ntr (RW)	Yes	Status reset	Not saved	0
.ptr (RW)	Yes	Status reset	Not saved	32,767 (All bits set)

Usage

```
enableRegister = status.system3.condition
enableRegister = status.system3.enable
enableRegister = status.system3.event
enableRegister = status.system3.ntr
enableRegister = status.system3.ptr
status.system3.enable = enableRegister
status.system3.ntr = enableRegister
status.system3.ptr = enableRegister
```

<i>enableRegister</i>	The system summary 3 register's status; a zero (0) indicates no bits set; other values indicate various bit settings
-----------------------	--

Details

In an expanded system (TSP-Link), these attributes are used to read or write to the system summary registers. They are set using a constant or a numeric value, but are returned as a numeric value. The binary equivalent of the value indicates which register bits are set. In the binary equivalent, the least significant bit is bit B0, and the most significant bit is bit B15. For example, if a value of $1.29000e+02$ (which is 129) is read as the value of the condition register, the binary equivalent is 0000 0000 1000 0001. This value indicates that bit B0 and bit B7 are set.

B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0
**	>	>	>	>	>	>	>	>	>	>	>	>	>	>	*
0	0	0	0	0	0	0	0	1	0	0	0	0	0	0	1

* Least significant bit

** Most significant bit

For information about .condition, .enable, .event, .ntr, and .ptr registers, refer to [Status register sets](#) (on page D-2) and [Enable and transition registers](#) (on page D-22). The individual bits of this register are defined in the following table.

Bit	Value	Description
B0	<code>status.system3.EXTENSION_BIT</code> <code>status.system3.EXT</code>	Bit B0 decimal value: 1
B1	<code>status.system3.NODE29</code>	Bit B1 decimal value: 2
B2	<code>status.system3.NODE30</code>	Bit B2 decimal value: 4
B3	<code>status.system3.NODE31</code>	Bit B3 decimal value: 8
B4	<code>status.system3.NODE32</code>	Bit B4 decimal value: 16
B5	<code>status.system3.NODE33</code>	Bit B5 decimal value: 32
B6	<code>status.system3.NODE34</code>	Bit B6 decimal value: 64
B7	<code>status.system3.NODE35</code>	Bit B7 decimal value: 128
B8	<code>status.system3.NODE36</code>	Bit B8 decimal value: 256
B9	<code>status.system3.NODE37</code>	Bit B9 decimal value: 512
B10	<code>status.system3.NODE38</code>	Bit B10 decimal value: 1024
B11	<code>status.system3.NODE39</code>	Bit B11 decimal value: 2048
B12	<code>status.system3.NODE40</code>	Bit B12 decimal value: 4096
B13	<code>status.system3.NODE41</code>	Bit B13 decimal value: 8192
B14	<code>status.system3.NODE42</code>	Bit B14 decimal value: 16,384
B15	Not used	Not applicable

As an example, to set bit B0 of the system summary 3 enable register, set `status.system3.enable = status.system3.EXT`.

In addition to the above constants, `enableRegister` can be set to the numeric equivalent of the bit to set. To set more than one bit of the register, set `enableRegister` to the sum of their decimal weights. For example, to set bits B11 and B14, set `enableRegister` to 18,432 (which is the sum of 2048 + 16,384).

Bit	B7	B6	B5	B4	B3	B2	B1	B0
Binary value	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
Decimal	128	64	32	16	8	4	2	1
Weights	(2 ⁷)	(2 ⁶)	(2 ⁵)	(2 ⁴)	(2 ³)	(2 ²)	(2 ¹)	(2 ⁰)

Bit	B15	B14	B13	B12	B11	B10	B9	B8
Binary value	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
Decimal	32,768	16,384	8,192	4,096	2,048	1024	512	256
Weights	(2 ¹⁵)	(2 ¹⁴)	(2 ¹³)	(2 ¹²)	(2 ¹¹)	(2 ¹⁰)	(2 ⁹)	(2 ⁸)

Example 1

```
enableRegister = status.system3.NODE39 +
  status.system3.NODE42
status.system3.enable = enableRegister
```

Sets bits B11 and B14 of the system summary 3 enable register using constants.

Example 2

```
-- decimal 18432 = binary 0100 1000 0000 0000
enableRegister = 18432
status.system3.enable = enableRegister
```

Sets bits B11 and B14 of the system summary 3 enable register using a decimal value.

Also see

[status.system2.*](#) (on page 8-410)

[status.system4.*](#) (on page 8-414)

[System summary and standard event registers](#) (see "[System summary bit \(System register\)](#)" on page D-5)

status.system4.*

These attributes manage the status model's TSP-Link® system summary register for nodes 43 through 56.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute	--	--	--	--
.condition (R)	Yes	Not applicable	Not saved	Not applicable
.enable (RW)	Yes	Status reset	Not saved	0
.event (R)	Yes	Status reset	Not saved	0
.ntr (RW)	Yes	Status reset	Not saved	0
.ptr (RW)	Yes	Status reset	Not saved	32,767 (All bits set)

Usage

```
enableRegister = status.system4.condition
enableRegister = status.system4.enable
enableRegister = status.system4.event
enableRegister = status.system4.ntr
enableRegister = status.system4.ptr
status.system4.enable = enableRegister
status.system4.ntr = enableRegister
status.system4.ptr = enableRegister
```

<i>enableRegister</i>	The system summary 4 register's status; a zero (0) indicates no bits set; other values indicate various bit settings
-----------------------	--

Details

In an expanded system (TSP-Link), these attributes are used to read or write to the system summary registers. They are set using a constant or a numeric value, but are returned as a numeric value. The binary equivalent of the value indicates which register bits are set. In the binary equivalent, the least significant bit is bit B0, and the most significant bit is bit B15. For example, if a value of $1.29000e+02$ (which is 129) is read as the value of the condition register, the binary equivalent is 0000 0000 1000 0001. This value indicates that bit B0 and bit B7 are set.

B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0
**	>	>	>	>	>	>	>	>	>	>	>	>	>	>	*
0	0	0	0	0	0	0	0	1	0	0	0	0	0	0	1

* Least significant bit

** Most significant bit

For information about .condition, .enable, .event, .ntr, and .ptr registers, refer to [Status register sets](#) (on page D-2) and [Enable and transition registers](#) (on page D-22). The individual bits of this register are defined in the following table.

Bit	Value	Description
B0	<code>status.system4.EXTENSION_BIT</code> <code>status.system4.EXT</code>	Bit B0 decimal value: 1
B1	<code>status.system4.NODE43</code>	Bit B1 decimal value: 2
B2	<code>status.system4.NODE44</code>	Bit B2 decimal value: 4
B3	<code>status.system4.NODE45</code>	Bit B3 decimal value: 8
B4	<code>status.system4.NODE46</code>	Bit B4 decimal value: 16
B5	<code>status.system4.NODE47</code>	Bit B5 decimal value: 32
B6	<code>status.system4.NODE48</code>	Bit B6 decimal value: 64
B7	<code>status.system4.NODE49</code>	Bit B7 decimal value: 128
B8	<code>status.system4.NODE50</code>	Bit B8 decimal value: 256
B9	<code>status.system4.NODE51</code>	Bit B9 decimal value: 512
B10	<code>status.system4.NODE52</code>	Bit B10 decimal value: 1024
B11	<code>status.system4.NODE53</code>	Bit B11 decimal value: 2048
B12	<code>status.system4.NODE54</code>	Bit B12 decimal value: 4096
B13	<code>status.system4.NODE55</code>	Bit B13 decimal value: 8192
B14	<code>status.system4.NODE56</code>	Bit B14 decimal value: 16,384
B15	Not used	Not applicable

As an example, to set bit B0 of the system summary 4 enable register, set `status.system4.enable = status.system4.enable.EXT`.

In addition to the above constants, `enableRegister` can be set to the numeric equivalent of the bit to set. To set more than one bit of the register, set `enableRegister` to the sum of their decimal weights. For example, to set bits B11 and B14, set `enableRegister` to 18,432 (which is the sum of 2048 + 16,384).

Bit	B7	B6	B5	B4	B3	B2	B1	B0
Binary value	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
Decimal	128	64	32	16	8	4	2	1
Weights	(2 ⁷)	(2 ⁶)	(2 ⁵)	(2 ⁴)	(2 ³)	(2 ²)	(2 ¹)	(2 ⁰)

Bit	B15	B14	B13	B12	B11	B10	B9	B8
Binary value	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
Decimal	32,768	16,384	8,192	4,096	2,048	1024	512	256
Weights	(2 ¹⁵)	(2 ¹⁴)	(2 ¹³)	(2 ¹²)	(2 ¹¹)	(2 ¹⁰)	(2 ⁹)	(2 ⁸)

Example 1

```
enableRegister = status.system4.NODE53 +
status.system4.NODE56
status.system2.enable = enableRegister
```

Sets bit B11 and bit B14 of the system summary 4 enable register using constants.

Example 2

```
-- decimal 18432 = binary 0100 1000 0000 0000
enableRegister = 18432
status.system4.enable = enableRegister
```

Sets bit B11 and bit B14 of the system summary 4 enable register using a decimal value.

Also see

[status.system3.*](#) (on page 8-412)

[status.system5.*](#) (on page 8-416)

[System summary and standard event registers](#) (see "[System summary bit \(System register\)](#)" on page D-5)

status.system5.*

These attributes manage the status model's TSP-Link® system summary register for nodes 57 through 64.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute	--	--	--	--
.condition (R)	Yes	Not applicable	Not saved	Not applicable
.enable (RW)	Yes	Status reset	Not saved	0
.event (R)	Yes	Status reset	Not saved	0
.ntr (RW)	Yes	Status reset	Not saved	0
.ptr (RW)	Yes	Status reset	Not saved	510 (All bits set)

Usage

```
enableRegister = status.system5.condition
enableRegister = status.system5.enable
enableRegister = status.system5.event
enableRegister = status.system5.ntr
enableRegister = status.system5.ptr
status.system5.enable = enableRegister
status.system5.ntr = enableRegister
status.system5.ptr = enableRegister
```

<i>enableRegister</i>	The system summary 5 register's status; a zero (0) indicates no bits set; other values indicate various bit settings
-----------------------	--

Details

In an expanded system (TSP-Link), these attributes are used to read or write to the system summary registers. They are set using a constant or a numeric value, but are returned as a numeric value. The binary equivalent of the value indicates which register bits are set. In the binary equivalent, the least significant bit is bit B0, and the most significant bit is bit B15. For example, if a value of $1.30000e+02$ (which is 130) is read as the value of the condition register, the binary equivalent is 0000 0000 1000 0010. This value indicates that bit B1 and bit B7 are set.

B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0
**	>	>	>	>	>	>	>	>	>	>	>	>	>	>	*
0	0	0	0	0	0	0	0	1	0	0	0	0	0	1	0

* Least significant bit

** Most significant bit

For information about `.condition`, `.enable`, `.event`, `.ntr`, and `.ptr` registers, refer to [Status register sets](#) (on page D-2) and [Enable and transition registers](#) (on page D-22). The individual bits of this register are defined in the following table.

Bit	Value	Description
B0	Not used	Not applicable
B1	<code>status.system5.NODE57</code>	Bit B1 decimal value: 2
B2	<code>status.system5.NODE58</code>	Bit B2 decimal value: 4
B3	<code>status.system5.NODE59</code>	Bit B3 decimal value: 8
B4	<code>status.system5.NODE60</code>	Bit B4 decimal value: 16
B5	<code>status.system5.NODE61</code>	Bit B5 decimal value: 32
B6	<code>status.system5.NODE62</code>	Bit B6 decimal value: 64
B7	<code>status.system5.NODE63</code>	Bit B7 decimal value: 128
B8	<code>status.system5.NODE64</code>	Bit B8 decimal value: 256
B9-B15	Not used	Not applicable

As an example, to set bit B1 of the system summary 5 enable register, set `status.system5.enable = status.system5.NODE57`.

In addition to the above constants, `enableRegister` can be set to the numeric equivalent of the bit to set. To set more than one bit of the register, set `enableRegister` to the sum of their decimal weights. For example, to set bits B1 and B4, set `enableRegister` to 18 (which is the sum of 2 + 16).

Bit	B7	B6	B5	B4	B3	B2	B1	B0
Binary value	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
Decimal	128	64	32	16	8	4	2	1
Weights	(2 ⁷)	(2 ⁶)	(2 ⁵)	(2 ⁴)	(2 ³)	(2 ²)	(2 ¹)	(2 ⁰)

Bit	B15	B14	B13	B12	B11	B10	B9	B8
Binary value	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
Decimal	32,768	16,384	8,192	4,096	2,048	1024	512	256
Weights	(2 ¹⁵)	(2 ¹⁴)	(2 ¹³)	(2 ¹²)	(2 ¹¹)	(2 ¹⁰)	(2 ⁹)	(2 ⁸)

Example 1

```
enableRegister = status.system5.NODE57 +
status.system5.NODE60
status.system2.enable = enableRegister
```

Sets bits B1 and B4 of the system summary 5 enable register using constants.

Example 2

```
-- decimal 18 = binary 0000 0000 0001 0010
enableRegister = 18
status.system5.enable = enableRegister
```

Sets bits B1 and B4 of the system summary 5 enable register using a decimal value.

Also see

[status.system4.*](#) (on page 8-414)

[System summary and standard event registers](#) (see "[System summary bit \(System register\)](#)" on page D-5)

timer.measure.t()

This function measures the elapsed time since the timer was last reset.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
time = timer.measure.t()
```

<code>time</code>	The elapsed time in seconds (1 μ s resolution)
-------------------	--

Example 1

```
timer.reset()
-- (intervening code)
time = timer.measure.t()
print(time)
```

Resets the timer and measures the time since the reset.

Output:

```
1.469077e+01
```

The output will vary. The above output indicates that `timer.measure.t()` was executed 14.69077 seconds after `timer.reset()`.

Example 2

```
beeper.beeper(0.5, 2400)
print("reset timer")
timer.reset()
delay(0.5)
dt = timer.measure.t()
print("timer after delay:", dt)
beeper.beeper(0.5, 2400)
```

Sets the beeper, resets the timer, sets a delay, then verifies the time of the delay before the next beeper.

Output:

```
reset timer
timer after delay: 5.00e-01
```

Also see

[timer.reset\(\)](#) (on page 8-418)

timer.reset()

This function resets the timer to zero (0) seconds.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
timer.reset()
```

Example

```
timer.reset()
-- (intervening code)
time = timer.measure.t()
print(time)
```

Resets the timer and then measures the time since the reset.

Output:
1.469077e+01

The above output indicates that `timer.measure.t()` was executed 14.69077 seconds after `timer.reset()`.

Also see

[timer.measure.t\(\)](#) (on page 8-418)

trigger.blender[N].clear()

This function clears the blender event detector and resets blender *N*.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
trigger.blender[N].clear()
```

<i>N</i>	The blender number (1 or 2)
----------	-----------------------------

Details

This function sets the blender event detector to the undetected state and resets the event detector's overrun indicator.

Example

```
trigger.blender[2].clear()
```

Clears the event detector for blender 2.

Also see

None

trigger.blender[N].EVENT_ID

This constant contains the trigger blender event number.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Constant	Yes			

Usage

```
eventID = trigger.blender[N].EVENT_ID
```

<i>eventID</i>	Trigger event number
<i>N</i>	The blender number (1 or 2)

Details

Set the stimulus of any trigger event detector to the value of this constant to have it respond to trigger events from this trigger blender.

Example

```
digio.trigger[1].stimulus = trigger.blender[2].EVENT_ID
```

Set the trigger stimulus of digital I/O trigger 1 event detector to be controlled by the trigger blender 2 event.

Also see

None

trigger.blender[N].orenable

This attribute selects whether the blender operates in OR mode or AND mode.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Instrument reset Trigger blender N reset Recall setup	Create configuration script Save setup	false (AND mode)

Usage

```
orenable = trigger.blender[N].orenable
trigger.blender[N].orenable = orenable
```

<i>orenable</i>	The orenable mode: <ul style="list-style-type: none"> • true: OR mode • false: AND mode
<i>N</i>	The trigger blender (1 or 2)

Details

This attribute selects whether the blender waits for any one event (the “OR” mode) or waits for all selected events (the “AND” mode) before signaling an output event.

Example

```
digio.trigger[3].mode = digio.TRIG_FALLING
digio.trigger[5].mode = digio.TRIG_FALLING
trigger.blender[1].orenable = true
trigger.blender[1].stimulus[1] = digio.trigger[3].EVENT_ID
trigger.blender[1].stimulus[2] = digio.trigger[5].EVENT_ID
```

Generate a trigger blender 1 event when a digital I/O trigger happens on line 3 or 5.

Also see

[trigger.blender\[N\].reset\(\)](#) (on page 8-421)

trigger.blender[N].overrun

This attribute indicates whether or not an event was ignored because of the event detector state.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Reset Trigger blender N clear Trigger blender N reset	Not applicable	Not applicable

Usage

```
overrun = trigger.blender[N].overrun
```

<i>overrun</i>	Trigger blender overrun state
<i>N</i>	The trigger event blender (1 or 2)

Details

Indicates if an event was ignored because the event detector was already in the detected state when the event occurred. This is an indication of the state of the event detector that is built into the event blender itself.

This attribute does not indicate if an overrun occurred in any other part of the trigger model or in any other trigger object that is monitoring the event. It also is not an indication of an action overrun.

Example

```
print(trigger.blender[1].overrun)
```

If an event was ignored, the output is `true`.
If an event was not ignored, the output is `false`.

Also see

[trigger.blender\[N\].reset\(\)](#) (on page 8-421)

trigger.blender[N].reset()

This function resets some of the trigger blender settings to their factory defaults.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
trigger.blender[N].reset()
```

<i>N</i>	The trigger event blender (1 or 2)
----------	------------------------------------

Details

The `trigger.blender[N].reset()` function resets the following attributes to their factory defaults:

- `trigger.blender[N].orenable`
- `trigger.blender[N].stimulus[M]`

It also clears `trigger.blender[N].overrun`.

Example

```
trigger.blender[1].reset()
```

Resets the trigger blender 1 settings back to factory defaults.

Also see

[trigger.blender\[N\].orenable](#) (on page 8-420)
[trigger.blender\[N\].overrun](#) (on page 8-421)
[trigger.blender\[N\].stimulus\[M\]](#) (on page 8-422)

trigger.blender[N].stimulus[M]

This attribute specifies which events trigger the blender.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset Recall setup Trigger blender N reset	Create configuration script Save setup	0

Usage

```
eventID = trigger.blender[N].stimulus[M]  

trigger.blender[N].stimulus[M] = eventID
```

<i>eventID</i>	The event that triggers the blender action; see Details
<i>N</i>	An integer representing the trigger event blender (1 or 2)
<i>M</i>	An integer representing the stimulus index (1 to 4)

Details

There are four acceptors that can each select a different event. The *eventID* parameter can be the event ID of any trigger event.

The *eventID* parameter may be one of the existing trigger event IDs shown in the following table.

Trigger event IDs	
Trigger event ID	Description
<code>channel.trigger[N].EVENT_ID</code>	A channel trigger event starts the scan.
<code>digio.trigger[N].EVENT_ID</code>	An edge (either rising, falling, or either based on the configuration of the line) on the digital input line.
<code>display.trigger.EVENT_ID</code>	The trigger key on the front panel is pressed.
<code>dmm.trigger.EVENT_LIMIT1_HIGH</code>	A DMM trigger event that indicates a measurement has exceed the high limit value on limit 1.
<code>dmm.trigger.EVENT_LIMIT1_LOW</code>	A DMM trigger event that indicates a measurement has exceed the low limit value on limit 1.
<code>dmm.trigger.EVENT_LIMIT2_HIGH</code>	A DMM trigger event that indicates a measurement has exceed the high limit value on limit 2.
<code>dmm.trigger.EVENT_LIMIT2_LOW</code>	A DMM trigger event that indicates a measurement has exceed the low limit value on limit 2.
<code>trigger.EVENT_ID</code>	A *trg message on the active command interface. If GPIB is the active command interface, a GET message also generates this event.
<code>trigger.blender[N].EVENT_ID</code>	A combination of events has occurred.
<code>trigger.timer[N].EVENT_ID</code>	A delay expired.
<code>tsplink.trigger[N].EVENT_ID</code>	An edge (either rising, falling, or either based on the configuration of the line) on the TSP-Link trigger line.
<code>lan.trigger[N].EVENT_ID</code>	A LAN trigger event has occurred.
<code>scan.trigger.EVENT_SCAN_READY</code>	Scan ready event.
<code>scan.trigger.EVENT_SCAN_START</code>	Scan start event.
<code>scan.trigger.EVENT_CHANNEL_READY</code>	Channel ready event.
<code>scan.trigger.EVENT_MEASURE_COMP</code>	Measure complete event.
<code>scan.trigger.EVENT_SEQUENCE_COMP</code>	Sequence complete event.
<code>scan.trigger.EVENT_SCAN_COMP</code>	Scan complete event.
<code>scan.trigger.EVENT_IDLE</code>	Idle event.
<code>schedule.alarm[N].EVENT_ID</code>	A scan starts when alarm <i>N</i> fires.

Example

```
digio.trigger[3].mode = digio.TRIG_FALLING
digio.trigger[5].mode = digio.TRIG_FALLING
trigger.blender[1].orenable = true
trigger.blender[1].stimulus[1] = digio.trigger[3].EVENT_ID
trigger.blender[1].stimulus[2] = digio.trigger[5].EVENT_ID
```

Generate a trigger blender 1 event when a digital I/O trigger happens on line 3 or 5.

Also see

[trigger.blender\[N\].reset\(\)](#) (on page 8-421)

trigger.blender[N].wait()

This function waits for a blender trigger event to occur.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
triggered = trigger.blender[N].wait(timeout)
```

<i>triggered</i>	Trigger detection indication for blender
<i>N</i>	The trigger blender (1 or 2) on which to wait
<i>timeout</i>	Maximum amount of time in seconds to wait for the trigger blender event

Details

This function waits for an event blender trigger event. If one or more trigger events were detected since the last time `trigger.blender[N].wait()` or `trigger.blender[N].clear()` was called, this function returns immediately.

After detecting a trigger with this function, the event detector automatically resets and rearms. This is true regardless of the number of events detected.

Example

```
digio.trigger[3].mode = digio.TRIG_FALLING
digio.trigger[5].mode = digio.TRIG_FALLING
trigger.blender[1].orenable = true
trigger.blender[1].stimulus[1] = digio.trigger[3].EVENT_ID
trigger.blender[1].stimulus[2] = digio.trigger[5].EVENT_ID

print(trigger.blender[1].wait(3))
```

Generate a trigger blender 1 event when a digital I/O trigger happens either on line 3 or 5.

Wait three seconds while checking if trigger blender 1 event has occurred.

If the blender trigger event has happened, then `true` is output. If the trigger event has not happened, then `false` is output after the timeout expires.

Also see

[trigger.blender\[N\].clear\(\)](#) (on page 8-419)

trigger.clear()

This function clears the command interface trigger event detector.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
trigger.clear()
```

Details

The trigger event detector indicates if an event has been detected since the last `trigger.wait()` call. This function clears the trigger's event detector and discards the previous history of command interface trigger events.

Also see

[trigger.wait\(\)](#) (on page 8-432)

trigger.EVENT_ID

This constant contains the command interface trigger event number.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Constant	Yes			

Usage

```
eventID = trigger.EVENT_ID
```

<code>eventID</code>	The command interface trigger event number
----------------------	--

Details

You can set the stimulus of any trigger event detector to the value of this constant to have it respond to command interface trigger events.

Example

<code>scan.trigger.channel.stimulus = trigger.EVENT_ID</code>	Sets the trigger stimulus of the channel event detector to command an interface trigger event.
---	--

Also see

None

trigger.timer[N].clear()

This function clears the timer event detector and overrun indicator for the specified trigger timer number.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
trigger.timer[N].clear()
```

<i>N</i>	Trigger timer number to clear (1 to 4)
----------	--

Details

This function sets the timer event detector to the undetected state and resets the overrun indicator.

Example

<code>trigger.timer[1].clear()</code>	Clears trigger timer 1.
---------------------------------------	-------------------------

Also see

[trigger.timer\[N\].count](#) (on page 8-426)

trigger.timer[N].count

This attribute sets the number of events to generate each time the timer is triggered.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset Recall setup Trigger timer N reset	Create configuration script Save setup	1

Usage

```
count = trigger.timer[N].count
trigger.timer[N].count = count
```

<i>count</i>	Number of times to repeat the trigger
<i>N</i>	A trigger timer number (1 to 4)

Details

If *count* is set to a number greater than 1, the timer automatically starts the next delay at expiration of the previous delay.

Set *count* to zero (0) to cause the timer to generate trigger events indefinitely.

Example

<code>print(trigger.timer[1].count)</code>	Read trigger count for timer number 1.
--	--

Also see

[trigger.timer\[N\].clear\(\)](#) (on page 8-426)

[trigger.timer\[N\].reset\(\)](#) (on page 8-430)

trigger.timer[N].delay

This attribute sets and reads the timer delay.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset Recall setup Trigger timer N reset	Create configuration script Save setup	10e-6

Usage

```
interval = trigger.timer[N].delay
trigger.timer[N].delay = interval
```

<i>interval</i>	Delay interval in seconds
<i>N</i>	Trigger timer number (1 to 4)

Details

Each time the timer is triggered, it uses this delay period.

Assigning a value to this attribute is equivalent to:

```
trigger.timer[N].delaylist = {interval}
```

This creates a delay list of one value.

Reading this attribute returns the delay interval that will be used the next time the timer is triggered.

Example

```
trigger.timer[1].delay = 50e-6
```

Set the trigger timer 1 to delay for 50 μ s.

Also see

[trigger.timer\[N\].reset\(\)](#) (on page 8-430)

trigger.timer[N].delaylist

This attribute sets an array of timer intervals that are used when triggered.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset Recall setup Trigger timer N reset	Create configuration script Save setup	{10e-6}

Usage

```
intervals = trigger.timer[N].delaylist
trigger.timer[N].delaylist = intervals
```

<i>intervals</i>	Table of delay intervals in seconds
<i>N</i>	Trigger timer number (1 to 4)

Details

Each time the timer is triggered, it uses the next delay period from the array.

After all elements in the array have been used, the delays restart at the beginning of the list.

If the array contains more than one element, the average of the delay intervals in the list must be $\geq 50 \mu$ s.

Example

```
trigger.timer[3].delaylist = {50e-6, 100e-6, 150e-6}

DelayList = trigger.timer[3].delaylist
for x = 1, table.getn(DelayList) do
    print(DelayList[x])
end
```

Set a delay list on trigger timer 3 with three delays (50 μ s, 100 μ s, and 150 μ s).

Read the delay list on trigger timer 3.

Output (assuming the delay list was set to 50 μ s, 100 μ s, and 150 μ s):

```
5.000000000e-05
1.000000000e-04
1.500000000e-04
```

Also see

[trigger.timer\[N\].reset\(\)](#) (on page 8-430)

trigger.timer[N].EVENT_ID

This constant specifies the trigger timer event number.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Constant	Yes			

Usage

```
eventID = trigger.timer[N].EVENT_ID
```

<i>eventID</i>	The trigger event number
<i>N</i>	The trigger timer number (1 to 4)

Details

This constant is an identification number that identifies events generated by this timer.

Set the stimulus of any trigger event detector to the value of this constant to have it respond to events from this timer.

Example

```
scan.trigger.channel.stimulus = trigger.timer[2].EVENT_ID
```

Sets the trigger stimulus of the channel event detector to trigger timer 2 event.

Also see

None

trigger.timer[N].overrun

This attribute indicates if an event was ignored because of the event detector state.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Reset Recall setup Trigger timer N clear Trigger timer N reset	Not applicable	false

Usage

```
overrun = trigger.timer[N].overrun
```

<i>overrun</i>	Trigger overrun state
<i>N</i>	Trigger timer number (1 to 4)

Details

This attribute indicates if an event was ignored because the event detector was already in the detected state when the event occurred.

This is an indication of the state of the event detector built into the timer itself. It does not indicate if an overrun occurred in any other part of the trigger model or in any other construct that is monitoring the delay completion event. It also is not an indication of a delay overrun.

Example

```
print(trigger.timer[1].overrun)
```

If an event was ignored, the output is `true`.
If the event was not ignored, the output is `false`.

Also see

[trigger.timer\[N\].reset\(\)](#) (on page 8-430)

trigger.timer[N].passthrough

This attribute enables or disables the timer trigger pass-through mode.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset Recall setup Trigger timer N reset	Create configuration script Save setup	false (disabled)

Usage

```
passthrough = trigger.timer[N].passthrough
trigger.timer[N].passthrough = passthrough
```

<i>passthrough</i>	The state of pass-through mode. Set to to one of the following values: true: Enabled false: Disabled
<i>N</i>	Trigger timer number (1 to 4)

Details

When enabled, triggers are passed through immediately and initiate the delay. When disabled, a trigger only initiates a delay.

Example

```
trigger.timer[1].passthrough = true
```

Enables pass-through mode on trigger timer 1.

Also see

[trigger.timer\[N\].reset\(\)](#) (on page 8-430)

trigger.timer[N].reset()

This function resets some of the trigger timer settings to their factory defaults.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
trigger.timer[N].reset()
```

<i>N</i>	Trigger timer number (1 to 4)
----------	-------------------------------

Details

The `trigger.timer[N].reset()` function resets the following attributes to their factory defaults:

- `trigger.timer[N].count`
- `trigger.timer[N].delay`
- `trigger.timer[N].delaylist`
- `trigger.timer[N].passthrough`
- `trigger.timer[N].stimulus`

It also clears `trigger.timer[N].overrun`.

Example

```
trigger.timer[1].reset()
```

Resets the attributes associated with timer 1 back to factory default values.

Also see

- [trigger.timer\[N\].count](#) (on page 8-426)
- [trigger.timer\[N\].delay](#) (on page 8-427)
- [trigger.timer\[N\].delaylist](#) (on page 8-427)
- [trigger.timer\[N\].overrun](#) (on page 8-428)
- [trigger.timer\[N\].passthrough](#) (on page 8-429)
- [trigger.timer\[N\].stimulus](#) (on page 8-430)

trigger.timer[N].stimulus

This attribute specifies which event starts the timer.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset Recall setup Trigger timer N reset	Create configuration script Save setup	0

Usage

```
eventID = trigger.timer[N].stimulus  
trigger.timer[N].stimulus = eventID
```

<i>eventID</i>	The event that triggers the timer delay
<i>N</i>	Trigger timer number (1 to 4)

Details

The *eventID* parameter may be one of the trigger event IDs shown in the following table.

Trigger event IDs	
Trigger event ID	Description
<code>channel.trigger[N].EVENT_ID</code>	A channel trigger event starts the scan.
<code>digio.trigger[N].EVENT_ID</code>	An edge (either rising, falling, or either based on the configuration of the line) on the digital input line.
<code>display.trigger.EVENT_ID</code>	The trigger key on the front panel is pressed.
<code>dmm.trigger.EVENT_LIMIT1_HIGH</code>	A DMM trigger event that indicates a measurement has exceed the high limit value on limit 1.
<code>dmm.trigger.EVENT_LIMIT1_LOW</code>	A DMM trigger event that indicates a measurement has exceed the low limit value on limit 1.
<code>dmm.trigger.EVENT_LIMIT2_HIGH</code>	A DMM trigger event that indicates a measurement has exceed the high limit value on limit 2.
<code>dmm.trigger.EVENT_LIMIT2_LOW</code>	A DMM trigger event that indicates a measurement has exceed the low limit value on limit 2.
<code>trigger.EVENT_ID</code>	A *trg message on the active command interface. If GPIB is the active command interface, a GET message also generates this event.
<code>trigger.blender[N].EVENT_ID</code>	A combination of events has occurred.
<code>trigger.timer[N].EVENT_ID</code>	A delay expired.
<code>tsplink.trigger[N].EVENT_ID</code>	An edge (either rising, falling, or either based on the configuration of the line) on the TSP-Link trigger line.
<code>lan.trigger[N].EVENT_ID</code>	A LAN trigger event has occurred.
<code>scan.trigger.EVENT_SCAN_READY</code>	Scan ready event.
<code>scan.trigger.EVENT_SCAN_START</code>	Scan start event.
<code>scan.trigger.EVENT_CHANNEL_READY</code>	Channel ready event.
<code>scan.trigger.EVENT_MEASURE_COMP</code>	Measure complete event.
<code>scan.trigger.EVENT_SEQUENCE_COMP</code>	Sequence complete event.
<code>scan.trigger.EVENT_SCAN_COMP</code>	Scan complete event.
<code>scan.trigger.EVENT_IDLE</code>	Idle event.
<code>schedule.alarm[N].EVENT_ID</code>	A scan starts when alarm <i>N</i> fires.

Set this attribute to the *eventID* of any trigger event to wait for that event.

Use zero (0) to disable event processing.

Example

```
print(trigger.timer[1].stimulus)
```

Prints the event that will start a trigger 1 timer action.

Also see

[trigger.timer\[N\].reset\(\)](#) (on page 8-430)

trigger.timer[N].wait()

This function waits for a trigger.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
triggered = trigger.timer[N].wait(timeout)
```

<i>triggered</i>	Trigger detection indication
<i>N</i>	Trigger timer number (1 to 4)
<i>timeout</i>	Maximum amount of time in seconds to wait for the trigger

Details

If one or more trigger events were detected since the last time `trigger.timer[N].wait()` or `trigger.timer[N].clear()` was called, this function returns immediately.

After waiting for a trigger with this function, the event detector is automatically reset and rearmed. This is true regardless of the number of events detected.

Example

```
triggered = trigger.timer[3].wait(10)
print(triggered)
```

Waits up to 10 seconds for a trigger on timer 3.
If `false` is returned, no trigger was detected during the 10-second timeout.
If `true` is returned, a trigger was detected.

Also see

[trigger.timer\[N\].clear\(\)](#) (on page 8-426)

trigger.wait()

This function waits for a command interface trigger event.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
triggered = trigger.wait(timeout)
```

<i>triggered</i>	<code>true</code> : A trigger was detected during the timeout period <code>false</code> : No triggers were detected during the timeout period
<i>timeout</i>	Maximum amount of time in seconds to wait for the trigger

Details

This function waits up to *timeout* seconds for a trigger on the active command interface. A command interface trigger occurs when:

- A GPIB GET command is detected (GPIB only)
- A VXI-11 device_trigger method is invoked (VXI-11 only)
- A *TRG message is received

If one or more of these trigger events were previously detected, this function returns immediately.

After waiting for a trigger with this function, the event detector is automatically reset and rearmed. This is true regardless of the number of events detected.

Example

```
triggered = trigger.wait(10)
print(triggered)
```

Waits up to 10 seconds for a trigger.
If *false* is returned, no trigger was detected during the 10-second timeout.
If *true* is returned, a trigger was detected.

Also see

[trigger.clear\(\)](#) (on page 8-425)

tsplink.group

This attribute is the group number of a TSP-Link node used for delay tolerant networks (DTNs).

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Not applicable	Not saved	0

Usage

```
groupNumber = tsplink.group
tsplink.group = groupNumber
```

<i>groupNumber</i>	The group number of the TSP-Link node (0 to 64)
--------------------	---

Details

To remove the node from all groups, set the attribute value to 0.

When the node is turned off, the group number for that node changes to 0.

Example

```
tsplink.group = 3
```

Assign the instrument to TSP-Link group number 3.

Also see

None

tsplink.master

This attribute reads the node number assigned to the master node.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
masterNodeNumber = tsplink.master
```

<i>masterNodeNumber</i>	The node number of the master node
-------------------------	------------------------------------

Details

After doing a TSP-Link reset (`tsplink.reset()`), use this attribute to access the node number of the master in a set of instruments connected over TSP-Link.

Example

```
LinkMaster = tsplink.master
```

Store the TSP-Link master node number in a variable called LinkMaster.

Also see

[tsplink.reset\(\)](#) (on page 8-436)

tsplink.node

This attribute defines the node number.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Not applicable	Nonvolatile memory	2

Usage

```
nodeNumber = tsplink.node
tsplink.node = nodeNumber
```

<i>nodeNumber</i>	Set node to a number (1 to 64)
-------------------	--------------------------------

Details

This attribute sets the TSP-Link node number and saves the value in nonvolatile memory.

Changes to the node number do not take effect until the next time `tsplink.reset()` is executed on any node in the system.

Each node connected to the TSP-Link system must be assigned a different node number.

Example

```
tsplink.node = 2
```

Sets the TSP-Link node to number 2.

Also see

[tsplink.reset\(\)](#) (on page 8-436)

[tsplink.state](#) (on page 8-436)

tsplink.readbit()

This function reads the state of a TSP-Link synchronization line.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
data = tsplink.readbit(N)
```

<i>data</i>	A custom variable that stores the state of the synchronization line
<i>N</i>	The trigger line (1 to 3)

Details

Returns a value of zero (0) if the line is low and 1 if the line is high.

Example

```
data = tsplink.readbit(3)
print(data)
```

Assume line 3 is set high, and it is then read.
Output
1.000000e+00

Also see

[tsplink.readport\(\)](#) (on page 8-435)
[tsplink.writebit\(\)](#) (on page 8-445)

tsplink.readport()

This function reads the TSP-Link[®] synchronization lines as a digital I/O port.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
data = tsplink.readport()
```

<i>data</i>	Numeric value returned indicating which register bits are set
-------------	---

Details

The binary equivalent of the returned value indicates the input pattern on the I/O port. The least significant bit of the binary number corresponds to line 1 and bit B3 corresponds to line 3. For example, a returned value of 2 has a binary equivalent of 010. Line 2 is high (1), and the other 2 lines are low (0).

Example

```
data = tsplink.readport()
print(data)
```

Reads state of all three TSP-Link lines.
Assuming line 2 is set high, the output is:
2.000000e+00
(binary 010)

Also see

[TSP-Link synchronization lines](#) (on page 3-48)
[tsplink.readbit\(\)](#) (on page 8-435)
[tsplink.writebit\(\)](#) (on page 8-445)
[tsplink.writeport\(\)](#) (on page 8-446)

tsplink.reset()

This function initializes (resets) all nodes (instruments) in the TSP-Link system.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
nodesFound = tsplink.reset()
nodesFound = tsplink.reset(expectedNodes)
```

<i>nodesFound</i>	The number of nodes actually found on the system
<i>expectedNodes</i>	The number of nodes expected on the system (1 to 64)

Details

This function erases all knowledge of other nodes connected on the TSP-Link system and regenerates the system configuration. This function must be called at least once before any remote nodes can be accessed. If the node number for any instrument is changed, the TSP-Link nodes must be initialized again.

If *expectedNodes* is not given, this function generates an error if no other nodes are found on the TSP-Link network.

If *nodesFound* is less than *expectedNodes*, an error is generated. Note that the node on which the command is running is counted as a node. For example, giving an expected node count of 1 will not generate any errors, even if there are no other nodes on the TSP-Link network.

Also returns the number of nodes found.

Example

```
nodesFound = tsplink.reset(2)
print("Nodes found = " .. nodesFound)
```

Perform a TSP-Link reset and indicate how many nodes are found.

Sample output if fewer nodes are found:

```
1219, TSP-Link found fewer nodes
than expected
```

```
Nodes found = 1
```

Sample output if found 2 nodes:

```
Nodes found = 2
```

Also see

[tsplink.node](#) (on page 8-434)
[tsplink.state](#) (on page 8-436)

tsplink.state

This attribute describes the TSP-Link online state.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Not applicable	Not applicable	Not applicable

Usage

```
state = tsplink.state
```

state	TSP-Link state (online or offline)
-------	------------------------------------

Details

When the instrument power is turned on, the state is `offline`. After `tsplink.reset()` function is successful, the state is `online`.

Example

```
state = tsplink.state
print(state)
```

Read the state of the TSP-Link. If it is online, the output is:
online

Also see

[tsplink.node](#) (on page 8-434)
[tsplink.reset\(\)](#) (on page 8-436)

tsplink.trigger[N].assert()

This function simulates the occurrence of the trigger and generates the corresponding event ID.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
tsplink.trigger[N].assert()
```

N	The trigger line (1 to 3)
---	---------------------------

Details

The set pulse width determines how long the trigger is asserted.

Example

```
tsplink.trigger[2].assert()
```

Asserts trigger on trigger line 2.

Also see

[tsplink.trigger\[N\].clear\(\)](#) (on page 8-438)
[tsplink.trigger\[N\].mode](#) (on page 8-439)
[tsplink.trigger\[N\].overrun](#) (on page 8-441)
[tsplink.trigger\[N\].pulsewidth](#) (on page 8-441)
[tsplink.trigger\[N\].release\(\)](#) (on page 8-442)
[tsplink.trigger\[N\].stimulus](#) (on page 8-443)
[tsplink.trigger\[N\].wait\(\)](#) (on page 8-445)

tsplink.trigger[N].clear()

This function clears the event detector for a trigger.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
tsplink.trigger[N].clear()
```

<i>N</i>	The trigger line (1 to 3)
----------	---------------------------

Details

The event detector for a trigger recalls if a trigger event has been detected since the last `tsplink.trigger[N].wait()` call. This function clears a trigger event detector, discards the previous history of the trigger line, and clears the `tsplink.trigger[N].overrun` attribute.

Example

```
tsplink.trigger[2].clear()      Clears trigger event on synchronization line 2.
```

Also see

[tsplink.trigger\[N\].mode](#) (on page 8-439)
[tsplink.trigger\[N\].overrun](#) (on page 8-441)
[tsplink.trigger\[N\].release\(\)](#) (on page 8-442)
[tsplink.trigger\[N\].stimulus](#) (on page 8-443)
[tsplink.trigger\[N\].wait\(\)](#) (on page 8-445)

tsplink.trigger[N].EVENT_ID

This constant identifies the number that is used for the trigger events.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Constant	Yes			

Usage

```
eventID = tsplink.trigger[N].EVENT_ID
```

<i>eventID</i>	The trigger event number
<i>N</i>	The trigger line (1 to 3)

Details

This number is used by the TSP-Link trigger line when it detects an input trigger.

Set the stimulus of any trigger event detector to the value of this constant to have it respond to trigger events from this line.

Example

```
scan.trigger.channel.stimulus = tsplink.trigger[2].EVENT_ID
```

Sets the trigger stimulus of the channel event detector to the TSP-Link trigger 2 event.

Also see

None

tsplink.trigger[N].mode

This attribute defines the trigger operation and detection mode.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset Recall setup TSP-Link trigger N reset	Create configuration script Save setup	tsplink.TRIG_BYPASS

Usage

```
mode = tsplink.trigger[N].mode
tsplink.trigger[N].mode = mode
```

<i>mode</i>	The trigger mode
<i>N</i>	The trigger line (1 to 3)

Details

This attribute controls the mode in which the trigger event detector and the output trigger generator operate on the given trigger line.

The setting for *mode* can be one of the following values:

Mode	Number value	Description
<code>tsplink.TRIG_BYPASS</code>	0	Allows direct control of the line as a digital I/O line.
<code>tsplink.TRIG_FALLING</code>	1	Detects falling-edge triggers as input. Asserts a TTL-low pulse for output.
<code>tsplink.TRIG_RISING</code>	2	If the programmed state of the line is high, the <code>tsplink.TRIG_RISING</code> mode behaves similar to <code>tsplink.TRIG_RISINGA</code> . If the programmed state of the line is low, the <code>tsplink.TRIG_RISING</code> mode behaves similar to <code>tsplink.TRIG_RISINGM</code> . Use <code>tsplink.TRIG_RISINGA</code> if the line is in the high output state. Use <code>tsplink.TRIG_RISINGM</code> if the line is in the low output state.
<code>tsplink.TRIG_EITHER</code>	3	Detects rising- or falling-edge triggers as input. Asserts a TTL-low pulse for output.
<code>tsplink.TRIG_SYNCHRONOUS</code>	4	Detects the falling-edge input triggers and automatically latches and drives the trigger line low.
<code>tsplink.TRIG_SYNCHRONOUSM</code>	5	Detects the falling-edge input triggers and automatically latches and drives the trigger line low. Asserts a TTL-low pulse as an output trigger.
<code>tsplink.TRIG_SYNCHRONOUSA</code>	6	Detects rising-edge triggers as an input. Asserts a TTL-low pulse for output.
<code>tsplink.TRIG_RISINGA</code>	7	Detects rising-edge triggers as input. Asserts a TTL-low pulse for output.
<code>tsplink.TRIG_RISINGM</code>	8	Edge detection as an input is not available. Generates a TTL-high pulse as an output trigger.

When programmed to any other mode, the output state of the I/O line is controlled by the trigger logic, and the user-specified output state of the line is ignored.

When the trigger mode is set to `tsplink.TRIG_RISING`, the user-specified output state of the line will be examined. If the output state selected when the mode is changed is high, the actual mode used will be `tsplink.TRIG_RISINGA`. If the output state selected when the mode is changed is low, the actual mode used will be `tsplink.TRIG_RISINGM`.

The custom variable `mode` stores the trigger mode as a numeric value when the attribute is read.

To control the line state, use the `tsplink.TRIG_BYPASS` mode with the `tsplink.writebit()` and the `tsplink.writeport()` commands.

Example

```
tsplink.trigger[3].mode =
  tsplink.TRIG_RISINGM
```

Sets the trigger mode for synchronization line 3 to `tsplink.TRIG_RISINGM`.

Also see

[digio.writebit\(\)](#) (on page 8-130)
[digio.writeport\(\)](#) (on page 8-130)
[tsplink.trigger\[N\].assert\(\)](#) (on page 8-437)
[tsplink.trigger\[N\].clear\(\)](#) (on page 8-438)
[tsplink.trigger\[N\].overrun](#) (on page 8-441)
[tsplink.trigger\[N\].release\(\)](#) (on page 8-442)
[tsplink.trigger\[N\].reset\(\)](#) (on page 8-442)
[tsplink.trigger\[N\].stimulus](#) (on page 8-443)
[tsplink.trigger\[N\].wait\(\)](#) (on page 8-445)

tsplink.trigger[N].overrun

This attribute indicates if the event detector ignored an event while in the detected state.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (R)	Yes	Reset Recall setup TSP-Link trigger N clear TSP-Link trigger N reset	Not applicable	Not applicable

Usage

```
overrun = tsplink.trigger[N].overrun
```

<i>overrun</i>	Trigger overrun state
<i>N</i>	The trigger line (1 to 3)

Details

Indicates that an event was ignored because the event detector was in the detected state when the event was detected.

Indicates the overrun state of the event detector built into the line itself.

It does not indicate whether an overrun occurred in any other part of the trigger model or in any other detector that is monitoring the event.

It does not indicate output trigger overrun.

Example

```
print(tsplink.trigger[1].overrun)
```

If an event was ignored, displays `true`; if an event was not ignored, displays `false`.

Also see

[tsplink.trigger\[N\].assert\(\)](#) (on page 8-437)
[tsplink.trigger\[N\].clear\(\)](#) (on page 8-438)
[tsplink.trigger\[N\].mode](#) (on page 8-439)
[tsplink.trigger\[N\].release\(\)](#) (on page 8-442)
[tsplink.trigger\[N\].reset\(\)](#) (on page 8-442)
[tsplink.trigger\[N\].stimulus](#) (on page 8-443)
[tsplink.trigger\[N\].wait\(\)](#) (on page 8-445)

tsplink.trigger[N].pulsewidth

This attribute sets the length of time that the trigger line is asserted for output triggers.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset Recall setup TSP-Link trigger N reset	Create configuration script Save setup	10e-6

Usage

```
width = tsplink.trigger[N].pulsewidth  
tsplink.trigger[N].pulsewidth = width
```

<i>width</i>	The pulse width (in seconds)
<i>N</i>	The trigger line (1 to 3)

Details

Setting the pulse width to 0 (seconds) asserts the trigger indefinitely.

Example

```
tsplink.trigger[3].pulsewidth = 20e-6
```

 Sets pulse width for trigger line 3 to 20 μ s.
Also see

[tsplink.trigger\[N\].release\(\)](#) (on page 8-442)

tsplink.trigger[N].release()

This function releases a latched trigger on the given TSP-Link trigger line.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
tsplink.trigger[N].release()
```

N The trigger line (1 to 3)

Details

Releases a trigger that was asserted with an indefinite pulse width, as well as a trigger that was latched in response to receiving a synchronous mode trigger.

Example

```
tsplink.trigger[3].release()
```

 Releases trigger line 3.
Also see

[tsplink.trigger\[N\].assert\(\)](#) (on page 8-437)
[tsplink.trigger\[N\].clear\(\)](#) (on page 8-438)
[tsplink.trigger\[N\].mode](#) (on page 8-439)
[tsplink.trigger\[N\].overrun](#) (on page 8-441)
[tsplink.trigger\[N\].pulsewidth](#) (on page 8-441)
[tsplink.trigger\[N\].stimulus](#) (on page 8-443)
[tsplink.trigger\[N\].wait\(\)](#) (on page 8-445)

tsplink.trigger[N].reset()

This function resets some of the TSP-Link trigger settings to their factory defaults.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
tsplink.trigger[N].reset()
```

N The trigger line (1 to 3)

Details

The `tsplink.trigger[N].reset()` function resets the following attributes to their factory defaults:

- `tsplink.trigger[N].mode`
- `tsplink.trigger[N].stimulus`
- `tsplink.trigger[N].pulsewidth`

This also clears `tsplink.trigger[N].overrun`.

Example

```
tsplink.trigger[3].reset()
```

Resets TSP-Link trigger line 3 attributes back to factory default values.

Also see

[tsplink.trigger\[N\].pulsewidth](#) (on page 8-441)

[tsplink.trigger\[N\].mode](#) (on page 8-439)

[tsplink.trigger\[N\].overrun](#) (on page 8-441)

[tsplink.trigger\[N\].stimulus](#) (on page 8-443)

tsplink.trigger[N].stimulus

This attribute specifies the event that causes the synchronization line to assert a trigger.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset Recall setup TSP-Link trigger N reset	Create configuration script Save setup	0

Usage

```
eventID = tsplink.trigger[N].stimulus
tsplink.trigger[N].stimulus = eventID
```

<i>eventID</i>	The event identifier for the triggering event
<i>N</i>	The trigger line (1 to 3)

Details

To disable automatic trigger assertion on the synchronization line, set this attribute to zero (0). Do not use this attribute when triggering under script control. Use `tsplink.trigger[N].assert()` instead. The `eventID` parameter may be one of the existing trigger event IDs shown in the following table.

Trigger event IDs	
Trigger event ID	Description
<code>channel.trigger[N].EVENT_ID</code>	A channel trigger event starts the scan.
<code>digio.trigger[N].EVENT_ID</code>	An edge (either rising, falling, or either based on the configuration of the line) on the digital input line.
<code>display.trigger.EVENT_ID</code>	The trigger key on the front panel is pressed.
<code>dmm.trigger.EVENT_LIMIT1_HIGH</code>	A DMM trigger event that indicates a measurement has exceeded the high limit value on limit 1.
<code>dmm.trigger.EVENT_LIMIT1_LOW</code>	A DMM trigger event that indicates a measurement has exceeded the low limit value on limit 1.
<code>dmm.trigger.EVENT_LIMIT2_HIGH</code>	A DMM trigger event that indicates a measurement has exceeded the high limit value on limit 2.
<code>dmm.trigger.EVENT_LIMIT2_LOW</code>	A DMM trigger event that indicates a measurement has exceeded the low limit value on limit 2.
<code>trigger.EVENT_ID</code>	A *trg message on the active command interface. If GPIB is the active command interface, a GET message also generates this event.
<code>trigger.blender[N].EVENT_ID</code>	A combination of events has occurred.
<code>trigger.timer[N].EVENT_ID</code>	A delay expired.
<code>tsplink.trigger[N].EVENT_ID</code>	An edge (either rising, falling, or either based on the configuration of the line) on the TSP-Link trigger line.
<code>lan.trigger[N].EVENT_ID</code>	A LAN trigger event has occurred.
<code>scan.trigger.EVENT_SCAN_READY</code>	Scan ready event.
<code>scan.trigger.EVENT_SCAN_START</code>	Scan start event.
<code>scan.trigger.EVENT_CHANNEL_READY</code>	Channel ready event.
<code>scan.trigger.EVENT_MEASURE_COMP</code>	Measure complete event.
<code>scan.trigger.EVENT_SEQUENCE_COMP</code>	Sequence complete event.
<code>scan.trigger.EVENT_SCAN_COMP</code>	Scan complete event.
<code>scan.trigger.EVENT_IDLE</code>	Idle event.
<code>schedule.alarm[N].EVENT_ID</code>	A scan starts when alarm <i>N</i> fires.

Example

```
tsplink.trigger[3].stimulus = scan.trigger.EVENT_CHANNEL_READY
```

Sets the trigger stimulus of the TSP-Link trigger line 3 event detector to scan the trigger channel ready event.

Also see

[tsplink.trigger\[N\].assert\(\)](#) (on page 8-437)
[tsplink.trigger\[N\].reset\(\)](#) (on page 8-442)

tsplink.trigger[N].wait()

This function waits for a trigger.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
triggered = tsplink.trigger[N].wait(timeout)
```

<i>triggered</i>	Trigger detection indication; set to one of the following values: true: A trigger is detected during the timeout period false: A trigger is not detected during the timeout period
<i>N</i>	The trigger line (1 to 3)
<i>timeout</i>	The timeout value in seconds

Details

This function waits up to the timeout value for an input trigger. If one or more trigger events were detected since the last time `tsplink.trigger[N].wait()` or `tsplink.trigger[N].clear()` was called, this function returns immediately.

After waiting for a trigger with this function, the event detector is automatically reset and rearmed. This is true regardless of the number of events detected.

Example

```
triggered = tsplink.trigger[3].wait(10)
print(triggered)
```

Waits up to 10 seconds for a trigger on TSP-Link® line 3.
If `false` is returned, no trigger was detected during the 10-second timeout.
If `true` is returned, a trigger was detected.

Also see

[tsplink.trigger\[N\].clear\(\)](#) (on page 8-438)

tsplink.writebit()

This function sets a TSP-Link synchronization line high or low.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
tsplink.writebit(N, data)
```

<i>N</i>	The trigger line (1 to 3)
<i>data</i>	The value to write to the bit: <ul style="list-style-type: none"> Low: 0 High: 1

Details

Use `tsplink.writebit()` and `tsplink.writeport()` to control the output state of the trigger line when trigger operation is set to `tsplink.TRIG_BYPASS`.

If the output line is write-protected by the `tsplink.writeprotect` attribute, this command is ignored.

The reset function does not affect the present states of the TSP-Link trigger lines.

Example

```
tsplink.writebit(3, 0)    Sets trigger line 3 low (0).
```

Also see

[tsplink.readbit\(\)](#) (on page 8-435)

[tsplink.readport\(\)](#) (on page 8-435)

[tsplink.writeport\(\)](#) (on page 8-446)

[tsplink.writeprotect](#) (on page 8-447)

tsplink.writeport()

This function writes to all TSP-Link synchronization lines.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
tsplink.writeport(data)
```

```
data          Value to write to the port (0 to 7)
```

Details

The binary representation of `data` indicates the output pattern that is written to the I/O port. For example, a data value of 2 has a binary equivalent of 010. Line 2 is set high (1), and the other two lines are set low (0).

Write-protected lines are not changed.

The `reset()` function does not affect the present states of the trigger lines.

Use the `tsplink.writebit()` and `tsplink.writeport()` commands to control the output state of the synchronization line when trigger operation is set to `tsplink.TRIG_BYPASS`.

Example

```
tsplink.writeport(3)    Sets the synchronization lines 1 and 2 high (binary 011).
```

Also see

[tsplink.readbit\(\)](#) (on page 8-435)

[tsplink.readport\(\)](#) (on page 8-435)

[tsplink.writebit\(\)](#) (on page 8-445)

[tsplink.writeprotect](#) (on page 8-447)

tsplink.writeprotect

This attribute contains the write-protect mask that protects bits from changes by the `tsplink.writebit()` and `tsplink.writeport()` functions.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset Recall setup	Create configuration script Save setup	0

Usage

```
mask = tsplink.writeprotect
tsplink.writeprotect = mask
```

<i>mask</i>	An integer that specifies the value of the bit pattern for write-protect; set bits to 1 to write-protect the corresponding TSP-Link trigger line
-------------	--

Details

The binary equivalent of *mask* indicates the mask to be set for the TSP-Link trigger line. For example, a *mask* value of 5 has a binary equivalent 101. This *mask* write-protects TSP-Link trigger lines 1 and 3.

Example

```
tsplink.writeprotect = 5
```

Write-protects TSP-Link trigger lines 1 and 3.

Also see

[tsplink.readbit\(\)](#) (on page 8-435)
[tsplink.readport\(\)](#) (on page 8-435)
[tsplink.writebit\(\)](#) (on page 8-445)
[tsplink.writeport\(\)](#) (on page 8-446)

tspnet.clear()

This function clears any pending output data from the instrument.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
tspnet.clear(connectionID)
```

<i>connectionID</i>	The connection ID returned from <code>tspnet.connect()</code>
---------------------	---

Details

This function clears any pending output data from the device. No data is returned to the caller and no data is processed.

Example

```
tspnet.write(testdevice, "print([[hello]])")
print(tspnet.readavailable(testdevice))
```

Write data to a device, then print how much is available.

Output:
6.00000e+00

```
tspnet.clear(testdevice)
print(tspnet.readavailable(testdevice))
```

Clear data and print how much data is available again.

Output:
0.00000e+00

Also see

[tspnet.connect\(\)](#) (on page 8-448)
[tspnet.readavailable\(\)](#) (on page 8-452)
[tspnet.write\(\)](#) (on page 8-457)

tspnet.connect()

This function connects the device processing the command to another device through the LAN interface.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
connectionID = tspnet.connect(ipAddress)
connectionID = tspnet.connect(ipAddress, portNumber, initString)
```

<i>connectionID</i>	The connection ID to be used as a handle in all other <code>tspnet</code> function calls
<i>ipAddress</i>	IP address to which to connect
<i>portNumber</i>	Port number
<i>initString</i>	Initialization string to send to <i>ipAddress</i>

Details

This command connects a device to another device through the LAN interface. The default port number is 5025. If the *portNumber* is 23, the interface uses the Telnet protocol and sets appropriate termination characters to communicate with the device.

If a *portNumber* and *initString* are provided, it is assumed that the remote device is not TSP-enabled. The Series 3700A does not perform any extra processing, prompt handling, error handling, or sending of commands. Additionally, the `tspnet.tsp.*` commands cannot be used on devices that are not TSP-enabled.

If neither a *portNumber* nor an *initString* is provided, the remote device is assumed to be a Keithley Instruments TSP-enabled device. Depending on the state of the `tspnet.tsp.abortonconnect` attribute, the Series 3700A sends an `abort` command to the remote device on connection.

The Series 3700A also enables TSP prompts on the remote device and error management. The Series 3700A places remote errors from the TSP-enabled device in its own error queue and prefaces these errors with `Remote Error`, followed by an error description.

Do not manually change either the prompt functionality (`localnode.prompts`) or show errors by changing `localnode.showerrors` on the remote TSP-enabled device, or subsequent `tspnet.tsp.*` commands using the connection may fail.

You can simultaneously connect to a maximum of 32 remote devices.

Example 1

```
instrumentID = tspnet.connect("192.0.2.1")
if instrumentID then
  -- Use instrumentID as needed here
  tspnet.disconnect(instrumentID)
end
```

Connect to a TSP-enabled device.

Example 2

```
instrumentID = tspnet.connect("192.0.2.1", 1394,
  "*rst\r\n")
if instrumentID then
  -- Use instrumentID as needed here
  tspnet.disconnect(instrumentID)
end
```

Connect to a device that is not TSP-enabled.

Also see

[localnode.prompts](#) (on page 8-297)
[localnode.showerrors](#) (on page 8-301)
[tspnet.tsp.abortonconnect](#) (on page 8-455)
[tspnet.disconnect\(\)](#) (on page 8-449)

tspnet.disconnect()

This function disconnects a specified TSP-Net session.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
tspnet.disconnect(connectionID)
```

<i>connectionID</i>	The connection ID returned from <code>tspnet.connect()</code>
---------------------	---

Details

This function disconnects the two devices by closing the connection. The *connectionID* is the session handle returned by `tspnet.connect()`.

For TSP-enabled devices, this aborts any remotely running commands or scripts.

Example

```
testID = tspnet.connect("192.0.2.0")
-- Use the connection

tspnet.disconnect(testID)
```

Create a TSP-Net session.

Close the session.

Also see

[tspnet.connect\(\)](#) (on page 8-448)

tspnet.execute()

This function executes a command string on the remote device.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
tspnet.execute(connectionID, commandString)
value1 = tspnet.execute(connectionID, commandString, formatString)
value1, value2 = tspnet.execute(connectionID, commandString, formatString)
value1, ..., valuen = tspnet.execute(connectionID, commandString, formatString)
```

<i>connectionID</i>	The connection ID returned from <code>tspnet.connect()</code>
<i>commandString</i>	The command to send to the remote device
<i>value1</i>	The first value decoded from the response message
<i>value2</i>	The second value decoded from the response message
<i>valuen</i>	The nth value decoded from the response message; there is one return value per format specifier in the format string
<i>...</i>	One or more values separated with commas
<i>formatString</i>	Format string for the output

Details

This command sends the command string to the remote instrument. A termination is added to the command string when it is sent to the remote instrument (`tspnet.termination()`). You can also specify a format string, which causes the command to wait for a response from the remote instrument. The Series 3700A decodes the response message according to the format specified in the format string and returns the message as return values from the function (see `tspnet.read()` for format specifiers).

When this command is sent to a TSP-enabled instrument, the Series 3700A suspends operation until a timeout error is generated or until the instrument responds, even if no format string is specified. The TSP prompt from the remote instrument is read and thrown away. The Series 3700A places any remotely generated errors into its error queue. When the optional format string is not specified, this command is equivalent to `tspnet.write()`, except that a termination is automatically added to the end of the command.

Example 1

```
tspnet.execute(instrumentID, "runScript()")
```

Command remote device to run script named `runScript`.

Example 2

```
tspnet.termination(instrumentID, tspnet.TERM_CRLF)
tspnet.execute(instrumentID, "*idn?")
print("tspnet.execute returns:", tspnet.read(instrumentID))
```

Print the `*idn?` string from the remote device.

Also see

[tspnet.connect\(\)](#) (on page 8-448)
[tspnet.read\(\)](#) (on page 8-451)
[tspnet.termination\(\)](#) (on page 8-453)
[tspnet.write\(\)](#) (on page 8-457)

tspnet.idn()

This function retrieves the response of the remote device to *IDN?.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
idnString = tspnet.idn(connectionID)
```

<i>idnString</i>	The returned *IDN? string
<i>connectionID</i>	The connection ID returned from <code>tspnet.connect()</code>

Details

This function retrieves the response of the remote device to *IDN?.

Example

```
deviceID = tspnet.connect("192.0.2.1")
print(tspnet.idn(deviceID))
tspnet.disconnect(deviceID)
```

Assume the instrument at IP address 192.0.2.1. The output from connecting to the instrument and reading the IDN string may appear as:

```
KEITHLEY INSTRUMENTS INC.,MODEL
3706A,00000170,01.10h
```

Also see

[tspnet.connect\(\)](#) (on page 8-448)

tspnet.read()

This function reads data from a remote device.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
value1 = tspnet.read(connectionID)
value1 = tspnet.read(connectionID, formatString)
value1, value2 = tspnet.read(connectionID, formatString)
value1, ..., valuen = tspnet.read(connectionID, formatString)
```

<i>value1</i>	The first value decoded from the response message
<i>value2</i>	The second value decoded from the response message
<i>valuen</i>	The nth value decoded from the response message; there is one return value per format specifier in the format string
...	One or more values separated with commas
<i>connectionID</i>	The connection ID returned from <code>tspnet.connect()</code>
<i>formatString</i>	Format string for the output, maximum of 10 specifiers

Details

This command reads available data from the remote instrument and returns responses for the specified number of arguments.

The format string can contain the following specifiers:

<code>%[width]s</code>	Read data until the specific length
<code>%[max width]t</code>	Read data until the specific length or delimited by punctuation
<code>%[max width]n</code>	Read data until a newline or carriage return
<code>%d</code>	Read a number (delimited by punctuation)

A maximum of 10 format specifiers can be used for a maximum of 10 return values.

If *formatString* is not provided, the command returns a string containing the data until a new line is reached. If no data is available, the Series 3700A pauses operation until the requested data is available or until a timeout error is generated. Use `tspnet.timeout` to specify the timeout period.

When reading from a TSP-enabled remote instrument, the Series 3700A removes Test Script Processor (TSP®) prompts and places any errors received from the remote instrument into its own error queue. The Series 3700A prefaces errors from the remote device with "Remote Error," and follows this with the error number and error description.

Example

```
tspnet.write(deviceID, "*idn?\r\n")
print("write/read returns:", tspnet.read(deviceID))
```

Send the "*idn?\r\n" message to the instrument connected as deviceID.
Display the response that is read from deviceID (based on the *idn? message).

Also see

[tspnet.connect\(\)](#) (on page 8-448)
[tspnet.readavailable\(\)](#) (on page 8-452)
[tspnet.timeout](#) (on page 8-454)
[tspnet.write\(\)](#) (on page 8-457)

tspnet.readavailable()

This function checks to see if data is available from the remote device.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
bytesAvailable = tspnet.readavailable(connectionID)
```

<i>bytesAvailable</i>	The number of bytes available to be read from the connection
<i>connectionID</i>	The connection ID returned from <code>tspnet.connect()</code>

Details

This command checks to see if any output data is available from the device. No data is read from the instrument. This allows TSP scripts to continue to run without waiting on a remote command to finish.

Example

```
ID = tspnet.connect("192.0.2.1")
tspnet.write(ID, "**idn?\r\n")
```

```
repeat bytes = tspnet.readavailable(ID) until bytes > 0
```

```
print(tspnet.read(ID))
tspnet.disconnect(ID)
```

Send commands that will create data.

Wait for data to be available.

Also see

[tspnet.connect\(\)](#) (on page 8-448)

[tspnet.read\(\)](#) (on page 8-451)

tspnet.reset()

This function disconnects all TSP-Net sessions.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
tspnet.reset()
```

Details

This command disconnects all remote instruments connected through TSP-Net. For TSP-enabled devices, this causes any commands or scripts running remotely to be terminated.

Also see

None

tspnet.termination()

This function sets the device line termination sequence.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
type = tspnet.termination(connectionID)
type = tspnet.termination(connectionID, termSequence)
```

<i>type</i>	An enumerated value indicating the termination type: <ul style="list-style-type: none"> 1 of <code>tspnet.TERM_LF</code> 4 of <code>tspnet.TERM_CR</code> 2 of <code>tspnet.TERM_CRLF</code> 3 of <code>tspnet.TERM_LFCR</code>
<i>connectionID</i>	The connection ID returned from <code>tspnet.connect()</code>
<i>termSequence</i>	The termination sequence

Details

This function sets and gets the termination character sequence that is used to indicate the end of a line for a TSP-Net connection.

Using the *termSequence* parameter sets the termination sequence. The present termination sequence is always returned.

For the *termSequence* parameter, use the same values listed in the table above for type. There are four possible combinations, all of which are made up of line feeds (LF or 0x10) and carriage returns (CR or 0x13). For TSP-enabled devices, the default is `tspnet.TERM_LF`. For devices that are not TSP-enabled, the default is `tspnet.TERM_CRLF`.

Example

```
deviceID = tspnet.connect("192.0.2.1")
if deviceID then
    tspnet.termination(deviceID,
        tspnet.TERM_LF)
end
```

Sets termination type for IP address 192.0.2.1 to `TERM_LF`.

Also see

[tspnet.connect\(\)](#) (on page 8-448)

[tspnet.disconnect\(\)](#) (on page 8-449)

tspnet.timeout

This attribute sets the timeout value for the `tspnet.connect()`, `tspnet.execute()`, and `tspnet.read()` commands.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset Recall setup	Create configuration script	20.0

Usage

```
value = tspnet.timeout
tspnet.timeout = value
```

<i>value</i>	The timeout duration in seconds (0.001 s to 30.000 s)
--------------	---

Details

This attribute sets the amount of time the `tspnet.connect()`, `tspnet.execute()`, and `tspnet.read()` commands will wait for a response.

The time is specified in seconds. The timeout may be specified to millisecond resolution, but is only accurate to the nearest 10 ms.

Example

```
tspnet.timeout = 2.0
```

Sets the timeout duration to two seconds.

Also see

[tspnet.connect\(\)](#) (on page 8-448)

[tspnet.execute\(\)](#) (on page 8-450)

[tspnet.read\(\)](#) (on page 8-451)

tspnet.tsp.abort()

This function stops remote instrument execution a TSP-enabled instrument.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
tspnet.tsp.abort(connectionID)
```

<i>connectionID</i>	Integer value used as a handle for other <code>tspnet</code> commands
---------------------	---

Details

This function is appropriate only for TSP-enabled instruments.
Sends an abort command to the remote instrument.

Example

<code>tspnet.tsp.abort(testConnection)</code>	Stops remote instrument execution on <code>testConnection</code> .
---	--

Also see

None

tspnet.tsp.abortonconnect

This attribute contains the setting for abort on connect to a TSP-enabled instrument.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Attribute (RW)	Yes	Reset Recall setup	Create configuration script Save setup	1 (enable)

Usage

```
tspnet.tsp.abortonconnect = value
value = tspnet.tsp.abortonconnect
```

<i>value</i>	1 (enable) or 0 (disable)
--------------	---------------------------

Details

This setting determines if the instrument sends an abort message when it attempts to connect to a TSP-enabled instrument using the `tspnet.connect()` function.

When you send the abort command on an interface, it causes any other active interface on that instrument to close. If you do not send an abort command (or if `tspnet.tsp.abortonconnect` is set to 0) and another interface is active, connecting to a TSP-enabled remote instrument results in a connection. However, the instrument will not respond to subsequent reads or executes because control of the instrument is not obtained until an abort command has been sent. See Communications interfaces.

Example

```
tspnet.tsp.abortonconnect = 0
```

Configure the instrument so that it does not send an abort command when connecting to a TSP-enabled instrument.

Also see

[tspnet.connect\(\)](#) (on page 8-448)

tspnet.tsp.rhtablecopy()

This function copies a reading buffer synchronous table from a remote instrument to a TSP-enabled instrument.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
table = tspnet.tsp.rhtablecopy(connectionID, name)
table = tspnet.tsp.rhtablecopy(connectionID, name, startIndex, endIndex)
```

<i>table</i>	A copy of the synchronous table or a string
<i>connectionID</i>	Integer value used as a handle for other <code>tspnet</code> commands
<i>name</i>	The full name of the reading buffer name and synchronous table to copy
<i>startIndex</i>	Integer start value
<i>endIndex</i>	Integer end value

Details

This function is only appropriate for TSP-enabled instruments.

This function reads the data from a reading buffer on a remote instrument and returns an array of numbers or a string representing the data. The *startIndex* and *endIndex* parameters specify the portion of the reading buffer to read. If no index is specified, the entire buffer is copied.

The function will return a table if the table is an array of numbers; otherwise a comma-delimited string is returned.

This command is limited to transferring 50,000 readings at a time.

Example

```
times =
    tspnet.tsp.rhtablecopy(testTspdevice,
        "testRemotebuffername.timestamps", 1, 3)
print(times)
```

Copy the specified timestamps table for items 1 through 3, then display the table. Sample output:

```
01/01/2011
 10:10:10.0000013,01/01/2011
 10:10:10.0000233,01/01/2011
 10:10:10.0000576
```

Also see

None

tspnet.tsp.runscript()

This function loads and runs a script on a remote TSP-enabled instrument.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
tspnet.tsp.runscript(connectionID, script)
tspnet.tsp.runscript(connectionID, name, script)
```

<i>connectionID</i>	Integer value used as an identifier for other <code>tspnet</code> commands
<i>name</i>	The name that is assigned to the script
<i>script</i>	The body of the script as a string

Details

This function is appropriate only for TSP-enabled instruments.

This function downloads a script to a remote instrument and runs it. It automatically adds the appropriate `loadscript` and `endscript` commands around the script, captures any errors, and reads back any prompts. No additional substitutions are done on the text.

The script is automatically loaded, compiled, and run.

Any output from previous commands is discarded.

This command does not wait for the script to complete.

If you do not want the script to do anything immediately, make sure the script only defines functions for later use.

Use the `tspnet.execute()` function to execute those functions at a later time.

If no name is specified, the script will be loaded as the anonymous script.

Example

```
tspnet.tsp.runscript(myconnection, "mytest",
"print([[start]]) for d = 1, 10 do print([[work]]) end print([[end]])")
Load and run a script entitled mytest on the TSP-enabled instrument connected with myconnection.
```

Also see

[tspnet.execute\(\)](#) (on page 8-450)

tspnet.write()

This function writes a string to the remote instrument.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
tspnet.write(connectionID, inputString)
```

<i>connectionID</i>	The connection ID returned from <code>tspnet.connect()</code>
<i>inputString</i>	The string to be written

Details

The `tspnet.write()` function sends *inputString* to the remote instrument. It does not wait for command completion on the remote instrument.

The Series 3700A sends *inputString* to the remote instrument exactly as indicated. The *inputString* must contain any necessary new lines, termination, or other syntax elements needed to complete properly.

Because `tspnet.write()` does not process output from the remote instrument, do not send commands that generate too much output without processing the output. This command can stop executing if there is too much unprocessed output from previous commands.

Example

```
tspnet.write(myID, "runscript()\r\n")
```

Commands the remote instrument to execute a command or script named "runscript()" on a remote device identified in the system as myID.

Also see

[tspnet.connect\(\)](#) (on page 8-448)

[tspnet.read\(\)](#) (on page 8-451)

upgrade.previous()

This function upgrades a previous version of the Model 3706A firmware.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
upgrade.previous()
```

Details

This function is equivalent to manually reverting to a previous firmware version from the front panel.

This function allows you to revert to an earlier version of the firmware.

The function searches the flash drive for a file to upgrade the instrument. If the file is found, the function performs the upgrade. An error is returned if an upgrade file is not found.

Also see

[Upgrading the firmware](#) (on page A-6)

[upgrade.unit\(\)](#) (on page 8-459)

upgrade.unit()

This function upgrades the Model 3706A firmware.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
upgrade.unit()
```

Details

This function is equivalent to manually performing an upgrade from the Model 3706A front panel.

The function searches the flash drive for a file to upgrade the instrument, and then performs an upgrade if an upgrade file is found. If an upgrade file is not found, an error is returned.

When `upgrade.unit()` is used, the firmware is only loaded if the version of the firmware component is newer than the existing version. If the version is older or at the same revision level, it is not upgraded.

Also see

[Upgrading the firmware](#) (on page A-6)
[upgrade.previous\(\)](#) (on page 8-458)

userstring.add()

This function adds a user-defined string to nonvolatile memory.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
userstring.add(name, value)
```

<i>name</i>	The name of the string; the key of the key-value pair
<i>value</i>	The string to associate with <i>name</i> ; the value of the key-value pair

Details

This function associates the string *value* with the string *name* and stores this key-value pair in nonvolatile memory.

Use the `userstring.get()` function to retrieve the *value* associated with the specified *name*.

Example

```
userstring.add("assetnumber", "236")
userstring.add("product", "Widgets")
userstring.add("contact", "John Doe")
```

Stores user-defined strings in nonvolatile memory.

Also see

[userstring.catalog\(\)](#) (on page 8-460)
[userstring.delete\(\)](#) (on page 8-460)
[userstring.get\(\)](#) (on page 8-461)

userstring.catalog()

This function creates an iterator for the user string catalog.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
for name in userstring.catalog() do body end
```

<i>name</i>	The name of the string; the key of the key-value pair
<i>body</i>	Code to execute in the body of the for loop

Details

The catalog provides access for userstring pairs, allowing you to manipulate all the key-value pairs in nonvolatile memory. The entries are enumerated in no particular order.

Example 1

```
for name in userstring.catalog() do
  userstring.delete(name)
end
```

Deletes all user strings in nonvolatile memory.

Example 2

```
for name in userstring.catalog() do
  print(name .. " = " ..
        userstring.get(name))
end
```

Prints all userstring key-value pairs.

Output:

```
product = Widgets
assetnumber = 236
contact = John Doe
```

The above output lists the user strings added in the example for the `userstring.add()` function. Notice the key-value pairs are not listed in the order they were added.

Also see

[userstring.add\(\)](#) (on page 8-459)
[userstring.delete\(\)](#) (on page 8-460)
[userstring.get\(\)](#) (on page 8-461)

userstring.delete()

This function deletes a user-defined string from nonvolatile memory.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
userstring.delete(name)
```

<i>name</i>	The name (key) of the key-value pair of the userstring to delete
-------------	--

Details

This function deletes the string that is associated with *name* from nonvolatile memory.

Example

```
userstring.delete("assetnumber")
userstring.delete("product")
userstring.delete("contact")
```

Deletes the user-defined strings associated with the "assetnumber", "product", and "contact" names.

Also see

[userstring.add\(\)](#) (on page 8-459)
[userstring.catalog\(\)](#) (on page 8-460)
[userstring.get\(\)](#) (on page 8-461)

userstring.get()

This function retrieves a user-defined string from nonvolatile memory.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	Yes			

Usage

```
value = userstring.get(name)
```

<i>value</i>	The value of the userstring key-value pair
<i>name</i>	The name (key) of the userstring

Details

This function retrieves the string that is associated with *name* from nonvolatile memory.

Example

```
value = userstring.get("assetnumber")
print(value)
```

Read the value associated with a user-string named "assetnumber". Store it in a variable called *value*, then print the variable *value*.
 Output:
 236

Also see

[userstring.add\(\)](#) (on page 8-459)
[userstring.catalog\(\)](#) (on page 8-460)
[userstring.delete\(\)](#) (on page 8-460)

waitcomplete()

This function waits for all overlapped commands in a specified group to complete.

Type	TSP-Link accessible	Affected by	Where saved	Default value
Function	No			

Usage

```
waitcomplete()  
waitcomplete(group)
```

<i>group</i>	Specifies which TSP-Link group on which to wait
--------------	---

Details

This function will wait for all previously started overlapped commands to complete.

Currently, the Series 3700A has no overlapped commands implemented. However, other TSP-enabled products, such as the Series 2600A System SourceMeter[®] Instruments, have overlapped commands. Therefore, when the Series 3700A is a TSP master to a subordinate device with overlapped commands, use this function to wait until all overlapped operations are completed.

A group number may only be specified when this node is the master node.

If no *group* is specified, the local group is used.

If zero (0) is specified for the *group*, this function waits for all nodes in the system.

NOTE

Any nodes that are not assigned to a group (group number is 0) are part of the master node's group.

Example 1

<code>waitcomplete()</code>	Waits for all nodes in the local group.
-----------------------------	---

Example 2

<code>waitcomplete(G)</code>	Waits for all nodes in group G.
------------------------------	---------------------------------

Example 3

<code>waitcomplete(0)</code>	Waits for all nodes on the TSP-Link network.
------------------------------	--

Also see

None

Troubleshooting guide

In this section:

Contacting support	9-1
USB troubleshooting	9-2
Troubleshooting GPIB interfaces	9-5
Troubleshooting LAN interfaces	9-5
Testing the display, keys, and channel matrix	9-9
Update drivers	9-10
Error and status messages	9-10

Contacting support

If you have any questions after reviewing this information, please contact your local Keithley Instruments representative or call Keithley Instruments corporate headquarters (toll-free inside the U.S. and Canada only) at 1-888-KEITHLEY (1-888-534-8453), or from outside the U.S. at +1-440-248-0400. For worldwide contact numbers, visit the [Keithley Instruments website](http://www.keithley.com) (<http://www.keithley.com>).

When contacting Keithley, please have ready:

- The serial number of the instrument.
- The firmware revision of the instrument.
- The model and firmware revision of all installed cards.

When you call, have the information available, and, if possible, be near the instrument.

Locating serial number or firmware revision

The serial number is on the rear panel of the instrument. You can also use the front panel **MENU** option to display the serial number and firmware version.

To display serial number or firmware revision on the front panel:

1. If the Series 3700A is in remote mode, press the **EXIT (LOCAL)** key once to place the instrument in local mode.
2. Press the **MENU** key.
3. Use the navigation wheel  to scroll to the **UNIT-INFO** menu.
4. Press the **ENTER** key.

On the UNIT INFORMATION menu, scroll to the **SERIAL#** or **FIRMWARE** option and press the **ENTER** key. The Series 3700A serial number is displayed.

Locating information on the installed cards

To identify installed switching cards from the front panel:

Press the **SLOT** key to scroll through the model numbers, descriptions, and firmware revisions of the installed switching cards.

To identify installed switching cards from the web interface:

1. Select the **Unit** page.
2. In the Report area, select the slots that you want information about.
3. Select **Firmware Revision**.
4. Click **Generate Report**. Information about the cards in the slots is displayed below the button.

To identify installed switching cards from the remote command interface:

Use `print (slot [X] . idn)` to query and identify installed switching cards:

```
print (slot [X] . idn)
```

Where: x = slot number (from 1 to 6)

Example

To get a list of all switching cards installed in the slots of a Series 3700A, send the following command over the remote command interface:

```
for x=1,6 do print (slot[x].idn) end
```

The response will be similar to the following:

```
3722, Dual 1x48 Multiplexer, 01.00a, <Module Serial Number>
3721, Dual 1x20 Multiplexer, 01.02a, <Module Serial Number>
Empty Slot
Empty Slot
Empty Slot
Empty Slot
```

USB troubleshooting

This section provides information checks you can perform if the USB communication with the instrument is not working.

Check driver for the USB Test and Measurement Device

1. Open the Device Manager.




Quick Tip

From the Start menu, you can enter `Devmgmt.msc` in the Run box or the Windows 7 search box to start Device Manager.


2. Under USB Test and Measurement Devices, look for USB Test and Measurement Device.

If the device is not there, either VISA is not installed or the instrument is not plugged in and switched on.

Figure 9-1: Device Manager dialog box showing USB Test and Measurement Device

3. Right-click the device.
4. Select Properties.
5. Select the Driver tab.
6. Click **Driver Details**.
7. Verify that the device driver is the winusb.sys. driver from Microsoft.

Figure 9-2: Driver File Details dialog box



8. If the incorrect driver is installed, click **OK**.
9. On the Driver tab, click **Update Driver**.
10. Browse for the driver; select the C:\windows\inf folder and you should see the winusb.inf file. Select this and make sure the driver is now in use.
11. If this does not work, uninstall VISA, unplug the instrument and follow the steps to reinstall VISA in the section [Modifying, repairing, or removing Keithley I/O Layer software](#) (on page 2-72).

Troubleshooting GPIB interfaces

If the hardware is not recognized by the computer:

1. Uninstall the software drivers.
2. Reboot the computer.
3. Check for newer drivers on the vendor's website. Check that the drivers are valid for the operating system you have and any updates that might be necessary. This information is typically found in the readme file that comes with the drivers.
4. Install software drivers.
5. Reboot the computer.
6. Plug in the hardware.

If it is still not recognized, you can try a different computer using a different operating system to rule out operating system issues.

If this does not resolve the issue, contact the vendor of the GPIB controller for assistance.

Timeout errors

If your GPIB controller is recognized by the operating system, but you get a timeout error when you try to communicate with the instrument, check the following:

1. Confirm that the GPIB address you assigned to the instrument is unique and between the range of 0 to 30. It should not be 0 or 21 because they are common controller addresses.
2. Check cabling connection. GPIB cables are heavy and can fall out of the connectors if they are not screwed in securely.
3. Substitute cables to verify cable integrity. For example, if you can send and receive ASCII text, but you cannot do a binary transfer, check your program and the decoding of the binary data. If that does not resolve the problem, try another cable. ASCII text only uses seven data lines in the cable; the binary transfer requires all eight lines.

Troubleshooting LAN interfaces

This section provides information on troubleshooting LAN interfaces.

For detailed information on setting up remote interfaces see Communication interfaces.

Verify connections and settings

If you are unable to connect to the instrument's internal web page, check the following items:

- Verify that the crossover cable is in the correct LAN port on the instrument. Do not connect to one of the TSP-Link ports.
- Verify that the crossover cable is in the correct port on the computer. The Ethernet port of a laptop may be disabled while the computer is in a docking station.
- Verify that the correct Ethernet card configuration information was used during the setup procedure.
- Verify that the computer's network card is enabled.
- Verify the instrument IP address is compatible with the IP address on the computer.
- Verify the instrument subnet mask address is the same as the computer's subnet mask address.
- Turn the instrument power off, and then on.
- Reboot the computer.

Use Ping to test the connection

Ping is a computer network administration utility that you can use to test whether a particular host can be reached across an Internet Protocol (IP) network. It also measures the round-trip time for packets sent from the local host to a destination computer, including the local host's own interfaces.

To run Ping:

1. From the Windows Start menu, type cmd in the Run box or Search box. The Command window is displayed.
2. At the > prompt, type ping followed by the IP address. For example:

```
ping 169.254.52.51
```

Beware that some network devices, especially LXI instruments, can disable the ping response to prevent denial of service attacks. This prevents hackers from pinging your instrument indefinitely, which causes the instrument to become so busy it cannot respond to a web browser or instrument driver.

If you cannot ping an instrument from the computer, you will not be able to communicate with the instrument. You will need to check the LAN settings from the front panel of the instrument to see if they match the configuration of your network.

If you can ping your instrument, you should be able to bring up the web page in the instrument from a browser by typing the IP address in the address (URL) field.

Open ports on firewalls

A firewall is a part of a computer system or network that is designed to block unauthorized access while permitting authorized communications. It is a device or set of devices that are configured to permit or deny applications based on a set of rules and other criteria.

If you have a firewall in the network between your computer and the instrument, you need to make sure the following ports are opened for UDP and TCP packets:

- Port 80: Web server. This is normally open.
- Port 1024: VXI-11 connection for sending and receiving commands from the instrument.
- Port 5025: Raw socket connection for sending and receiving commands from the instrument.

Web page problems

All LXI instruments have a web server. The LAN configuration information on these pages is mandated by the LXI consortium. For Keithley's LXI instruments, the standard LXI pages use standard HTML.

The added value pages that Keithley has added to control the instruments use Java. If Java is not installed when you select one of these instrument-specific web pages, the web page prompts you to install it. To do this, your computer must have access to the Internet so it can access the web browser plug-in Sun Java Runtime Environment Version 6 or higher. Installation files are available at the [Java download site](http://www.java.com/en/download/manual.jsp) (<http://www.java.com/en/download/manual.jsp>).

When you connect to the instrument web page for the first time, several things can happen:

- If the security settings are high, scripting might be disabled and the browser will prompt you to enable ActiveX and scripting.
- If Java is not installed, the browser will prompt you to install it and provide a link to the download. If you do not have an Internet connection, you must download it elsewhere and install it on the computer that it connected to the instrument.
- When the Java applet from the instrument gets downloaded into the browser it will ask you if you trust this active content from Keithley Instruments. Select Yes.

If you have resolved the problems, the instrument control pages should work and if you try to perform an action, such as closing a relay, you are prompted for the password (the default is "admin").

NOTE

If you update the firmware for the instrument using the web page (not available for all instruments), you need to flush the browser cache so that a fresh Java Applet gets downloaded the next time you access the web page.

LXI LAN status indicator

Most LAN network interface cards have two LEDs, one that indicates LAN traffic and one that designates the LAN speed (10 Mbits, 100 Mbits, 1 Gbits) through the color of the LED. LXI goes one level higher than this and states that all LXI compliant devices need a LAN status indicator. This can be an LED or an indicator on a display. It shows if the instrument has a valid IP address or is in a fault state.

When diagnosing a LAN connection issue with an LXI instrument, see if the LAN status indicator is signaling a valid or fault condition. If there is an error, you cannot communicate with the instrument through the LAN connection. In this case, you need to check the LAN parameter settings from the front panel of the instrument. Make sure if you change a LAN setting through the front panel that you select the “Apply LAN Settings” for the changes to take affect.

Initialize the LAN configuration

The LXI specification mandates that all instruments the conform to LXI need a LAN reset mechanism. This can be a recessed switch or a menu option on the front panel that will put all the LAN settings back to known defaults. If you cannot communicate with your instrument, perform this reset.

If you perform a reset, the instrument is returned to DHCP and Auto-IP enabled. If you set your computer to match, you should be able to use a discovery tool to determine the IP address and communicate with the instrument again. Also check the LAN status indicator to verify that there are no faults.

Install LXI Discovery Tool software on your computer

You can use the LXI Discovery Tool to identify the IP addresses of LXI certified instruments that are set up for automatic IP address selection. Once identified, you can double-click the IP address in the LXI Discovery Tool to open the web interface for the instrument.

The LXI Discovery Tool is available on the instrument CD. It is also available on the [Keithley website \(http://www.keithley.com\)](http://www.keithley.com).

To locate the LXI Discovery Tool on the website:

1. Select the **Support** tab.
2. In the model number box, type **3706A**.
3. From the list, select **Software**. A list of software applications for the Model 3706A is displayed.
4. See the readme file included with the application for more information.

For more information about the LXI Consortium, see the [LXI Consortium website \(http://www.lxistandard.org\)](http://www.lxistandard.org).

Communicate using VISA communicator

There are several interactive communication utilities that you can use to communicate with LAN instruments:

- The KIOIOL installs the Keithley Communicator.
- NI VISA (full version) installs the NI VISA Interactive Control utility, which can also be launched from NI-MAX.
- Agilent has a similar utility called Interactive IO that gets installed with their IO Libraries Suite.

All these utilities require you to enter the VISA resource string for your instrument. See [Communicate with the instrument](#) (on page 2-54) for more information on the VISA resource string formats.

HyperTerminal, which comes with Microsoft Windows, also allows you to connect to the raw socket port of the instrument.

WireShark

WireShark is an open source LAN packet sniffer. You can run it to spy on all the packets going across a network. It allows you to filter what you spy on so that you can narrow the content down to just what you are interested in. For example, you could check just web page packets (http) or all packets being sent by a device on a certain IP address.

See the WireShark documentation for information. WireShark can be downloaded from www.wireshark.org (<http://www.wireshark.org>).

Testing the display, keys, and channel matrix

You can test operation of the keys, display, and channel matrix from the front panel of the instrument.

Verify front panel key operation

You can verify that the instrument is properly reading front panel key presses.

To verify key operation:

1. From the front panel, select **MAIN MENU > DISPLAY > TEST > KEYS**. The message "No keys pressed" is displayed.
2. Press a key. The name of the key is displayed. For a list of key values, see [display.sendkey\(\)](#) (on page 8-145).
3. Press **EXIT (LOCAL)** twice to return to the menu.

Verify display operation

You can verify that all the pixels on the vacuum fluorescent display (VFD) are working.

To verify VFD operation:

1. From the front panel, select **MAIN MENU > DISPLAY > TEST > DISPLAY-PATTERNS**. A pattern is displayed.
2. Press the navigation wheel to display the next pattern.
3. When you have viewed the patterns, press **EXIT** to return to the menu.

Update drivers

For the latest drivers and additional support information, see the [Keithley Instruments support website](http://www.keithley.com/support) (<http://www.keithley.com/support>).

To see what drivers are available for your instrument:

1. Go to the [Keithley website](http://www.keithley.com) (<http://www.keithley.com>).
2. Select the Support tab.
3. Enter the model number of your instrument.
4. Select Software Driver from the list.

For LabVIEW, you can also go to National Instrument's website and search their instrument driver database.

Error and status messages

Introduction

This section includes information on error levels, how to read errors, and a complete listing of error messages.

Error summary

Error and status messages are assigned a level of severity, as listed in the table below.

Severity level descriptions		
Number	Level	Description
0	Informational	Indicates that there are no entries in the queue
10	Informational	Indicates a status message or minor error
20	Recoverable	Indicates possible invalid user input; operation continues but action should be taken to correct the error
30	Serious	Indicates a serious error that may require technical assistance, such as corrupted data
40	Fatal	Instrument is not operational

Effects of errors on scripts

Most errors will not abort a running script. The only time a script is aborted is when a Lua runtime error (error number -286) is detected.

Runtime errors are caused by actions such as trying to index into a variable that is not a table.

Syntax errors (error number -285) in a script or command will not abort the script, but will prevent the script or command from being executed.

Error queue remote commands

When errors occur, the error messages are placed in the error queue. Use error queue commands to request error message information. For example, the following commands request the next complete error information from the error queue and return the code, message, severity, and node for that error:

```
errorCode, message, severity, errorNode = errorqueue.next()
print(errorcode, message, severity, errorNode)
```

The following table lists the commands associated with the error queue.

Remote commands associated with the error queue	
Command	Description
errorqueue.clear() (on page 8-248)	Clear error queue of all errors
errorqueue.count (on page 8-248)	Number of messages in the error queue
errorqueue.next() (on page 8-248)	Request next error message from queue

Error and status message list

Error and status messages

Error number	Error level	Error message
-430	RECOVERABLE	Query deadlocked
-420	RECOVERABLE	Query unterminated
-410	RECOVERABLE	Query interrupted
-363	RECOVERABLE	Input buffer over-run
-360	RECOVERABLE	Communication error
-350	RECOVERABLE	Queue overflow
-315	RECOVERABLE	Configuration memory lost
-314	RECOVERABLE	Save/recall memory lost
-292	RECOVERABLE	Referenced name does not exist
-286	RECOVERABLE	TSP runtime error
-285	RECOVERABLE	Program syntax
-282	RECOVERABLE	Illegal program name
-281	RECOVERABLE	Cannot create program
-225	RECOVERABLE	Out of memory or TSP memory allocation error
-224	RECOVERABLE	Illegal parameter value
-223	RECOVERABLE	Too much data
-222	RECOVERABLE	Parameter data out of range
-221	RECOVERABLE	Settings conflict
-220	RECOVERABLE	Parameter
-203	RECOVERABLE	Command protected
-200	RECOVERABLE	Execution error
-154	RECOVERABLE	String too long
-151	RECOVERABLE	Invalid string data
-144	RECOVERABLE	Character data too long
-141	RECOVERABLE	Invalid character data
-140	RECOVERABLE	Character data error
-121	RECOVERABLE	Invalid character in number
-120	RECOVERABLE	Numeric data
-109	RECOVERABLE	Missing parameter
-108	RECOVERABLE	Parameter not allowed
-105	RECOVERABLE	Trigger not allowed
-104	RECOVERABLE	Data type
-101	RECOVERABLE	Invalid character
-100	RECOVERABLE	Command error
0	NO_SEVERITY	Queue is empty
603	RECOVERABLE	Power on state lost
605	RECOVERABLE	Calibration dates lost
820	RECOVERABLE	Parsing value
900	FATAL	Internal system
1100	RECOVERABLE	Command unavailable
1101	RECOVERABLE	Parameter too big
1102	RECOVERABLE	Parameter too small

Error and status messages

Error number	Error level	Error message
1103	RECOVERABLE	Min greater than max
1104	RECOVERABLE	Too many digits for param type
1107	RECOVERABLE	Cannot modify factory menu
1108	RECOVERABLE	Menu name does not exist
1109	RECOVERABLE	Menu name already exists
1112	RECOVERABLE	Password entered does not match current password
1114	RECOVERABLE	Settings conflict with %s, where %s represents specifics on what the conflict is
1115	RECOVERABLE	Parameter error %s, where %s explains why parameter error
1116	RECOVERABLE	Configuration error %s, where %s explains why configuration error
1200	RECOVERABLE	TSP-Link initialization failed
1201	RECOVERABLE	TSP-Link initialization failed
1202	RECOVERABLE	TSP-Link initialization failed
1203	RECOVERABLE	TSP-Link initialization failed (possible loop in node chain)
1204	RECOVERABLE	TSP-Link initialization failed
1205	RECOVERABLE	TSP-Link initialization failed (no remote nodes found)
1206	RECOVERABLE	TSP-Link initialization failed
1207	RECOVERABLE	TSP-Link initialization failed
1208	RECOVERABLE	TSP-Link initialization failed
1209	RECOVERABLE	TSP-Link initialization failed
1210	RECOVERABLE	TSP-Link initialization failed (node ID conflict)
1211	RECOVERABLE	Node %u is inaccessible, where %u represents a number
1212	RECOVERABLE	Invalid node ID
1213	RECOVERABLE	TSP-Link session expired
1214	RECOVERABLE	TSP-Link unknown remote command encoding
1215	RECOVERABLE	Code execution requested within the local group
1216	RECOVERABLE	Remote execution requested on node in group with pending overlapped operations
1217	RECOVERABLE	Remote execution requested on node outside the local group
1400	RECOVERABLE	Expected at least %d parameters, where %d represents a number
1401	RECOVERABLE	Parameter %d is invalid, where %d represents a number
1402	RECOVERABLE	User scripts lost
1403	RECOVERABLE	Factory scripts lost
1404	RECOVERABLE	Invalid byte order
1405	RECOVERABLE	Invalid ASCII precision
1406	RECOVERABLE	Invalid data format
1600	RECOVERABLE	Maximum GPIB message length exceeded
1601	RECOVERABLE	GPIB input queue overrun
1800	RECOVERABLE	Invalid digital trigger mode
1801	RECOVERABLE	Invalid digital I/O line
1802	RECOVERABLE	Digital bit in parameter write protected
2100	FATAL	Could not open socket
2101	FATAL	Could not close socket
2102	RECOVERABLE	LAN configuration already in progress
2103	RECOVERABLE	LAN disabled

Error and status messages

Error number	Error level	Error message
2104	RECOVERABLE	Socket error
2105	RECOVERABLE	Unreachable gateway
2106	RECOVERABLE	Could not acquire ip address
2107	RECOVERABLE	Duplicate IP address detected
2108	RECOVERABLE	DHCP lease lost
2109	RECOVERABLE	LAN cable disconnected
2110	RECOVERABLE	Could not resolve hostname
2111	RECOVERABLE	DNS name (FQDN) too long
2112	RECOVERABLE	Connection not established
2200	RECOVERABLE	File write error
2201	RECOVERABLE	File read error
2202	RECOVERABLE	Cannot close file
2203	RECOVERABLE	Cannot open file
2204	RECOVERABLE	Directory not found
2205	RECOVERABLE	File not found
2206	RECOVERABLE	Cannot read current working directory
2207	RECOVERABLE	Cannot change directory
2208	RECOVERABLE	Cannot create directory
2209	RECOVERABLE	Cannot remove directory
2210	RECOVERABLE	File is not a valid script format
2211	RECOVERABLE	File system error
2212	RECOVERABLE	File system command not supported
2213	RECOVERABLE	Too many open files
2214	RECOVERABLE	File access denied
2215	RECOVERABLE	Invalid file handle
2216	RECOVERABLE	Invalid drive
2217	RECOVERABLE	File system busy
2218	RECOVERABLE	Disk full
2219	RECOVERABLE	File corrupt
2220	RECOVERABLE	File already exists
2221	RECOVERABLE	File seek error
2222	RECOVERABLE	End-of-file error
2223	RECOVERABLE	Directory not empty
2300	RECOVERABLE	Upgrade found not upgradable
2301	RECOVERABLE	Upgrade uncompress failed
2302	RECOVERABLE	Upgrade device not ready
2303	RECOVERABLE	Upgrade device type not acceptable
2304	RECOVERABLE	Upgrade write to device checksum failure
2305	RECOVERABLE	Upgrade write to device failed
2306	RECOVERABLE	Upgrade timeout connect with device
2307	RECOVERABLE	Upgrade failure
2400	RECOVERABLE	Invalid specified connection
2401	RECOVERABLE	Invalid timeout seconds (.001 to 30)
2402	RECOVERABLE	TSPnet remote error: %s, where %s explains the remote error
2403	RECOVERABLE	TSPnet failure

Error and status messages

Error number	Error level	Error message
2404	RECOVERABLE	TSPnet read failure
2405	RECOVERABLE	TSPnet read failure, aborted
2406	RECOVERABLE	TSPnet read failure, timeout
2407	RECOVERABLE	TSPnet write failure
2408	RECOVERABLE	TSPnet write failure, aborted
2409	RECOVERABLE	TSPnet write failure, timeout
2410	RECOVERABLE	TSPnet max connections reached
2411	RECOVERABLE	TSPnet connection failed
2412	RECOVERABLE	TSPnet invalid termination
2413	RECOVERABLE	TSPnet invalid reading buffer table
2414	RECOVERABLE	TSPnet invalid reading buffer index range
2415	RECOVERABLE	TSPnet feature only supported on TSP connections
2416	RECOVERABLE	TSPnet must specify both port and init
2417	RECOVERABLE	TSPnet disconnected by other side
4900	RECOVERABLE	Reading buffer index %d is invalid, where %d represents a number
4901	RECOVERABLE	The maximum index for this buffer is %d, where %d represents a number
4902	RECOVERABLE	Reading buffers must be able to contain at least one element
4903	RECOVERABLE	Reading buffer expired
4904	RECOVERABLE	ICX parameter count mismatch, %s (Line #%d), where %s and %d provide more information on error
4905	RECOVERABLE	ICX parameter invalid value, %s (Line #%d), where %s and %d provide more information on error
4906	RECOVERABLE	ICX invalid function id, %s (Line #%d), where %s and %d provide more information on error
4907	RECOVERABLE	Cannot modify built-in reading buffers
4908	RECOVERABLE	Cannot change this setting unless buffer is cleared
4909	RECOVERABLE	Reading buffer not found within device
4910	RECOVERABLE	No readings exist within buffer
4911	RECOVERABLE	Table not found within buffer
4912	RECOVERABLE	Attribute not found within buffer
4914	RECOVERABLE	Index exceeds maximum readings stored in buffer
4915	RECOVERABLE	Attempting to store past capacity of reading buffer
5500	RECOVERABLE	Card unknown error
5501	RECOVERABLE	Failed card NVMEM write
5502	RECOVERABLE	Failed card NVMEM read
5503	RECOVERABLE	Closure count lost
5504	RECOVERABLE	Temperature sensor failure
5505	RECOVERABLE	Error completing a card action in requested operation
5506	RECOVERABLE	Communication error with a card in requested operation
5507	RECOVERABLE	Card operation completed under low total power
5508	RECOVERABLE	Card operation completed under low bank power
5509	RECOVERABLE	Card operation completed under low slot power
5510	RECOVERABLE	Not enough total power to hold requested card operation
5511	RECOVERABLE	Not enough bank power to hold requested card operation
5512	RECOVERABLE	Not enough slot power to hold requested card operation

Error and status messages

Error number	Error level	Error message
5513	RECOVERABLE	Not enough total power to complete requested card operation
5514	RECOVERABLE	Not enough bank power to complete requested card operation
5515	RECOVERABLE	Not enough slot power to complete requested card operation
5516	RECOVERABLE	Slot empty, no configuration data exist
5517	RECOVERABLE	Slot error, configuration data not found
5518	RECOVERABLE	Slot error, communication error accessing configuration data
5519	RECOVERABLE	Slot error, timeout error accessing configuration data
5520	RECOVERABLE	Channel error, channel list contains a channel not in system
5521	RECOVERABLE	Parameters adjusted, must recreate scan
5522	RECOVERABLE	Scan running, must abort scan
5600	RECOVERABLE	10 vdc zero error
5601	RECOVERABLE	100 vdc zero error
5602	RECOVERABLE	10 vdc full scale error
5603	RECOVERABLE	-10 vdc full scale error
5604	RECOVERABLE	100 vdc full scale error
5605	RECOVERABLE	100m vdc zero error
5606	RECOVERABLE	100 2-w zero error
5607	RECOVERABLE	10k 2-w zero error
5608	RECOVERABLE	100k 2-w zero error
5609	RECOVERABLE	10M 2-w zero error
5610	RECOVERABLE	10M 2-w full scale error
5611	RECOVERABLE	10M 2-w open error
5612	RECOVERABLE	100 4-w zero error
5613	RECOVERABLE	10k 4-w zero error
5614	RECOVERABLE	100k 4-w zero error
5615	RECOVERABLE	10M 4-w sense lo zero error
5616	RECOVERABLE	1k 4-w full scale error
5617	RECOVERABLE	10k 4-w full scale error
5618	RECOVERABLE	100k 4-w full scale error
5619	RECOVERABLE	1M 4-w full scale error
5620	RECOVERABLE	10M 4-w full scale error
5621	RECOVERABLE	10m adc zero error
5622	RECOVERABLE	100m adc zero error
5623	RECOVERABLE	10m adc full scale error
5624	RECOVERABLE	100m adc full scale error
5625	RECOVERABLE	1 adc full scale error
5626	RECOVERABLE	2k 4-w dckt loff zero error
5627	RECOVERABLE	2k 4-w dckt lon zero error
5628	RECOVERABLE	1k 4-w dckt loff zero error
5629	RECOVERABLE	1k 4-w dckt lon zero error
5630	RECOVERABLE	100 4-w dckt loff zero error
5631	RECOVERABLE	100 4-w dckt lon zero error
5632	RECOVERABLE	10 4-w dckt loff zero error
5633	RECOVERABLE	10 4-w dckt lon zero error
5634	RECOVERABLE	1 4-w dckt lon zero error
5635	RECOVERABLE	10 2-w zero error

Error and status messages

Error number	Error level	Error message
5636	RECOVERABLE	10 4-w full scale error
5637	RECOVERABLE	100 4-w full scale error
5638	RECOVERABLE	10u adc zero error
5639	RECOVERABLE	100u adc zero error
5640	RECOVERABLE	1m adc zero error
5641	RECOVERABLE	1 adc zero error
5642	RECOVERABLE	10u adc full scale error
5643	RECOVERABLE	100u adc full scale error
5644	RECOVERABLE	1m adc full scale error
5645	RECOVERABLE	1 vac fast noise error
5646	RECOVERABLE	1 vac fast full scale error
5647	RECOVERABLE	100m vac dac error
5648	RECOVERABLE	1 vac dac error
5649	RECOVERABLE	10 vac dac error
5650	RECOVERABLE	100 vac dac error
5651	RECOVERABLE	100m vac zero error
5652	RECOVERABLE	100m vac full scale error
5653	RECOVERABLE	1 vac zero error
5654	RECOVERABLE	1 vac full scale error
5655	RECOVERABLE	1 vac noise error
5656	RECOVERABLE	10 vac zero error
5657	RECOVERABLE	10 vac full scale error
5658	RECOVERABLE	10 vac noise error
5659	RECOVERABLE	100 vac zero error
5660	RECOVERABLE	100 vac full scale error
5661	RECOVERABLE	300 vac zero error
5662	RECOVERABLE	300 vac full scale error
5663	RECOVERABLE	300 vac noise error
5664	RECOVERABLE	Post filter offset error
5665	RECOVERABLE	1 aac zero error
5666	RECOVERABLE	1 aac full scale error
5667	RECOVERABLE	3 aac zero error
5668	RECOVERABLE	3 aac full scale error
5669	RECOVERABLE	1V 10 Hz amplitude error
5670	RECOVERABLE	Frequency gain error
5671	RECOVERABLE	100 Ohm loff Ocomp FS error
5672	RECOVERABLE	10k Ohm loff Ocomp FS error
5673	RECOVERABLE	Temperature cold cal error
5674	RECOVERABLE	Analog output zero error
5675	RECOVERABLE	Analog output pos. gain error
5676	RECOVERABLE	Analog output neg. gain error
5677	RECOVERABLE	100 4-w dckt loff full scale error
5678	RECOVERABLE	100 4-w dckt lon full scale error
5679	RECOVERABLE	10 4-w dckt full scale error
5680	RECOVERABLE	1 4-w dckt lon full scale error
5681	RECOVERABLE	10k 4-w ocomp loff full scale error

Error and status messages

Error number	Error level	Error message
5682	RECOVERABLE	10k 4-w ocomp lon full scale error
5683	RECOVERABLE	2k 4-w dckt loff full scale error
5684	RECOVERABLE	2k 4-w dckt lon full scale error
5685	RECOVERABLE	1k 4-w dckt loff full scale error
5686	RECOVERABLE	1k 4-w dckt lon full scale error
5687	RECOVERABLE	10 4-w zero error
5688	RECOVERABLE	10 4-w loff zero error
5689	RECOVERABLE	1m aac full scale error
5690	RECOVERABLE	1m aac zero error
5691	RECOVERABLE	10m aac full scale error
5692	RECOVERABLE	10m aac zero error
5693	RECOVERABLE	100m aac full scale error
5694	RECOVERABLE	100m aac zero error
5695	RECOVERABLE	Offset calibration error
5696	RECOVERABLE	1V 10 Hz frequency error
5697	RECOVERABLE	Calibration data invalid
5698	RECOVERABLE	AC calibration data lost
5699	RECOVERABLE	DC calibration data lost
5700	RECOVERABLE	PreCal calibration data lost
5701	RECOVERABLE	A/D timeout
5702	RECOVERABLE	1 4-w dckt loff zero error
5703	RECOVERABLE	100 4-w loff zero error
5704	RECOVERABLE	10k 4-w loff zero error
5705	RECOVERABLE	10 4-w dckt loff full scale error
5706	RECOVERABLE	1 4-w dckt loff full scale error
5707	RECOVERABLE	1k TRTD HI lon zero error
5708	RECOVERABLE	1k TRTD HI loff zero error
5709	RECOVERABLE	1k TRTD SLO lon zero error
5710	RECOVERABLE	1k TRTD SLO loff zero error
5711	RECOVERABLE	10k TRTD HI lon zero error
5712	RECOVERABLE	10k TRTD HI loff zero error
5713	RECOVERABLE	10k TRTD SLO lon zero error
5714	RECOVERABLE	10k TRTD SLO loff zero error
5715	RECOVERABLE	100k TRTD HI lon zero error
5716	RECOVERABLE	100k TRTD SLO lon zero error
5717	RECOVERABLE	1k TRTD HI lon full scale error
5718	RECOVERABLE	1k TRTD HI loff full scale error
5719	RECOVERABLE	1k TRTD SLO lon full scale error
5720	RECOVERABLE	1k TRTD SLO loff full scale error
5721	RECOVERABLE	10k TRTD HI lon full scale error
5722	RECOVERABLE	10k TRTD HI loff full scale error
5723	RECOVERABLE	10k TRTD SLO lon full scale error
5724	RECOVERABLE	10k TRTD SLO loff full scale error
5725	RECOVERABLE	100k TRTD HI lon full scale error
5726	RECOVERABLE	100k TRTD SLO lon full scale error
5727	RECOVERABLE	10 vdc full scale 6p4 error

Error and status messages

Error number	Error level	Error message
5728	RECOVERABLE	10 vdc full scale p64 error
5729	RECOVERABLE	10 vdc zero 6p4 error
5730	RECOVERABLE	10 vdc zero p64 error
5731	RECOVERABLE	1k 4-w ocomp loff full scale error
5732	RECOVERABLE	Questionable calibration
5733	RECOVERABLE	Questionable temperature
5734	RECOVERABLE	Internal DMM system error
5735	RECOVERABLE	General unknown DMM error
5736	RECOVERABLE	Untranslated DMM error
5737	RECOVERABLE	Error completing DMM action in requested operation
5738	RECOVERABLE	Communication error with DMM in requested operation
5739	RECOVERABLE	DMM calibration error occurred during processing command
5740	RECOVERABLE	DMM calibration error occurred setting adjustment date
5741	RECOVERABLE	DMM calibration error occurred getting adjustment date
5742	RECOVERABLE	DMM calibration error occurred setting verify date
5743	RECOVERABLE	DMM calibration error occurred getting verify date
5744	RECOVERABLE	DMM calibration error occurred setting password
5745	RECOVERABLE	DMM calibration error occurred getting password
5746	RECOVERABLE	DMM calibration error occurred setting count
5747	RECOVERABLE	DMM calibration error occurred getting count

Frequently asked questions (FAQs)

In this section:

How do I get my LAN or web connection to work?	10-1
Why can't I close a channel?	10-1
How do I know if an error has occurred on my instrument? ...	10-2
How do I find the serial number and firmware version of the instrument?	10-3

How do I get my LAN or web connection to work?

For troubleshooting suggestions, see [Troubleshooting LAN interfaces](#) (on page 9-5).

For more detailed information on remote interface connections, see Communication interfaces.

Why can't I close a channel?

The channel might be set to be forbidden to close.


To check the forbidden state of a channel from the front panel:

1. Display a channel (you might need to press **DISPLAY**).
2. Use the navigation wheel  to select the channel you want to check.
3. Press **CONFIG**, then press **CHAN**.
4. Select **FORBID**.
5. Press **ENTER**.
6. **Yes** and **No** are displayed. The current selection blinks. To change the setting to allow the channel to close, select **No**.

To check the forbidden state of a channel from the web interface:

1. From the list on the left, select the slot that contains the channel.
2. Right-click the channel. The Channel Configuration dialog box is displayed.

Figure 10-1: Channel configuration dialog box



3. If the forbidden box is selected, the channel is forbidden to close. To allow the channel to close, clear the box.
4. Click **OK** to save the change.

To check the forbidden state of a channel from a remote interface:

You can also clear, check, and set the forbidden state of channels using the following commands:

- [channel.clearforbidden\(\)](#) (on page 8-49)
- [channel.getforbidden\(\)](#) (on page 8-66)
- [channel.setforbidden\(\)](#) (on page 8-94)

How do I know if an error has occurred on my instrument?

If you are using TSB Embedded, error messages are displayed in the Instrument Output box when they occur.

If you are using another remote interface, you might need to use commands to retrieve the error messages. You can use the commands [errorqueue.count](#) (on page 8-248) and [errorqueue.next\(\)](#) (on page 8-248) to retrieve the number of messages and the text of the messages.

To set the instrument to automatically send generated errors, set [localnode.showerrors](#) (on page 8-301) to 1 (enabled).

To set the instrument to automatically send prompts after each command message, set [localnode.prompts](#) (on page 8-297) to 1 (enabled).

How do I find the serial number and firmware version of the instrument?

The serial number is on the rear panel of the instrument. You can also use the front panel **MENU** option to display the serial number and firmware version.

To display serial number or firmware revision on the front panel:

1. If the Series 3700A is in remote mode, press the **EXIT (LOCAL)** key once to place the instrument in local mode.
2. Press the **MENU** key.
3. Use the navigation wheel  to scroll to the **UNIT-INFO** menu.
4. Press the **ENTER** key.

On the UNIT INFORMATION menu, scroll to the **SERIAL#** or **FIRMWARE** option and press the **ENTER** key. The Series 3700A serial number is displayed.

In this section:

Additional Series 3700A information	11-1
---	------

Additional Series 3700A information

For additional information about the Series 3700A, refer to:

- The Product Information CD-ROM (ships with the product): Contains software tools, drivers, and product documentation, including documentation for switch cards that are compatible with the Series 3700A
- The [Keithley Instruments website](http://www.keithley.com) (<http://www.keithley.com>): Contains the most up-to-date information. From the website, you can access:
 - The Knowledge Center, which contains the following handbooks:
 - *The Low Level Measurements Handbook: Precision DC Current, Voltage, and Resistance Measurements*
 - Application notes
 - Updated drivers
 - Information about related products, including:
 - The Model 4200-SCS Semiconductor Characterization System
- Your local Field Applications Engineer can help you with product selection, configuration, and usage. Check the website for contact information.

In this appendix:

Introduction.....	A-1
Line fuse replacement.....	A-1
Fuse replacement.....	A-2
AMPS analog backplane fuse replacement.....	A-3
Front panel tests.....	A-3
Displaying the instrument's serial number.....	A-6
Upgrading the firmware.....	A-6

Introduction

The information in this section deals with routine maintenance of Keithley Instruments Series 3700A System Switch Multimeter instruments that can be performed by the operator.

Line fuse replacement

A fuse located on the Series 3700A rear panel protects the power line input of the System Switch/Multimeter.



WARNING

Disconnect the line cord at the rear panel, and remove all test leads connected to the instrument before replacing the line fuse. Failure to do so could expose the operator to hazardous voltages that could result in personal injury or death.

NOTE

The power line fuse is accessible from the rear panel, just below the AC power receptacle (see the following figure).

Perform the following steps to replace the line fuse:



WARNING

To prevent injury, death, or instrument damage, use only the correct fuse type (see table).

1. Power off the unit and remove the line cord.
2. The fuse drawer (1) is located below the AC receptacle. A small tab is located on the top of the fuse drawer (2). Using a thin-bladed knife or a screwdriver, pry this tab away from the AC receptacle.
3. Slide the fuse drawer out to gain access to the fuse (the fuse drawer does not pull completely out of the power module).
4. Snap the fuse out of the drawer and replace it with the same type (the fuse is specified in the table below).



CAUTION

To prevent instrument damage, use only the correct fuse type (see table).

5. Push the fuse drawer back into the module.

If the power line fuse continues to blow, a circuit malfunction exists and must be corrected. Return the unit to Keithley Instruments for repair.

Fuse replacement

The analog backplane AMPS fuse (see item 1 in Fuse location figure) is accessible from the rear panel, just below the analog backplane connector. The instrument fuse (see item 2 in Fuse location figure) is accessible from the rear panel, below the GPIB Connector.




WARNING

Disconnect all external power from the equipment and the line cord before performing any maintenance on the Model 3706A.

Failure to disconnect all power may expose you to hazardous voltages, that if contacted, could cause personal injury or death. Use appropriate safety precautions when working with hazardous voltages.

Figure 11-1: Fuse location



Fuse location	Rating	Keithley Instruments part number
(1) Analog backplane fuse	250V, 3A fast blow 5x20mm	FU-99-1
(2) Instrument fuse	250V / 1.25A slow blow 5x20mm	FU-106-1.25

To replace a fuse:

1. Using a flat-tip screwdriver, disengage the fuse holder by rotating it counter-clockwise.
2. Pull out the fuse holder and replace the fuse with the correct type (see table).
3. Reinstall the fuse holder.

If the fuse continues to blow, a circuit malfunction exists and must be corrected. Return the instrument to Keithley Instruments for repair.

AMPS analog backplane fuse replacement

WARNING

Make sure the instrument is disconnected from the power line and other equipment before replacing the AMPS fuse.

CAUTION

Do not use a fuse with a higher current rating than specified or instrument damage may occur. If the instrument repeatedly blows fuses, locate and correct the cause of the trouble before replacing the fuse.

NOTE

Model 3721 card supports both AC and DC current measurements. Refer to the [Schematic](#) (see "[Rear panel, backplane, and DMM connect relays schematic](#)" on page 5-1) in the Series 3700A Switching and Control Cards Reference Manual. The Model 3721 card has replaceable fuses. For replacement information, refer to the "Model 3721: AMPS channels fuse replacement" section in the Series 3700A Switching and Control Cards Reference Manual.

1. Turn off the power and disconnect the power line and connections.
2. From the rear panel, gently push in the AMPS fuse holder with a flat blade screwdriver and rotate the fuse holder one-quarter turn counterclockwise.
3. Remove the fuse and replace it with the same type (3A, 250V, fast-blow, 5 × 20mm). The Keithley Instruments part number is FU-99-1.
4. Install the new fuse by reversing the procedure above.

Front panel tests

You can test the functionality of the front panel keys and the display.

Test procedure

This procedure tests the functionality of each front panel key and the display.

To run the test:

1. If the Series 3700A is in remote mode, press the **EXIT (LOCAL)** key once to place the instrument in local mode.
2. Display the MAIN MENU by pressing the **MENU** key.
3. Turn the navigation wheel  to scroll to the **DISPLAY** menu item. Press the **ENTER** key to select.
4. Press the **ENTER** key to select **TEST**.
5. Turn the navigation wheel  until the **KEYS** menu item is highlighted.
6. To start the test, press the **ENTER** key.
7. Press a key. The label name for that key is displayed, which indicates that it is functioning properly. When the key is released, the message “No keys pressed” is displayed.
8. When the test is complete, press the **EXIT (LOCAL)** key twice. The FRONT PANEL TESTS menu is displayed.
9. Select **DISPLAY-PATTERNS**. This test lets you verify that each pixel and indicator in the vacuum fluorescent display is working properly.
10. To start the test, press the **ENTER** key.
11. The checkerboard pattern and the annunciators that are on during normal operation are displayed. Verify that they are displayed correctly.
12. Press the **ENTER** key.
13. The checkerboard pattern (alternate pixels on) and all annunciators are displayed. Verify that they are displayed correctly.
14. Press the **ENTER** key.
15. Each digit (and adjacent annunciator) is sequenced. All of the pixels of the selected digit are on. Verify that they are displayed correctly.
16. Press the **EXIT** key to end the test.
17. Continue pressing the **EXIT** key to back out of the menu structure.

Keys test

This test lets you check the functionality of each front panel key.

Perform the following steps to run the KEYS test:

1. If the Series 3700A is in remote mode, press the **EXIT (LOCAL)** key once to place the instrument in local mode.
2. Press the **MENU** key.
3. Navigate through the menus by turning the navigation wheel , and then pressing the **ENTER** key to select the items as follows: **DISPLAY > TEST > DISPLAY-TESTS**.
4. Turn the navigation wheel  until the **KEYS** menu item is highlighted.
5. To start the test, press the **ENTER** key. While testing, when a key is pressed, the label name for that key will be displayed to indicate that it is functioning properly. When the key is released, the message "No keys pressed" is displayed.
6. Pressing the **EXIT (LOCAL)** key tests the **EXIT (LOCAL)** key. However, the second consecutive press of the **EXIT (LOCAL)** key aborts the test and returns the instrument to the FRONT PANEL TESTS menu. Continue pressing the **EXIT (LOCAL)** key to back out of the menu structure.

Display patterns test

This test lets you verify that each pixel and indicator in the vacuum fluorescent display is working properly.

Perform the following steps to run the display test:

1. If the Series 3700A is in remote mode, press the **EXIT (LOCAL)** key once to place the instrument in local mode.
2. Press the **MENU** key.
3. Navigate through the menus by turning the navigation wheel , and then pressing the **ENTER** key to select the items as follows: **DISPLAY > TEST > DISPLAY-TESTS**.
4. Turn the navigation wheel  until the **DISPLAY-PATTERNS** menu item is highlighted.
5. To start the display test, press the **ENTER** key. There are three parts to the display test. Each time the **ENTER** key or the navigation wheel  is pressed, the next part of the test sequence is selected. The three parts of the test sequence are as follows:
 - Checkerboard pattern and the indicators that are on during normal operation
 - Checkerboard pattern (alternate pixels on) and all the numeric indicators (which are not used) are illuminated
 - Each digit (and adjacent indicators) is sequenced; all of the pixels of the selected digit are on
6. When finished, abort the display test by pressing the **EXIT (LOCAL)** key. The instrument returns to the FRONT PANEL TESTS menu. Continue pressing the **EXIT (LOCAL)** key to back out of the menu structure.

Displaying the instrument's serial number

To display the serial number on the front panel:

1. If the Series 3700A is in remote operation, press the **EXIT (LOCAL)** key once to place the instrument in local operation.
2. Press the **MENU** key.
3. Use the navigation wheel  to scroll to the **UNIT-INFO** menu.
4. Press the **ENTER** key.
5. On the SYSTEM INFORMATION menu, scroll to the **SERIAL#** menu item.
6. Press the **ENTER** key. The Series 3700A serial number is displayed.

Upgrading the firmware

Use this procedure to upgrade the Model 3706A firmware directly from a USB flash drive using a file. The upgrade process should take approximately five minutes, depending on the cards in the system and if a digital multimeter (DMM) is installed.

The normal upgrade procedure only upgrades to a higher level software version. If any part of the system is already at a higher software revision, that part of the system is skipped during the upgrade. A separate operation is available to revert to an earlier revision firmware.

The upgrade process upgrades not only the mainframe, but also the DMM and any cards in the system. Make sure all available cards are populated in the mainframe before beginning the upgrade procedure.

You can upgrade the firmware using a USB flash drive on the front panel, through the web interface, or using remote interface.

NOTE

You can upgrade a single card at a later time by installing the card in the instrument and re-running the upgrade procedure. The upgrade procedure will verify that the instrument firmware is at the latest revision and will only upgrade the additional installed card.

Upgrade files are available on the [Keithley Instruments website](http://www.keithley.com) (<http://www.keithley.com>).

To locate the upgrade files on the Keithley website:

1. Select the **Support** tab.
2. In the model number box, type **3700A**.
3. From the list, select **Firmware** and click the search icon. A list of software applications for the instrument is displayed.
4. See the release notes for the upgrade for more information.



CAUTION

Disconnect the input and output terminals before you upgrade. Do not remove power from the Series 3700A System Switch/Multimeter or remove the flash drive while an upgrade is in progress. Wait until the instrument completes the upgrade procedure and the opening display is shown.

Complete the following steps to upgrade the firmware through the front panel:

1. Copy the firmware upgrade file to an empty USB flash drive.
2. Disconnect the input and output terminals to and from the instrument.
3. Power on the Series 3700A.
4. If the Series 3700A is in remote mode, press the **EXIT (LOCAL)** key once to place the instrument in local mode.
5. Insert the flash drive into the USB port on the front panel of the Series 3700A.
6. From the Series 3700A front panel, press the **MENU** key
7. Scroll to the **UPGRADE** menu item (by turning the navigation wheel ) and then press the **ENTER** key.
8. Scroll to and select the file (located on the USB flash drive) that contains the appropriate version of firmware.
9. The question **UPGRADE UNIT?** is displayed. Select **Previous** to revert to a previous version or select **Yes** to upgrade to a newer version.
10. Press the navigation wheel.

The upgrade status is displayed on the front panel, including the percentage complete. When the file has been unpacked, the upgrade status will be displayed as it is upgraded, first cards installed in the slots, including the DMM if available, and then the Series 3700A.

11. The instrument will reboot automatically when the upgrade is complete.

Upgrade procedure using the remote interface

You can also upgrade or revert to a previous version of firmware using the remote interface command [upgrade.unit\(\)](#) (on page 8-459) or [upgrade.previous\(\)](#) (on page 8-458).

NOTE

For models without a front panel, the LAN Status and clock status LEDs blink in unison during the upgrade process.

Firmware upgrade from a USB flash drive

Use this procedure to upgrade the Model 3706A firmware directly from a USB flash drive using a *.cab file. The upgrade process should take approximately 5 minutes, depending on the cards in the system and if a DMM is installed.

The normal upgrade procedure only upgrades to a higher level software version. If any part of the system is already at a higher software revision, that part of the system is skipped during the upgrade. A separate operation is available to upgrade to earlier revision firmware.

The upgrade process upgrades not only the mainframe, but also the digital multimeter (DMM) and any cards in the system. Make sure all available cards are populated in the mainframe before beginning the upgrade procedure.

Firmware upgrade procedure using the front panel USB port

NOTE

You can upgrade a single card at a later time by installing the card in the instrument and re-running the upgrade procedure. The upgrade procedure will verify that the instrument firmware is at the latest revision and will only upgrade the additional installed card.



CAUTION

Do not turn off the instrument or remove the flash drive during the upgrade procedure. Wait until the instrument completes the upgrade procedure and the opening display is shown.

NOTE

If your model does not have a front panel, upgrade over the remote interface with the appropriate command ([upgrade.unit\(\)](#) (on page 8-459) or [upgrade.previous\(\)](#) (on page 8-458)).

To upgrade the firmware using the front panel USB port:

1. Copy upgrade *.cab file to a blank USB flash drive. Ensure that the drive size is large enough for the size of the upgrade file.

NOTE

Verify that the USB flash drive is blank.

2. Power on the instrument
3. Install a USB flash drive in the front panel connector
4. On the front panel, press the **MENU** key
5. Turn the navigation wheel to scroll to **UPGRADE** and press the navigation wheel.
6. The question **UPGRADE UNIT?** is displayed. Select **Previous** to install a previous version or select **Yes** to upgrade to a newer version and press the navigation wheel.
7. The upgrade status is displayed on the front panel, including the percentage complete. When the file has been unpacked, the upgrade status will be displayed as it is upgraded (first cards installed in the slots including the DMM if installed, and then the Main Series 3700).

NOTE

For models without a front panel, the LAN Status and clock status LEDs blink in unison during the upgrade process.

The instrument will reboot automatically when the upgrade is complete.

Firmware upgrade using the instrument web interface

To upgrade the firmware from the web interface:

1. From the left navigation area, select **Unit**.
2. Log in if necessary.
3. From the Unit buttons, click **Upgrade Firmware**.
4. A confirmation message is displayed.
5. A version message is displayed. Select the appropriate option..
6. Select the file that contains the appropriate version of firmware.
7. Click **Open**. A progress dialog box is displayed. When the upgrade begins, the front panel display will also display the progress.
During the upgrade, you will see messages that indicate that the connection has been lost. This is normal.
8. After the instrument automatically restarts, it will be ready for use.

LAN concepts and settings

In this appendix:

Overview	B-1
Establishing a point-to-point connection	B-1
Connecting to the LAN	B-7
LAN speeds	B-9
Duplex mode	B-10
Viewing LAN status messages	B-10
Viewing the network settings	B-11
Selecting a remote command interface	B-12
Logging LAN trigger events in the event log	B-15

Overview

The Keithley Instruments Series 3700A System Switch/Multimeter is class C LXI version 1.2 compliant. The Series 3700A is a scalable test system that can connect directly to a host computer or interact with a DHCP or DNS server and other LXI-compliant instruments on a local area network (LAN).

The Series 3700A is compliant with the IEEE Std 802.3 and supports full connectivity on a 10 Mbps or 100 Mbps network. The LAN interface is an alternative solution to GPIB that can be used to build flexible test systems that include web access.

NOTE

Please read this entire section before you connect the Series 3700A to the LAN.

Establishing a point-to-point connection

To enable access to the instrument's internal web page and other web applications from a computer, use a one-to-one LAN connection to set up a static IP address between the host computer and the instrument.

The following instructions describe how to configure the instrument's IP address. The instrument's IP address is based on the present IP address of the host computer. Each device on the LAN (corporate or private) requires a unique IP address.



CAUTION

Contact your corporate information technology (IT) department for permission before you connect the Series 3700A to a corporate network.

If you have problems, see [LAN troubleshooting suggestions](#) (see "[Verify connections and settings](#)" on page 9-6).



CAUTION

Record all network configurations before modifying any existing network configuration information on the network interface card. Once the network configuration settings are updated, the older information is lost. This may cause a problem reconnecting the host computer to a corporate network, particularly if DHCP Enabled = NO (disabled).

Be sure to return all settings to their original configuration before reconnecting the host computer to a corporate network. Failure to do this could result in damage to the equipment and loss of data. Contact your system administrator for more information.

Step 1: Identify and record the existing IP configuration

To identify the existing IP configuration:

1. Open a command prompt window:

Microsoft® Windows® 2000 or Windows XP:

- a. Click **Start** and select **Run**.
- b. In the Open box, type `cmd`.
- c. Click **OK**.

Microsoft Windows Vista® or Windows 7:

- a. Click **Start**.
 - b. Select **All Programs > Accessories > Command Prompt**.
2. At the command prompt, type `ipconfig/all` and press the **Enter** key. A list of existing IP configuration information for your computer is displayed.

Figure 11-2: Computer IP configuration using the command prompt

```

C:\WINDOWS>ipconfig/all

Windows IP Configuration

Host Name . . . . . : mycomputer
Primary Dns Suffix . . . . . :
Node Type . . . . . : Hybrid
IP Routing Enabled. . . . . : No
WINS Proxy Enabled. . . . . : No
DNS Suffix Search List. . . . . : mycompany.com

Ethernet adapter Wireless Network Connection:

Connection-specific DNS Suffix . . . :
Description . . . . . : Intel(R) Wireless WiFi Link 4965AG
Physical Address. . . . . : 00-01-02-03-04-05
Dhcp Enabled. . . . . : Yes
IP Address. . . . . : 1.2.3.87
Subnet Mask . . . . . : 255.255.255.0
Default Gateway . . . . . : 1.2.3.1
DNS Servers . . . . . : 1.2.3.2

Ethernet adapter Local Area Connection:

Connection-specific DNS Suffix . . . :
Description . . . . . : Intel(R) 82566MM Gigabit Network Connection
Physical Address. . . . . : 00-02-03-04-05-06
Dhcp Enabled. . . . . : No
IP Address. . . . . : 192.168.1.100
Subnet Mask . . . . . : 255.255.255.0
Default Gateway . . . . . : 192.168.1.1
DNS Servers . . . . . :

C:\WINDOWS>

```

NOTE

If the information for the Ethernet adapter displays "Media Disconnected," close the command prompt and go to [Step 2: Disable DHCP to use the computer's existing IP address](#) (on page B-4).

- When the information is displayed, record the following information for the correct network card:
 - DHCP mode: _____
 - IP address: _____
 - Subnet mask: _____
 - Default gateway: _____
 - DNS servers: _____



CAUTION

The `ipconfig/all` command displays the configuration of every network card. Make sure that you record the information for the proper network card.

- If:
 - DHCP Enabled = Yes:** Go to [Step 2: Disable DHCP to use the computer's existing IP address](#) (on page B-4)
 - DHCP Enabled = No:** Go to [Step 3: Configure the Instrument's LAN settings](#) (on page B-5).
- To exit the IP configuration screen, type **exit** at the command prompt and press **Enter**.

Step 2: Disable DHCP to use the computer's existing IP address


NOTE

Do not change the IP address at any time without talking to your system administrator first. Entering an incorrect IP address can prevent your workstation from connecting to your corporate network.

1. Open the Internet Protocol Properties dialog box:

Windows 2000:	Windows XP:	Windows Vista and Windows 7:
<ol style="list-style-type: none"> a. Click the Start > Settings > Control Panel. b. Open Network and Dial-up Connections. c. Right-click Local AreaConnection and select Properties. The Local Area Connection Properties dialog box is displayed. d. Double-click Internet Protocol (TCP/IP) in the items list. The Internet Protocol (TCP/IP) Properties dialog box is displayed (see the figure titled "Internet protocol (TCP/IP) Properties dialog box" below). 	<ol style="list-style-type: none"> a. Click Start > Settings > Control Panel. b. Open Network Connections. c. Right-click Local Area Connection and select Properties. The Local Area Connection Properties dialog box is displayed. d. Double-click Internet Protocol (TCP/IP) in the items list. The Internet Protocol (TCP/IP) Properties dialog box is displayed (see the figure titled "Internet protocol (TCP/IP) Properties dialog box" below). 	<ol style="list-style-type: none"> a. Click the Start > Control Panel. b. Open Network & Sharing Center. c. In the list, click View Status next to Connection. The Wireless Network Connection Status dialog box is displayed. d. Click Properties. Windows displays a permissions message. e. If you are logged in as administrator, click Continue. If you are not logged in as administrator, enter the administrator's password to continue. f. The Network Connection Properties dialog box is displayed. g. Double-click Internet Protocol Version 6 (TCP/IPv6) in the items list. The Internet Protocol Version 6 (TCP/IPv6) Properties dialog box is displayed (see the figure titled "Internet protocol (TCP/IP) Properties dialog box" below).

2. Select **Use the following IP address**. The option for "Use the following DNS server addresses" is automatically selected.
3. Set the IP address:
 - a. Are the IP address and subnet mask fields populated?
 - **Yes:** If populated, record the IP address, subnet mask, default gateway, and DNS servers to use in [Step 3: Configure the Instrument's LAN settings](#) (on page B-5).
 - **No:** If blank, enter the IP address 192.168.1.100 in the IP address field and 255.255.255.0 in the subnet mask field. These will be used to configure the instrument's LAN settings.
 - b. After recording or entering the IP address, click **OK**.
4. Click **OK** to close the Local Area Connection Properties dialog box.
5. Close the Network Connections window.

Figure 11-3: Internet protocol (TCP/IP) Properties dialog box

Step 3: Configure the instrument's LAN settings

To configure the Series 3700A using the front panel:

1. Press the **MENU** key to display the MAIN MENU. Use the navigation wheel  to select **LAN**; the LAN CONFIG menu displays.
2. Change the IP address assignment method:
 - a. Select **CONFIG > METHOD > MANUAL**, and then press the **ENTER** key.
 - b. Press the **EXIT (LOCAL)** key once to return to the LAN CONFIG menu.
 - c. Select **APPLY_SETTINGS > YES**, then press the **ENTER** key.
3. Enter the IP address using the LAN CONFIG menu:
 - a. Select **CONFIG > IP-ADDRESS**.
 - b. Refer to the recorded computer's IP address ([Step 1: Identify and record the existing IP configuration](#) (on page B-2)). A portion of the computer's IP address is used as a base for the instrument's unique ID. Only the last three numbers (after the last decimal point) of the IP address will differ between the computer and the instrument. The last three digits can be any value from 1 to 255 for a subnet mask of 255.255.255.0.

For example, the Internet Protocol (TCP/IP) Properties dialog box shows that the computer's IP address is 192.168.1.100 (see the figure titled "Internet protocol (TCP/IP) Properties dialog box" in [Step 2: Disable DHCP to use the computer's existing IP address](#) (on page B-4)). A unique IP address for the instrument is 192.168.001.101.

NOTE

The instrument's IP address can have leading zeros, but the computer's cannot.

- c. Use the navigation wheel  to select and enter an appropriate IP address for the instrument. Be sure to record the instrument's IP address to use in [Step 5: Access the instrument's internal web page](#) (on page B-6).
 - d. Press **ENTER** key or navigation wheel  to confirm the changes.
 - e. Press the **EXIT (LOCAL)** key to return to the LAN CONFIG menu.
 - f. From the **LAN CONFIG** menu, select **APPLY_SETTINGS > YES**, and then press the **ENTER** key.
4. Change the subnet mask from within the LAN CONFIG menu:
- a. Select **CONFIG > SUBNETMASK**, and then press the **ENTER** key. The SUBNETMASK menu item is to the right of GATEWAY. Use the navigation wheel  to scroll through the options.
 - b. Modify the SUBNETMASK value to match the computer settings recorded earlier (or 255.255.255.000 if DHCP Enabled = YES).
 - c. Press the **ENTER** key or the navigation wheel  when you are finished changing all the characters.
 - d. Press the **EXIT (LOCAL)** key to return to the LAN CONFIG menu.
 - e. From the **LAN CONFIG** menu, select **APPLY_SETTINGS > YES**, and then press the **ENTER** key.

NOTE

You must select **APPLY_SETTINGS** before changes to the IP address or subnet mask are applied.

Step 4: Install the crossover cable

Connect the supplied crossover cable between the computer's NIC card and the LAN connector on the instrument's rear panel. There are multiple connectors on the Series 3700A rear panel. Be sure to connect to the LAN connection port.

NOTE

Connect the crossover cable into the same computer LAN port used during instrument configuration to ensure that the system is using the correct network card.

Step 5: Access the instrument's internal web page

1. Open a web browser on the host computer.
2. Enter the instrument's IP address in the browser's address box. For example, if the instrument's IP address is 192.168.1.101, enter 192.168.1.101 in the browser's address box.
3. Press **Enter** on the computer keyboard to open the instrument's web page.

NOTE

If the web page does not open in the browser, see [LAN troubleshooting suggestions](#) (see "[Verify connections and settings](#)" on page 9-6).

Connecting to the LAN

Each device on the LAN (corporate or private) requires a unique IP address. Contact your IT department for details on obtaining an IP address before you deploy the Series 3700A on a corporate or private network.



CAUTION

Contact your corporate information technology (IT) department for permission before you connect the Series 3700A to a corporate network.

Setting the LAN configuration method

There are two methods used to configure the LAN.

AUTO: Use the Auto setting to allow the DHCP server to automatically set the LAN settings.

You do not need to set the LAN options manually. The DHCP server automatically configures the IP address, subnet mask and the default gateway. To use this option, a DHCP server must be available on the LAN.

MANUAL: Use the Manual setting to manually configure the communication parameters.

The MANUAL setting requires you to configure the following:

- IP address
- Gateway
- Subnet mask

To select a LAN configuration method:

1. From the front panel, press the **MENU** key, and then select **LAN > CONFIG > METHOD**.
2. Select either **AUTO** or **MANUAL**.
3. Press the **ENTER** key.
4. Press the **EXIT (LOCAL)** key once to return to the LAN CONFIG menu.
5. Select **APPLY_SETTINGS > YES**, and then press the **ENTER** key.

Setting the IP address

NOTE

Contact your IT department to secure a valid IP address for the instrument when placing the instrument on a corporate network.

You do not need to set the IP address manually if the LAN configuration method is set to AUTO.

To set the IP address (when LAN configuration method is set to MANUAL):

1. From the front panel, press the **MENU** key, and then select **LAN > CONFIG > IP-ADDRESS**.
2. Turn the navigation wheel  to select and enter a valid IP address for the instrument.
3. Press the **ENTER** key to confirm the changes.
4. Press the **EXIT (LOCAL)** key to return to the LAN CONFIG menu.
5. Select **APPLY_SETTINGS > YES**, and then press the **ENTER** key.

Setting the gateway

NOTE

Contact your IT department to secure a valid gateway for the instrument when placing the instrument on a corporate network.

You do not need to set the gateway manually if the LAN configuration method is set to AUTO.

To set the gateway (when LAN configuration method is set to MANUAL):

1. From the front panel, press the **MENU** key, and then select **LAN > CONFIG > GATEWAY**.
2. Turn the navigation wheel  to select and enter a valid gateway address for the instrument.
3. Press the **ENTER** key to confirm the changes.
4. Press the **EXIT (LOCAL)** key to return to the LAN CONFIG menu.
5. Select **APPLY_SETTINGS > YES**, and then press the **ENTER** key.

Setting the subnet mask

NOTE

Contact your IT department to secure a valid subnet mask for the instrument when placing the instrument on a corporate network.

You do not need to set the subnet mask manually if the LAN configuration method is set to AUTO.

To set the subnet mask (when LAN configuration method is set to MANUAL):

1. From the front panel, press the **MENU** key, and then select **LAN > CONFIG > SUBNETMASK**.
2. Turn the navigation wheel  to select and enter a valid subnet mask for the instrument.
3. Press the **ENTER** key to confirm the changes.
4. Press the **EXIT (LOCAL)** key to return to the LAN CONFIG menu.
5. Select **APPLY_SETTINGS > YES**, and then press the **ENTER** key.

Configuring the domain name system (DNS)

The domain name system (DNS) lets you type a domain name in the address bar to connect to the instrument. The DNS removes the requirement to memorize the IP address; instead you only need to know the domain name.

Example:

Series3700AS.yourcompany.com

NOTE

If a DNS server is not part of the LAN infrastructure, this setting is not used.
• Contact your IT department to learn more about DNS.

To enable or disable DNS host name verification:

1. From the front panel, press the **MENU** key, and then select **LAN > CONFIG > DNS > VERIFY**.
2. Turn the navigation wheel  to select either **ENABLE** or **DISABLE**. When enabled, the instrument performs a DNS lookup to verify the DNS host name matches the value specified in the command [lan.config.dns.hostname](#) (on page 8-272).
3. Press the **ENTER** key.
4. Press the **EXIT (LOCAL)** key twice to return to the LAN CONFIG menu.
5. Select **APPLY_SETTINGS > YES**, and then press the **ENTER** key.

To enable or disable DNS registration:

1. From the front panel, press the **MENU** key and select **LAN > CONFIG > DNS > DYNAMIC**.
2. Turn the navigation wheel  to select either **ENABLE** or **DISABLE**. DNS registration works with the DHCP to register the host name specified in the `lan.config.dns.hostname` attribute with the DNS server.
3. Press the **ENTER** key.
4. Press the **EXIT (LOCAL)** key twice to return to the LAN CONFIG menu.
5. Select **APPLY_SETTINGS > YES**, and then press the **ENTER** key.

To set the DNS server IP addresses:

1. From the front panel, press the **MENU** key and select **LAN > CONFIG > DNS**.
2. Turn the navigation wheel  to select either **DNS-ADDRESS1** or **DNS-ADDRESS2**.
3. Press the **ENTER** key.
4. Turn the navigation wheel  to select and enter a valid IP address for the DNS server.
5. Press the **ENTER** key.
6. Press the **EXIT (LOCAL)** key twice to return to the LAN CONFIG menu.
7. Select **APPLY_SETTINGS > YES**, and then press the **ENTER** key.

LAN speeds

Another characteristic of the LAN is speed. The Series 3700A negotiates with the host computer and other LXI-compliant devices on the LAN to transmit data at the highest speed possible. LAN speeds must be configured to match the speed of the other instruments on the network.

To set the LAN speed:

1. From the front panel, press the **MENU** key and select **LAN > CONFIG > SPEED**.
2. Turn the navigation wheel  to select either **10 Mbps** or **100 Mbps**.
3. Press the **ENTER** key.
4. Press the **EXIT (LOCAL)** key once to return to the LAN CONFIG menu.
5. Select **APPLY_SETTINGS > YES**, and then press the **ENTER** key.

Duplex mode

The duplex mode is based on the LAN configuration. There are two settings:

- **Half-duplex:** Allows communications in both directions, but only one direction is active at a time (not simultaneously).
- **Full:** Permits communications in both directions simultaneously.

To set the duplex mode:

1. From the front panel, press **MENU** key and select **LAN > CONFIG > DUPLEX**.
2. Turn the navigation wheel  to select either **HALF** or **FULL**.
3. Press the **ENTER** key.
4. Press the **EXIT (LOCAL)** key once to return to the LAN CONFIG menu.
5. Select **APPLY_SETTINGS > YES**, and then press the **ENTER** key.

Viewing LAN status messages

To view the LAN status messages:

1. From the front panel, press the **MENU** key and select **LAN > STATUS > CONFIG/FAULT**.
2. Press the **ENTER** key.

Figure 11-4: LAN CONFIG/FAULT (Series 2650)



There are two types of LAN status messages:

- **LAN fault messages:** Communicate issues related to physical connectivity.
- **LAN configuration messages:** Communicate issues or events related to configuration.

The following table displays possible fault and configuration messages.

LAN CONFIG/FAULT messages

LAN message type	Possible messages
LAN fault	Could not acquire IP address
	Duplicate IP address detected
	DHCP lease lost
	Lan Cable Disconnected
LAN configuration	Starting DHCP Configuration
	DHCP Server Not Found

	DHCP configuration started on xxx.xxx.xxx.xxx
	Searching for DNS server(s)
	Starting DLLA Configuration
	DLLA Failed
	DLLA configuration started on xxx.xxx.xxx.xxx
	Starting Manual Configuration
	Manual configuration started on xxx.xxx.xxx.xxx
	Closed

Viewing the network settings

To view the active network settings:

1. From the front panel, press the **MENU** key, and then select **LAN > STATUS**.
2. Use the navigation wheel  to select one of the following network settings:
 - **IP-ADDRESS**
 - **GATEWAY**
 - **SUBNET-MASK**
 - **METHOD**
 - **DNS**
 - **MAC-ADDRESS**
3. Press the **ENTER** key to view the active setting.
4. Press the **EXIT (LOCAL)** key once to return to the STATUS menu.

Confirming the active speed and duplex negotiation

The Series 3700A automatically detects the speed and duplex negotiation active on the LAN. Once the speed and duplex negotiation is detected, the instrument automatically adjusts its own settings to match the LAN settings.

To confirm the active LAN speed and duplex mode:

1. From the front panel, press the **MENU** key.
2. Select **LAN > STATUS**.
3. Use the navigation wheel  to select one of the following:
 - **SPEED**
 - **DUPLEX**
4. Press the **ENTER** key to view the active setting.
5. Press the **EXIT (LOCAL)** key once to return to the STATUS menu

Confirming port numbers

To view the port number assigned to each remote interface protocol:

1. From the front panel, press the **MENU** key, and then select **LAN > STATUS > PORT**.
2. Use the navigation wheel  to select one of the following:
 - **RAW-SOCKET**
 - **TELNET**
 - **VXI-11**
 - **DST**
3. Press the **ENTER** key to view the port number.
4. Press the **EXIT (LOCAL)** key once to return to the PORT menu.

The following table displays the remote interface protocols supported by the Series 3700A and their assigned port numbers.

Port number	
Command interface	Port number
Raw socket	5025
Telnet	23
VXI-11	1024
DST (dead socket termination)	5030

Selecting a remote command interface

This section provides details about how to select a remote command interface to connect to the Series 3700A.

VXI-11 connection

This remote interface is similar to GPIB and supports message boundaries, serial poll, and service requests (SRQs). A VXI-11 driver or NI-VISA™ software is required. Test Script Builder (TSB) uses NI-VISA and can be used with the VXI-11 interface. You can expect a slower connection with this protocol.

Raw socket connection

Raw socket is a basic Ethernet connection that communicates similarly to RS-232 without explicit message boundaries. The instrument will always terminate messages with a line feed, but because binary data may include bytes that resemble line-feed characters, it may be difficult to distinguish between data and line-feed characters.

Use raw socket as an alternative to VXI-11. Raw socket offers a faster connection than VXI-11. However, raw socket does not support explicit message boundaries, serial poll, and service requests.

Dead socket connection

The dead socket termination (DST) port is used to terminate all existing Ethernet connections. A dead socket is a socket that is held open by the instrument because it has not been properly closed. This most often happens when the host computer is turned off or reboots without first closing the socket. This port cannot be used for command and control functions.

Use the dead socket termination port to manually disconnect a dead session on any open socket. All existing Ethernet connections will be terminated and closed when the connection to the dead socket termination port is closed.

Telnet connection

Telnet is similar to raw socket, and can be used when you need to interact directly with the instrument (typically for debugging and troubleshooting). Telnet requires a separate Telnet program. The Series 3700A supports the Telnet protocol that you can use over a TCP/IP connection to send commands to the instrument. You can use a Telnet connection to interact with scripts or send real-time commands.

Configuring a Telnet connection

NOTE

This procedure uses HyperTerminal™, which is available with the Microsoft® Windows® XP operating system. Consult the help system for your version of Microsoft Windows to identify a compatible tool.

To connect with the Series 3700A using HyperTerminal on a Windows XP system:

1. On the host computer, click **Start > Accessories > Communications > HyperTerminal**. The Connection Description dialog box will open.


Figure 11-5: Connection description dialog box



2. Type a name to identify the connection (for example, `My Instrument`) and then click **OK**.
3. In the Connect To dialog box, click the **Connect using** drop-down list and select **TCP/IP (Winsock)**.

Figure 11-6: Connect To dialog box


4. In the Host address field, type the instrument's IP address (for example, 192.168.1.101).
5. Type 23 in the **Port number** field, and then click **OK**. The HyperTerminal program window displays.
6. From the HyperTerminal program window, click **File > Properties**.
7. In the properties dialog box, click the **Settings** tab.

Figure 11-7: Properties dialog box

8. Click **ASCII Setup**. The ASCII Setup dialog box is displayed.

9. From the ASCII Setup window, select the following options:
 - **Send line ends with line feeds**
 - **Echo typed characters locally**

Figure 11-8: ASCII Setup window



10. Click **OK** in the ASCII Setup dialog box. The Properties window displays.
 11. Click **OK** in the Properties dialog box.
- Use the HyperTerminal window to interact directly with the instrument.

Logging LAN trigger events in the event log

You can use the event log to record all LXI triggers generated and received by the Series 3700A, and you can view the event log using any command interface or the embedded web interface. The following figure shows the view of the LXI event log from the embedded web interface.

Figure 11-9: 3700A LXI event log

LXI Event Log ... 00:00:00.000 1 Jan 1970

Receive Time	EventID	From	System Timestamp		HWDetect	Sequence	Domain	Flags	Data
			Seconds	FractionalSeconds					



The timestamp, event identifier, IP address, and the domain name identify the incoming and outgoing LXI trigger packets. The following table provides detailed descriptions for the columns in the event log.

Event log descriptions

Column title	Description	Example
Received Time	Displays the date and time that the LAN trigger occurred in UTC, 24-hour time	06:56:28.000 8 May 2011
EventID	Identifies the <code>lan.trigger[N]</code> that generates an event	LAN0 = <code>lan.trigger[1]</code> LAN1 = <code>lan.trigger[2]</code> LAN2 = <code>lan.trigger[3]</code> LAN3 = <code>lan.trigger[4]</code> LAN4 = <code>lan.trigger[5]</code> LAN5 = <code>lan.trigger[6]</code> LAN6 = <code>lan.trigger[7]</code> LAN7 = <code>lan.trigger[8]</code>
From	Displays the IP address for the device that generates the LAN trigger	localhost 192.168.5.20
Timestamp	A timestamp that identifies the time the event occurred; the timestamp uses the following: <ul style="list-style-type: none"> • PTP timestamp • Seconds • Fractional seconds 	The Series 3700A does not support the IEEE Std 1588 standard. The values in this field are always 0 (zero).
HWDetect	Identifies a valid LXI trigger packet	LXI
Sequence	Each instrument maintains independent sequence counters: <ul style="list-style-type: none"> • One for each combination of UDP multicast network interface and UDP multicast destination port • One for each TCP connection 	
Domain	Displays the LXI domain number. <ul style="list-style-type: none"> • The default value is 0 (zero) 	0 1523
Flags	Contain data about the LXI trigger packet	Values: <ul style="list-style-type: none"> • 1 - Error • 2 - Retransmission • 4 - Hardware • 8 - Acknowledgments • 16 - Stateless bit
Data	The Series 3700A does not support the IEEE Std 1588 standard; the values in this are always 0 (zero)	

Accessing the event log from the command interface

You can access the event log from any remote command interface. The event log must be enabled before LXI trigger events can be viewed. To enable the event log, send:

```
eventlog.enable = 1
```

To view the event log from a remote interface, send:

```
print(eventlog.all())
```

This command outputs one or more strings similar to the following:

```
14:14:02.000 17 Jun 2008, LAN0, 10.80.64.191, LXI, 0, 1213712000, not
available, 0, 0x10,0x00
```

The string displays the same information as the web interface. Commas separate the different fields. The fields output in the following order:

- UTC time
- Event Id
- Sender
- HwDetect / version
- Domain
- sequence number
- ptp time
- epoch (from 1588)
- flags
- Data

See the table in [Logging LAN trigger events in the event log](#) (on page B-15) for detailed descriptions.

In this appendix:

Verification.....	C-1
Calibration	C-22

Verification

Use the procedures in this section to verify that the Keithley Instruments Model 3706A System Switch/Multimeter's accuracy is within the limits stated in the instrument's one-year accuracy specifications. Verifying the accuracy of your Model 3706A is recommended:

- When you first receive the instrument to make sure that it was not damaged during shipment
- To verify that the unit meets factory specifications
- To determine if calibration is required
- Following calibration to make sure that calibration was performed properly



WARNING

The information in this section is intended for qualified service personnel only. Do not attempt these procedures unless you are qualified to do so.

Some of these procedures may expose you to hazardous voltages, that if contacted, could cause personal injury or death. Use appropriate safety precautions when working with hazardous voltages.

For the plug-in modules, the maximum common-mode voltage (voltage between any plug-in module terminal and chassis ground) is 300V DC or 300V RMS. Exceeding this value may cause a breakdown in insulation, creating a shock hazard.

NOTE

If the instrument is still under warranty and its performance is outside specified limits, contact your Keithley Instruments representative or the factory to determine the correct course of action.

Verification test requirements

Be sure that you perform these verification tests:

- Under the proper environmental conditions
- After the specified warmup period
- Using the correct line voltage
- Using the proper test equipment
- Using the specified output signal and reading limits

Environmental conditions

Conduct the verification procedures in a location that has:

- An ambient temperature of 18 °C to 28 °C (65 °F to 82 °F)
- A relative humidity of less than 80%, unless otherwise noted

Warmup period

NOTE

At the factory, instruments are calibrated without any switch cards installed and all slots are covered with blank slot covers. The slot covers come installed on the instrument when it is shipped.

If it is more convenient to calibrate the instrument with switch cards installed, make sure all channels are open and any empty slots are covered with blank slot covers.

Allow the System Switch/Multimeter to warm up for at least two hours before performing calibration.

If the instrument has been subjected to temperature extremes (those outside the ranges stated in [Environmental conditions](#) (on page C-2)), allow extra time for the instrument's internal temperature to stabilize. Typically, you need to allow one extra hour to stabilize an instrument that is 10 °C (18 °F) outside the specified temperature range.

Also, allow the test equipment to warm up for the minimum time specified by the manufacturer.

Line power

The Model 3706A requires a line voltage of 100 V to 240 V ($\pm 10\%$), and a line frequency of 50 Hz or 60 Hz.

NOTE

The instrument automatically senses the line frequency at power-up.

Recommended test equipment

The following table summarizes recommended verification equipment. You can use alternate equipment if that equipment has specifications equal to or greater than those listed in the table. Note, however, that test equipment uncertainty will add to the uncertainty of each measurement. Generally, test equipment uncertainty should be at least four times better (more accurate) than corresponding Model 3706A specifications.

NOTE

The Keithley Instruments Model 3706-190 backplane connector board is an accessory that can be used to make connections to the calibrator. Additional boards, such as a 4-wire short or the discrete resistors, would also be convenient to eliminate rewiring for different setups used in verification.

Manufacturer	Model	Description	Used for:	Uncertainty
Fluke	5700	Calibrator	All DCV, ACV, DCI, ACI, and resistance	See NOTE.
Fluke	5725	Amplifier	High voltage, high current	See NOTE.
HP	3458	DMM	10 μ A, 100 μ A DCI range	See NOTE.
Agilent	33220A	Function generator	Frequency	See NOTE.
N/A	N/A	4-wire short	DCV, resistance zeros	N/A
N/A	N/A	1 Ohm discrete resistor	1 Ohm range	+/- 20ppm
N/A	N/A	10 Ohm discrete resistor	10 Ohm range	+/- 20ppm

NOTE

Refer to the manufacturer's specifications to calculate the uncertainty, which will vary for each test point.

Verification limits

The verification limits stated in this section have been calculated using only the Model 3706A one-year accuracy specifications, and they do not include test equipment uncertainty. If a particular measurement falls outside the allowable range, recalculate new limits based both on the Model 3706A specifications and corresponding test equipment specifications.

Example reading limit calculation

The following is an example of how reading limits have been calculated. Assume you are testing the 10V DC range using a 10V input value. Using the Model 3706A one-year accuracy specification for 10V DC of \pm (25ppm of reading + 2ppm of range), the calculated limits are:

$$\text{Reading limits} = 10V \pm [(10V \times 25\text{ppm}) + (10V \times 2\text{ppm})]$$

$$\text{Reading limits} = 10V \pm (0.00025 + 0.00002)$$

$$\text{Reading limits} = 10V \pm 0.00027V$$

$$\text{Reading limits} = 9.99973V \text{ to } 10.00027V$$

Calculating resistance reading limits

Resistance reading limits must be recalculated based on the actual calibration resistance values supplied by the equipment manufacturer. Calculations are performed in the same manner as shown in the preceding example, using the actual calibration resistance values instead of the nominal values in the example when performing your calculations.

For example, assume that you are testing the 10k Ω range using an actual 10.03k Ω calibration resistance value. Using Model 3706A one-year 10k Ω range accuracy of \pm (60ppm of reading + 4ppm of range), the calculated reading limits are:

$$\text{Reading limits} = 10.03\text{k}\Omega \pm [(10.03\text{k}\Omega \times 60\text{ppm}) + (10.03\text{k}\Omega \times 6\text{ppm})]$$

$$\text{Reading limits} = 10.03\text{k}\Omega \pm [(0.000618) + (0.0000618)]$$

$$\text{Reading limits} = 10.03\text{k}\Omega \pm 0.0006798$$

$$\text{Reading limits} = 10.0293202\text{k}\Omega \text{ to } 10.0306798\text{k}\Omega$$

Restoring factory defaults

To restore the instrument to its factory front panel (bench) defaults before performing the verification procedures:

1. Press the **MENU** key.
2. Turn the navigation wheel to highlight **SETUP** and then press the **ENTER** key.
3. Turn the navigation wheel to highlight **RESET** and then press the **ENTER** key.

Performing the verification test procedures

The following topics provide a summary of verification test procedures, as well as items to take into consideration before performing any verification test.

Test summary

- [Verifying DC voltage](#) (on page C-5)
- [Verifying AC voltage](#) (on page C-7)
- [Verifying DC current 10 \$\mu\$ A to 100 \$\mu\$ A ranges](#) (on page C-9)
- [Verifying DC current 1 mA to 3 A ranges](#) (on page C-10)
- [Verifying AC current 1 mA to 3 A ranges](#) (on page C-12)
- [Verifying frequency](#) (on page C-14)
- [Verifying 4-wire resistance](#) (on page C-15)
- [Verifying 2-wire resistance](#) (on page C-16)
- [Verifying dry circuit resistance](#) (on page C-17)
- [Verifying 1-ohm and 10-ohm resistance ranges](#) (on page C-19)
- [Verifying zeros using a 4-wire short](#) (on page C-20)

If the Model 3706A is not within specifications and not under warranty, calibrate the unit.

Test considerations

When performing the verification procedures:

- Be sure to restore factory front panel defaults as outlined in [Restoring factory defaults](#) (on page C-4).
- Make sure that the test equipment is properly warmed up and connected to the Model 3706A terminals.
- Be sure the test equipment is set up for the proper function and range.
- Do not connect test equipment to the Model 3706A through a scanner, multiplexer, or other switching equipment.

WARNING

The input/output terminals of the digital multimeter (DMM) and switch cards are rated for connection to circuits rated Installation Category I only, with transients rated less than 1500V peak. Do not connect the DMM or switch card terminals to CAT II, CAT III, or CAT IV circuits.

Connections of the DMM or switch card terminals to circuits higher than CAT I can cause damage to the equipment or expose the operator to hazardous voltages.

Model 3706A verification tests

Perform these tests to verify the accuracy of your Model 3706A at the analog backplane connector.

Verifying DC voltage

Check DC voltage accuracy by applying accurate voltages from the DC voltage calibrator to the Model 3706A analog backplane connector and verifying that the displayed readings fall within specified limits.

CAUTION

Do not exceed 300 V peak between INPUT HI and INPUT LO because instrument damage may occur.

To verify DC voltage accuracy:

NOTE


Use shielded, low-thermal connections when testing the 100 mV and 1 V ranges to avoid errors caused by noise or thermal effects. Connect the shield to the calibrator's output LO terminal.

1. Connect the Model 3706A HI and LO INPUT pins to the DC voltage calibrator as shown in the "DC voltage verification" below.
2. Select the DC volts function.
3. Set the Model 3706A to the 100 mV range.

4. If relative offset is needed, set the calibrator output to 0.00000 mVDC and allow the reading to settle.
5. Enable the Model 3706A relative offset mode.
6. Source positive and negative full-scale and half-scale voltages for each of the ranges listed in the table below. For each voltage setting, be sure that the reading is within stated limits.

Figure 11-10: DC voltage verification

Analog backplane connector



DC voltage verification data

Use the following values to verify the performance of the Model 3706A. Actual values depend on the published specifications (see [Example reading limit calculation](#) (on page C-3)).

Connect to the Fluke 5700A Calibrator				
Description	Range (V)	Test point (V)	Lower limit (V)	Upper limit (V)
Rel Series 3700	1.00E-01	0.00E+00	N/A	N/A
Verify DCV 100mV	1.00E-01	1.00E-01	9.999610E-02	1.000039E-01
Verify DCV 100mV	1.00E-01	5.00E-02	4.999760E-02	5.000240E-02
Verify DCV 100mV	1.00E-01	-5.00E-02	-5.000240E-02	-4.999760E-02
Verify DCV 100mV	1.00E-01	-1.00E-01	-1.000039E-01	-9.999610E-02
Rel Series 3700	1.00E+00	0.00E+00	N/A	N/A
Verify DCV 1V	1.00E+00	1.00E+00	9.999680E-01	1.000032E+00
Verify DCV 1V	1.00E+00	5.00E-01	4.999830E-01	5.000170E-01
Verify DCV 1V	1.00E+00	-5.00E-01	-5.000170E-01	-4.999830E-01
Verify DCV 1V	1.00E+00	-1.00E+00	-1.000032E+00	-9.999680E-01
Verify DCV 10V	1.00E+01	1.00E+01	9.999730E+00	1.000027E+01
Verify DCV 10V	1.00E+01	5.00E+00	4.999855E+00	5.000145E+00
Verify DCV 10V	1.00E+01	0.00E+00	-2.000000E-05	2.000000E-05
Verify DCV 10V	1.00E+01	-5.00E+00	-5.000145E+00	-4.999855E+00
Verify DCV 10V	1.00E+01	-1.00E+01	-1.000027E+01	-9.999730E+00

Connect to the Fluke 5700A Calibrator				
Description	Range (V)	Test point (V)	Lower limit (V)	Upper limit (V)
Verify DCV 100V	1.00E+02	1.00E+02	9.999540E+01	1.000046E+02
Verify DCV 100V	1.00E+02	5.00E+01	4.999740E+01	5.000260E+01
Verify DCV 100V	1.00E+02	0.00E+00	-6.000000E-04	6.000000E-04
Verify DCV 100V	1.00E+02	-5.00E+01	-5.000260E+01	-4.999740E+01
Verify DCV 100V	1.00E+02	-1.00E+02	-1.000046E+02	-9.999540E+01
Verify DCV 300V	3.00E+02	3.00E+02	2.999862E+02	3.000138E+02
Verify DCV 300V	3.00E+02	1.50E+02	1.499922E+02	1.500078E+02
Verify DCV 300V	3.00E+02	0.00E+00	-1.800000E-03	1.800000E-03
Verify DCV 300V	3.00E+02	-1.50E+02	-1.500078E+02	-1.499922E+02
Verify DCV 300V	3.00E+02	-3.00E+02	-3.000138E+02	-2.999862E+02

Verifying AC voltage

Check AC voltage accuracy by applying accurate voltages from the AC voltage calibrator to the Model 3706A analog backplane connector and verifying that the displayed readings fall within specified limits.



CAUTION

Do not exceed 300 V peak between INPUT HI and INPUT LO, or 8×10^7 VHz input, because instrument damage may occur.


To verify AC voltage accuracy:

NOTE

Use shielded, low-thermal connections when testing the 100 mV and 1 V ranges to avoid errors caused by noise or thermal effects. Connect the shield to the calibrator's output LO terminal.

1. Connect the Model 3706A HI and LO INPUT pins to the DC voltage calibrator as shown in "AC voltage verification" below.
2. Select the AC volts function.
3. Set the Model 3706A to the 100 mV range. Make sure that relative offset is disabled.
4. Source AC voltages for each of the frequencies and ranges are summarized in the [ACV verification data](#) (on page C-8) table. For each setting, be sure that the reading is within stated limits.
5. Repeat steps 3 and 4 for each item in the table.

Figure 11-11: AC voltage verification



ACV verification data

Use the following values to verify the performance of the Model 3706A. Actual values depend on published specifications (see [Example reading limit calculation](#) (on page C-3)).

Connect to the Fluke 5700A calibrator				
Description	Range (V)	Test point (V)	Lower limit (V)	Upper limit (V)
Verify ACV 100mV @ 20Hz	1.00E-01	1.00E-01	9.897000E-02	1.010300E-01
Verify ACV 100mV @ 1kHz	1.00E-01	1.00E-01	9.992000E-02	1.000800E-01
Verify ACV 100mV @ 50kHz	1.00E-01	1.00E-01	9.984000E-02	1.001600E-01
Verify ACV 100mV @ 100kHz	1.00E-01	1.00E-01	9.932000E-02	1.006800E-01
Verify ACV 1V @ 20Hz	1.00E+00	1.00E+00	9.992000E-01	1.000800E+00
Verify ACV 1V @ 1kHz	1.00E+00	1.00E+00	9.992000E-01	1.000800E+00
Verify ACV 1V @ 50kHz	1.00E+00	1.00E+00	9.984000E-01	1.001600E+00
Verify ACV 1V @ 100kHz	1.00E+00	1.00E+00	9.932000E-01	1.006800E+00
Verify ACV 10V @ 1kHz	1.00E+01	1.00E+01	9.992000E+00	1.000800E+01
Verify ACV 10V @ 50kHz	1.00E+01	1.00E+01	9.984000E+00	1.001600E+01
Verify ACV 10V @ 100kHz	1.00E+01	1.00E+01	9.932000E+00	1.006800E+01
Verify ACV 100V @ 1kHz	1.00E+02	1.00E+02	9.992000E+01	1.000800E+02
Verify ACV 100V @ 50kHz	1.00E+02	1.00E+02	9.984000E+01	1.001600E+02
Verify ACV 100V @ 100kHz	1.00E+02	1.00E+02	9.932000E+01	1.006800E+02

Connect to the Fluke 5700A calibrator				
Description	Range (V)	Test point (V)	Lower limit (V)	Upper limit (V)
Verify ACV 300V @ 1kHz	3.00E+02	3.00E+02	2.997600E+02	3.002400E+02
Verify ACV 300V @ 50kHz	3.00E+02	3.00E+02	2.995200E+02	3.004800E+02

Connect to the Fluke 5725A amplifier				
Description	Range (V)	Test point (V)	Lower limit (V)	Upper limit (V)
Verify ACV 300V @ 100kHz	3.00E+02	3.00E+02	2.979600E+02	3.020400E+02


Verifying DC current 10 μ A to 100 μ A ranges

Check DC current accuracy by applying accurate current from the DC current calibrator to the Model 3706A analog backplane connector and verifying that the displayed readings fall within specified limits.

To verify DC current accuracy:

1. Set up the Model 3706A for DC current and the range being tested. Make sure relative offset is disabled.
2. Verify the zero test point for each range without any connection to the equipment and verify that the readings fall within specified limits.
3. Connect the Model 3706A AMPS and LO INPUT pins to the DC current calibrator as shown in the "DC current verification 10 μ A to 100 μ A ranges diagram" below.
4. Set up the HP3458A to the DC current function and range.
5. Set the calibrator to source zero current and rel both the Model 3706A and the HP3458A.
6. Source DC current for each of the test points summarized in the [DC voltage verification data](#) (on page C-6) table. For each setting, be sure that the reading is within stated limits.

Figure 11-12: DC current verification 10µA to 100µA ranges



DC current verification data 10 µA to 100 µA ranges

Use the following values to verify the performance of the Model 3706A. Actual values depend on published specifications (see [Example reading limit calculation](#) (on page C-3)).

Connect HP3458A in series with 5700 calibrator				
Description	Range (A)	Test point(A)	Lower limit (A)	Upper limit (A)
Verify 10 µA Zero	1.00E-05	0.00E+00	-3.000000E-10	3.000000E-10
Verify DC Curr 10 µA	1.00E-05	1.00E-05	9.994700E-06	1.000530E-05
Verify DC Curr 10 µA	1.00E-05	-1.00E-05	-1.000530E-05	-9.994700E-06
Verify 100 µA Zero	1.00E-04	0.00E+00	-3.000000E-09	3.000000E-09
Verify DC Curr 100 µA	1.00E-04	1.00E-04	9.994910E-05	1.000509E-04
Verify DC Curr 100 µA	1.00E-04	-1.00E-04	-1.000509E-04	-9.994910E-05

Verifying DC current 1 mA to 3 A ranges



Check DC current accuracy by applying accurate current from the DC current calibrator to the Model 3706A analog backplane connector and verifying that the displayed readings fall within specified limits.

NOTE

The Fluke 5725A amplifier is only needed when verifying the 3 A range.

To verify DC current accuracy:

1. Connect the Model 3706A AMPS and LO INPUT pins to the DC current calibrator as shown in the "DC current verification 1 mA to 3 A ranges diagram" below, using the Keithley Instruments Model 3706-751 fixture cable.
2. Select the DC current function.
3. Set the Model 3706A to the applicable ranges. Make sure that relative offset is disabled.
4. Source DC current for each of the test points summarized in the DC current verification data table. For each setting, be sure that the reading is within stated limits.

Figure 11-13: DC current verification 1mA to 3A ranges**Figure 11-14: DC current verification 3A range diagram**

DC current verification data 1 mA to 3 A ranges

Use the following values to verify the performance of the Model 3706A. Actual values depend on published specifications (see [Example reading limit calculation](#) (on page C-3)).

Remove HP3458A, only connect the 5700				
Description	Range (A)	Test point (A)	Lower limit (A)	Upper limit (A)
Verify 1mA Zero	1.00E-03	0.00E+00	-9.000000E-09	9.000000E-09
Verify DC Curr 1mA	1.00E-03	1.00E-03	9.994910E-04	1.000509E-03
Verify DC Curr 1mA	1.00E-03	-1.00E-03	-1.000509E-03	-9.994910E-04
Verify 10mA Zero	1.00E-02	0.00E+00	-9.000000E-08	9.000000E-08
Verify DC Curr 10mA	1.00E-02	1.00E-02	9.994910E-03	1.000509E-02
Verify DC Curr 10mA	1.00E-02	-1.00E-02	-1.000509E-02	-9.994910E-03
Verify 100mA Zero	1.00E-01	0.00E+00	-9.000000E-07	9.000000E-07
Verify DC Curr 100mA	1.00E-01	1.00E-01	9.994910E-02	1.000509E-01
Verify DC Curr 100mA	1.00E-01	-1.00E-01	-1.000509E-01	-9.994910E-02
Verify DC Curr 1A	1.00E+00	1.00E+00	9.991900E-01	1.000810E+00
Verify DC Curr 1A	1.00E+00	-1.00E+00	-1.000810E+00	-9.991900E-01

Connect to the Fluke 5725A amplifier				
Description	Range (A)	Test point (A)	Lower limit (A)	Upper limit (A)
Verify DC Curr 3A	3.00E+00	3.00E+00	2.996355E+00	3.003645E+00
Verify DC Curr 3A	3.00E+00	-3.00E+00	-3.003645E+00	-2.996355E+00

Verifying AC current 1 mA to 3 A ranges

Check AC current accuracy by applying accurate current from the AC current calibrator at specific frequencies to the Model 3706A analog backplane connector and verifying that the displayed readings fall within specified limits.

To verify AC current accuracy:

1. Set up the Model 3706A for AC current and the range being tested. Make sure relative offset is disabled.
2. Source AC current for the 1 mA to 1 A range test points summarized in "AC current calibration diagram" below. For each setting, be sure that the reading is within stated limits.
3. Install the Fluke 5725A amplifier.
4. Source AC current for the 3 A range test points summarized in the [AC current verification data 1mA to 1A ranges](#) (see "[AC current verification data 1 mA to 1 A ranges](#)" on page C-14) table. Be sure that the 3 A readings are within stated limits.

Figure 11-15: AC current verification 1mA to 1A range





Figure 11-16: AC current verification 3A range



AC current verification data 1 mA to 1 A ranges

Use the following values to verify the performance of the Model 3706A. Actual values depend on published specifications (see [Example reading limit calculation](#) (on page C-3)).

Connect to the Fluke 5700A calibrator				
Description	Range (A)	Test point (A)	Lower limit (A)	Upper limit (A)
Verify AC Curr 1mA @ 20Hz	1.00E-03	1.00E-03	9.989000E-04	1.001100E-03
Verify AC Curr 1mA @ 1kHz	1.00E-03	1.00E-03	9.989000E-04	1.001100E-03
Verify AC Curr 1mA @ 5kHz	1.00E-03	1.00E-03	9.989000E-04	1.001100E-03
Verify AC Curr 10mA @ 40Hz	1.00E-02	1.00E-02	9.989000E-03	1.001100E-02
Verify AC Curr 10mA @ 1kHz	1.00E-02	1.00E-02	9.989000E-03	1.001100E-02
Verify AC Curr 10mA @ 5kHz	1.00E-02	1.00E-02	9.989000E-03	1.001100E-02
Verify AC Curr 100mA @ 40Hz	1.00E-01	1.00E-01	9.989000E-02	1.001100E-01
Verify AC Curr 100mA @ 1kHz	1.00E-01	1.00E-01	9.989000E-02	1.001100E-01
Verify AC Curr 100mA @ 5kHz	1.00E-01	1.00E-01	9.989000E-02	1.001100E-01
Verify AC Curr 1A @ 40Hz	1.00E+00	1.00E+00	9.977000E-01	1.002300E+00
Verify AC Curr 1A @ 1kHz	1.00E+00	1.00E+00	9.977000E-01	1.002300E+00
Verify AC Curr 1A @ 5kHz	1.00E+00	1.00E+00	9.977000E-01	1.002300E+00

AC current verification data 3A range

Use the following values to verify the performance of the Model 3706A. Actual values depend on published specifications (see [Example reading limit calculation](#) (on page C-3)).

Connect to the Fluke 5725A amplifier				
Description	Range (A)	Test point (A)	Lower limit (A)	Upper limit (A)
Verify AC Curr 3A @ 40Hz	3.00E+00	3.00E+00	2.993100E+00	3.006900E+00
Verify AC Curr 3A @ 1kHz	3.00E+00	3.00E+00	2.993100E+00	3.006900E+00
Verify AC Curr 3A @ 5kHz	3.00E+00	3.00E+00	2.993100E+00	3.006900E+00


Verifying frequency

To verify the Model 3706A frequency function:

1. Connect the Agilent 33220A function generator to the Model 3706A INPUT pins.
2. Set the function generator to output a 1 kHz, 5 V RMS sine wave.
3. Select the Model 3706A frequency function by pressing the **FREQ** key.
4. Verify that each Model 3706A frequency reading is within the limits contained in the table contained in [Frequency verification data](#) (on page C-15).

Figure 11-17: Frequency verification

Analog backplane connector

**Frequency verification data**

Use the following values to verify the performance of the Model 3706A. Actual values depend on published specifications (see [Example reading limit calculation](#) (on page C-3)).

Connect the Agilent 33220A Generator				
Description	Range (V)	Frequency (Hz)	Lower limit (Hz)	Upper limit (Hz)
Verify Frequency 1kHz	1.00E+01	1.00E+03	9.999167E+02	1.000083E+03
Verify Frequency 10kHz	1.00E+01	1.00E+04	9.999167E+03	1.000083E+04
Verify Frequency 100kHz	1.00E+01	1.00E+05	9.999167E+04	1.000083E+05
Verify Frequency 250kHz	1.00E+01	2.50E+05	2.499797E+05	2.500203E+05
Verify Frequency 500kHz	1.00E+01	5.00E+05	4.999597E+05	5.000403E+05

Verifying 4-wire resistance

Check the normal resistance function by connecting accurate resistance values to the Model 3706A analog backplane connector and verifying that the displayed readings fall within specified limits.

**CAUTION**


Do not exceed 300 V peak between INPUT HI and INPUT LO because instrument damage may occur.

To verify 4-wire resistance accuracy:

1. Using shielded, Teflon-insulated or equivalent cables in a 4-wire configuration, connect the Model 3706A INPUT and SENSE pins to the calibrator as shown for 100 Ω to 10 M Ω ranges.
2. Set the calibrator for 4-wire resistance with external sense on.
3. Select the Model 3706A 4-wire resistance function.
4. Select the SLOW integration rate with the **RATE** key.

5. Set the Model 3706A for the 100 Ω range, and make sure the FILTER is on. Enable OC+ (offset-compensated ohms). Use OC+ for 100 Ω and 1 kΩ range verification only. See [Enabling/disabling offset-compensated ohms](#) (on page 4-63) in the User's manual.
6. Recalculate reading limits based on actual calibrator resistance values.
7. Source the nominal full-scale resistance values for the 100 Ω to 10 MΩ ranges summarized in the [4-wire resistance verification data](#) (on page C-16) table. Recalculate the limits based on the actual value of the resistor and verify the reading is within the calculated limits.

Figure 11-18: Resistance verification



4-wire resistance verification data

Use the following values to verify the performance of the Model 3706A. Actual values depend on published specifications (see [Calculating resistance reading limits](#) (on page C-4)).

Connect to the Fluke 5700A calibrator				
Description	Range (Ohms)	Test point (Ohms)	Lower limit (Ohms)	Upper limit (Ohms)
Verify 4W Res 100 Ohm *	1.00E+02	1.00E+02	9.999310E+01	1.000069E+02
Verify 4W Res 1k Ohm	1.00E+03	1.00E+03	9.999360E+02	1.000064E+03
Verify 4W Res 10k Ohm	1.00E+04	1.00E+04	9.999360E+03	1.000064E+04
Verify 4W Res 100k Ohm	1.00E+05	1.00E+05	9.999360E+04	1.000064E+05
Verify 4W Res 1M Ohm	1.00E+06	1.00E+06	9.999560E+05	1.000044E+06
Verify 4W Res 10M Ohm	1.00E+07	1.00E+07	9.995900E+06	1.000410E+07

NOTE

The asterisk (*) designates the ranges that offset compensation is being used.

Verifying 2-wire resistance

Check the normal resistance function by connecting accurate resistance values to the Model 3706A analog backplane connector and verifying that the displayed readings fall within specified limits.


⚠ CAUTION

Do not exceed 300V peak between INPUT HI and INPUT LO because instrument damage may occur.

To verify normal resistance accuracy:

1. Using shielded, Teflon-insulated or equivalent cables in a 2-wire configuration, connect the Model 3706A INPUT and SENSE pins to the calibrator as shown in the "2-wire resistance verification diagram" below.
2. Disable the external sense on the calibrator.
3. Set the Series 3700A to the 2-wire resistance function, set to the proper range.
4. Source a nominal 100 k Ω to 100 M Ω resistance value. Recalculate the limits based on the actual value of the resistor and verify that the reading is within the calculated limits.

Figure 11-19: 2-wire resistance verification



2-wire resistance verification data

Use the following values to verify the performance of the Model 3706A. Actual values depend on published specifications (see [Calculating resistance reading limits](#) (on page C-4)).

Description	Range (Ohms)	Test point (Ohms)	Lower limit (Ohms)	Upper limit (Ohms)
Verify 2W Res 100k Ohm	1.00E+05	1.00E+05	9.999360E+04	1.000064E+05
Verify 2W Res 1M Ohm	1.00E+06	1.00E+06	9.999360E+05	1.000064E+06
Verify 2W Res 10M Ohm	1.00E+07	1.00E+07	9.995900E+06	1.000410E+07
Verify 2W Res 100M Ohm	1.00E+08	1.00E+08	9.979700E+07	1.002030E+08

Verifying dry circuit resistance

Check the dry circuit resistance function by connecting accurate resistance values to the Model 3706A analog backplane connector and verifying that the displayed readings fall within specified limits.


⚠ CAUTION

Do not exceed 300V peak between INPUT HI and INPUT LO because instrument damage may occur.

To verify dry circuit resistance accuracy:

1. Using shielded, Teflon-insulated or equivalent cables in a 4-wire configuration, connect the Model 3706A INPUT and SENSE pins to the calibrator as shown for 100 Ω to 10 M Ω ranges.
2. Set the calibrator for 4-wire resistance with external sense on.
3. Select the Model 3706A 4-wire resistance function.
4. Select the SLOW integration rate with the **RATE** key.
5. Enable dry circuit resistance function (see [Enabling/disabling dry circuit ohms](#) (see "[Enable or disable dry circuit ohms from the front panel](#)" on page 4-61) in the User's manual).
6. Set the Model 3706A for the 100 Ω range, and make sure the FILTER is on. Enable OC+ (offset-compensated ohms). Use OC+ for 100 Ω , and 1 kOhm range verification. See [Enabling/disabling offset-compensated ohms](#) (on page 4-63) in the User's manual.
7. Recalculate reading limits based on actual calibrator resistance values.
8. Source the nominal full-scale resistance values for the 100 Ω to 2 k Ω ranges summarized in the [Dry circuit resistance verification data](#) (on page C-18) table. Verify that the readings are within calculated limits.

Figure 11-20: Resistance verification



Dry circuit resistance verification data

Use the following values to verify the performance of the Model 3706A. Actual values depend on published specifications (see [Calculating resistance reading limits](#) (on page C-4)).

Description	Range (Ohms)	Test point (Ohms)	Lower limit (Ohms)	Upper limit (Ohms)
Verify Dry Circuit 100 Ohm *	1.00E+02	1.00E+02	9.997800E+01	1.000220E+02
Verify Dry Circuit 1k Ohm	1.00E+03	1.00E+03	9.995200E+02	1.000480E+03
Verify Dry Circuit 2k Ohm	2.00E+03	1.90E+03	1.898320E+03	1.901680E+03

NOTE

The asterisk (*) designates the ranges that offset compensation is being used.

Verifying 1-OHM and 10-OHM resistance ranges

Check the normal resistance function by connecting accurate resistance values to the Model 3706A analog backplane connector and verifying that the displayed readings fall within specified limits.


CAUTION

Do not exceed 300V peak between INPUT HI and INPUT LO because instrument damage may occur.

To verify normal resistance accuracy:

1. Connect the 1 Ω discrete resistor to the Model 3706A input.
2. For the dry circuit test points, enable the dry circuit resistance attribute (DRY+).
3. Select the SLOW integration rate with the **RATE** key.
4. Set the Model 3706A for the 1 Ω range, and make sure the FILTER is on. Enable OC+ (offset-compensated ohms). Use OC+ for 1 Ω and 10 Ω range verification.
5. Recalculate reading limits based on actual discrete resistor resistance values.
6. Repeat using the 10 Ω discrete resistor on the 10 Ω range.

Figure 11-21: Verifying discrete resistance



Discrete resistance verification data

Use the following values to verify the performance of the Model 3706A. Actual values depend on published specifications (see [Calculating resistance reading limits](#) (on page C-4)).

1 Ohm discrete resistor applied				
Description	Range (Ohms)	Test point (Ohms)	Lower limit (Ohms)	Upper limit (Ohms)
Verify Res 1 Ohm *	1.00E+00	1.00E+00	9.998600E-01	1.000140E+00
Verify Dry Circuit 1 Ohm *	1.00E+00	1.00E+00	9.998500E-01	1.000150E+00

10 Ohm discrete resistor applied				
Description	Range (Ohms)	Test point (Ohms)	Lower limit (Ohms)	Upper limit (Ohms)
Verify Res 10 Ohm *	1.00E+01	1.00E+01	9.999310E+00	1.000069E+01
Verify Dry Circuit 10 Ohm *	1.00E+01	1.00E+01	9.998500E+00	1.000150E+01

NOTE

The asterisk (*) designates the ranges that offset compensation is being used.

Verifying zeros using a 4-wire short

Check the zeros of various test points while the 4-wire is connected to the Model 3706A analog backplane connector and verify that the displayed readings fall within specified limits.



CAUTION


Do not exceed 300 V peak between INPUT HI and INPUT LO because instrument damage may occur.

To verify DC voltage and resistance zeros:

1. Select the DC volts function.
2. Set the Model 3706A to the 100 mV range.
3. Connect the 4-wire short to the Model 3706A analog backplane connector and allow to settle for 5 minutes (do not use relative offset).
4. Verify the 100 mV zero is within specification (see the [4-wire short applied verification data](#) (on page C-21) table).
5. Set the Model 3706A to the 1 V range.
6. Allow to settle for 30 seconds (do not use relative offset).
7. Verify the 1 V zero is within specification (see the [4-wire short applied verification data](#) (on page C-21) table).

To verify resistance using the 4-wire short:

1. With the 4-wire short still applied, select the Model 3706A 4-wire resistance function.
2. Select the SLOW integration rate with the **RATE** key.
3. Set the Model 3706A for the 1 Ω range, and make sure the FILTER is on. Enable OC+ (offset-compensated ohms). Use OC+ for 1 Ω and 10 Ω range verification.
4. Verify the 1 Ω range zero is within specification (see the [4-wire short applied verification data](#) (on page C-21) table).
5. Set the Model 3706A for the 10 Ω range (make sure the FILTER is on and OC+ is still enabled).
6. Verify the 10 Ω range zero is within specification (see the [4-wire short applied verification data](#) (on page C-21) table).

Figure 11-22: 4-wire short diagram**4-wire short applied verification data**

Use the following values to verify the performance of the Model 3706A. Actual values depend on published specifications (see [Calculating resistance reading limits](#) (on page C-4)).

4-wire short applied				
Description	Range (V)	Test point (V)	Lower limit (V)	Upper limit (V)
Verify Zeros 100 mVDC	1.00E-01	0.00E+00	-9.000000E-07	9.000000E-07
Verify Zeros 1 VDC	1.00E+00	0.00E+00	-2.000000E-06	2.000000E-06

Description	Range (Ohms)	Test point (Ohms)	Lower limit (Ohms)	Upper limit (Ohms)
Verify Zeros 1 Ohm *	1.00E+00	0.00E+00	-8.000000E-05	8.000000E-05
Verify Zeros 10 Ohm *	1.00E+01	0.00E+00	-9.000000E-05	9.000000E-05

NOTE

The asterisk (*) designates the ranges that offset compensation is being used.

This completes the verification procedure.

Calibration

Overview

Use the procedures in this section to calibrate the Keithley Instruments Model 3706A System Switch/Multimeter.

WARNING

The information in this section is intended for qualified service personnel only. Do not attempt these procedures unless you are qualified to do so.

Some of these procedures may expose you to hazardous voltages, that if contacted, could cause personal injury or death. Use appropriate safety precautions when working with hazardous voltages.

For the plug-in modules, the maximum common-mode voltage (voltage between any plug-in module terminal and chassis ground) is 300V DC or 300V RMS. Exceeding this value may cause a breakdown in insulation, creating a shock hazard.

All procedures in this section require accurate equipment calibration to supply precise DC and AC voltages, DC and AC currents, and resistance values. Calibration can be performed any time by an operator using the remote commands sent either over the IEEE-488 bus or Ethernet. DC-only or AC-only calibration may be performed individually, if desired.

Environmental conditions

Conduct the verification procedures in a location that has:

- An ambient temperature of 18 °C to 28 °C (65 °F to 82 °F)
- A relative humidity of less than 80%, unless otherwise noted

Warmup period

NOTE

At the factory, instruments are calibrated without any switch cards installed and all slots are covered with blank slot covers. The slot covers come installed on the instrument when it is shipped.

If it is more convenient to calibrate the instrument with switch cards installed, make sure all channels are open and any empty slots are covered with blank slot covers.

Allow the System Switch/Multimeter to warm up for at least two hours before performing calibration.

If the instrument has been subjected to temperature extremes (those outside the ranges stated in [Environmental conditions](#) (on page C-2)), allow extra time for the instrument's internal temperature to stabilize. Typically, you need to allow one extra hour to stabilize an instrument that is 10 °C (18 °F) outside the specified temperature range.

Also, allow the test equipment to warm up for the minimum time specified by the manufacturer.

Line power

The Model 3706A requires a line voltage of 100 V to 240 V ($\pm 10\%$), and a line frequency of 50 Hz or 60 Hz.

NOTE

The instrument automatically senses the line frequency at power-up.

Calibration considerations

When performing calibration procedures:

- Make sure that the equipment is properly warmed up and connected to the appropriate input jacks.
- Make sure the calibrator is in OPERATE mode before you complete each calibration step.
- Always let the source signal settle before calibrating each point.
- If an error occurs during a calibration, the Model 3706A will generate an appropriate error message. See [Error summary](#) (on page 9-10) for more information.



WARNING

The input/output terminals of the digital multimeter (DMM) and switch cards are rated for connection to circuits rated Installation Category I only, with transients rated less than 1500V peak. Do not connect the DMM or switch card terminals to CAT II, CAT III, or CAT IV circuits.

Connections of the DMM or switch card terminals to circuits higher than CAT I can cause damage to the equipment or expose the operator to hazardous voltages.

Calibration cycle

Perform calibration at least once a year, or every 90 days to ensure the unit meets the corresponding specifications.

Recommended equipment

The following table lists the recommended equipment and settings you need for DC-only, and AC-only calibration procedures. Alternate equipment may be used, such as a DC transfer standard and characterized resistors, as long as the equipment has specifications at least as good as those listed in the table. In general, equipment uncertainty should be at least four times better (more accurate) than the corresponding Model 3706A specifications.

Manufacturer	Model	Description	Used for:	Uncertainty
Fluke	5700A	Calibrator	All DCV, ACV, DCI, ACI, and Resistance	See NOTE.
N/A	N/A	4-wire short	DCV, resistance zeros	N/A
Agilent	33220A	Function generator	For frequency factory calibration only	See NOTE.

NOTE

Refer to the manufacturer's specifications to calculate the uncertainty, which will vary for each test point.

Calibration

Calibration must be performed by remote control using Ethernet, GPIB, or USB interfaces. No front panel calibration is available. Refer to System connections for more information on communicating with the instrument.

"Factory calibration" refers to additional calibration steps that are only performed once at the factory or when a unit has been repaired by replacing PC boards or components of the boards. The remaining calibration steps can be performed as needed.

The factory calibration steps are:

- **DC Cal Step 0:** A/D MUX Offset, which is performed at the beginning prior to other DC calibration steps
- **Frequency Cal step 17:** 1 V @ 10 Hz and step 18: 1 V @ 1 kHz, which are performed at the end of AC calibration

You can perform individual sections of calibration, but for the instrument to be calibrated properly, all the steps of a section should be performed. For example, DC Cal Step 1: 4-wire short should be done as well as Steps 2 through 5 to properly calibrate DC volts. Other sections are resistance, DC current, AC volts, and AC current. The calibrations must be saved after you have completed all of the steps in order for the adjustments to be permanent.

Before performing a calibration, check the system date of the Model 3706A. This can be done by sending the following command:

```
print(os.date("%x"))
```

If the date is wrong, the date and time need to be reset using the following command:

```
settime(os.time{year = yyyy, month = mm, day = dd, hour = hh, min = mm, sec = ss})
```

Make sure to enter the correct date and time using the 24-hour clock. If the date is incorrect, it will not save the proper date when the calibration is saved. For additional information about this command, see `localnode.settime()`.

Remote calibration procedure

To perform calibrations, use the following procedure:

1. Connect the Model 3706A to the IEEE-488 bus of the computer using a shielded IEEE-488 cable, such as the Keithley Instruments Model 7007, over the Ethernet, or directly to a computer through the Ethernet port using a cross-over cable.
2. Turn on the Model 3706A and allow it to warm up for at least two hours before performing calibrations.
3. Make sure the primary address of the Model 3706A is the same as the address specified in the program that you will be using to send commands (the GPIB default address is 16; the Ethernet default port number is 23).

- Turn the TSP[®] prompt and errors off and unlock the calibration function by sending the following commands:

```
SEND localnode.prompts=0
SEND localnode.showerrors=0
SEND dmm.reset()
SEND errorqueue.clear()
SEND dmm.calibration.unlock("KI003706")
```

NOTE

When remotely changing the unlock code, send the [dmm.calibration.unlock\(\)](#) (on page 8-168) command twice, first with the present code, then with the new code.


- Check for errors after sending each calibration command by using the following command:


```
SEND print(errorqueue.count)
```
- Send each calibration command with `print ("done")` appended to allow the program to know when operation is complete. Some calibration steps may take up to five minutes to perform, so the communication time-out setting should be adjusted, because otherwise time-out errors might occur.

DC volts calibration

- Install the 4-wire short on the analog backplane connector inputs of the Model 3706A.
- Allow the instrument to settle for five minutes.
- Perform the following calibration steps (DC Cal Step 0 through Step 5):

Figure 11-23: 4-wire short diagram



DC adjustment step 0: A/D MUX Offset (factory calibration only)

Send the commands:

```
SEND dmm.calibration.dc(0) print("done")
SEND print(errorqueue.count)
```

DC adjustment step 1: Input four-wire short circuit

1. Allow the instrument to settle for 30 seconds.
2. Send the commands:


```
SEND dmm.calibration.dc(1) print("done")
SEND print(errorqueue.count)
```

DC calibration step 2: Open circuit

1. Remove the four-wire short from the inputs.

NOTE


Do not install cables to the inputs (cables will be installed in [DC calibration step 3: +10 Volt](#) (see "[DC adjustment step 3: +10 V](#)" on page C-26)).

2. Send the commands:


```
SEND dmm.calibration.dc(2) print("done")
SEND print(errorqueue.count)
```

DC adjustment step 3: +10 V**Figure 11-24: DC voltage calibration**

Analog backplane connector



1. Connect a cable between the calibrator and the Model 3706A.
2. Allow the instrument to settle for 30 seconds.
3. Send the command:


```
SEND dmm.range = 10
```
4. Source +10 V.
5. Send the commands:


```
SEND dmm.calibration.dc(3,10) print("done")
SEND print(errorqueue.count)
```

DC adjustment step 4: -10 V

1. Source -10 V.
2. Send the commands:



```
SEND dmm.calibration.dc(4,-10) print("done")
SEND print(errorqueue.count)
```

DC adjustment 5: 100 V

1. Send the command:
SEND dmm.range = 100
2. Source 100 V.
3. Send the commands:
SEND dmm.calibration.dc(5,100) print("done")
SEND print(errorqueue.count)

Resistance calibration

Perform the following calibration steps (DC Cal Step 6 through Step 9):

Figure 11-25: Resistance calibration**DC adjustment step 6: 100 Ohm**

1. Send the commands:
SEND dmm.func = dmm.FOUR_WIRE_OHMS
SEND dmm.range = 100
2. Source 100 Ohms.
3. Read the resistor value from the calibrator.
4. Send the command:
SEND dmm.calibration.dc(6, (resistor value)) print("done")

DC adjustment step 7: 10 kOhm

1. Send the command:
SEND dmm.range = 10e+3
2. Source 10 kOhm.
3. Read the resistor value from the calibrator.
4. Send the command:
SEND dmm.calibration.dc(7, (resistor value)) print("done")

DC adjustment step 8: 100 kOhm


1. Send the command:
`SEND dmm.range = 100e+3`
2. Source 100 kOhm.
3. Read the resistor value from the calibrator.
4. Send the command:
`SEND dmm.calibration.dc(8, (resistor value)) print("done")`

DC adjustment step 9: 1 MOhm

1. Send the command:
`SEND dmm.range = 1e+6`
2. Source 1 MOhm then read the resistor value from the calibrator.
3. Send the command:
`SEND dmm.calibration.dc(9, (resistor value)) print("done")`

DC current calibration

Make the connections as shown, then perform the following calibration steps (DC Cal Step 10 through Step 14):

Figure 11-26: DC current calibration**DC adjustment step 10: 100 μ A**

1. Send the commands:
`SEND dmm.func = dmm.DC_CURRENT`
`SEND dmm.range = 100e-6`
2. Source 100 μ A.
3. Send the commands:
`SEND dmm.calibration.dc(10, .0001) print("done")`

DC adjustment step 11: 1 mA

1. Send the command:
`SEND dmm.range = 1e-3`
2. Source 1 mA.
3. Send the command:
`SEND dmm.calibration.dc(11,.001) print("done")`

DC adjustment step 12: 10 mA

1. Send the command:
`SEND dmm.range = 10e-3`
2. Source 10 mA.
3. Send the command:
`SEND dmm.calibration.dc(12,.01) print("done")`

DC adjustment step 13: 100 mA

1. Send the command:
`SEND dmm.range = 100e-3`
2. Source 100 mA.
3. Send the command:
`SEND dmm.calibration.dc(13,.1) print("done")`

DC adjustment step 14: 1 A


1. Send the command:
`SEND dmm.range = 1`
2. Source 1 A.
3. Send the command:
`SEND dmm.calibration.dc(14,1) print("done")`

AC volts calibration

Make the connections as shown below, then perform the following calibration steps (AC Cal Step 1 through Step 10):

Figure 11-27: AC voltage calibration

Analog backplane connector



AC adjustment step 1: 10 mV at 1 kHz

1. Send the commands:
SEND dmm.func = dmm.AC_VOLTS
SEND dmm.range = 10e-3
2. Source 10 mV at 1 kHz.
3. Send the command:
SEND dmm.calibration.ac(1) print("done")

AC adjustment step 2: 100 mV at 1 kHz

1. Send the command:
SEND dmm.range = 100e-3
2. Source 100 mV at 1 kHz.
3. Send the command:
SEND dmm.calibration.ac(2) print("done")

AC adjustment step 3: 100 mV at 50 kHz

1. Source 100 mV at 50 kHz.
2. Send the command:
SEND dmm.calibration.ac(3) print("done")

AC adjustment step 4: 1 V at 1 kHz

1. Send the command:
SEND dmm.range = 1
2. Source 1 V at 1 kHz.
3. Send the command:
SEND dmm.calibration.ac(4) print("done")

AC adjustment step 5: 1 V at 50 kHz

1. Source 1 V at 50 kHz.
2. Send the command:
SEND dmm.calibration.ac(5) print("done")

AC adjustment step 6: 10 V at 1 kHz

1. Send the command:
SEND dmm.range = 10
2. Source 10 V at 1 kHz.
3. Send the command:
SEND dmm.calibration.ac(6) print("done")

AC adjustment step 7: 10 V at 50 kHz

1. Source 10 V at 50 kHz.
2. Send the command:
SEND dmm.calibration.ac(7) print("done")

AC adjustment step 8: 100 V at 1 kHz

1. Send the command:
`SEND dmm.range = 100`
2. Source 100 V at 1 kHz.
3. Send the command:
`SEND dmm.calibration.ac(8) print("done")`

AC adjustment step 9: 100 V at 50 kHz


1. Source 100 V at 50 kHz.
2. Send the command:
`SEND dmm.calibration.ac(9) print("done")`

AC adjustment step 10: 300 V at 1 kHz

1. Send the command:
`SEND dmm.range = 300`
2. Source 300 V at 1 kHz
3. Send the command:
`SEND dmm.calibration.ac(10) print("done")`

AC current calibration

Make the connections as shown, then perform the calibration steps (AC calibration step 11 through step 16).

Figure 11-28: AC current calibration 1mA to 1A range**AC adjustment step 11: 100 μ A at 1 kHz**

1. Send the commands:
`SEND dmm.func = dmm.AC_CURRENT`
`SEND dmm.range = 100e-6`
2. Source 100 μ A at 1 kHz.
3. Send the command:
`SEND dmm.calibration.ac(11) print("done")`

AC adjustment step 12: 1 mA at 1 kHz

1. Send the following command:
`SEND dmm.range = 1e-3`
2. Source 1 mA at 1 kHz.
3. Send the following command:
`SEND dmm.calibration.ac(12) print("done")`

AC adjustment step 13: 10 mA at 1 kHz

1. Send the command:
`SEND dmm.range = 10e-3`
2. Source 10 mA at 1 kHz.
3. Send the command:
`SEND dmm.calibration.ac(13) print("done")`

AC adjustment step 14: 100 mA at 1 kHz

1. Send the command:
`SEND dmm.range = 100e-3`
2. Source 100 mA at 1 kHz.
3. Send the command:
`SEND dmm.calibration.ac(14) print("done")`

AC adjustment step 15: 1 A at 1 kHz

1. Send the command:
`SEND dmm.range = 1`
2. Source 1 A at 1 kHz.
3. Send the command:
`SEND dmm.calibration.ac(15) print("done")`

AC adjustment step 16: 2 A at 1 kHz


1. Send the command:
`SEND dmm.range = 2`
2. Source 2 A at 1 kHz.
3. Send the command:
`SEND dmm.calibration.ac(16) print("done")`

Frequency calibration

Make the connections as shown below, then perform the following calibration steps (AC Cal Step 17 and Step 18):

Figure 11-29: Low frequency calibration

Analog backplane connector



AC adjustment step 17: 1 V at 10 Hz (factory calibration only)

1. Send the commands:



```
SEND dmm.func = dmm.AC_VOLTS
SEND dmm.range = 1
```
2. Source 1 V at 10 Hz.
3. Send the command:


```
SEND dmm.calibration.ac(17,1) print("done")
```

AC adjustment step 18: 1 V at 1 kHz (factory calibration only)

Figure 11-30: Frequency verification

Analog backplane connector



1. Source 1 V at 1 kHz
2. Send the command:


```
SEND dmm.calibration.ac(18,1000) print("done")
```

Save calibrations

Program today's date, calibration due date, and serial number, and save the calibration constants in EEPROM (electrically erasable programmable read-only memory) by sending the following commands:

```
dmm.adjustment.date=os.time()  
dmm.calibration.save()  
dmm.calibration.verifydate=dmm.adjustment.date  
dmm.calibration.lock()  
dmm.reset()
```

NOTE

Calibrations are complete after they have been saved and locked.

Status model

In this appendix:

Overview	D-1
Status model diagrams	D-3
Status function summary	D-15
Clearing registers and queues	D-15
Startup state	D-16
Programming and reading registers	D-16
Status byte and service request (SRQ)	D-18
TSP-Link system status	D-23

Overview

Each Keithley Instruments Series 3700A System Switch/Multimeter provides a number of status registers and queues that are collectively referred to as the "status model." Through manipulation and monitoring of these registers and queues, you can view and control various instrument events. Commands included in your test program can determine if a service request (SRQ) event has occurred and the cause of the event. The heart of the status model is the Status Byte Register. All status model registers and queues eventually flow into the Status Byte Register. As a programmer, you are in full control of all enable registers, while the System Switch/Multimeter has full control of all event status registers. In order for an event to be accounted for in the register's summary bit, first enable it by setting the appropriate bit in the applicable enable register. The entire status model is illustrated in the Status model diagrams topic.

Status Byte Register

The Status Byte Register receives summary bits from the other status register sets and queues, and also from itself (which sets the Master Summary Status, or MSS, bit). For details, see [Status Byte Register](#) (on page D-18).

Status register sets

Typically, a status register set contains the following registers:

- **Condition** (`.condition`): A read-only register that constantly updates to reflect the present operating conditions of the instrument.
- **Enable Register** (`.enable`): A read-write register that allows a summary bit to be set when an enabled event occurs.
- **Event Register** (`.event`): A read-only register that sets a bit to 1 when the applicable event occurs. If the enable register bit for that event is also set, the summary bit of the register will set to 1.
- **Negative Transition Register** (`.ntr`): A read-write register that when set to 1, specifies a negative transition (change from 1 to 0) sets the event register bit.
- **Positive Transition Register** (`.ptr`): A read-write register that when set to 1, specifies a positive transition (change from 0 to 1) sets the event register bit.

When an event occurs and the appropriate NTR or PTR bit is set, the matching event register bit is set to 1. The event bit remains latched to 1 until the register is read or the status model is reset. When an event register bit is set and its corresponding enable bit is set, the output (summary bit) of the register will set to 1. This, in turn, sets a bit in a higher-level register cascading to the associated summary bit of the Status Byte Register.

Summary bit

The summary bit of each register is either set (1) or clear (0). A set summary bit indicates that one (or more) of the enabled events in that register has occurred.

Queues

The Series 3700A uses an output queue and an error or event queue. Response messages, such as those generated from print commands, are placed in the output queue. As programming errors and status messages occur, they are placed in the error queue. When a queue contains data, it sets the appropriate summary bit of the Status Byte Register (EAV for the error or event queue; MAV for the output queue).

The [Status model overview](#) (see "[Status Byte Register overview](#)" on page D-4) shows how the two queues are structured with the other registers.

Output queue

When the instrument is in the remote state, the output queue holds data that pertains to the normal operation of the instrument. For example, when a `print()` command is sent, the response message is placed in the output queue.

When data is placed in the output queue, the Message Available (MAV) bit in the status byte register is set. A response message is cleared from the output queue when it is read. The output queue is considered cleared when it is empty. An empty output queue clears the MAV bit in the status byte register.


A message is read from the output queue by addressing the instrument to talk.

Status model diagrams

The register sets (and queues) monitor various instrument events. When an enabled event occurs in one of the five registers, it sets the associated summary bit in the Status Byte register. When a summary bit of the Status Byte is set and its corresponding enable bit is set (as programmed using `status.request_enable`), the MSS bit will set to indicate that an SRQ has occurred. View the master summary bit using `status.condition` attribute. In an expanded system (TSP-link), setting the `status.node_enable` attribute allows the System registers to be shared by all nodes in the TSP-Link system. The following figures and topics illustrate the relationships of the individual registers and queues with the Status Byte register.

Status Byte Register overview


Figure 11-31: Status Byte register



Measurement summary bit (Measurement event register)

The summary bit of the measurement event register provides enabled summary information to Bit B0 (MSB) of the status byte.


Figure 11-32: Measurement event register



System summary bit (System register)

The summary bit of the system register provides enabled summary information to Bit B1 (SSB) of the status byte.

Figure 11-33: System summary bit (System register)



As shown above, there are five register sets associated with System Event Status. These registers summarize system status for various nodes connected to the TSP-Link. Note that all nodes on the TSP-Link share a copy of the system summary registers once the TSP-Link has been initialized. This feature allows all nodes to access the status models of other nodes, including SRQ.

In a TSP-Link system, the status model can be configured such that a status event in any node in the system can set the RQS (Request for Service) bit of the Master Node Status Byte. See [TSP-Link system status](#) (on page D-23) for details on using the status model in a TSP-Link system.

Attributes are summarized in [status.system.*](#) (on page 8-408), [status.system2.*](#) (on page 8-410), [status.system3.*](#) (on page 8-412), [status.system4.*](#) (on page 8-414), and [status.system5.*](#) (on page 8-416).

For example, any of the following commands will set the EXT enable bit:

```
status.system.enable = status.system.EXT
status.system.enable = status.system.EXTENSION_BIT
status.system.enable = 1
```

When reading a register, a numeric value is returned. The binary equivalent of this value indicates which bits in the register are set. For details, see [Reading registers](#) (on page D-17). For example, the following command will read the system enable register:

```
print(status.system.enable)
```

The bits used in the system register sets are described as follows:

- **Bit B0, Extension Bit (EXT):** Set bit indicates that an extension bit from another system status register is set.
- **Bits B1-B14* NODEN:** Indicates a bit on TSP-Link node n has been set ($N = 1$ to 64).
- **Bits B15:** Not used.

*status.system5 does not use bits B9 through B15.

Refer to the following table for available N values:

Command	N value
status.system.*	1 to 14
status.system2.*	15 to 28
status.system3.*	29 to 42
status.system4.*	43 to 56
status.system5.*	57 to 64


Standard Event Register

The bits used in the Standard Event Register are described as follows:

- **Bit B0, Operation Complete (OPC):** Set bit indicates that all pending selected device operations are completed and the Series 3700A instrument is ready to accept new commands. The bit is set in response to an *OPC command. The `opc()` function can be used in place of the *OPC command. See Common commands for details on the *OPC command.
- **Bit B1:** Not used.
- **Bit B2, Query Error (QYE):** Set bit indicates that you attempted to read data from an empty output queue.
- **Bit B3, Device-Dependent Error (DDE):** Set bit indicates that an instrument operation did not execute properly due to some internal condition.
- **Bit B4, Execution Error (EXE):** Set bit indicates that the Series 3700A instrument detected an error while trying to execute a command.
- **Bit B5, Command Error (CME):** Set bit indicates that a command error has occurred. Command errors include:
 - IEEE Std 488.2 syntax error: The Series 3700A instrument received a message that does not follow the defined syntax of IEEE Std 488.2.
 - Semantic error: Series 3700A instrument received a command that was misspelled or received an optional IEEE Std 488.2 command that is not implemented.
 - The instrument received a Group Execute Trigger (GET) inside a program message.
- **Bit B6, User Request (URQ):** Set bit indicates that the LOCAL key on the Series 3700A instrument front panel was pressed.
- **Bit B7, Power ON (PON):** Set bit indicates that the Series 3700A instrument has been turned off and turned back on since the last time this register has been read.

Commands to program and read the register are summarized below and also in the [Status function summary](#) (on page D-15) table.

Figure 11-34: Standard event register



Standard event commands

Command	Description
*ESR? or print(status.standard.event)	Read Standard Event Status Register.
*ESE <mask> or status.standard.enable = <mask>	Program the Event Status Enable Register: <mask> = 0 to 255 See Status register sets.
*ESE? or print(status.standard.enable)	Read Event Status Enable Register.

Error available bit (Error or Event queue)

The summary bit of the Error or Event queue provides enabled summary information to Bit B2 (EAV) of the status byte.

The Error Available Bit (EAV) is set when a message defining an error (or status) is placed in the Error or Event queue. The Error or Event queue is one of the two System Switch/Multimeter queues associated with the status model. The other queue sets the Message available bit (Output queue)). Both queues are first-in, first-out (FIFO) queues. The Error queue holds error and status messages. The status model shows how these queues are structured with regard to the other registers.

The following sequence outlines typical events associated with this queue:

1. When an error or status event occurs, a message defining the error (or status) is placed in the Error queue.
2. The Error Available (EAV) bit in the Status Byte Register is set.
3. Through programming, the error (or status) message is read. This clears the error (or status) from the Error Queue. The Error queue is considered cleared when it is empty.
4. An empty Error queue clears the EAV bit in the Status Byte Register.

The commands to control the Error queue are listed below. When you read a single message in the Error queue, the oldest message is read and then removed from the queue. On power-up, the Error queue is initially empty. If there are problems detected during power-on, entries will be placed in the queue. If no problems are detected, the error number 0 and “No Error” will be returned.

Error queue command	Description
<code>errorqueue.clear()</code>	Clear error queue of all errors.
<code>errorqueue.count</code>	Number of messages in the error/event queue.
<code>errorqueue.next()</code>	Request error message.

Messages in the Error queue include a code number, message text, severity, and TSP-Link node number. For example, the following commands request the next complete error information from the error queue and displays the code, message, severity and node of the next error:


```
errorcode, message, severity, errornode = errorqueue.next()
print(errorcode, message, severity, errornode)
```

The error messages, as well as error numbers, are listed in the Error summary list.

Questionable summary bit (Questionable event register)

The summary bit of the questionable event register provides enabled summary information to Bit B3 (QSB) of the status byte.

Figure 11-35: Questionable event register



As shown above, there is only one register set associated with the questionable status. Attributes are summarized in [status.questionable.*](#) (on page 8-400). Keep in mind that bits can also be set by using numeric parameter values. For details, see [Programming enable and transition registers](#) (on page D-16).

For example, any of the following statements will set the thermal aspect enable bit of a card in slot 1:

```
status.questionable.enable = status.questionable.S1THR
status.questionable.enable = status.questionable.SLOT1_THERMAL
status.questionable.enable = 512
```

The following command will request the questionable enable register value in numeric form:

```
print(status.questionable.enable)
```

The bits used in this register set are described as follows:

- **SxTHR:** Set bit indicates the thermal aspect of the card in slot x is in question, where x = 1 to 6.

Message available bit (Output queue)

The summary bit of the output queue provides enabled summary information to Bit B4 (MAV) of the status byte.

The Message Available Bit (MAV) is set when the Output queue holds data that pertains to the normal operation of the instrument. The Output queue is one of the two System Switch/Multimeter queues associated with the status model. The other queue sets the [Error Available Bit \(Error or Event queue\)](#) (on page D-9). Both queues are first-in, first-out (FIFO) queues. The [Status Byte Register overview](#) (on page D-4) shows how these queues are structured with regard to the other registers.


As an example, when a print command is sent, the response message is placed in the Output queue. When data is placed in the Output queue, the Message Available (MAV) bit in the Status Byte Register sets. A response message is cleared from the Output queue when it is read. The Output queue is considered cleared when it is empty. An empty Output queue clears the MAV bit in the Status Byte Register.

A message is read from the Output queue by addressing the System Switch/Multimeter to talk.

Event summary bit (ESB register)

The summary bit of the Standard event register provides enabled summary information to Bit B5 (OSB) of the status byte.

Figure 11-36: Event summary bit (Standard event register)



As shown above, there is only one register set associated with the event status register. Attributes are summarized in [status.standard.*](#) (on page 8-406). Keep in mind that bits can also be set by using numeric parameter values. For details, see [Programming enable and transition registers](#) (on page D-16).

For example, any of the following statements will set the operation complete enable bit:

```
standardRegister = status.standard.OPC
status.questionable.enable = status.standard.OPERATION_COMPLETE
status.questionable.enable = 1
```

The bits used in this register set are described as follows:

- **Bit B0, Operation Complete (OPC):** Set bit indicates that all pending selected device operations are completed and the instrument is ready to accept new commands. The bit is set in response to an *OPC command. The remote command `opc()` can be used in place of the *OPC command.
- **Bit B1:** Not used.
- **Bit B2, Query Error (QYE):** Set bit indicates that you attempted to read data from an empty Output queue.
- **Bit B3, Device-Dependent Error (DDE):** Set bit indicates that an instrument operation did not execute properly due to some internal condition.
- **Bit B4, Execution Error (EXE):** Set bit indicates that the instrument detected an error while trying to execute a command.
- **Bit B5, Command Error (CME):** Set bit indicates that a command error has occurred. Command errors include:
 - IEEE-488.2 syntax error: The instrument received a message that does not follow the defined syntax of the IEEE-488.2 standard.
 - Semantic error: instrument received a command that was misspelled or received an optional IEEE-488.2 command that is not implemented.
 - GET error: The instrument received a Group Execute Trigger (GET) inside a program message.
- **Bit B6, User Request (URQ):** Set bit indicates that the LOCAL key on the instrument front panel was pressed.
- **Bit B7, Power ON (PON):** Set bit indicates that the instrument has been turned off and turned back on since the last time this register has been read.

Master summary status bit (MSS bit register)

The master summary status bit provides summary information to Bit B6 (MSS) of the status byte. Although this bit is always enabled for the status byte, it has to be enabled (using `status.node_enable`) if needed in an expanded system (TSP-link).


The Master Summary Status Bit (MSS) is set when an enabled summary bit of the Status Byte Register is set. This bit (B6) may also be interpreted as a Request Service (RQS) bit. Depending on how it is used, Bit B6 of the Status Byte Register is either the Request for Service (RQS) bit or the Master Summary Status (MSS) bit.

When using the GPIB serial poll sequence of the System Switch/Multimeter to obtain the status byte (serial poll byte), B6 is the RQS bit. See [Serial polling and SRQ](#) (on page D-20) for details on using the serial poll sequence. For common and script commands (Status Byte Register), B6 is the MSS (Message Summary Status) bit. The serial poll, although automatically resetting the RQS bit, does not clear MSS. The MSS remains set until all Status Byte summary bits are reset.

Operation summary bit (Operation event register)

The summary bit of the operation event register provides enabled summary information to Bit B7 (OSB) of the status byte.


Figure 11-37: Operation event registers



Operation user bit (Operation user register)

The summary bit of the operation user register provides the user bit (User) (Bit B12) to the operation status register. In turn, the summary bit of the operation status register will provide the operation summary bit (OSB) (Bit B7) to the status byte.

Figure 11-38: Operation user summary bit (Operation user register)



The bits used in this register set are described as follows:

- **Bits B0-B14:** status.operation.user.BIT0 through status.operation.user.BIT14
- **Bits B15:** Not used.

Status function summary

The following functions and attributes control and read the various registers. Additional information is included in the command listings for the various register sets.

Status function summary

Type	Function or attribute*
System summary	status.condition (on page 8-389) status.node_event (on page 8-394) status.node_enable (on page 8-393) status.request_event (on page 8-404) status.request_enable (on page 8-402) status.reset() (on page 8-406)
Measurement event	status.measurement.* (on page 8-391)
Operation event	status.operation.* (on page 8-396) status.operation.user.* (on page 8-398)
Questionable event	status.questionable.* (on page 8-400)
Standard event	status.standard.* (on page 8-406)
System events	status.system.* (on page 8-408) status.system2.* (on page 8-410) status.system3.* (on page 8-412) status.system4.* (on page 8-414) status.system5.* (on page 8-416)

* Note that the asterisk (*) at the end of a command represents one of the following: .ntr, .ptr, .enable, .event, or .condition.

Clearing registers and queues

Commands to reset the status registers and the error queue are listed in the table below. In addition to these commands, any programmable register can be reset by sending the individual command to program the register with a 0 as its parameter value.

Commands to reset registers and clear queues	
Commands	Description
To reset registers: *CLS status.reset()	Clears the output queue. Reset bits of status registers to 0. Reset bits of status registers to 0.
To clear error queue: errorqueue.clear()	Clear all messages from error queue.

The instrument automatically clears the output queue when the instrument transitions from the local control state to the remote control state.

Startup state

When the System Switch/Multimeter is turned on, various register status elements are set as follows:

- The power on (PON) bit in the `status.operation.condition` register is set.
- Other bits are set appropriately based on the instrument's power-on configuration.
- All enable registers (`.enable`) are set to 0.
- All negative transition registers (`.ntr`) are set to 0.
- All used positive transition registers (`.ptr`) bits are set to 1.
- The two queues are empty.

Programming and reading registers

Programming enable and transition registers

The only registers that you can program are the enable and transition registers. All other registers in the status structure are read-only registers. The following explains how to determine the parameter values for the various commands used to program enable registers. The actual commands are summarized in [Status function summary](#) (on page D-15).

A command to program an event enable or transition register is sent with a parameter value that determines the desired state (0 or 1) of each bit in the appropriate register. The bit positions of the register (see the following figure) indicate the binary parameter value and decimal equivalent. To program one of the registers, send the decimal value for the bits to be set. The registers are discussed further in [Enable and transition registers](#) (on page D-22).

Figure 11-39: 16-bit status register

Bit position	B7	B6	B5	B4	B3	B2	B1	B0
Binary value	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
Decimal	128	64	32	16	8	4	2	1
Weights	(2 ⁷)	(2 ⁶)	(2 ⁵)	(2 ⁴)	(2 ³)	(2 ²)	(2 ¹)	(2 ⁰)

A. Bits 0 through 7

Bit position	B15	B14	B13	B12	B11	B10	B9	B8
Binary alue	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
Decimal	32768	16384	8192	4096	2048	1024	512	256
Weights	(2 ¹⁵)	(2 ¹⁴)	(2 ¹³)	(2 ¹²)	(2 ¹¹)	(2 ¹⁰)	(2 ⁹)	(2 ⁸)

B. Bits 8 through 15

When using a numeric parameter, registers are programmed by including the appropriate `<mask>` value. For example:

```
*ese 1169
status.standard.enable = 1169
```

To convert from decimal to binary, use the information shown in the above figure. For example, to set bits B0, B4, B7, and B10, a decimal value of 1169 would be used for the mask parameter ($1169 = 1 + 16 + 128 + 1024$).

Reading registers

Any register in the status structure can be read either by sending the common command query (where applicable), or by including the script command for that register in either the `print()` or `print(tostring())` command. The `print()` command outputs a numeric value; the `print(tostring())` command outputs the string equivalent. For example, any of the following commands requests the Service Request Enable Register value:

```
*SRE?
print(tostring(status.request_enable))
print(status.request_enable)
```

The response message will be a decimal value that indicates which bits in the register are set. That value can be converted to its binary equivalent using the information in [Programming enable and transition registers](#) (on page D-16). For example, for a decimal value of 37 (binary value of 100101), bits B5, B2, and B0 are set.

Register programming example

The command sequence below programs the instrument to generate a service request (SRQ) and set the system summary bit in all TSP-Link nodes when the current limit on channel A is exceeded.

```
-- Clear all registers.
status.reset()

-- Enable SLOT1_THERMAL bit in questionable register.
status.questionable.enable = status.questionable.SLOT1_THERMAL

-- Set the system summary node QSB enable bit.
status.node_enable = status.QSB

-- Set the QSB bit of the service request enable register.
status.request_enable = status.QSB
```

Status byte and service request (SRQ)

Two 8-bit registers control service requests, the Status Byte Register and the Service Request Enable Register. The [Status Byte Register](#) (on page D-18) topic describes the structure of these registers.

Service Request Enable Register


The Service Request Enable Register controls the generation of a service request. This register is programmed by the user and is used to enable or disable the setting of bit B6 (RQS/MSS) by the Status Summary Message bits (B0, B1, B2, B3, B4, B5, and B7) of the Status Byte Register. As shown in the [Status Byte Register](#) (on page D-18) topic, a logical AND operation is performed on the summary bits (&) with the corresponding enable bits of the Service Request Enable Register. When a logical AND operation is performed with a set summary bit (1) and with an enabled bit (1) of the enable register, the logic "1" output is applied to the input of the logical OR gate and, therefore, sets the MSS/RQS bit in the Status Byte Register.

The individual bits of the Service Request Enable Register can be set or cleared by using the `*SRE` common command or `status.request_enable`. To read the Service Request Enable Register, use the `*SRE?` query or `print(status.request_enable)`. The Service Request Enable Register clears when power is cycled or a parameter value of 0 is sent with a status request enable command (for example, a `*SRE 0` or `status.request_enable = 0` is sent). The commands to program and read the SRQ Enable Register are listed in [Status byte and service request commands](#) (on page D-22).

Status Byte Register

The summary messages from the status registers and queues are used to set or clear the appropriate bits (B0, B1, B2, B3, B4, B5, and B7) of the Status Byte Register. These summary bits do not latch, and their states (0 or 1) are dependent upon the summary messages (0 or 1). For example, if the Standard Event Register is read, its register will clear. As a result, its summary message will reset to 0, which will then reset the ESB bit in the Status Byte Register.

Figure 11-40: Status byte and service request (SRQ)



The bits of the Status Byte Register are described as follows:

- **Bit B0, Measurement Summary Bit (MSB):** Set summary bit indicates that an enabled measurement event has occurred.
- **Bit B1, System Summary Bit (SSB):** Set summary bit indicates that an enabled system event has occurred.
- **Bit B2, Error Available (EAV):** Set bit indicates that an error or status message is present in the error queue.
- **Bit B3, Questionable Summary Bit (QSB):** Set summary bit indicates that an enabled questionable event has occurred.
- **Bit B4, Message Available (MAV):** Set bit indicates that a response message is present in the output queue.
- **Bit B5, Event Summary Bit (ESB):** Set summary bit indicates that an enabled standard event has occurred.
- **Bit B6, Request Service (RQS)/Master Summary Status (MSS):** Set bit indicates that an enabled summary bit of the Status Byte Register is set. Depending on how it is used, bit B6 of the Status Byte Register is either the Request for Service (RQS) bit or the Master Summary Status (MSS) bit:
 - When using the GPIB serial poll sequence of the Series 3700A to obtain the status byte (serial poll byte), B6 is the RQS bit. See [Serial polling and SRQ](#) (on page D-20) for details on using the serial poll sequence.
 - When using the *STB? common command or status.condition [Status byte and service request commands](#) (on page D-22) to read the status byte, B6 is the MSS bit.
- **Bit B7, Operation Summary (OSB):** Set summary bit indicates that an enabled operation event has occurred.

Serial polling and SRQ

Any enabled event summary bit that goes from 0 to 1 sets bit B6 and generates a service request (SRQ).

In your test program, you can periodically read the Status Byte to check if an SRQ has occurred and what caused it. If an SRQ occurs, the program can, for example, branch to an appropriate subroutine that will service the request.

SRQs can be managed by the serial poll sequence of the System Switch/Multimeter. If an SRQ does not occur, bit B6 (RQS) of the Status Byte Register remains cleared, and the program will simply proceed normally after the serial poll is performed. If an SRQ does occur, bit B6 of the Status Byte Register is set, and the program can branch to a service subroutine when the SRQ is detected by the serial poll.

The serial poll automatically resets RQS of the Status Byte Register. This allows subsequent serial polls to monitor bit B6 for an SRQ occurrence generated by other event types.

For common and script commands, B6 is the MSS (Message Summary Status) bit. The serial poll does not clear the MSS bit. The MSS bit stays set until all Status Byte Register summary bits are reset.

SPE, SPD (serial polling)

For the GPIB interface only, the SPE and SPD general bus commands are used to serial poll the System Switch/Multimeter. Serial polling obtains the serial poll byte (status byte). Typically, serial polling is used by the controller to determine which of several instruments has requested service with the SRQ line.

Service requests and connections

Service requests (SRQs) affect both the GPIB and the VXI-11 connections. On a GPIB connection, the SRQ line is asserted. On a VXI-11 connection, an SRQ event is generated.

Status byte and service request commands

The commands to program and read the Status Byte Register and Service Request Enable Register are listed in [Status byte and service request commands](#) (on page D-22). Note that the table includes both common commands and their script command equivalents. For details on programming and reading registers, see [Programming enable and transition registers](#) (on page D-16) and [Reading registers](#) (on page D-17).

To reset the bits of the Service Request Enable Register to 0, use 0 as the parameter value for the command (for example, `*SRE 0` or `status.request_enable = 0`).

Status Byte and Service Request Enable Register commands

Command	Description
<code>*STB?</code> or <code>print(status.condition)</code>	Read the Status Byte Register.
<code>*SRE <mask></code> or <code>status.request_enable = <mask></code>	Program the Service Request Enable Register where <code><mask> = 0 to 255</code> .
<code>*SRE?</code> or <code>print(status.request_enable)</code>	Read the Service Request Enable Register.

Enable and transition registers

In general, there are three types of user-writable registers that are used to configure which bits feed the register summary bit and when it occurs. The registers are identified in each applicable [Command reference](#) (see "[Commands](#)" on page 8-10) command table and defined as follows:

- **Enable register** (identified as `.enable` in each attribute's command listing): Allows various associated events to be included in the summary bit for the register.
- **Negative-transition register** (identified as `.ntr` in each attributes command listing): A particular bit in the event register will be set when the corresponding bit in the NTR is set, and the corresponding bit in the condition register transitions from 1 to 0.
- **Positive-transition register** (identified as `.ptr` in each attributes command listing): A particular bit in the event register will be set when the corresponding bit in the PTR is set, and the corresponding bit in the condition register transitions from 0 to 1.

Controlling node and SRQ enable registers

Attributes to control system node and service request (SRQ) enable bits and read associated registers are summarized in the [Status Byte Register overview](#) (on page D-4). For example, either of the following will set the system node QSB enable bit:

```
status.node_enable = status.QSB
status.node_enable = 8
```

TSP-Link system status

The TSP-Link[®] expansion interface allows instruments to communicate with each other. The test system can be expanded to include up to TSP-enabled instruments. In a TSP-Link system, one node (instrument) is the master and the other nodes are the subordinates. The master can control the other nodes (subordinates) in the system. See [TSP-Link system expansion interface](#) (on page 7-45) for details about the TSP-Link system.

The system summary registers, shown in [Status Byte Register overview](#) (on page D-4) and [System summary and standard event registers](#) (see "[System summary bit \(System register\)](#)" on page D-5), are shared by all nodes in the TSP-Link system. A status event that occurs at a subordinate node can generate an SRQ (service request) in the master node. After detecting the service request, your program can then branch to an appropriate subroutine that will service the request. See [Status byte and service request \(SRQ\)](#) (on page D-18) for details.

Status model configuration example

The following example illustrates the status model configuration for a TSP-Link system. In this example, a Node 15 thermal aspect event will set the RQS bit of the Status Byte of the master Node.

When the interlock event occurs on Node 15, the following sequence of events will occur:

1. On Node 15, with Bit B1 of the Questionable event register enabled, when the interlock event occurs, Bit B1 bit sets (`status.questionable.condition`) which causes Bit B1 to be set in `status.questionable.event`. This in turn causes the Questionable event summary bit (QSB) to set.
2. With QSB set, and Bit B3 of the System node enabled (`status.node_enable`), Bit B3 of the Status Byte register (Node 15) sets. This in turn causes the System node summary bit to set.
3. With the System node summary bit set, and Bit B1 of the System2 summary event register enabled (which is Node 15), Bit B1 of the System2 register sets. This in turn causes the System2 event summary bit (EXT) to set.
4. With EXT set, and Bit B0 of the System summary event register enabled, Bit B0 of the System register sets. This in turn causes the System event summary bit (SSB) to set.
5. With SSB set, and Bit B1 of the Service request enable register enabled, Bit B6 of the Status Byte register sets. This in turn initiates a request for service (SRQ).
6. When your program performs the next serial poll of the Master Node, it will detect the interlock event and can branch to a routine to service the request.

NOTE

The System Summary Registers are shared by all nodes in the TSP-Link system. When a bit in a system register of Node 15 sets, the same bit in the master node system register also sets.

The following commands (sent from the master node) enable the appropriate register bits for the above example:

Node 15 status registers: The following commands enable the events for Node 15:

```
node[15].status.questionable.enable = status.questionable.S1INL
node[15].status.node_enable = status.QSB
```

The affected status registers for the above commands are indicated by labels (1) and (2) (see the "TSP-Link status model configuration example" figure below).

System registers: The following commands enable the required system summary bits for Node 15:

```
status.system2.enable = status.system2.NODE15
status.system.enable = status.system.EXT
```


The affected system registers for the above commands are indicated by labels (3) and (4) (see the "TSP-Link status model configuration example" figure below).

Master Node service request: The following command enables the service request for the measurement event:

```
status.request_enable = status.SSB
```

The affected status register for the above command is indicated by labels (5) and (6) (see the "TSP-Link status model configuration example" figure below).

Figure 11-41: TSP-Link status model configuration example



Index

+

+5 output • 3-43

<

<ch_list> queries • 2-88

1

1-OHM and 10-OHM resistance ranges, verifying • C-19

2

2-wire

constant-current method • 5-9
resistance verification data • C-17
verifying • C-16

3

3-wire RTD connections • 4-31

4

4-wire

constant-current method • 5-9
dry-circuit open lead detection • 5-17
resistance verification data • C-16
RTD connections • 4-32
short applied verification data • C-21
short, verifying zeros • C-20
verifying • C-15

A

AC characteristics accuracy • 5-21

AC current

1mA to 1A ranges, verification data • C-14
1mA to 3A ranges, verifying • C-12
3A range, verification data • C-14
and AC voltage • 4-55, 4-57
calibration • C-31

AC voltage

and AC current • 4-55, 4-57
measurements and crest factor • 5-5
verifying • C-7

AC volts calibration • C-29

access recall attributes example • 3-60

accuracy calculations • 5-21

ACI current measurements • 4-14

ACV

derating factors, additional • 5-22

factors, additional derating • 5-22

verification data • C-8

adjustcount • 8-99

adjustdate • 8-100

allslots notation • 8-62

AMPS

fuse replacement • A-3

measurement • 4-17

annunciators • 8-190

anonymous script • 7-6

appending readings • 3-54

Arrays

arrays, TSL • 7-29

assigning groups • 7-51

attribute, assigning a value to • 6-2

attributes • 6-2

reading • 6-2

auto

definition • 4-5

auto ranging • 4-51

over front panel • 4-51

Autoexec script • 7-7

autorun scripts • 7-6

autozero • 4-3

AUTOZERO • 4-3

B

background scan execution • 3-8

backplane relay notation • 2-80

analog backplane relay channel specifiers • 2-80

bandwidth • 4-54

base library functions • 7-30

basic front panel REL procedure • 4-41

basic reciprocal operation • 4-43

basic scan procedure • 3-4

beeper • 8-68

beeper functions and attributes

beeper.enable • 8-68

bit • See index

Boolean value • 8-74

field • 8-72

index • 8-70, 8-71, 8-72, 8-73, 8-74

toggle • 8-75

weighted value, bit • 8-71

- bit functions • 8-69, 8-70, 8-71, 8-72, 8-73, 8-74, 8-75, 8-190
- bitwise • 8-69, 8-70
- branching • 7-24
- Break-Before-Make • 2-90
- buffer • 3-5
 - AC characteristics accuracy • 5-21
 - configuration (front panel) • 3-54
 - data store commands • 3-55
 - for...do loops • 3-62
 - overview • 3-50
 - programming examples • 3-57
 - reading attributes • 3-58
 - reading buffer • 3-56
 - read-only attributes • 3-57
 - recall attributes • 3-58
 - remote operation • 3-55
 - status • 3-60
 - storage control attributes • 3-56
- bufferVar.appendmode • 8-75
- bufferVar.basetimefractional • 8-76
- bufferVar.basetimeseconds • 8-77
- bufferVar.cachemode • 8-78
- bufferVar.capacity • 8-78
- bufferVar.clear • 8-81
- bufferVar.clearcache • 8-81
- bufferVar.collectchannels • 8-82
- bufferVar.collecttimestamps • 8-83
- bufferVar.dates • 8-84
- bufferVar.formattedreadings • 8-86
- bufferVar.fractionalseconds • 8-87
- bufferVar.n • 8-88
- bufferVar.ptpseconds • 8-88
- bufferVar.readings • 8-89
- bufferVar.relativetimestamps • 8-91
- bufferVar.seconds • 8-92
- bufferVar.statuses • 8-93
- bufferVar.times • 8-94
- bufferVar.timestampresolution • 8-95
- bufferVar.timestamps • 8-96
- bufferVar.units • 8-97
- bus operation
 - scanning • 3-8
- C**
- cable leakage • 4-21
- calculated measurement open voltage • 5-15, 5-19
- calculating
 - AC characteristics accuracy • 5-21
 - DC characteristics accuracy • 5-21
 - open voltage • 5-22
 - reading limits • C-4
- calculations
 - accuracy • 5-21
 - math • 4-43
- calibration • 8-99, 8-100, 8-102, 8-103, 8-104, 8-105, 8-106, C-22, C-24
 - considerations • C-23
 - cycle • C-23
 - DC current • C-28
 - saving • 8-103, C-34
- channel • 8-99, 8-100
 - break before make • 8-110
 - close/open operations and commands • 2-81, 8-108, 8-110
 - commands, using • 8-62
 - connect rule • 2-90
 - designations • 2-79
 - display • 3-54
 - existing scan • 3-6
 - forbidden to close • 8-107, 8-152
 - list parameter • 2-88
 - make before break • 8-110
 - pattern attributes • 2-97
 - patterns • 2-97
 - range • 2-89, 4-51
- channel commands
 - channel.clearforbidden() • 8-107
 - channel.close() • 8-108
 - channel.connectrule • 8-110
 - channel.connectsequential • 8-111
 - channel.createspecifier() • 8-112
 - channel.exclusiveclose() • 8-114
 - channel.exclusiveslotclose() • 8-115
 - channel.getclose() • 8-119
 - channel.getcount() • 8-121
 - channel.getdelay() • 8-122
 - channel.getforbidden() • 8-124
 - channel.getimage() • 8-126
 - channel.getlabel() • 8-127
 - channel.getstate() • 8-134
 - channel.gettype() • 8-137
 - channel.open() • 8-138
 - channel.pattern.catalog() • 8-139
 - channel.pattern.delete() • 8-140
 - channel.pattern.getimage() • 8-140
 - channel.pattern.setimage() • 8-141
 - channel.pattern.snapshot() • 8-143
 - channel.reset() • 8-146
 - channel.setdelay() • 8-151
 - channel.setforbidden() • 8-152
 - channel.setlabel() • 8-152
- channel patterns • 2-97
- clear • 8-190, 8-505
 - bit.clear() • See bit.clear()
- clearing
 - readings • 3-52
- close
 - close channel operations • 2-81, 8-108, 8-114, 8-115, 8-119, 8-138

- Comm attributes
 - comm • 8-168
 - comm.lan.rawsockets.enable • 8-168
 - comm.lan.telnet.enable • 8-170
 - comm.lan.vxi11.enable • 8-171
 - comm.lan.web.enable • 8-172
- command
 - programming notes • 8-59
 - queries • 6-3
- CONFIG CHAN key • 2-17
- configuration
 - configuration • 4-49
 - configuration (front panel) • 3-54
 - createconfigscript() • 8-173
 - script • See createconfigscript()
- connecting multiple units • 7-46
- connection
 - connect rule (channel) • 8-110
 - line power • C-2
 - methods • 2-90
 - warning • 2-33
- considerations
 - calibration • C-23
 - dry circuit ohms measurement • 4-60
 - low level • 4-58
 - performance • 4-2
 - test • C-5
- constant-current source method • 5-9
- contact information • 1-1
- continuity testing
 - connections • 4-39
 - overview • 4-38
 - procedure • 4-39
- count • 8-99
- counts • 3-4
- createconfigscript() • 8-173
- current verification data
 - 10 μ A to 100 μ A ranges • C-10
 - 1mA to 3A ranges • C-12
- cursor • 8-192, 8-205
- cycle, calibration • C-23
- D**
- data store (buffer) commands • 3-55
- date • 8-100
- date values • 3-60, 8-100
- dB
 - characteristics accuracy • 5-22
 - configuration • 4-49
 - non-switch channels • 2-25
 - scanning • 4-49
- DC
 - characteristics accuracy • 5-21
 - voltage verification data • C-6
 - volts calibration • C-25
- DC current
 - 10 μ A to 100 μ A ranges, verification data • C-10
 - 10 μ A to 100 μ A ranges, verifying • C-9
 - 1mA to 3A ranges, verification data • C-12
 - 1mA to 3A ranges, verifying • C-10
 - with DC voltage and resistance • 4-54, 4-57
- DC voltage • 4-54, 4-57, C-5, C-6, C-25
- DCI current measurements • 4-14
- DCV
 - input divider • 4-58
- default file extensions • 3-23
- delay functions
 - delay() • 8-177
- detection, open lead • 5-14
- digital
 - filter types • 4-65
 - filter window • 4-66
- Digital I/O
 - port • 2-29
- Digital I/O port • 3-48
 - +5V output • 3-43
 - Bit weighting • 3-47
 - Commands • 3-47
 - Configuration • 3-42, 3-44
 - Controlling I/O lines • 3-45
 - Output enable • 3-48
 - Programming examples • 3-48
 - Remote operation • 3-47, 3-49
- digits ICL programming • 4-6
- Discrete
 - discrete resistance verification data • C-20
- Display
 - display • 3-54
 - DISPLAY PATTERNS test • A-5
 - unit serial number • 1-4
- Display operations
 - Adding menu entries • 3-39
 - Character codes • 3-33
 - Clearing • 3-32
 - Deleting menu entries • 3-40
 - Functions and attributes • 3-31
 - Indicators • 3-37
 - Input prompting • 3-35
 - Keycodes • 3-41
 - Key-press codes • 3-41
 - LOCAL lockout • 3-38
 - Menu • 3-35
 - Messages • 3-31
 - Text messages • 3-33
 - Triggering • 3-41
- DMM
 - attributes, existing scan • 3-6
 - key • 2-16
 - key configuration • 2-21
 - measurement capabilities • 4-1

Documentation • 1-2, 11-1
 dry circuit ohms
 DRY+ • 4-60
 enabling • 4-61
 measurement considerations • 4-60
 dry circuit resistance • C-5
 verification data • C-18
 verifying • C-17
 dry-clamp open lead detector • 5-18
 dynamic buffer programming example • 3-62
 dynamically-allocated buffers • 3-61

E

environmental conditions • C-2
 equipment
 recommended • C-23
 recommended test • C-2
 errorqueue functions and attribute
 errorqueue.clear() • 8-306
 errorqueue.count • 8-306
 errors
 and status message list • 8-62, 9-530
 effects on scripts • 9-530
 summary • 9-530
 event blenders • 3-19
 events • 3-18
 Event log • B-15
 Examples
 access recall attributes example • 3-60
 dynamic buffer programming example • 3-62
 exceeding reading buffer capacity • 3-64
 external reference junction • 5-14
 passing parameter • 6-2
 reading limit calculation • C-3
 script • 7-55
 variable assignment • 6-2
 exceeding reading buffer capacity example • 3-64
 exit functions
 exit() • 8-312

F

factory defaults, restoring • C-4
 file • 3-23
 formats • 3-23
 I/O • 3-24
 system navigation • 3-24
 FILTER
 key configuration • 2-24
 filter, digital • 4-65
 characteristics • 4-65
 overview • 4-65
 repeating average • 4-66
 Firmware
 Upgrading • A-6

 Using TSB for upgrade • A-6
 firmware upgrade • A-7
 foreground scan execution • 3-8
 format attributes
 format.asciiprecision • 8-315
 format.byteorder • 8-316
 format.data • 8-317
 frequency
 calibration • C-33
 connections • 4-36
 verification data • C-15
 verifying • C-14
 frequency measurements
 and period measurements, ranges • 4-35
 procedure • 4-37
 Front panel
 gate time • 4-36
 operation • 3-51
 scanning • 3-7
 tests • A-3
 FUNC
 key configuration • 2-24
 functions • 7-19
 Fuse
 Line, replacement • A-1
 fuse replacement • A-2

G

get • 8-71, 8-72, 8-119, 8-121, 8-122, 8-124, 8-126,
 8-127, 8-134, 8-137, 8-140, 8-190, 8-192, 8-193,
 8-194, 8-321, 8-363
 GPIB
 connector • 2-29
 gpib attribute
 gpib.address • 8-321
 groups
 assigning • 7-51
 coordinating remote • 7-52
 different test scripts • 7-50
 reassigning • 7-51

H

high-energy circuit safety precautions • 4-2
 hot switching • 8-110

I

ICL
 general device control • 7-57
 ICL commands • 3-8
 TSP-specific device control • 7-57
 IEEE-1588
 configuring • 3-21
 enabling • 3-21
 implementation in Series 3700A • 3-20

- introduction • 3-19
- index • 8-70, 8-71, 8-72, 8-73, 8-74
- Indicators • 3-37
- internal reference junction • 5-13
- ISOUR open voltage • 5-15

K

- Keithley website • 11-1
- key configuration • 2-21
- key-press codes • 3-41
- Keys • 2-6
 - key • 2-16
- KEYS test • A-5
- key-value pairs • 6-21, 8-517, 8-518, 8-519

L

LAN

- Assigning the Method • B-1
- Connecting to • B-1
- Domain name system • B-1
- Duplex mode • B-10
- MAC address • B-11
- Overview • B-1
- Point-to-point connection • B-1
- Setting the IP address • B-1
- Setting the method • B-1
- Setting the subnet mask • B-1
- Troubleshooting • B-1

- libraries, standard • 7-30

LIMIT

- key configuration • 2-23

Line

- Fuse replacement • A-1
- line cycle synchronization • 5-2
- line power • C-2
- local group • 8-374
- logical

- logical AND operation • 8-69

- logical OR operation • 8-69

- loop control • 7-25

- low ohm measurement • 4-59

LXI

- event log • 3-22
- LXI Class B triggering (IEEE-1588) • 3-19

M

- MAC address • B-11
- maintenance
 - Fuse replacement • A-1
- Make-Before-Break • 2-90
- makegetter functions
 - makegetter() • 8-359
 - makesetter() • 8-360
- manual range keys • 4-50

- Manuals • 1-2, 11-1
- master node • 8-374
- master node overview • 7-50
- math

- calculations • 4-43

- library functions • 7-34

- matrix card notation • 2-80

Measure

- and switching capabilities • 1-4

- capabilities • 1-4

- contact resistance • 4-60

- count • 4-5

- resistance of voltage-sensitive devices • 4-60

Measurement

- accuracy • 4-55

- basic resistance • 4-22

- current • 4-14

- maximum readings • 4-49

- ranges • 4-49

- temperature • 4-23

- voltage • 4-17

Memory functions

- memory.available() • 8-361

- memory.used() • 8-362

modules

- cold junction • 5-13

- connection warning • 2-33

- hardware interlocks • 3-44

- identify installed • 2-78

- monitoring alarms • 3-22

- moving average filter • 4-65

- multiple units, connecting • 7-46

- MUX channel notation • 2-80

- mX+b • 4-44

- mX+b REL • 4-44

N

named scripts

- overview • 7-4

- RUN • 7-6

Node

- master overview • 7-50

- nonblocking • 8-190, 8-205, 8-206

- notation, channels • 8-62

O

- offset-compensated ohms • 4-63

opc functions

- opc() • 8-365

open

- open channel operations • 2-81

- open lead detection • 5-14

- open thermocouple detection • 5-19

- open voltage • 5-15, 5-16, 5-19

- Operation keys
 - key • 2-16
- operations
 - mX+b • 4-44
 - mX+b REL • 4-44
 - reciprocal (1/X) • 4-47
- os.date() • 8-100, 8-106
- os.time() • 8-100, 8-106
- Output enable • 3-48
- overlapped operations in remote groups,
 - coordinating • 7-52
- overwrite a bit field • 8-73
- P**
- p • 2-97
- parallel test scripts • 7-51
- password • 8-102
- PATT
 - configuration • 2-20
- percent • 4-46
- performance considerations • 4-2
- Power
 - blinking • 8-192
- Power-on setup • 2-35, 2-36
- precautions • 4-2
- Precedence • 7-23
- print functions
 - print() • 8-365
 - printbuffer() • 8-366
 - printnumber() • 8-367
- programming
 - interaction • 7-37
 - script model • 7-3
- pseudocards • 2-100, 2-101
- PTP
 - understanding • 5-23
- PTP to UTC, correlating • 3-20
- Q**
- queries • 6-3
- queues • D-2
 - Output • D-2
- R**
- Range
 - and channel types • 4-49
 - manual keys • 4-50
 - Selecting auto • 4-51
 - selecting manual • 4-50
- RATE key • 4-52
- ratiometric method • 5-9
- Reading buffer • 3-56
 - capacity, exceeding • 3-64
 - creating • 3-51
 - deleting • 3-53
 - described • 3-56
 - designations • 3-56
 - removing stale values • 7-53
 - selecting • 3-51
- reading limit calculation example • C-3
- Readings
 - errors • 9-531
 - RECall • 3-53
 - saving • 3-52
 - storing • 3-52
- rear panel
 - connection details • 2-27
 - summary • 2-27
- reciprocal (1/X) • 4-47
- reference junctions • 5-13
- registers
 - Enable and transition • D-22
 - Programming example • D-17
 - Reading • D-17
 - Serial polling and SRQ • D-20
 - Service request enable • D-18
 - Standard event • D-8
- REL
 - buffer operation • 3-55
 - key configuration • 2-24
 - remote operation • 4-42
- relay closure count • 2-93
- remote
 - calibration procedure • C-24
- remote buffer operation • 3-55
- Remote command interface
 - Selecting • B-12
- repeating average filter • 4-66
- requirements
 - verification tests • C-2
- Reset
 - digio trigger • 8-184
 - lan • 8-334
 - localnode • 8-357
 - reset • 8-374
 - scan • 8-391
 - status • 8-464
 - timer • 8-476
- resistance
 - calibration • C-27
 - measurements • 4-17, 4-22, 5-9
 - reading limits • C-4
 - verifying • C-15, C-16, C-17
- resistance measurements, standard • 4-23
- resistance ranges (1-OHM and 10-OHM), verifying • C-19
- RTD • 4-31, 4-33
- run-time environment
 - script, restoring • 7-41

S

SCAN

- configuration • 2-20

scanning

- counts • 3-4
- DMM configuration • 4-51
- execution, foreground and background • 3-8
- math setup • 4-48
- REL value • 4-43

- schematics • 5-1

- Script Editor • 7-37

Scripts

- autoexec • 7-7
- autorun scripts • 7-6
- Deleting • 7-43
- error effects • 9-530
- Examples • 3-26, 7-55
- function, using • 7-21
- interactive • 7-3
- loading from front panel • 7-12
- name attribute • 8-419
- named • 7-4, 7-6
- parallel test, running • 7-51
- restoring in run-time environment • 7-41
- running • 7-5, 7-6, 7-11, 7-51
- saving • 7-13
- Script Editor • 7-37
- test scripts across the TSP-Link network • 7-53
- unnamed • 7-6
- user • 7-3, 7-5, 7-8, 7-11

- scripts, error effects • 9-530

- serial number • 1-4

- serial polling • D-20

Setups

- Power-on • 2-35

- shielding • 4-21, 4-58

- simulated reference junction • 5-13

- slot[X] notation • 8-62

- sound • 8-68

- SRQ (Service Request) • D-18

standard

- libraries • 7-30
- resistance measurements • 4-23

- standard libraries • 7-30

- state • 7-53

- Status byte and service request (SRQ) • D-18

- Commands • D-22

- status model • D-1

- Clearing registers and queues • D-15

- Programming registers and queues • D-15

- Queues • D-2

- Status byte and SRQ • D-1, D-18

- Status register sets • D-2

- TSP-Link system • D-23

- status register sets • D-2

- step counts • 3-4, 8-104

STORE

- key configuration • 2-24

- string library functions • 7-32

- style • 8-192, 8-205

- substring • 7-32

- summary, test • C-4

- switching capabilities • 1-4

synchronization

- AC functions, not available • 5-2

synchronous

- triggering modes, understanding • 3-14

T

- tables • 7-29

Telnet

- Configuring • B-13

temperature

- measurements • 4-23

- range • 4-50

test

- considerations • C-5

- procedure • A-4

- summary • C-4

- verification requirements • C-2

- Test Script Builder • 7-35

- test scripts across the TSP-Link network • 7-53

- thermistors • 4-28, 4-29

- thermocouple • 4-25, 4-26, 5-19

- time • 8-422, 8-423

- stamp • 3-53

- values • 3-60, 8-100, 8-106

Trigger model

- components • 3-3

- Described • 3-1

Triggering

- TSP-Link • 7-49

Troubleshooting

- Web page • 2-37

TSP

- installing software • 7-36

TSP-Link • 7-45

- Abort • 7-49

- Accessing nodes • 7-48

- communicating between TSP-enabled instruments • 7-57

- connector • 2-28

- Initialization • 7-47

- Master • 7-46

- Node numbers • 7-47

- Reset • 7-47

- reset() command • 7-49

- Slaves • 7-46

- synchronization lines

- Connecting to • 3-48
- Digital I/O • 3-49
- Remote commands • 3-49
- Triggering • 7-49

U

- unnamed scripts • 7-6
- upgrade
 - firmware • A-7
 - procedure • A-7, A-8
- upgrade functions • 8-516, 8-517
- USB
 - connectors • 2-32
- user scripts
 - creating alternative • 7-3
 - modifying • 7-8
 - running • 7-5
 - running from front panel • 7-11
- User setups
 - Recalling • 2-35
 - Saving • 2-34
 - Saving from a command interface • 2-35
- userstring functions • 7-50
- UTC • 8-100, 8-106, 8-422

V

- values • 3-60, 8-100, 8-106
- variables • 7-17
- verification • 8-106
 - data • C-20, C-21
 - instrument address • C-2
 - limits • C-3
 - test procedures • C-4, C-5
 - test requirements • C-2
- Verify menu • B-1
- Voltage
 - autozero • 4-3
 - calculated measurement • 5-15
 - ISOUR open • 5-15

W

- waitcomplete functions
 - waitcomplete() • 8-519
- warm-up • 4-2, C-2
- Warranty • 1-1
- Web interface
 - Home page • 2-37

Specifications are subject to change without notice.
All Keithley trademarks and trade names are the property of Keithley Instruments, Inc.
All other trademarks and trade names are the property of their respective companies.



A G R E A T E R M E A S U R E O F C O N F I D E N C E

Keithley Instruments, Inc.

Corporate Headquarters • 28775 Aurora Road • Cleveland, Ohio 44139 • 440-248-0400 • Fax: 440-248-6168 • 1-888-KEITHLEY • www.keithley.com